

# easYgen-1800

## Manual | Genset Control



easYgen-1800

37685A

This is no translation but the original Technical Manual in English.  
Designed in Germany and Poland; manufactured in China.

**Woodward GmbH**

Handwerkstrasse 29

70565 Stuttgart

Germany

Telephone: +49 (0) 711 789 54-510

Fax: +49 (0) 711 789 54-101

E-mail: [stgt-info@woodward.com](mailto:stgt-info@woodward.com)

Internet: <http://www.woodward.com>

## Brief Overview




Fig. 1: easYgen-1800

- |  |  |
|--|--|
| 1 Terminals 1 to 22: Power supply, relays, discrete inputs, MPU, D+, ... | 7 Terminals 56 to 61: Analog inputs                            |
| 2 Terminals 23 to 26: CAN (J1939)  | 8 Terminals 49 to 55 (screwable): Generator and Ground current |
| 3 Terminals 33 to 35: RS-485 interface                                   | 9 Terminals 45 to 48: Generator voltage                        |
| 4 USB service port for PC/laptop with ToolKit-SC                         | 10 Terminals 41 to 44: Mains voltage                           |
| 5 Terminals 62 to 64: RS-232 interface                                   | 11 Terminals 36 to 40: Relay outputs                           |
| 6 ETHERNET interface connector (RJ-45)                                   | 12 SD micro card slot  |

The easYgen-1800 are control units for engine-generator system management applications.

The control units can be used in applications such as: co-generation, stand-by, AMF or distributed generation.

### Scope of delivery

The following parts are included in the covering box. Please check prior to the installation that all parts are present:

- Device easYgen genset control  
All screwable terminal connectors are delivered with plug and jack
- Clamp fastener installation material (4x)
- "Installation Procedure Supplement" paper with links to the latest edition of Technical Documentation and software for download:  
(<http://www.wwdmanuals.com/easygen-1800>)



Configuration software and Technical Manual are available at Woodward web site:  
<http://www.woodward.com/easYgen-1800.aspx>

## Sample application setup




Fig. 2: Sample application setup

The picture above shows a typical application of the easYgen control unit. It is used as control unit of an AMF (automatic mains failure) application with a single genset.

- In this case, it will function as an engine control with generator, mains and engine protection.
- The control unit can open and close the generator circuit breaker (GCB) and the mains circuit breaker (MCB).



Transition procedures are described in chapter  
 ↪ Chapter 5.5 "Transition Procedures"  
 on page 102.

## Table of contents

|          |   |           |
|----------|---|-----------|
| <b>1</b> | <b>General Information</b> .....                          | <b>9</b>  |
| 1.1      | About This Manual.....                                    | 9         |
| 1.1.1    | Revision History.....                                     | 9         |
| 1.1.2    | Depiction Of Notes And Instructions.....                  | 9         |
| 1.2      | General Information.....                                  | 10        |
| 1.2.1    | Copyright And Disclaimer.....                             | 10        |
| 1.2.2    | Service And Warranty.....                                 | 11        |
| 1.2.3    | Safety.....   | 11        |
| 1.2.3.1  | Intended Use.....   | 11        |
| 1.2.3.2  | Personnel.....  | 12        |
| 1.2.3.3  | General Safety Notes.....                                 | 13        |
| <b>2</b> | <b>System Overview</b> .....                              | <b>15</b> |
| 2.1      | Display and Status Indicators.....                        | 15        |
| 2.2      | Operation Modes.....                                      | 16        |
| 2.2.1    | Operation Mode AUTO.....                                  | 16        |
| 2.2.2    | Operation Mode MANual.....                                | 17        |
| 2.2.3    | Operation Mode STOP.....                                  | 17        |
| 2.3      | Features and Functions of both easYgen-800 and -1800..... | 17        |
| 2.4      | Functions.....  | 20        |
| 2.5      | Intended Use of This Control.....                         | 20        |
| <b>3</b> | <b>Installation</b> .....                                 | <b>21</b> |
| 3.1      | Mounting.....   | 21        |
| 3.2      | Wiring.....   | 21        |
| 3.3      | Interfaces.....   | 26        |
| 3.3.1    | Ethernet Interface Connection.....                        | 26        |
| 3.4      | Micro SD Card Slot.....                                   | 27        |
| 3.5      | Install ToolKit-SC.....                                   | 28        |
| <b>4</b> | <b>Configuration</b> .....                                | <b>29</b> |
| 4.1      | Access to the Control.....                                | 30        |
| 4.1.1    | Access Via The Front Panel.....                           | 30        |
| 4.1.1.1  | Front Panel: Operating and Display Elements.....          | 30        |
| 4.1.1.2  | Front Panel Control.....                                  | 32        |
| 4.1.2    | Configure ToolKit-SC.....                                 | 34        |
| 4.1.2.1  | Configure Communication.....                              | 35        |
| 4.1.2.2  | Manage Configuration Data.....                            | 35        |
| 4.1.2.3  | Configure Customized Language.....                        | 35        |
| 4.1.3    | Access via ToolKit-SC Configuration Tool.....             | 36        |

## Table of contents

---

|          |  |           |
|----------|--|-----------|
| 4.1.3.1  | Read/Write Configuration.....                    | 37        |
| 4.2      | Parameters.....                                  | 37        |
| 4.2.1    | Parameter Menu Structure.....                    | 37        |
| 4.2.2    | Parameter Settings Menu--HMI Access.....         | 39        |
| 4.2.3    | Configure Measurement.....                       | 40        |
| 4.2.4    | Configure Application.....                       | 41        |
| 4.2.4.1  | Configure Inputs and Outputs.....                | 41        |
| 4.2.4.2  | Configure Engine.....                            | 51        |
| 4.2.4.3  | Configure TEST Run.....                          | 52        |
| 4.2.4.4  | Configure Breakers.....                          | 53        |
| 4.2.5    | Configure Monitoring.....                        | 54        |
| 4.2.5.1  | Monitoring Mains .....                           | 54        |
| 4.2.5.2  | Monitoring Generator .....                       | 55        |
| 4.2.5.3  | Monitoring Breakers.....                         | 59        |
| 4.2.5.4  | Monitoring Engine.....                           | 59        |
| 4.2.5.5  | Other Monitoring.....                            | 60        |
| 4.2.6    | Configure Interfaces.....                        | 61        |
| 4.2.6.1  | Configure GSM Module.....                        | 62        |
| 4.2.6.2  | Configure Ethernet Interface.....                | 63        |
| 4.2.7    | Configure Maintenance.....                       | 65        |
| 4.2.8    | Configure Counters.....                          | 66        |
| 4.2.9    | Configure Switchable Parameter Set.....          | 67        |
| 4.2.10   | Configure Language / Clock.....                  | 68        |
| 4.2.11   | Configure System Management.....                 | 69        |
| 4.2.12   | Configure HMI.....                               | 69        |
| 4.3      | Selectable Inputs/Outputs/Sensors.....           | 70        |
| 4.3.1    | Programmable Sensors.....                        | 70        |
| 4.3.2    | Programmable Inputs.....                         | 71        |
| 4.3.3    | Programmable Outputs.....                        | 73        |
| 4.4      | Status Menu.....                                 | 77        |
| 4.4.1    | HMI Status Screens.....                          | 78        |
| 4.4.2    | ToolKit-SC Status Screens.....                   | 78        |
| 4.4.3    | Configure For Using Accessories.....             | 80        |
| 4.4.3.1  | Digital Input Module WWDIN16.....                | 81        |
| 4.4.3.2  | Digital Output Module WWDOUT16.....              | 88        |
| <b>5</b> | <b>Operation.....</b>                            | <b>93</b> |
| 5.1      | Front Panel: Operating and Display Elements..... | 93        |
| 5.2      | Warning/Alarm Signaling.....                     | 95        |
| 5.2.1    | Alarm Acknowledgment.....                        | 95        |
| 5.3      | Operation Modes.....                             | 96        |
| 5.3.1    | Operation Mode AUTO.....                         | 96        |

|          |   |            |
|----------|---|------------|
| 5.3.2    | Operation Mode MANual.....                          | 96         |
| 5.3.3    | Operation Mode STOP.....                            | 97         |
| 5.4      | START/STOP Operation.....                           | 97         |
| 5.4.1    | Start engine to supply load.....                    | 97         |
| 5.4.2    | Stop engine after mains supplying load (again)..... | 100        |
| 5.4.3    | MANual START/STOP.....                              | 102        |
| 5.5      | Transition Procedures.....                          | 102        |
| 5.5.1    | Disconnect during Cranking.....                     | 102        |
| 5.5.2    | Manual Breaker Transition.....                      | 103        |
| 5.6      | Trouble Shooting.....                               | 104        |
| <b>6</b> | <b>Application.....</b>                             | <b>105</b> |
| 6.1      | Commissioning.....                                  | 105        |
| <b>7</b> | <b>Interfaces and Protocols.....</b>                | <b>107</b> |
| 7.1      | J1939.....  | 107        |
| <b>8</b> | <b>Technical Specifications.....</b>                | <b>113</b> |
| 8.1      | Measuring and Monitoring.....                       | 115        |
| <b>9</b> | <b>Appendix.....</b>                                | <b>117</b> |
| 9.1      | Alarms and Warnings.....                            | 117        |
| 9.1.1    | Alarm Classes.....                                  | 117        |
| 9.1.2    | Warnings.....                                       | 117        |
| 9.1.3    | Shutdown Alarms.....                                | 118        |
| 9.1.4    | Trip and Stop Alarms.....                           | 120        |
| 9.1.5    | Trip Alarms.....                                    | 120        |
| 9.2      | Trouble Shooting.....                               | 121        |
| 9.3      | Data Telegrams.....                                 | 121        |
| 9.3.1    | Modbus Basics.....                                  | 121        |
| 9.3.1.1  | Data Frame Format.....                              | 122        |
| 9.3.1.2  | Modbus Communication Protocol.....                  | 122        |
| 9.3.1.3  | Information Frame Format.....                       | 122        |
| 9.3.1.4  | Address Code.....                                   | 123        |
| 9.3.1.5  | Function Code.....                                  | 123        |
| 9.3.1.6  | Data Field.....                                     | 124        |
| 9.3.1.7  | Error Check Code (CRC).....                         | 124        |
| 9.3.1.8  | Error Handling.....                                 | 128        |
| 9.3.2    | Read Holding Registers 03_hex.....                  | 129        |
| 9.3.3    | Force Single Coil 05H_hex.....                      | 151        |
| 9.3.4    | Preset Single Register 06H_hex.....                 | 152        |
| 9.3.4.1  | Generator Status.....                               | 152        |

**Table of contents**

---

|           |  |            |
|-----------|--|------------|
| 9.3.4.2   | Remote Start Status.....                       | 152        |
| 9.3.4.3   | Breaker Status.....                            | 153        |
| <b>10</b> | <b>Glossary And List Of Abbreviations.....</b> | <b>155</b> |
| <b>11</b> | <b>Index.....</b>                              | <b>157</b> |



# 1 General Information

## 1.1 About This Manual

### 1.1.1 Revision History

| Rev. | Date    | Editor | Changes  |
|------|---------|--------|--|
| NEW  | 2018-03 | GG     | <p>Describes device implemented software version 2.x and ToolKit-SC version 1.1.x.x Technical Manual</p> <ul style="list-style-type: none"> <li>■ Release = 1st issue</li> </ul> |

### 1.1.2 Depiction Of Notes And Instructions

#### Safety instructions

Safety instructions are marked with symbols in these instructions. The safety instructions are always introduced by signal words that express the extent of the danger.



#### **DANGER!**

This combination of symbol and signal word indicates an immediately-dangerous situation that could cause death or severe injuries if not avoided.



#### **WARNING!**

This combination of symbol and signal word indicates a possibly-dangerous situation that could cause death or severe injuries if it is not avoided.



#### **CAUTION!**

This combination of symbol and signal word indicates a possibly-dangerous situation that could cause slight injuries if it is not avoided.



#### **NOTICE!**

This combination of symbol and signal word indicates a possibly-dangerous situation that could cause property and environmental damage if it is not avoided.







#### Tips and recommendations



*This symbol indicates useful tips and recommendations as well as information for efficient and trouble-free operation.*

#### Additional markings

To emphasize instructions, results, lists, references, and other elements, the following markings are used in these instructions:

| Marking  | Explanation   |
|--|---|
|   | Step-by-step instructions   |
|   | Results of action steps   |
|   | References to sections of these instructions and to other relevant documents  |
|   | Listing without fixed sequence  |
| [Buttons]  | Operating elements (e.g. buttons, switches), display elements (e.g. signal lamps)                                       |
| "Display"  | Screen elements (e.g. buttons, programming of function keys)  |
| "Screen xx → Screen xy<br>→ Screen xz" ...   | Menu path.<br>The following information and setting refer to a page on HMI screen or ToolKit located as described here. |
| <br> | Some parameters/settings/screens are available only either in ToolKit or in HMI/display.                                |



### ***Dimensions in Figures***

*All dimensions shown with no units specified are in mm.*

## 1.2 General Information

### 1.2.1 Copyright And Disclaimer

#### **Disclaimer**

All information and instructions in this manual have been provided under due consideration of applicable guidelines and regulations, the current and known state of the art, as well as our many years of in-house experience. Woodward assumes no liability for damages due to:

- Failure to comply with the instructions in this manual
- Improper use / misuse
- Willful operation by non-authorized persons
- Unauthorized conversions or non-approved technical modifications
- Use of non-approved spare parts

The originator is solely liable to the full extent for damages caused by such conduct. The agreed upon obligations in the delivery contract, the general terms and conditions, the manufacturer's delivery conditions, and the statutory regulations valid at the time the contract was concluded, apply.

#### **Copyright**

This manual is protected by copyright. No part of this manual may be reproduced in any form or incorporated into any information retrieval system without written permission of Woodward GmbH.

Delivery of this manual to third parties, duplication in any form - including excerpts - as well as exploitation and/or communication of the content, are not permitted without a written declaration of release by Woodward GmbH.

Actions to the contrary will entitle us to claim compensation for damages. We expressly reserve the right to raise any further accessory claims.

## 1.2.2 Service And Warranty

By opening the device you will lose any warranty!



### CAUTION!

Any unauthorized modifications or using this equipment outside its specified mechanical, electrical, or other operating limits may cause personal injury and/or property damage, including damage to the equipment.

Any such unauthorized modifications

- constitute "misuse" and/or "negligence" within the meaning of the product warranty
- thereby excluding warranty coverage for any resulting damage, and
- invalidate product certifications or listings.

Our Customer Service is available for technical information. Please see page 2 for the contact data.

In addition, our employees are constantly interested in new information and experiences that arise from usage and could be valuable for the improvement of our products.

## Warranty terms



*Please enquire about the terms of warranty from your nearest Woodward representative.*

*For our contact search webpage please go to:  
<http://www.woodward.com/Directory.aspx>*

## 1.2.3 Safety

### 1.2.3.1 Intended Use

The easYgen unit has been designed and constructed solely for the intended use described in this manual.

The easYgen unit has been designed and constructed solely for the intended use described in this Operation Manual and--with even more details-- in the Technical Manual.

- Intended use requires operation of the control unit within the specifications listed in ↪ *Chapter 8 "Technical Specifications" on page 113.*
- Intended use requires operation of the control unit within the written specifications.
- All permissible applications are outlined in ↪ *Chapter 6 "Application" on page 105.*
- Intended use includes compliance with all instructions and safety notes presented in this manual.

## General Information

General Information > Safety > Personnel

- Any use which exceeds or differs from the intended use shall be considered improper use.
- No claims of any kind for damage will be entertained if such claims result from improper use.



### NOTICE!

#### Damage due to improper use!

Improper use of the remote panel unit may cause damage to the control unit as well as connected components.

Improper use includes, but is not limited to:

- Operation outside the specified operation conditions.

### 1.2.3.2 Personnel



### WARNING!

#### Hazards due to insufficiently qualified personnel!

If unqualified personnel perform work on or with the control unit hazards may arise which can cause serious injury and substantial damage to property.

- Therefore, all work must only be carried out by appropriately qualified personnel.

This manual specifies the personnel qualifications required for the different areas of work, listed below:

- Well trained for electrical installations.
- Skilled and competent to be aware especially of the local safety regulations.
- Experienced in working on electronic measuring and control devices.
- Allowed to manage the controlled (engine/generator) system.

The workforce must only consist of persons who can be expected to carry out their work reliably. Persons with impaired reactions due to, for example, the consumption of drugs, alcohol, or medication are prohibited.

When selecting personnel, the age-related and occupation-related regulations governing the usage location must be observed.

### 1.2.3.3 General Safety Notes

#### Hazards by system controlled

**DANGER!****Moving parts and dangerous electricity!**

Be aware that the remote control of a system that is managing life dangerous engine-generator-electricity parts needs attention for the local situation!

The following safety notes cover both the device itself and basics of the overall genset system. The dedicated genset-system related safety instruction must be taken into account, too!

#### Prime mover safety

**WARNING!****Hazards due to insufficient prime mover protection**

The engine, turbine, or other type of prime mover should be equipped with an overspeed (over-temperature, or over-pressure, where applicable) shut-down device(s), that operates totally independently of the prime mover control device(s) to protect against runaway or damage to the engine, turbine, or other type of prime mover with possible personal injury or loss of life should the mechanical-hydraulic governor(s) or electric control(s), the actuator(s), fuel control(s), the driving mechanism(s), the linkage(s), or the controlled device(s) fail.

## General Information

---

General Information > Safety > General Safety Notes

## 2 System Overview

### General notes

The easYgen is a stand-alone genset controller with measuring, monitoring, and breaker control functionality. It comes with a easy mounting plastic housing covering a well tested electronic-electrical system.

Display and buttons of the HMI offer both access to states and values, and access to the application. Password protection enables dedicated operation access levels. Remote control, monitoring, visualization, and configuration are possible via integrated interfaces. Communication between easYgens, with PLC control, or as a network member offers an enhanced system management range; additionally supported by easy to implement accessories.



*For even higher challenges in genset control the easYgen series offers further solutions up to the most complex and ambitious applications.*

*For dedicated protection tasks ask Woodward for its protection (relay) solutions.*

### 2.1 Display and Status Indicators

#### General Notes

HMI and the configuration software enable access to control, settings, and visualization. The front panel offers a number of functional defined buttons and a set of menu management buttons. LEDs visualize fixed states, the graphic display works together with the menu management buttons to show all necessary information.



#### **Restrictions**

*Full access to all parameters and settings with configuration software only!*

*HMI access offers a number of information screens in general, and enables - password protected - access to parameters and settings.*




Fig. 3: easYgen-1800

## 2.2 Operation Modes

### General notes

The easYgen offers three operation modes:

- AUTO
- MANUAL (MAN)
- STOP
- ... and an internal (non) operating phase during starting the device itself

The operation mode can be initiated - if current settings allow this function:

- directly by pressing the according button at the front panel
- directly by click on the according button at the ToolKit-SC remote screen
- via discrete inputs
- via interface

### 2.2.1 Operation Mode AUTO

#### General notes

In operation mode AUTO both genset and breakers are under easYgen control. Start and stop of the engine is managed automatically together with open, close, and breaker transition.

Depending on settings and application status, AUTO control can:

- supply load by mains
- supply load by generator
- transition load supply from mains to generator or from generator to mains
- start the engine
- stop the engine



**Load supply transition from mains to genset****Situation**

- Mains becomes abnormal because one or more of the parameters below misses its well defined working range:
  - “Overvoltage”
  - “Undervoltage”
  - “Overfrequency”
  - “Underfrequency”
  - “Mains voltage asymmetry”
  - “Mains phase rotation fail”

Start procedure will include breaker handling, engine start, and signaling/warning.

**Load supply transition from genset (back) to mains**

All of the above listed parameters are (back) in normal range.

Stop procedure will include breaker handling, engine stand-by, and signaling/warning.

**2.2.2 Operation Mode MANual****General notes**

In operation mode MANual both genset and breakers are independently from each other under easYgen control.

Start and stop of the engine is managed with the same procedure as in AUTO mode but without breaker control. Breakers can be opened and closed without taking care of load, genset, or mains state!

**2.2.3 Operation Mode STOP****General notes**

In operation mode STOP breakers are open and engine is not running.



*This is a configurable operation mode, only. This is NO emergency STOP!*

**2.3 Features and Functions of both easYgen-800 and -1800**

Both easYgen-800 and easYgen-1800 are very close in hardware and software. The easYgen-1800 is the device with more/higher functionality. For comparison and better differentiation both are described below.

**easYgen-800** is intended to be used for single automation systems, auto start/stop of the unit are performed with the help of remote signal.

**easYgen-1800** has all functions of easYgen-800 as well as automatic mains failure function (AMF), particularly well suited for single automation systems that include mains and generator.

## System Overview

Features and Functions of bo...

### Functional Blocks

| Item                    |           | easYgen-800 | easYgen-1800 |
|-------------------------|-----------|-------------|--------------|
| LCD (with backlight)    | Dimension | 4.3"        | 4.3"         |
|                         | Pixel     | 480 x 272   | 480 x 272    |
| AMF                     |           | no          | •            |
| Input Port Number       |           | 8           | 8            |
| Output port Number      |           | 8           | 8            |
| Sensor number           |           | 5           | 5            |
| Neutral (earth) current |           | •           | •            |
| Schedule function       |           | •           | •            |
| RS485                   |           | •           | •            |
| Ethernet                |           | •           | •            |
| GSM                     |           | •           | •            |
| J1939                   |           | •           | •            |
| USB                     |           | •           | •            |
| Micro SD card (slot)    |           | •           | •            |
| Real-time clock         |           | •           | •            |
| Event log               |           | •           | •            |

### Key characteristics

- With ARM-based 32-bit SCM, highly integrated hardware, high reliability level
- Multilingual interface (including English, Chinese or other customer specific languages) which can be chosen at the site, making commissioning convenient for factory personnel
- Improved LCD wear-resistance and scratch resistance due to hard screen acrylic
- Silicon panel and pushbuttons for better operation in high-temperature environment
- RS-485 communication port enabling remote control, remote measuring, remote communication via ModBus protocol
- SMS (Short Message Service) function: When genset is alarming, controller can send short messages via SMS automatically to max. 5 telephone numbers (external GSM modem is needed). Besides this, generator status can be controlled and checked.
- Equipped with CAN bus port to communicate with J1939 genset. Monitoring frequently-used data such as water temperature, oil pressure, speed, fuel consumption and so on of ECU machine, and additionally also control start, stop, raising speed, and speed droop via CAN bus port
- Suitable for 3-phase 4-wire, 3-phase 3-wire, single phase 2-wire, and 2-phase 3-wire systems with voltage 120/240 V and frequency 50/60 Hz
- **easYgen-1800 only:** Collects and shows 3-phase voltage, current, power parameter and frequency of generator or mains. Mains Generator Line voltage ( $U_{AB}$ ,  $U_{BC}$ , and  $U_{CA}$ ) Line voltage ( $U_{AB}$ ,  $U_{BC}$ , and  $U_{CA}$ ) Phase voltage ( $U_A$ ,  $U_B$ , and  $U_C$ ) Phase voltage ( $U_A$ ,  $U_B$ , and  $U_C$ )
- **easYgen-800 only:** Collects and shows 3-phase voltage, current, power parameter and frequency of generator. Generator Line voltage ( $U_{AB}$ ,  $U_{BC}$ , and  $U_{CA}$ ) Line voltage ( $U_{AB}$ ,  $U_{BC}$ , and  $U_{CA}$ ) Phase voltage ( $U_A$ ,  $U_B$ , and  $U_C$ ) Phase voltage ( $U_A$ ,  $U_B$ , and  $U_C$ )

- Phase sequence, frequency, Load current  $I_A$ ,  $I_B$ ,  $I_C$
- Each phase: Total active power [kW], Total reactive power [kvar], Total apparent power [kVA], Average power factor PF
- Accumulated Total generator power [kWh], [kvarh], [kVAh], and Earth current
- **easYgen-1800 only:** For Mains, controller has over and under voltage, over and under frequency, loss of phase and phase sequence wrong detection functions
- For generator, controller has over and under voltage, over and under frequency, loss of phase, phase sequence wrong, over and reverse power, over current functions
- 3 fixed analog sensors (temperature, oil pressure and fuel level)
- Flexible sensors can be set as temperature sensor, oil pressure sensor or level sensor
- Precision measure and display parameters about Engine, Temp. (WT) °C/°F both be displayed Oil pressure (OP) kPa/psi/bar all be displayed Fuel level (FL) %(unit) Speed (SPD) r/min (unit) Battery Voltage (VB) V (unit) Charger Voltage (VD) V (unit) Hour count (HC) can accumulate to max. 65535 hours. Start times can accumulate to max. 65535 times
- Protection: automatic start/stop of the genset, ATS (Auto Transfer Switch) control with perfect failure indication and protection function
- All output ports are relay-out
- Parameter setting: parameters can be modified and stored in internal FLASH memory and cannot be lost even in case of power outage; most of them can be adjusted using front panel of the controller and all of them can be modified using ToolKit-SC configuration software on PC via USB, Ethernet, or RS485 ports
- More kinds of curves of temperature, oil pressure, fuel level can be used directly and users can define the sensor curves by themselves
- Multiple crank disconnect conditions (generator frequency, speed sensor, oil pressure) are optional
- Widely power supply range DC (8 to 35) V, suitable to different start battery voltage environment
- Event log, real-time clock, scheduled start & stop generator (can be set as start genset once a day/week/month whether with load or not)
- Logon wallpaper and display time are user-defined
- Can be used on pumping units and as an indicating instrument (indicate and alarm are enable only, relay is inhibited)
- With maintenance function. Actions (warning or shutdown) can be set when maintenance time out
- All parameters are digital adjusted (instead of conventional analog modulation with normal potentiometer) for more reliability and stability
- Waterproof security level IP55 due to rubber seal installed between the controller enclosure and front panel
- Metal fixing clips enable perfect in high temperature environment
- Modular design, self-extinguishing ABS plastic enclosure, plug-gable connection terminals and embedded installation way; compact structure with easy mounting
- Accumulation of total run time and total electric energy of A and B. Users can reset it for convenience.

## 2.4 Functions

- Protection: automatic start/stop of the genset, ATS (Auto Transfer Switch) control with failure indication and protection function
- All output ports are relay-out
- Parameter setting: parameters can be modified and stored in internal FLASH memory and cannot be lost even in case of power outage; most of them can be adjusted using front panel of the controller and all of them can be modified using ToolKit-SC on a PC via USB or RS485 ports.
- Curves of temperature, oil pressure, fuel level can be used directly and users can define the sensor curves by themselves
- Multiple crank disconnect conditions (generator frequency, speed sensor, oil pressure) are optional
- Event log, real-time clock, scheduled start & stop generator (can be set as start genset once a day/week/month whether with load or not)
- Logon wallpaper and display time are user-defined
- Can be used on pumping units and as an indicating instrument (indicate and alarm are enable only, relay is inhibited)
- Maintenance function: Actions (warning or shutdown) can be set when maintenance time out
- All parameters use digital adjustment, instead of conventional analog modulation with normal potentiometer for more reliability and stability
- Accumulative total run time and total electric energy of A and B. User can reset it as 0 and re-accumulative the value which allows to count the total value user defined.

## 2.5 Intended Use of This Control

easYgen-1800 genset controllers are used for

- genset automation and monitor control system of single unit to achieve
- automatic mains failure protection (AMF),
- automatic start/stop,
- data measurement,
- alarm protection and
- three remote features: control, measuring and communication.

The controller adopts large liquid crystal display (LCD) and selectable Chinese, English or other languages interface with easy and reliable operation.

This easYgen genset controllers adopt 32 bits micro-processor technology with precision parameters measuring, fixed value adjustment, time setting and threshold adjusting and etc. The majority of parameters can be set using front panel and all the parameters can be set using PC (via USB port) and can be adjusted and monitored with the help of RS-485 port. It can be widely used in a number of automatic genset control system with compact structure, simple connections and high reliability

## 3 Installation

### 3.1 Mounting

The controller unit is panel built-in design to be fixed by clips. The controller's overall dimensions and cutout dimensions for panel are: see graphic below.



*Use clips included in delivery. Tighten strong but not with brute force to get best IP protection result!*




Fig. 4: easYgen-800/1800 cut-out

### 3.2 Wiring

#### General Notes



#### **Battery Voltage Input**

*This controller can be used with a wide range of battery voltage 8 to 35 V<sub>DC</sub>.*

*Negative of battery must be connected with the engine shell. The wire between power supply and battery must be bigger than 2.5 mm<sup>2</sup>.*

*If floating charge is configured: In order to prevent charge disturbing the controller's normal working please ...*

- *first connect output wires of charger to battery's positive and negative directly,*
- *then connect wires from battery's positive and negative to controller's positive and negative input ports.*

**Speed Sensor Input**

Use two cores shielding line wires. Connect the shielding layer to terminal 16 while the other side is not connected.

Connect the two signal wires to terminals 17 and 18. The output voltage of speed sensor should be within 1 to 24 V<sup>eff</sup>. 12 V<sup>eff</sup> is recommended for rated speed.

**CAUTION!****Digital (Relays) Outputs**

To prevent the controller before damage ...

DC current relays: add freewheel diodes at both ends of relay's coils

AC current relays: increase resistance of the relay's coils return circuit



Current input of controller must be connected to the outside of the current transformer (secondary side current is 5 A). Phases of current transformer and input voltage must be correct. Otherwise, the current of collecting power and active power maybe not correct.

$I_{COM}$  port terminal 52 must be connected to negative pole of battery.

**WARNING!**

If there is a load current, open circuit of transformer's secondary side is not allowed!

**CAUTION!****Withstand Voltage Test**

Disconnect all terminal connections before high voltage test of the installed controller.

## Terminals




Fig. 5: easYgen-1800 Terminals

| No. | Function       | Cable Size          | Remarks   |   |
|-----|----------------|---------------------|---|---|
| 1   | POWER SUPPLY + | 2.5 mm <sup>2</sup> | Connected with negative of starter battery  |   |
| 2   | POWER SUPPLY - | 2.5 mm <sup>2</sup> | Connected with positive of starter battery. If wire length is over 30m, better to double wires in parallel. Max. 20A fuse is recommended. |   |
| 3   | E-STOP         | 2.5 mm <sup>2</sup> | Connected with B+ via emergency stop button   |   |
| 4   | FUEL/GAS       | 1.5 mm <sup>2</sup> | B+ is supplied by 3 terminal, rated 16 A  |   |
| 5   | STARTER        | 1.5 mm <sup>2</sup> | B+ is supplied by 3 terminal, rated 16 A  | Connected to starter coil   |
| 6   | RELAY 01       | 1.5 mm <sup>2</sup> | B+ is supplied by 2 terminal, rated 7 A   | Details see <a href="#">Chapter 4.3.3 "Programmable Outputs"</a> on page 73 |
| 7   | RELAY 02       | 1.5 mm <sup>2</sup> | B+ is supplied by 2 terminal, rated 7 A   |   |
| 8   | RELAY 03       | 1.5 mm <sup>2</sup> | B+ is supplied by 2 terminal, rated 7 A   |   |
| 9   | D+             | 1.0 mm <sup>2</sup> | Connected with charger starter's D+ (WL) terminals. Being hang up If there is no this terminal.   |   |
| 10  | DI 01          | 1.0 mm <sup>2</sup> | Ground connected is active (B-)   | Details see <a href="#">Chapter 4.3.2 "Programmable Inputs"</a> on page 71  |
| 11  | DI 02          | 1.0 mm <sup>2</sup> | Ground connected is active (B-)   |   |
| 12  | DI 03          | 1.0 mm <sup>2</sup> | Ground connected is active (B-)   |   |
| 13  | DI 04          | 1.0 mm <sup>2</sup> | Ground connected is active (B-)   |   |
| 14  | DI 05          | 1.0 mm <sup>2</sup> | Ground connected is active (B-)   |   |
| 15  | DI 06          | 1.0 mm <sup>2</sup> | Ground connected is active (B-)   |   |
| 16  | SHIELD/NC      | 0.5 mm <sup>2</sup> | Connected with Speed sensor, shielding line is recommended. (B-) has already connected with speed sensor 2.                               |   |
| 17  | MPU -          |                     |   |   |
| 18  | MPU +          |                     |   |   |

## Installation

## Wiring

| No.                  | Function  | Cable Size          | Remarks   |  |
|----------------------|-----------|---------------------|---|--|
| 19                   | DI 07     | 1.0 mm <sup>2</sup> | Ground connected is active (B-)   | Details see <a href="#">Chapter 4.3.2</a><br>"Programmable Inputs"<br>on page 71<br>Details see form 3 |
| 20                   | RELAY 04  | 1.5 mm <sup>2</sup> | Normally closed output, rated 7 A                                       | Details see <a href="#">Chapter 4.3.3</a><br>"Programmable Outputs"<br>on page 73                      |
| 21                   |           |                     | Common point of relay   |  |
| 22                   |           |                     | Normally open output, rated 7 A   |  |
| CAN (J1939)          |           |                     |   |  |
| 23                   | SHIELD/NC | /                   | Impedance-120 Ω shielding wire is recommended, its single-end grounded. |  |
| 24                   | CAN H     | 0.5 mm <sup>2</sup> |   |  |
| 25                   | CAN L     | 0.5 mm <sup>2</sup> |   |  |
| 26                   | NC        | /                   | Empty terminal  |  |
| RS485                |           |                     |   |  |
| 33                   | SHIELD/NC | /                   | Impedance-120 Ω shielding wire is recommended, its single-end grounded  |  |
| 34                   | A(+)      | 0.5 mm <sup>2</sup> |   |  |
| 35                   | B(-)      | 0.5 mm <sup>2</sup> |   |  |
| 36                   | RELAY 05  | 2.5 mm <sup>2</sup> | Normally closed output, rated 7 A                                       | Details see <a href="#">Chapter 4.3.3</a><br>"Programmable Outputs"<br>on page 73                      |
| 37                   |           | 2.5 mm <sup>2</sup> | Normally open output, rated 7 A   |  |
| 38                   |           | 2.5 mm <sup>2</sup> | Common pin of relay   |  |
| 39                   | RELAY 06  | 2.5 mm <sup>2</sup> | Normally open output, rated 7 A   |  |
| 40                   |           | 2.5 mm <sup>2</sup> | Common pin of relay   |  |
| MAINS VOLTAGE AC     |           |                     |   |  |
| 41                   | L1        | 1.0 mm <sup>2</sup> | Connected to A-phase of mains (2 A fuse is recommended)                 |  |
| 42                   | L2        | 1.0 mm <sup>2</sup> | Connected to B-phase of mains (2 A fuse is recommended)                 |  |
| 43                   | L3        | 1.0 mm <sup>2</sup> | Connected to C-phase of mains (2 A fuse is recommended)                 |  |
| 44                   | N         | 1.0 mm <sub>2</sub> | Connected to N-wire of mains  |  |
| GENERATOR VOLTAGE AC |           |                     |   |  |
| 45                   | L1        | 1.0 mm <sup>2</sup> | Connected to A-phase of genset (2A fuse is recommended)                 |  |
| 46                   | L2        | 1.0 mm <sup>2</sup> | Connected to B-phase of genset (2A fuse is recommended)                 |  |
| 47                   | L3        | 1.0 mm <sup>2</sup> | Connected to C-phase of genset (2A fuse is recommended)                 |  |
| 48                   | N         | 1.0 mm <sup>2</sup> | Connected to N-wire of genset   |  |
| GENERATOR CURRENT AC |           |                     |   |  |
| 49                   | L1        | 1.5 mm <sup>2</sup> | Outside connected to secondary coil of current transformer(rated 5 A)   |  |
| 50                   | L2        | 1.5 mm <sup>2</sup> | Outside connected to secondary coil of current transformer(rated 5 A)   |  |
| 51                   | L3        | 1.5 mm <sup>2</sup> | Outside connected to secondary coil of current transformer(rated 5 A)   |  |
| 52                   | GND       | 1.5 mm <sup>2</sup> | See <a href="#">"Wiring typical applications"</a> on page 25            |  |
| GROUND CURRENT AC    |           |                     |   |  |
| 53                   | L1        | 1.5 mm <sup>2</sup> | Outside connected to secondary coil of current transformer(rated 5 A)   |  |
| 54                   | GND       | 1.5 mm <sup>2</sup> |   |  |



| No.         | Function | Cable Size          | Remarks  |
|-------------|----------|---------------------|--|
| 55          | DI 08    | 1.0 mm <sup>2</sup> | Ground connected is active (B-).<br>Details see form 3.                |
| 56          | AI 05    | 1.0 mm <sup>2</sup> | Connected to temperature, oil pressure or level sensors<br>Details see |
| 57          | AI 04    | 1.0 mm <sup>2</sup> |  |
| 58          | AI 03    | 1.0 mm <sup>2</sup> |  |
| 59          | AI 02    | 1.0 mm <sup>2</sup> |  |
| 60          | AI 01    | 1.0 mm <sup>2</sup> |  |
| 61          | COMMON   | /                   | Common terminal of sensor, (B-) has already connected                  |
| RS232 (GSM) |          |                     |  |
| 62          | GND      | 0.5 mm <sup>2</sup> | Connected to GSM module  |
| 63          | RxD      | 0.5 mm <sup>2</sup> |  |
| 64          | TxD      | 0.5 mm <sup>2</sup> |  |
|             |          |                     |  |

### Wiring typical applications




Fig. 6: easYgen-1800 wiring of a typical application

## Installation

Interfaces > Ethernet Interface Connect...

### 3.3 Interfaces

#### Interface Connections




Fig. 7: Interface Connections

| Interfaces           | Intended use                                 | Remarks  |
|----------------------|--|--|
| RS-232               | For serial communication                     | For details see <a href="#">Chapter 8</a> "Technical Specifications" on page 113 |
| RS-485               | For Remote Control via Modbus                |  |
| J1939                | Engine communication J1939 and others        |  |
| USB                  | Configuration tool "ToolKit-SC" access only! |  |
| Ethernet             | For Ethernet network communication           |  |
| Micro SD card (slot) | To store event logs                          |  |

#### 3.3.1 Ethernet Interface Connection

##### Ethernet Port Terminals

The terminals are:

| No. | Name | Description       |
|-----|------|-------------------|
| 1   | TX+  | Transmit Data+    |
| 2   | TX-  | Transceiver Data- |
| 3   | RX+  | Receive Data+     |
| 4   | NC   | Not connected     |
| 5   | NC   | Not connected     |
| 6   | RX-  | Receive Data-     |

| No. | Name | Description   |
|-----|------|---------------|
| 7   | NC   | Not connected |
| 8   | NC   | Not connected |

There are two plug-integrated LEDs:

| Color  | Function   | Description  |
|--------|------------|--|
| Green  | Activity   | The LED is flashing when there is activity on the link; otherwise, the LED is off. |
| Yellow | Link speed | The LED is on when there is a link connection; otherwise, the LED is off.          |

### Direct Cable Connection

Controller and PC are connected directly using a crossover network cable. The crossover cable must fulfill EIA/TIA 568A standard on one end and EIA/TIA 568B on the other end.



*If PC network port has Auto MDI/MDIX function, parallel cable can also be used.*

### Connection via Ethernet Hub/Switch

Controller and PC connection via hub, switch or router needs a parallel cable that fulfills EIA/TIA 568A standard on both ends or EIA/TIA 568B standard on both ends.



*If switchboard (or router) network port has Auto MDI/MDIX function, crossover cable can also be used.*

## 3.4 Micro SD Card Slot

### General Notes

This easYgen controller supports Micro SD card usage. The controller can regularly save genset operational data (engine speed, temperature, oil pressure, generator voltage, generator frequency, load current, load power, alarm information etc.) to Micro SD card. The format used is a "[filename].DAT" file. It can be read and visualized with ToolKit-SC for the connected device with the SD card inside.



*At present the controllers support  $\leq 8$  GB Micro SD card.*

*Location of the SD card: see Fig. 7*

*Enabling SD card usage: see [Chapter 4.2.6 "Configure Interfaces"](#) on page 61*

## Installation

---

### Install ToolKit-SC

## 3.5 Install ToolKit-SC

### General notes

ToolKit-SC is a software tool for configuration including configuration file management, monitoring, remote control, and custom language management. The ToolKit-SC.exe file is available via download from Woodward web page and device specific download web page.

Please follow installation instruction.



***Remove "old" software before update!***

*Make sure your custom specific configuration and language pack(s) are saved in a separate directory!*

*For correct installation of the new ToolKit-SC software the "old" ToolKit-SC software must be uninstalled before.*

## 4 Configuration



### CAUTION!

Changing controller parameters is allowed in standby mode only! Otherwise, abnormal conditions up to shutdown may happen.

Configuration can be done via

- HMI by front panel buttons
- USB connected PC/laptop by ToolKit-SC configuration software (full edit)

The configuration software ToolKit-SC is part of delivery and (latest edition) can be downloaded from our web site Woodward.com: search for "ToolKit-SC".



*Different Discrete Inputs can NOT use one and the same Input Type; otherwise, there are abnormal functions!*

*E.g.: Contents Setting of Flexible Input Port 4 is Input Type #5 "Lamp test". So #5 "Lamp test" is no longer available for configuration of other Discrete Input Ports.*



*Different Digital/Relay Outputs can be configured with the same Output Type .*

*E.g.: Contents Setting of Flexible Output Port 1 is Output Type #18 "Horn". So #18 "Horn" can still be used for other Output ports, too.*



*Input the sensor curve: X values (resistor) must be arranged increasing from small to large, otherwise, a mistake occurs.*

*If select sensor type as "None", sensor curve is not working.*

*If a sensor has an alarm switch only, this sensor's release condition must be configured as "Never", otherwise, a shutdown or warning can occur.*

## Configuration

Access to the Control > Access Via The Front Panel > Front Panel: Operating and...

### 4.1 Access to the Control













#### 4.1.1 Access Via The Front Panel

##### 4.1.1.1 Front Panel: Operating and Display Elements



Fig. 8: HMI (front panel) easYgen-1800

| Icons | Keys                             | Description   |
|-------|----------------------------------|---|
|       | STOP                             | Auto/Manual mode: Stop running generator<br>Stop mode: Reset alarm<br>Lamp test (press at least 3 seconds)<br><b>Notes</b><br>During stopping process, press this button again to stop generator immediately.   |
|       | I (START)                        | MANual mode: Start genset   |
|       | MAN (Manual Mode)                | Press this key and controller enters into MANual mode   |
|       | AUTO (Automatic Mode)            | Press this key and controller enters into AUTO mode   |
|       | Mute "Horn"/ Alarm acknowl- edge | Press once: Alarming sound OFF<br>Second time pressing the button: <ul style="list-style-type: none"> <li>Alarm is acknowledged</li> <li>Alarm LED changes from twinkling to permanently illuminated</li> </ul> |

| Icons   | Keys             | Description   |
|---|------------------|---|
|    | Gen Open/Close   | MANual mode: Switch Generator breaker ON or OFF                                 |
|   | Mains Open/Close | MANual mode: Switch Mains breaker ON or OFF                                     |
|    | Up/Increase      | 1) Screen scroll<br>2) Setting menu: Up cursor and increase value in            |
|    | Down/Decrease    | 1) Screen scroll<br>2) Setting menu: Down cursor and decrease value             |
|    | Left             | 1) Screen scroll<br>2) Setting menu: Left move cursor                           |
|    | Right            | 1) Screen scroll<br>2) Setting menu: Right move cursor                          |
|    | Set/Confirm      | Select viewing area   |
|    | Exit             | 1) Returns to the main menu<br>2) In settings menu returns to the previous menu |
|   | Warning          |   |
|  | Alarm            |   |
|  | Running          |   |
|  | Genset           |   |
|  | Busbar           |   |
|  | Mains            |   |



#### *In MANual mode:*

*Pressing **MAN** and **I** (START) simultaneously will force generator to crank. Successful start will not be judged according to crank disconnect conditions, operator will have to crank the starter motor manually; when operator decides that the engine has fired, he/she should release the button and start output will be deactivated, safety on delay will start.*

## Configuration

Access to the Control > Access Via The Front Panel > Front Panel Control



### WARNING!

Passwords can be changed by user. Please clearly remember the password after changing. If you forget it, please contact Woodward services and send all device information of the controller page "ABOUT" for legitimation.

### 4.1.1.2 Front Panel Control

#### General Notes



*Buttons below the screen/display come with dedicated function described in chapter ↪ Chapter 5 "Operation" on page 93.*

The configuration via front panel is limited to the current code level and restricted due to the editing/input possibilities of buttons usage. Full access and visibility is available using the configuration (software) tool.

Navigation buttons enable selection of a dedicated menu screen and increase/decrease, next/previous, and enter.

#### On main menu (top) level:

1. Use next or previous button to switch to next or previous screen
2. Jump to main screen with ↻ button
3. Press and hold ENTER button for more than three seconds  
⇒ Main menu opens

#### In main menu buttons work like typical button managed inputs do:

1. Use down/decrease and up/increase button to select item/ screen
2. Enter with ↵
3. Use down/decrease and up/increase button to select item
4. ... if more than one selection: use next (or previous) button(s) to select item
5. ... Enter with ↵ and continue 4. and 5. as often as necessary
6. Make sure you latest input was entered
7. Go back to upper level with ↻ button
8. Repeat 7. as often as necessary - finally main menu is the latest back screen

#### 4.1.1.2.1 HMI Screens Without Password Level

##### General Notes

The Main Screen shows a summary of values, modes, messages, and states including a single line diagram. Three additional LEDs left beside the display twinkles if Alarm, Warning, or Running occurs.

Left and right buttons allow to scroll to the other screens in a loop:

- ... from Home screen to ...
- Status
- Engine



- Generator
- Load
- Mains
- Alarm
- Event log
- Others
- About
- ... and back to Home screen and so on.

*"Home"* screen includes:

- Gen: voltage, frequency, current, active power, reactive power
- Mains: voltage, frequency
- Engine: speed, temperature, oil pressure, battery voltage
- Other states

*"Status"* screen includes:

- Status of genset, mains, and breakers

*"Engine"* screen includes:


- Speed, engine temperature, engine oil pressure, fuel level, auxiliary analog 1, auxiliary analog 2, battery voltage, charger voltage, accumulated run time, accumulated start times, user's total run time A, user's total run time B.
- **If connected with J1939 engine via CANBUS port only:** coolant pressure, coolant level, fuel temperature, fuel pressure, inlet temperature, exhaust temperature, turbo pressure, fuel consumption, total fuel consumption and so on.  
(Different engine with different parameters)

*"Generator"* screen includes:

- Phase voltage, line voltage, frequency, phase sequence

*"Load"* screen includes:

- Current, active power (positive and negative), total active power (positive and negative), reactive power (positive and negative), total reactive power (positive and negative), apparent power, total apparent power,
- power factor (positive and negative), average power factor (positive and negative),
- accumulated energy,
- earth current,
- total electric energy A and B.



*Fig. 9: Power Factor*

- P Active power
- Q Reactive power

## Configuration

Access to the Control > Configure ToolKit-SC

| Power factor | Conditions | Active power | Reactive power | Remark                   |
|--------------|------------|--------------|----------------|--------------------------|
| COS>0L       | P>0, Q>0   | Positive     | Positive       | Positive inductive load  |
| COS>0C       | P>0, Q<0   | Positive     | Negative       | Positive capacitive load |
| COS<0L       | P<0, Q>0   | Negative     | Positive       | Negative inductive load  |
| COS<0C       | P<0, Q<0   | Negative     | Negative       | Negative capacitive load |

“Mains” screen includes:

- Phase voltage, line voltage,
- frequency,
- phase sequence

“Alarm” screen includes:

- Display all alarm information e.g., warning alarm, shutdown alarm, trip alarm, and trip and stop alarm.



### **ECU alarms and shutdown alarms:**

*If the alarm information is displayed, check engine accordingly, otherwise, please check the manual of the generator according to SPN alarm code.*

“Event log” screen includes:

- Records all start/stop events (shutdown alarm, trip and stop alarm, manual /auto start or stop) and
- the real time when alarm occurs.

“Others” screen includes:

- Time and Date
- count down time for maintenance
- input/output ports status

“About” screen includes:

- Issue time of software and hardware version
- product PD number

### 4.1.2 Configure ToolKit-SC



*After ToolKit-SC is started it tries to connect to the latest device via the latest selected connection. If application is as before, device's values and settings are read and visualization is updated.*

The lower status bar shows the current status of connection and if there is a Warning.

#### 4.1.2.1 Configure Communication

Make sure the connection hardware and your laptop/PC setting are fine.

“COM:” offers for connection:

- TCP/IP
- USB
- COM\*



*\* COM connection collects and presents for selection each RS-232 connection of your laptop/PC.*

Refresh connection with button “Refresh COM”.

The IP address for TCP/IP communication can be found at:  
 “Configure interfaces → Configure EtherNET interface  
 → IP address”.



*After changing the IP address of the device or other communication relevant settings, a power-cycle is mandatory to take over changes!*

#### 4.1.2.2 Manage Configuration Data

Configuration file handling:

- Save with “File → Save Config Strg+S”
- Select default configuration (factory settings) with “File → New Config → [device name]”
- Load a configuration into ToolKit-SC with “File → Open Config Strg+O”
- Print the current configuration (to your default printer) with “File → Print Config”



*Configuration update between ToolKit-SC and the device (and vice versa) requests pushing the button “Read config” or “Write config”!*

#### 4.1.2.3 Configure Customized Language

##### General notes

ToolKit-SC can display English, Chinese, or Traditional Chinese. This is selectable via menu “Language” (5).

The easYgen device can use one of three pre-defined languages (same as device: English, Chinese, or Traditional Chinese) or even a customized wording (language):

## Configuration

Access to the Control > Access via ToolKit-SC Conf...




Fig. 10: Configure custom language pack for device (HMI)

Menu "Language pack" (1) opens a language pack file management menu. Select a file (2); table will be imported to ToolKit-SC and can be directly customized. Save customized language file with (3) "Save".

To write this customized language into the device - via USB connection, only - needs to push button "Write" (4). To use this language data for display needs to select "Other language" in menu "PARAMETER → Configure language / clock → Language".

### 4.1.3 Access via ToolKit-SC Configuration Tool

#### ToolKit-SC Screen Overview




Fig. 11: ToolKit-SC home screen

### 1. Open ToolKit-SC on your computer/laptop



*ToolKit-SC is installed and connection between your computer and the easYgen device is established*

⇒ ToolKit-SC home screen (see above) appears

### 2. Accept to read device configuration

⇒ ToolKit-SC presents the current device configuration settings and values

### 3. Use the lower left area to select a screen/page to edit

### 4. Work with the selected screen at (lower) right side

### 5. To import your current ToolKit-SC configuration into the device: Click "Write config(W)" in the menu bar



*You are asked for password. Additionally the splash screen image can be selected.*

⇒ Settings - and if selected splash image - will be transferred to the device and changed immediately




Fig. 12: ToolKit-SC: write configuration

#### 4.1.3.1 Read/Write Configuration

##### General notes

## 4.2 Parameters

### 4.2.1 Parameter Menu Structure

#### Parameter Menu



*Parameter presentation of both HMI (front panel access) and ToolKit-SC do not follow the same structure*

## Configuration

Parameters &gt; Parameter Menu Structure







Fig. 13: Menu Structure easYgen-1800 - overview



## 4.2.2 Parameter Settings Menu--HMI Access

1.  Press and hold ENTER button for more than three seconds  
⇒ Main menu opens
2.  Select "Configure"
3.  A) Enter password for parameter settings screen



*Factory default: 0500, then press return*

⇒ Parameter settings list appears

4.  Select step-by-step until desired parameter is editable e.g. using "Right" button
5.  Edit parameter and quit with pushing "Set/Confirm" button  
⇒ Parameter is updated with the new setting immediately!



*Changing settings with ToolKit-SC needs to push "Write" button before device is updated!*



*Editor screen is closed automatically after five minutes of inactivity!*



*Setting is aborted immediately when pushing the "Stop" button!*

## Configuration

Parameters > Configure Measurement

### 4.2.3 Configure Measurement

#### Generator Settings

*"PARAMETER → Configure measurement → Generator"*

| Items                         | Parameters  | Defaults                      | Description  |
|-------------------------------|---|-------------------------------|--|
| <b>Generator</b>              |   |                               | <b>Notes</b><br>We propose to set the generator frequency value as low as possible when cranking, in order to make the starter be separated quickly as soon as crank disconnect.   |
| Generator voltage measuring   | 0: 3 Phase, 4 Wire (3P4W)<br>1: 3 Phase, 3 Wire (3P3W)<br>2: 2 Phase, 3 Wire (2P3W)<br>3: Single Phase, 2 Wire (1P2W) | <b>3 Phase, 4 Wire (3P4W)</b> | <b>3 Phase, 4 Wire (3P4W):</b><br>The measurement is performed Line-Neutral and Line-Line: VL12, VL23 and VL31 VL1N, VL2N and VL3N<br><b>3 Phase, 3 Wire (3P3W) :</b><br>The measurement is performed Line-Line. VL12, VL23 and VL31<br><b>2 Phase, 3 Wire (2P3W)</b><br>The measurement is performed Line-Neutral and Line-Line: VL12<br>VL1N and VL2N<br><b>Single Phase, 2 Wire (1P2W)</b><br>The measurement is performed Line-Neutral: VL1N |
| Generator rated voltage       | (30 to 30000) V   | <b>230 V</b>                  | To offer standards for detecting of generator's over/under voltage and loading voltage. (It is primary voltage when using voltage transformer).  |
| Generator poles               | (2 to 64)   | <b>4</b>                      | Number of generator poles. Used for calculating starter rotation speed if no speed sensor is used.   |
| <b>Gen. PT</b>                | unchecked: Disabled<br>checked: Enabled   | <b>disabled</b>               | <b>Notes</b><br>Access to parameters below only if <i>"enabled"</i>  |
| Gen. PT primary rated volt.   | 30 to 30000 V   | <b>100 V</b>                  | Primary value from the used potential transformer (PT)   |
| Gen. PT secondary rated volt. | 30 to 1000 V  | <b>100 V</b>                  | Secondary value from the used potential transformer (PT)   |

#### Load Settings

*"PARAMETER → Configure measurement → Load"*

| Items                         | Parameters     | Defaults      | Description   |
|-------------------------------|----------------|---------------|---|
| <b>Load</b>                   |                |               |   |
| Load CT primary rated current | (5 to 6000)/5  | <b>500/5</b>  | The ratio of external CT                            |
| Load rated current            | (5 to 6000) A  | <b>500 A</b>  | Generator's rated current, standard of load current |
| Load rated active power       | (0 to 6000) kW | <b>276 kW</b> | Generator's rated power, standard of load power     |



**Mains Settings***"PARAMETER → Configure measurement → Mains"*

| Items                          | Parameters  | Defaults                          | Description   |
|--------------------------------|---|-----------------------------------|---|
| <b>Mains</b>                   |   |                                   |   |
| Mains voltage measuring        | 0: 3 Phase, 4 Wire (3Ph4W)<br>1: 3 Phase, 3 Wire (3Ph3W)<br>2: 2 Phase, 3 Wire (2Ph3W)<br>3: Single Phase, 2 Wire (1Ph2W) | 0: <b>3 Phase, 4 Wire (3Ph4W)</b> | <b>3 Phase, 4 Wire (3Ph4W):</b><br>The measurement is performed Line-Neutral and Line-Line: VL12, VL23 and VL31 VL1N, VL2N and VL3N<br><b>3 Phase, 3 Wire (3Ph3W) :</b><br>The measurement is performed Line-Line: VL12, VL23, and VL31<br><b>2 Phase, 3 Wire (2Ph3W)</b><br>The measurement is performed Line-Neutral and Line-Line. VL12<br>VL1N and VL2N<br><b>Single Phase, 2 Wire (1Ph2W)</b><br>The measurement is performed Line-Neutral: VL1N |
| Mains rated voltage            | (30 to 30000) V   | <b>230 V</b>                      | Standard for checking mains over/under voltage. (It is primary voltage when using voltage transformer).   |
| <b>Mains PT</b>                | unchecked: Disabled<br>checked: Enabled   | <b>disabled</b>                   | <b>Notes</b><br>Access to parameters below only if <i>"enabled"</i>   |
| Mains PT primary rated volt.   | 30 to 30000 V   | <b>100 V</b>                      | Primary value from the used potential transformer (PT)  |
| Mains PT secondary rated volt. | 30 to 1000 V  | <b>100 V</b>                      | Secondary value from the used potential transformer (PT)  |

**General Measurement Settings***"PARAMETER → Configure measurement → General Measurement settings"*

| Items                               | Parameters        | Defaults       | Description   |
|-------------------------------------|-------------------|----------------|---|
| <b>General measurement settings</b> |                   |                |   |
| System rated frequency              | (10.0 to 85.0) Hz | <b>50.0 Hz</b> | Standard for checking mains over/under frequency            |
| Gnd. CT primary rated current       | (5 to 6000)/5     | <b>500/5</b>   | Primary value from the used ground current transformer (CT) |

**4.2.4 Configure Application****4.2.4.1 Configure Inputs and Outputs****4.2.4.1.1 Configure Discrete Inputs****Configure Discrete Inputs***"PARAMETER → Configure application → Configure discrete inputs"*

## Configuration

Parameters > Configure Application > Configure Inputs and Outpu...




Fig. 14: ToolKit-SC: Config discrete inputs

| Items                                | Parameters                            | Defaults                 | Description  |
|--------------------------------------|---------------------------------------|--------------------------|--|
| <b>Configure discrete inputs ...</b> |                                       |                          |  |
| ... for discrete inputs 1 to 3:      |                                       |                          |  |
| (Map Programmable Input)             | 00 to 52                              | 28 Start request in AUTO | Default of discrete input 1  |
|                                      |                                       | 26 High temperature      | Default of discrete input 2  |
|                                      |                                       | 27 Low oil pressure      | Default of discrete input 3  |
|                                      |                                       |                          | <b>Notes</b><br>See chapter <a href="#">Chapter 4.3.2 "Programmable Inputs"</a> on page 7 for details  |
| (Adjust to logic)                    | Close to Activate<br>Open to Activate | Close to Activate        | <b>Close to Activate (N.O.):</b> The discrete input is analyzed as "enabled" by energizing the input (normally open).<br><b>Open to Activate (N.C.):</b> The discrete input is analyzed as "enabled" by de-energizing the input (normally closed). |
| ... for discrete inputs 4 to 8:      |                                       |                          |  |
| (Map Programmable Input)             | 00 to 52                              | 00                       | See chapter <a href="#">Chapter 4.3.2 "Programmable Inputs"</a> on page 7 for details  |
| (Adjust to logic)                    | Close to Activate<br>Open to Activate | Close to Activate        | <b>Close to Activate (N.O.):</b> The discrete input is analyzed as "enabled" by energizing the input (normally open).<br><b>Open to Activate (N.C.):</b> The discrete input is analyzed as "enabled" by de-energizing the input (normally closed). |

| Items               | Parameters   | Defaults   | Description  |
|---------------------|--|------------|--|
| (Define alarm type) | Warning<br>Shutdown<br>Trip and Stop<br>Trip<br>Indication | Indication | Alarm type to be released by signal  |
| (Release condition) | From Safety On<br>From Starting<br>Always<br>Never         | Never      | Condition "switch" of releasing the input signal                             |
| Input delay         | 0.0 to 20.0 s  | 2.0 s      | The input status must be valid for this period of time before it is released |
| (Description)       | Text field for 20 letters                                  | ((empty))  | Customer specific sensor name  |

#### 4.2.4.1.2 Configure Discrete Outputs

##### Configure DC Outputs

Fig. 15: DC Outputs

"PARAMETER → Configure application  
→ Configure discrete outputs → DC outputs"

| Items                     | Parameters                     | Defaults  | Description   |
|---------------------------|--------------------------------|---|---|
| <b>DC outputs</b>         |                                |   | <b>Notes</b> For discrete outputs 1 to 3:   |
| (Description)             | Text field for 20 letters      | ((empty with note: Input output remark, as: Preheat)) | Customer specific output name   |
| (Adjust to logic)         | Output (N.O.)<br>Output (N.C.) | Output (N.O.)   | Select according to logic of the connected signal (normally open or normally connected)                 |
| (Map Programmable Output) | 00 to 299                      | 001 Engine flag 1                                     | Default of discrete output 1  |
|                           |                                | 035 Idle control                                      | Default of discrete output 2  |
|                           |                                | 029 Close GCB   | Default of discrete output 3  |
|                           |                                |   | <b>Notes</b><br>See chapter <a href="#">Chapter 4.3.3 "Programmable Outputs" on page 73</a> for details |

## Configuration

Parameters > Configure Application > Configure Inputs and Output...

### Configure Relay Outputs

#### Relay Outputs

Fig. 16: Relay Outputs

“PARAMETER → Configure application  
→ Configure discrete outputs → Relay outputs”

| Items                     | Parameters                     | Defaults  | Description   |
|---------------------------|--------------------------------|---|---|
| <b>Relay outputs</b>      |                                |   | <b>Notes</b> For discrete outputs 4 to 6:   |
| (Description)             | Text field for 20 letters      | ((empty with note: Input output remark, as: Preheat)) | Customer specific output name   |
| (Adjust to logic)         | Output (N.O.)<br>Output (N.C.) | Output (N.O.)   | Select according to logic of the connected signal (normally open or normally connected)                 |
| (Map Programmable Output) | 00 to 299                      | 031 Close MCB   | Default of discrete output 4  |
|                           |                                | 038 Stop solenoid                                     | Default of discrete output 5  |
|                           |                                | 048 Centralized alarm                                 | Default of discrete output 6  |
|                           |                                |   | <b>Notes</b><br>See chapter <a href="#">Chapter 4.3.3 “Programmable Outputs”</a> on page 73 for details |

### Configure Custom Sequences & Combinations

#### General note

easYgen offers customer programmable logic "inside". Two setting types are available and described below:

- Engine flags
- Logic flags

#### Engine Flags 1 to 6

Fig. 17: Engine Flags

Engine flags offer the opportunity to take an available time signal, switch it ON/OFF by a free selectable output. The result (Engine Flag 1..6) is available as input for further control or output/relay directly: Engine Flag X = S1 AND S2.



Fig. 18: Two switches in series

S1 offers the selection of up to 16 valid time parameters (logical OR) with configurable Delay and Duration time. Delay and Duration can be adjusted between 0 and 7200 seconds.

S2 enables the selection of a switching criteria (Programmable Output, see chapter [Chapter 4.3.3 "Programmable Outputs" on page 73](#)), and can be activated/deactivated in general.

The result is available as Programmable Output "Engine flag {X}"; see chapter [Chapter 4.3.3 "Programmable Outputs" on page 73](#).



If both S1-Delay and S1-Duration are "0", S1 is always TRUE.

## Logic flags 1 to 6




Fig. 19: Logic Flags

Logic Flag offers the opportunity to combine two Programmable Outputs as logical OR and switch it ON/OFF by a third Programmable Output in series. The result (Logical flag 1..6) is available as input for further control or output/relay directly: Logic Flag X = (S1 OR S2) AND S3




Fig. 20: Logic Flags parallel and in series

Each of the three switches enables the selection of a switching criteria (Programmable Output, see chapter [Chapter 4.3.3 "Programmable Outputs" on page 73](#)) and can be activated/deactivated in general.

The result itself is available too as an Programmable Output "Logic flag {X}"; see chapter [Chapter 4.3.3 "Programmable Outputs" on page 73](#).

## Configuration



Parameters > Configure Application > Configure Inputs and Outpu...



### 4.2.4.1.3 Configure Analog Inputs

“PARAMETER → Configure application  
→ Configure inputs/outputs → Configure analog inputs → ...”

| Items  | Parameters  | Defaults           | Description  |
|--|---|--------------------|--|
| <b>Temperature</b>                               |   |                    |  |
| Type   | 00 to 15  | 07 SGX             | See chapter <a href="#">↗ Chapter 4.3.1 “Programmable Sensors” on page 70</a>                |
| If a type (01 or higher) with curve is selected: | Curve can be loaded ...  | -/-                | <b>Notes</b><br>For temperature curve management and customization.                          |
|  | ... and/or edited        | (curve)            |  |
| Wire break alarm                                 | Warn<br>Shutdown<br>None  | Warn               | Alarm type to be released if wire break is detected  |
| <b>High limit warning</b>                        | enabled/disabled  | enabled            | <b>Notes</b><br>“enabled”: The following related settings will be taken into account         |
| Limit  | -50 to 300 °C   | 95 °C<br>(203 °F)  | Release the alarm when sensor value is same or higher than this value and Delay time is over |
| Return   | -50 to 300 °C   | 93 °C<br>(199 °F)  | Cancel the alarm when sensor value is same or lower than this value and Delay time is over   |
| Delay  | 0 to 3600 s   | 5 s                | The alarm status change must be valid for this period of time before it is released          |
| <b>High limit shutdown</b>                       | enabled/disabled  | enabled            | <b>Notes</b><br>“enabled”: The following related settings will be taken into account         |
| Limit  | -50 to 300 °C   | 98 °C<br>(208 °F)  | Release the alarm when sensor value is same or higher than this value and Delay time is over |
| Delay  | 0 to 3600 s   | 3 s                | The alarm status change must be valid for this period of time before it is released          |
| <b>Low limit warning</b>                         | enabled/disabled  | disabled           | <b>Notes</b><br>“enabled”: The following related settings will be taken into account         |
| Limit  | -50 to 300 °C   | 70 °C<br>(158 °F)  | Release the alarm when sensor value is same or lower than this value and Delay time is over  |
| Return   | -50 to 300 °C   | 75 °C<br>(167 °F)  | Cancel the alarm when sensor value is same or higher than this value and Delay time is over  |
| Delay  | 0 to 3600 s   | 5 s                | The alarm status change must be valid for this period of time before it is released          |
| <b>Engine heater control</b>                     | enabled/disabled  | disabled           | <b>Notes</b><br>“enabled”: The following related settings will be taken into account         |
| On   | -50 to 300 °C   | 50 °C<br>(-122 °F) | Release the alarm when sensor value is same or lower than this value and Delay time is over  |
| Off  | -50 to 300 °C   | 55 °C<br>(-131 °F) | Cancel the alarm when sensor value is same or higher than this value and Delay time is over  |
| Delay  | 0 to 3600 min   | 60 min             | The alarm status change must be valid for this period of time before it is released          |
| <b>Engine cooler control</b>                     | enabled/disabled  | disabled           | <b>Notes</b><br>“enabled”: The following related settings will be taken into account         |

| Items | Parameters    | Defaults          | Description   |
|-------|---------------|-------------------|---|
| On    | -50 to 300 °C | 80 °C<br>(176 °F) | Release the alarm when sensor value is same or lower than this value and Delay time is over |
| Off   | -50 to 300 °C | 75 °C<br>(167 °F) | Cancel the alarm when sensor value is same or higher than this value and Delay time is over |
| Delay | 0 to 3600 min | 60 min            | The alarm status change must be valid for this period of time before it is released         |


| Items  | Parameters  | Defaults                            | Description   |
|--|---|-------------------------------------|---|
| <b>Pressure</b>                                  |   |                                     |   |
| Type   | 00 to 15  | 07 SGX                              | See chapter <a href="#">Chapter 4.3.1 "Programmable Sensors"</a> on page 70                 |
| If a type (01 or higher) with curve is selected: | Curve can be loaded ...  | -/-                                 | <b>Notes</b><br>For pressure curve management and customization.                            |
|  | ... and/or edited        | (curve)                             |   |
| Wire break alarm                                 | Warn<br>Shutdown<br>None  | Warn                                | Alarm type to be released if wire break is detected   |
| <b>Low limit warning</b>                         | enabled/disabled  | enabled                             | <b>Notes</b><br>"enabled": The following related settings will be taken into account        |
| Limit  | 0 to 1000 kPa   | 124 kPa<br>(17.98 psi,<br>1.24 bar) | Release the alarm when sensor value is same or lower than this value and Delay time is over |
| Return   | 0 to 1000 kPa   | 138 kPa<br>(20.01 psi,<br>1.38 bar) | Cancel the alarm when sensor value is same or higher than this value and Delay time is over |
| Delay  | 0 to 3600 s   | 5 s                                 | The alarm status change must be valid for this period of time before it is released         |
| <b>Low limit shutdown</b>                        | enabled/disabled  | enabled                             | <b>Notes</b><br>"enabled": The following related settings will be taken into account        |
| Limit  | 0 to 1000 kPa   | 103 kPa<br>(14.94 psi,<br>1.03 bar) | Release the alarm when sensor value is same or lower than this value and Delay time is over |
| Delay  | 0 to 3600 s   | 3 s                                 | The alarm status change must be valid for this period of time before it is released         |

| Items  | Parameters  | Defaults | Description   |
|--|---|----------|---|
| <b>Fuel level</b>                                |   |          |   |
| Type   | 00 to 15  | 04 SGH   | See chapter <a href="#">Chapter 4.3.1 "Programmable Sensors"</a> on page 70 |
| If a type (01 or higher) with curve is selected: | Curve can be loaded ...  | -/-      | <b>Notes</b><br>For fuel level curve management and customization.          |
|  | ... and/or edited        | (curve)  |   |
| Wire break alarm                                 | Warn<br>Shutdown<br>None  | Warn     | Alarm type to be released if wire break is detected                         |

## Configuration

Parameters > Configure Application > Configure Inputs and Outpu...

| Items                    | Parameters       | Defaults | Description   |
|--------------------------|------------------|----------|---|
| <b>Low limit warning</b> | enabled/disabled | enabled  | <b>Notes</b><br>"enabled": The following related settings will be taken into account        |
| Limit                    | 0 to 300 %       | 10 %     | Release the alarm when sensor value is same or lower than this value and Delay time is over |
| Return                   | 0 to 300 %       | 15 %     | Cancel the alarm when sensor value is same or higher than this value and Delay time is over |
| Delay                    | 0 to 300 %       | 5 s      | The alarm status change must be valid for this period of time before it is released         |
| <b>Fuel pump control</b> | enabled/disabled | disabled | <b>Notes</b><br>"enabled": The following related settings will be taken into account        |
| On                       | 0 to 300 %       | 10 %     | Release the alarm when sensor value is same or lower than this value and Delay time is over |
| Off                      | 0 to 300 %       | 80 %     | Cancel the alarm when sensor value is same or higher than this value and Delay time is over |
| Max time on              | 0 to 3600 s      | 60 s     | The alarm status change must be valid for this period of time before it is released         |

| Items  | Parameters   | Defaults      | Description  |
|--|--|---------------|--|
| <b>Analog input {X}</b>                          |  |               | <b>Notes</b><br>{X} is a placeholder for Analog Inputs 4 and 5   |
| Sensor type                                      | None<br>Temperature sensor<br>Pressure sensor<br>Fuel level Sensor   | None          | Select sensor type<br><b>Notes</b><br>With selection of the sensor type, all limit warnings and shut-downs below are related to the according range, default value and units; marked with "" |
| Description                                      | Text field for 20 letters  | ((empty))     | Customer specific sensor name  |
| Type   | 00 to 15   | 00 Not used   | See chapter <a href="#">Chapter 4.3.1 "Programmable Sensors"</a> on page 70  |
| If a type (01 or higher) with curve is selected: | Curve can be loaded ... <br>... and/or edited  | -/<br>(curve) | <b>Notes</b><br>For fuel level curve management and customization.   |
| Wire break alarm                                 | Warn<br>Shutdown<br>None   | Warn          | Alarm type to be released if wire break is detected  |
| Enabled if a sensor type is selected:            |  |               | <b>Notes</b><br>* is filled with the related values and units (temperature, pressure, level)   |
| <b>High limit warning</b>                        | enabled/disabled   | disabled      | <b>Notes</b><br>"enabled": The following related settings will be taken into account   |
| Limit  | *  | *             | Release the alarm when sensor value is same or higher than this value and Delay time is over   |
| Return   | *  | *             | Cancel the alarm when sensor value is same or lower than this value and Delay time is over   |
| Delay  | 0 to 3600  | 5 s           | The alarm status change must be valid for this period of time before it is released  |



| Items                      | Parameters       | Defaults | Description  |
|----------------------------|------------------|----------|--|
| <b>High limit shutdown</b> | enabled/disabled | disabled | <b>Notes</b><br>"enabled": The following related settings will be taken into account         |
| Limit                      | *                | *        | Release the alarm when sensor value is same or higher than this value and Delay time is over |
| Delay                      | 0 to 3600        | 5 s      | The alarm status change must be valid for this period of time before it is released          |
| <b>Low limit warning</b>   | enabled/disabled | disabled | <b>Notes</b><br>"enabled": The following related settings will be taken into account         |
| Limit                      | *                | *        | Release the alarm when sensor value is same or lower than this value and Delay time is over  |
| Return                     | *                | *        | Cancel the alarm when sensor value is same or higher than this value and Delay time is over  |
| Delay                      | 0 to 3600        | 5 s      | The alarm status change must be valid for this period of time before it is released          |
| <b>Low limit shutdown</b>  | enabled/disabled | disabled | <b>Notes</b><br>"enabled": The following related settings will be taken into account         |
| Limit                      | *                | *        | Release the alarm when sensor value is same or higher than this value and Delay time is over |
| Delay                      | *                | 5 s      | The alarm status change must be valid for this period of time before it is released          |

| Items                  | Parameters | Defaults | Description                               |
|------------------------|------------|----------|---|
| <b>Displayed units</b> |            |          |   |
| Pressure               | kPa        | kPa      | Select local pressure unit for display    |
|                        | psi        |          |   |
|                        | bar        |          |   |
| Temperature            | °C         | °C       | Select local temperature unit for display |
|                        | °F         |          |   |

#### 4.2.4.1.4 Configure External Inputs

##### Configure External Discrete Inputs

"PARAMETER → Configure application  
 → Configure inputs/outputs → Configure external inputs  
 → Configure external inputs → Configure ext. discr. inputs  
 → Ext. discrete inputs 1-8(9-16)"

Configure each external discrete input as described below:

## Configuration

Parameters > Configure Application > Configure Inputs and Outpu...




Fig. 21: Edit External Discrete Input settings

| Items   | Parameters  | Defaults          | Description  |
|---|---|-------------------|--|
| <b>Ext. discrete inputs 1-16 (1-8)</b>  | enabled/disabled  | disabled          | <b>Notes</b><br>All 16 external discrete inputs are enabled/disabled together. 2nd page on ToolKit-SC depends on this selection (on first page!)<br>"enabled": The following related settings will be taken into account |
| Communication failure action  | Warn<br>Shutdown<br>None                                | Warn              | Alarm type to be released if wire break is detected  |
| <b>Notes</b> For Ext. discrete inputs <b>1 to 8</b> and <b>9 to 16</b> (two screens): |   |                   |  |
| Map Programmable Input  | 00 to 52  | 00                | See chapter <a href="#">Chapter 4.3.2 "Programmable Inputs"</a> on page 71 for details   |
| (Adjust to logic)   | Close to Activate<br>Open to Activate                   | Close to Activate | Select according to logic of the connected signal  |
| (Define alarm type)   | Warn<br>Shutdown<br>Trip and Stop<br>Trip<br>Indication | Indication        | Alarm type to be released by signal  |
| (Release condition)   | From Safety On<br>From Starting<br>Always<br>Never      | Never             | Condition "switch" of releasing the input signal   |
| Input delay   | 0.0 to 20.0 s   | 2.0 s             | The input status must be valid for this period of time before it is released   |
| (Description)   | Text field for 20 letters                               | ((empty))         | Customer specific sensor name  |

### 4.2.4.1.5 Configure External Outputs

#### Configure External Discrete Outputs

"PARAMETER → Configure application  
→ Configure inputs/outputs → Configure external inputs  
→ Configure external inputs → Configure ext. discr. inputs  
→ Ext. discrete inputs 1-8(9-16)"

Configure each external discrete input as described below:

| Items  | Parameters  | Defaults      | Description  |
|--|---|---------------|--|
| Ext. output enable                             | enabled/disabled  | disabled      | <b>Notes</b><br>All 16 external discrete inputs are enabled/disabled together.<br>“enabled”: The following related settings will be taken into account |
| Communication failure action                   | Warn<br>Shutdown<br>Trip and Stop<br>Trip<br>Indication | Warn          | Alarm type to be released if wire break is detected  |
| <b>Notes</b> For Ext. discrete outputs 1 to16: |   |               |  |
| (Adjust to logic)                              | Output (N.O.)<br>Output (N.C.)                          | Output (N.O.) | Select according to logic of the connected signal (normally open or normally connected)  |
| (Map Programmable Output)                      | 00 to 299   | 00 Not Used   | See chapter <a href="#">Chapter 4.3.3 “Programmable Outputs” on page 73</a> for details  |

#### 4.2.4.2 Configure Engine

“PARAMETER → Configure application → Configure engine”

| Items                       | Parameters        | Defaults               | Description   |
|-----------------------------|-------------------|------------------------|---|
| <b>Engine Type</b>          |                   |                        |   |
| Engine type                 | 00 to 39          | 00 Conventional Engine | Default: Conventional genset (not J1939).<br>When connected to J1939 engine, choose the corresponding type, see chapter <a href="#">Chapter 7.1 “J1939” on page 107</a> .   |
| Engine rated speed          | (0 to 6000) r/min | 1500 r/min             | Offer standard to judge over/under/loading speed  |
| MPU flywheel teeth          | 10 to 300         | 118                    | Tooth number of one 360° rotation, for judging of crank disconnect conditions and inspecting of engine speed  |
| ECU Inc. / Dec. steps       | 1 to 30 r/min     | 5 r/min                | The speed offset (J1939) works in combination with input sources (increase/decrease speed). The input sources can be configured to discrete inputs in order to adjust the speed of the engine. With an additional parameter the speed variation can be adjusted (Inc. / Dec. step 1 to 20 rpm) but the overall offset is limited to ±10 % from rated speed.<br><br>The speed offset is active as long as the engine is in operation and resets automatically to zero if the engine stops. |
| <b>Configure Start/Stop</b> |                   |                        |   |
| Start Attempts              | 1 to 10 times     | 3                      | Max. number of crank attempts. When reaching this number, controller will send start failure signal.  |
| <b>Start timers</b>         |                   |                        |   |
| Start delay                 | 0 to 3600 s       | 1 s                    | Time from mains abnormal or remote start signal is active to start genset   |
| Starter time                | 3 to 60 s         | 8 s                    | Time of starter power up  |
| Preglow time                | 0 to 3600 s       | 0 s                    | Time of pre-powering heat plug before starter is powered up   |
| Start pause time            | 3 to 60 s         | 10 s                   | The waiting time before second power up when engine start failed  |

## Configuration

Parameters > Configure Application > Configure TEST Run

| Items                        | Parameters       | Defaults | Description  |
|------------------------------|------------------|----------|--|
| Engine monitoring delay time | 0 to 3600 s      | 10 s     | Alarms for low oil pressure, high temperature, under speed, under frequency /voltage, charge fail are inactive.  |
| Start idle time              | 0 to 3600 s      | 0 s      | Idle running time of genset when starting  |
| Warming up time              | 0 to 3600 s      | 10 s     | Warming time between genset switch On and normal running   |
| <b>Stop timers</b>           |                  |          |  |
| Stop delay                   | 0 to 3600 s      | 1 s      | Time from mains abnormal or remote start signal is active to start genset  |
| Cool down time               | 0 to 3600 s      | 10 s     | Radiating time before genset stop, after it unloads  |
| Stop idle time               | 0 to 3600 s      | 0 s      | Idle running time when genset stop   |
| Stop solenoid hold           | 0 to 3600 s      | 20 s     | The time of powering up the electromagnet during stop procedure  |
| Stop time of engine          | 0 to 3600 s      | 0 s      | There is a time accepted for a regular stop to standby. Exceeding the "fail to stop delay" time (e.g. crank disconnect conditions contain oil pressure, and oil pressure drops quite slowly if genset stops), then this time is activated. |
| <b>Gas Engine Timers</b>     | enabled/disabled | disabled | When gas engine timer enabled, fuel oil output is used for controlling gas valve   |
| Choke on time                | 0-60 s           | 0 s      | Gas enrichment control output time when start engine   |
| Gas on delay                 | 0-60 s           | 0 s      | When engine started, it starts to output after the preset time delay   |
| Ignition off delay           | 0-60 s           | 0 s      | When gas valve closed, it stop to output after the preset delay  |
| <b>Firing Speed</b>          |                  |          |  |
| Firing speed Hz              | enabled/disabled | enabled  |  |
|                              | 0 to 200 %       | 24 %     | When generator frequency higher than the set value, starter will be disconnected. See the installation instruction.  |
| Firing speed RPM             | enabled/disabled | enabled  |  |
|                              | 0 to 200 %       | 24 %     | When generator speed higher than the set value, starter will be disconnected. See the installation instruction.  |
| Oil Pressure                 | enabled/disabled | enabled  |  |
|                              | 0 to 1000 kPa    | 200 kPa  | When generator oil pressure higher than the set value, starter will be disconnected. See the installation instruction.   |

### 4.2.4.3 Configure TEST Run

*"PARAMETER → Configure application → Configure TEST run"*

| Items                | Parameters          | Defaults | Description  |
|----------------------|---------------------|----------|--|
| <b>Scheduled run</b> | enabled/disabled    | disabled | <b>Notes</b><br>"enabled": The following related settings will be taken into account |
| Run mode             | Off load<br>On load | Off load |  |

| Items                     | Parameters          | Defaults    | Description   |
|---------------------------|---------------------|-------------|---|
| Schedule period           | Monthly             | Monthly     | <b>Notes</b><br><i>"Custom weekly"</i> : A table with 16 x setting blocks appear, each with ... <ul style="list-style-type: none"> <li>■ Start time (weekly) to select a week day</li> <li>■ Start time (hh:mm)</li> <li>■ Duration (m)</li> </ul> The TEST run is disabled if duration is "0" minutes. Max. duration is 30000 minutes. |
|                           | Weekly              |             |   |
|                           | Daily               |             |   |
|                           | Custom weekly       |             |   |
| Time (Day)                | 1 to 31             | 1           | <i>"Monthly"</i> : Select a week day  |
|                           | Sunday, to Saturday | Sunday      | <i>"Weekly"</i> : Select a week day   |
| Time (hour)               | 0 to 24 h           | 0 (o'clock) | Define the start time (hour)  |
| Time (minute)             | 0 to 59             | 0           | Define the start time (minute)  |
| Duration                  | 0 to 30000 min      | 30 min      | Select the duration for scheduled run   |
| <b>Auto start inhibit</b> | enabled/disabled    | disabled    | <b>Notes</b><br><i>"enabled"</i> : The following related settings will be taken into account  |
| Schedule period           | Monthly             | Monthly     |   |
|                           | Weekly              |             |   |
|                           | Daily               |             |   |
|                           |                     |             |   |
| Time (Day)                | 1 to 31             | 1           | <i>"Monthly"</i> : Select a week day  |
|                           | Sunday, to Saturday | Sunday      | <i>"Weekly"</i> : Select a week day   |
| Time (hour)               | 0 to 24 h           | 0 (o'clock) | Define the start time (hour)  |
| Time (minute)             | 0 to 59             | 0           | Define the start time (minute)  |
| Duration                  | 0 to 30000 min      | 30 min      | Select the duration for scheduled run   |

#### 4.2.4.4 Configure Breakers

*"PARAMETER → Configure application → Configure breakers"*

| Items                     | Parameters    | Defaults | Description   |
|---------------------------|---------------|----------|---|
| <b>Configure breakers</b> |               |          |   |
| Transfer time GCB<->MCB   | 0.0 to 7200 s | 5 s      | Interval time from mains switch OFF to generator switch ON; or from generator switch OFF to mains switch ON.  |
|                           |               |          | <b>Notes</b><br>Switching from generator supply to mains supply or from mains supply to generator supply occurs automatically if the operating conditions have been met.<br><br>The time between the command to open the one breaker and the pulse to close the other breaker is set by this parameter. This time applies for both directions. During this time the consumers are de-energized. |
| Closing time              | 0.0 to 20.0 s | 5.0 s    | Pulse width of mains/generator switch ON.   |
|                           |               |          | <b>Notes</b><br>This is the duration from the closing pulse for MCB and GCB as well. If the time is configured to "zero" the closing pulse acts as a steady pulse.  |
| Opening time              | 0.0 to 20.0 s | 3.0 s    | Pulse width of mains/generator switch OFF   |

## Configuration

Parameters > Configure Monitoring > Monitoring Mains

| Items                | Parameters       | Defaults | Description   |
|----------------------|------------------|----------|---|
|                      |                  |          | <b>Notes</b><br>This is the duration from the opening pulse for MCB and GCB as well.  |
| Immediately open MCB | enabled/disabled | enabled  | If this function is enabled, the MCB will open immediately if mains failure is detected.<br><br><b>Notes</b><br>The open sequence from the MCB after mains failure can be configured. If the function "Immediately open MCB" is enabled, the MCB opens after the Mains failure delay time independent from the generator status. In the other case the MCB opens after successful engine start. |

## 4.2.5 Configure Monitoring

### 4.2.5.1 Monitoring Mains

#### Monitoring General Mains Settings

*"PARAMETER → Configure monitoring → Mains  
→ General mains settings"*

| Items                            | Parameters       | Defaults | Description   |
|----------------------------------|------------------|----------|---|
| <b>General mains settings</b>    |                  |          |   |
| Mains fail delay time            | 0 to 3600 s      | 5 s      | To start the engine and to carry out an emergency operation the monitored mains must be failed continuously for the minimum period of time set with this parameter.<br><br>To Open the MCB is triggered if the parameter "Immediately open MCB" is enabled. |
| Mains settling time              | 0 to 3600 s      | 10 s     | To end the emergency operation the monitored mains must be without interruption in the operation range.<br><br>This parameter permits the delay time before switching the load from generator to mains.   |
| Enable mains phase rotation fail | enabled/disabled | enabled  | disabled: The related action is blocked   |
| Enable mains voltage asymmetry   | enabled/disabled | enabled  | disabled: The related action is blocked   |

#### Monitoring Frequency (Mains)

*"PARAMETER → Configure monitoring → Mains  
→ Frequency/Voltage → Frequency"*

| Items                 | Parameters       | Defaults | Description  |
|-----------------------|------------------|----------|--|
| <b>Overfrequency</b>  | enabled/disabled | disabled | <b>Notes</b><br><i>"enabled"</i> : The following related settings will be taken into account |
| Limit                 | 0 to 200 %       | 114 %    | Release the alarm when sensor value is same or higher than this value and Delay time is over |
| Return                | 0 to 200 %       | 110 %    | Cancel the alarm when sensor value is same or lower than this value and Delay time is over   |
| Delay                 | 0 to 3600 s      | 5 s      | The alarm status change must be valid for this period of time before it is released          |
| <b>Underfrequency</b> | enabled/disabled | disabled | <b>Notes</b><br><i>"enabled"</i> : The following related settings will be taken into account |

| Items  | Parameters  | Defaults | Description   |
|--------|-------------|----------|---|
| Limit  | 0 to 200 %  | 90 %     | Release the alarm when sensor value is same or lower than this value and Delay time is over |
| Return | 0 to 200 %  | 94 %     | Cancel the alarm when sensor value is same or higher than this value and Delay time is over |
| Delay  | 0 to 3600 s | 5 s      | The alarm status change must be valid for this period of time before it is released         |

### Monitoring Voltage (Mains)

*"PARAMETER → Configure monitoring → Mains  
→ Frequency/Voltage → Voltage"*

| Items               | Parameters       | Defaults | Description  |
|---------------------|------------------|----------|--|
| <b>Overvoltage</b>  | enabled/disabled | enabled  | <b>Notes</b><br>"enabled": The following related settings will be taken into account         |
| Limit               | 0 to 200 %       | 120 %    | Release the alarm when sensor value is same or higher than this value and Delay time is over |
| Return              | 0 to 200 %       | 116 %    | Cancel the alarm when sensor value is same or lower than this value and Delay time is over   |
| Delay               | 0 to 3600 s      | 5 s      | The alarm status change must be valid for this period of time before it is released          |
| <b>Undervoltage</b> | enabled/disabled | enabled  | <b>Notes</b><br>"enabled": The following related settings will be taken into account         |
| Limit               | 0 to 200 %       | 80 %     | Release the alarm when sensor value is same or lower than this value and Delay time is over  |
| Return              | 0 to 200 %       | 84 %     | Cancel the alarm when sensor value is same or higher than this value and Delay time is over  |
| Delay               | 0 to 3600 s      | 5 s      | The alarm status change must be valid for this period of time before it is released          |

### 4.2.5.2 Monitoring Generator

#### Monitoring Voltage

*"PARAMETER → Configure monitoring → Generator → Voltage"*

| Items                       | Parameters       | Defaults      | Description  |
|-----------------------------|------------------|---------------|--|
| <b>Overvoltage warning</b>  | enabled/disabled | disabled      | <b>Notes</b><br>"enabled": The following related settings will be taken into account         |
| Limit                       | 0 to 200 %       | 110 % (253 V) | Release the alarm when sensor value is same or higher than this value and Delay time is over |
| Return                      | 0 to 200 %       | 108 % (248 V) | Cancel the alarm when sensor value is same or lower than this value and Delay time is over   |
| Delay                       | 0 to 3600 s      | 5 s           | The alarm status change must be valid for this period of time before it is released          |
| <b>Overvoltage shutdown</b> | enabled/disabled | enabled       | <b>Notes</b><br>"enabled": The following related settings will be taken into account         |
| Limit                       | 0 to 200 %       | 120 % (276 V) | Release the alarm when sensor value is same or higher than this value and Delay time is over |

## Configuration

Parameters > Configure Monitoring > Monitoring Generator

| Items                        | Parameters       | Defaults     | Description   |
|------------------------------|------------------|--------------|---|
| Delay                        | 0 to 3600 s      | 3 s          | The alarm status change must be valid for this period of time before it is released         |
| <b>Undervoltage warning</b>  | enabled/disabled | enabled      | <b>Notes</b><br>"enabled": The following related settings will be taken into account        |
| Limit                        | 0 to 200 %       | 84 % (193 V) | Release the alarm when sensor value is same or lower than this value and Delay time is over |
| Return                       | 0 to 200 %       | 86 % (197 V) | Cancel the alarm when sensor value is same or higher than this value and Delay time is over |
| Delay                        | 0 to 3600 s      | 5 s          | The alarm status change must be valid for this period of time before it is released         |
| <b>Undervoltage shutdown</b> | enabled/disabled | enabled      | <b>Notes</b><br>"enabled": The following related settings will be taken into account        |
| Limit                        | 0 to 200 %       | 80 % (184 V) | Release the alarm when sensor value is same or lower than this value and Delay time is over |
| Delay                        | 0 to 3600 s      | 3 s          | The alarm status change must be valid for this period of time before it is released         |

## Monitoring Frequency

"PARAMETER → Configure monitoring → Generator  
→ Frequency"

| Items                          | Parameters       | Defaults        | Description  |
|--------------------------------|------------------|-----------------|--|
| <b>Overfrequency warning</b>   | enabled/disabled | enabled         | <b>Notes</b><br>"enabled": The following related settings will be taken into account         |
| Limit                          | 0 to 200 %       | 110 % (55.0 Hz) | Release the alarm when sensor value is same or higher than this value and Delay time is over |
| Return                         | 0 to 200 %       | 108 % (54.0 Hz) | Cancel the alarm when sensor value is same or lower than this value and Delay time is over   |
| Delay                          | 0 to 3600 s      | 5 s             | The alarm status change must be valid for this period of time before it is released          |
| <b>Overfrequency shutdown</b>  | enabled/disabled | enabled         | <b>Notes</b><br>"enabled": The following related settings will be taken into account         |
| Limit                          | 0 to 200 %       | 114 % (57.0 Hz) | Release the alarm when sensor value is same or higher than this value and Delay time is over |
| Delay                          | 0 to 3600 s      | 2 s             | The alarm status change must be valid for this period of time before it is released          |
| <b>Underfrequency warning</b>  | enabled/disabled | enabled         | <b>Notes</b><br>"enabled": The following related settings will be taken into account         |
| Limit                          | 0 to 200 %       | 84 % (42.0 Hz)  | Release the alarm when sensor value is same or lower than this value and Delay time is over  |
| Return                         | 0 to 200 %       | 86 % (43.0 Hz)  | Cancel the alarm when sensor value is same or higher than this value and Delay time is over  |
| Delay                          | 0 to 3600 s      | 5 s             | The alarm status change must be valid for this period of time before it is released          |
| <b>Underfrequency shutdown</b> | enabled/disabled | enabled         | <b>Notes</b><br>"enabled": The following related settings will be taken into account         |



| Items | Parameters  | Defaults       | Description   |
|-------|-------------|----------------|---|
| Limit | 0 to 200 %  | 80 % (40.0 Hz) | Release the alarm when sensor value is same or lower than this value and Delay time is over |
| Delay | 0 to 3600 s | 3 s            | The alarm status change must be valid for this period of time before it is released         |

### Monitoring Miscellaneous

*"PARAMETER → Configure monitoring → Generator → Miscellaneous"*

| Items                                | Parameters                                | Defaults    | Description  |
|--------------------------------------|---|-------------|--|
| <b>Ground fault</b>                  | enabled/disabled                          | disabled    | <b>Notes</b><br>"enabled": The following related settings will be taken into account   |
| Action                               | Warn<br>Shutdown<br>Trip and Stop<br>Trip | Warn        | Alarm type to be released if wire break is detected  |
| Limit                                | 0 to 100 %                                | 10 % (50 A) | Release the alarm when sensor value is same or higher than this value and Delay time is over   |
| Delay multiplier                     | 0.1 to 1.6                                | 0.1         | The "Delay multiplier" defines the grade of reaction on the ratio of current ground current to overcurrent setting. A low value means fast reaction (short delay time); the greater the value the slower reaction because longer delay time. |
| Enable generator phase rotation fail | enabled/disabled                          | enabled     |  |
| Enable generator voltage asymmetry   | enabled/disabled                          | enabled     |  |

### Monitoring Generator Current Alarm

*"PARAMETER → Configure monitoring → Generator → Generator current alarm"*

| Items                              | Parameters  | Defaults      | Description   |
|------------------------------------|---|---------------|---|
| <b>Generator current alarm</b>     | enabled/disabled                                      | enabled       | <b>Notes</b><br>"enabled": The following related settings will be taken into account  |
| Limit                              | 0 to 200 %  | 120 % (600 A) | Release the alarm when sensor value is same or higher than this value and Delay time is over  |
| Action                             | Warn<br>Shutdown<br>Trip and Stop<br>Trip             | Warn          | Alarm type to be released if wire break is detected   |
| Type                               | Definite time<br>IDMT (Inverse Definite Minimum Time) | Definite time |   |
| If Type is "Define Time":<br>Delay | 0 to 3600 s   | 10 s          | The alarm status change must be valid for this period of time before it is released   |
| If Type is "IDMT ...":<br>Delay    | 1 to 36   | 36            | "Multiply" defines the grade of reaction on the ratio of generator current to overcurrent setting. A low value means fast reaction (short delay time); the greater the value the slower reaction because longer delay time. |

## Configuration

Parameters > Configure Monitoring > Monitoring Generator

### Monitoring Power

*"PARAMETER → Configure monitoring → Generator → Power"*

| Items                | Parameters                                | Defaults       | Description  |
|----------------------|---|----------------|--|
| <b>Reserve power</b> | enabled/disabled                          | disabled       | <b>Notes</b><br>"enabled": The following related settings will be taken into account         |
| Action               | Warn<br>Shutdown<br>Trip and Stop<br>Trip | Warn           | Alarm type to be released if wire break is detected  |
| Limit                | 0 to 200 %                                | 10 % (27 kW)   | Release the alarm when sensor value is same or higher than this value and Delay time is over |
| Return               | 0 to 200 %                                | 5 % (13 kW)    |  |
| Delay                | 0 to 3600 s                               | 5 s            | The alarm status change must be valid for this period of time before it is released          |
| <b>Overload</b>      | enabled/disabled                          | disabled       | <b>Notes</b><br>"enabled": The following related settings will be taken into account         |
| Action               | Warn<br>Shutdown<br>Trip and Stop<br>Trip | Warn           | Alarm type to be released if wire break is detected  |
| Limit                | 0 to 200 %                                | 110 % (303 kW) | Release the alarm when sensor value is same or higher than this value and Delay time is over |
| Return               | 0 to 200 %                                | 105 % (289 kW) |  |
| Delay                | 0 to 3600 s                               | 5 s            | The alarm status change must be valid for this period of time before it is released          |

### Monitoring Generator Operating Range

*"PARAMETER → Configure monitoring → Generator → Generator operating range"*

| Items                            | Parameters | Defaults       | Description  |
|----------------------------------|------------|----------------|--|
| <b>Generator operating range</b> |            |                |  |
| Loading voltage                  | 0 to 200 % | 85 % (196 V)   | In AUTO mode the GCB closes if the actual generator voltage is higher than the configured loading voltage.     |
| Loading frequency                | 0 to 200 % | 85 % (42.5 Hz) | In AUTO mode the GCB closes if the actual generator frequency is higher than the configured loading frequency. |

### 4.2.5.3 Monitoring Breakers

#### Monitoring Breakers

*"PARAMETER → Configure monitoring → Breakers"*

| Items                              | Parameters       | Defaults | Description  |
|------------------------------------|------------------|----------|--|
| Enable breaker feedback monitoring | enabled/disabled | disabled | With enabled breaker feedback monitoring, the device uses the configured discrete inputs for the breaker status. |
| Check fail warn(ing)               | enabled/disabled | disabled | Enable the breaker feedback monitoring. This requires the "Enable breaker feedback monitoring".                  |
| Check time                         | 0.0 to 20.0 s    | 5.0 s    | Breaker monitoring delay time. After the configured check time, a breaker failure alarm sounds.                  |

### 4.2.5.4 Monitoring Engine

#### Monitoring Loading Speed

*"PARAMETER → Configure monitoring → Engine → Loading speed"*

| Items         | Parameters | Defaults          | Description  |
|---------------|------------|-------------------|--|
| Loading speed | 0 to 100 % | 90 % (1350 r/min) | In AUTO mode the GCB closes if the actual engine speed is higher than the configured loading speed. This function is only used if the MPU input is used. |

#### Monitoring Speed

*"PARAMETER → Configure monitoring → Engine → Speed"*

| Items                     | Parameters       | Defaults           | Description  |
|---------------------------|------------------|--------------------|--|
| <b>Overspeed warning</b>  | enabled/disabled | enabled            | <b>Notes</b><br>"enabled": The following related settings will be taken into account         |
| Limit                     | 0 to 200 %       | 110 % (1650 r/min) | Release the alarm when sensor value is same or higher than this value and Delay time is over |
| Return                    | 0 to 200 %       | 108 % (1620 r/min) | Cancel the alarm when sensor value is same or lower than this value and Delay time is over   |
| Delay                     | 0 to 3600 s      | 5 s                | The alarm status change must be valid for this period of time before it is released          |
| <b>Overspeed shutdown</b> | enabled/disabled | enabled            | <b>Notes</b><br>"enabled": The following related settings will be taken into account         |
| Limit                     | 0 to 200 %       | 114 % (1710 r/min) | Release the alarm when sensor value is same or higher than this value and Delay time is over |
| Delay                     | 0 to 3600 s      | 2 s                | The alarm status change must be valid for this period of time before it is released          |
| <b>Underspeed warning</b> | enabled/disabled | enabled            | <b>Notes</b><br>"enabled": The following related settings will be taken into account         |
| Limit                     | 0 to 200 %       | 86 % (1290 r/min)  | Release the alarm when sensor value is same or lower than this value and Delay time is over  |
| Return                    | 0 to 200 %       | 90 % (1350 r/min)  | Cancel the alarm when sensor value is same or higher than this value and Delay time is over  |
| Delay                     | 0 to 3600 s      | 5 s                | The alarm status change must be valid for this period of time before it is released          |

## Configuration

Parameters > Configure Monitoring > Other Monitoring

| Items                       | Parameters       | Defaults          | Description   |
|-----------------------------|------------------|-------------------|---|
| <b>Underspeed shutdown</b>  | enabled/disabled | enabled           | <b>Notes</b><br>"enabled": The following related settings will be taken into account        |
| Limit                       | 0 to 200 %       | 80 % (1200 r/min) | Release the alarm when sensor value is same or lower than this value and Delay time is over |
| Delay                       | 0 to 3600 s      | 3 s               | The alarm status change must be valid for this period of time before it is released         |
| <b>Loss of speed signal</b> |                  |                   |   |
| Delay                       | 0 to 3600 s      | 5 s               | The alarm status change must be valid for this period of time before it is released         |
| Action                      | Warn<br>Shutdown | Warn              |   |

### Monitoring Start/Stop

"PARAMETER → Configure monitoring → Engine → Start/Stop"

| Items                       | Parameters  | Defaults | Description   |
|-----------------------------|-------------|----------|---|
| <b>Shutdown malfunction</b> |             |          |   |
| Shutdown malfunction delay  | 0 to 3600 s | 0 s      | Time between ending of genset idle delay and stopped when "Stop solenoid Hold" is set as "0" or<br>Time between ending of Stop solenoid hold delay and stopped when "Stop solenoid Hold" time is not "0". |

### 4.2.5.5 Other Monitoring

#### Monitoring Battery Voltage

"PARAMETER → Configure monitoring → Engine  
→ Other monitoring → Battery voltage"

| Items               | Parameters       | Defaults       | Description  |
|---------------------|------------------|----------------|--|
| Rated               | 0.0 to 60.0 V    | 24.0 V         |  |
| <b>Overvoltage</b>  | enabled/disabled | enabled        | <b>Notes</b><br>"enabled": The following related settings will be taken into account         |
| Limit               | 0 to 200 %       | 120 % (28.8 V) | Release the alarm when sensor value is same or higher than this value and Delay time is over |
| Return              | 0 to 200 %       | 115 % (27.6 V) | Cancel the alarm when sensor value is same or lower than this value and Delay time is over   |
| Delay               | 0 to 3600 s      | 60 s           | The alarm status change must be valid for this period of time before it is released          |
| <b>Undervoltage</b> | enabled/disabled | enabled        | <b>Notes</b><br>"enabled": The following related settings will be taken into account         |
| Limit               | 0 to 200 %       | 85 % (20.4 V)  | Release the alarm when sensor value is same or lower than this value and Delay time is over  |
| Return              | 0 to 200 %       | 90 % (21.6 V)  | Cancel the alarm when sensor value is same or higher than this value and Delay time is over  |
| Delay               | 0 to 3600 s      | 60 s           | The alarm status change must be valid for this period of time before it is released          |

**Monitoring Charge Alternator (D+)**

*"PARAMETER → Configure monitoring → Engine  
→ Other monitoring → Charge alternator"*

| Items                         | Parameters       | Defaults | Description  |
|-------------------------------|------------------|----------|--|
| <b>Charge alternator (D+)</b> | enabled/disabled | enabled  | <b>Notes</b><br>"enabled": The following related settings will be taken into account         |
| Limit                         | 0.0 to 60.0 V    | 8.0 V    | Release the alarm when sensor value is same or higher than this value and Delay time is over |
| Return                        | 0.0 to 60.0 V    | 10.0 V   | Cancel the alarm when sensor value is same or lower than this value and Delay time is over   |
| Delay                         | 0 to 3600 s      | 10 s     | The alarm status change must be valid for this period of time before it is released          |

**4.2.6 Configure Interfaces**

*"PARAMETER → Configure interfaces"*

| Items                  | Parameters              | Defaults              | Description  |
|------------------------|-------------------------|-----------------------|--|
| <b>Modbus slave ID</b> |                         |                       |  |
| Modbus slave ID        | 1 to 254                | 1                     |  |
| <b>RS485</b>           |                         |                       |  |
| Baud rate              | 2400, 4800, 9600, 19200 | 19200                 |  |
| Data bit               | 8                       |                       |  |
| Parity bit             | None                    |                       |  |
| Stop bit               | 2                       | 1, 2                  |  |
| <b>Ethernet</b>        | enabled/disabled        | enabled               | <b>Notes</b><br>"enabled": The following related settings will be taken into account             |
| IP address             | XXX.XXX.XXX.XXX         | 192.168.0.1<br>44     |  |
| Subnet mask            | XXX.XXX.XXX.XXX         | 255.255.255<br>.0     |  |
| Gateway                | XXX.XXX.XXX.XXX         | 192.168.0.1           |  |
| Gateway                | XXX.XXX.XXX.XXX         | 192.168.0.1           |  |
| MAC address            | XX-XX-XX-XX-XX-XX       | 25-25-25-25<br>-25-25 |  |
| <b>SD card</b>         |                         |                       |  |
| Enable SD card         | enabled/disabled        | disabled              | <b>Notes</b><br>"enabled": SD card is used to save Event Logs as an "[date].dat" file every week |

## Configuration

Parameters > Configure Interfaces > Configure GSM Module

### 4.2.6.1 Configure GSM Module

#### General Notes

The external GSM module enables communication via radio frequency transmission e.g. with a mobile phone.

*"PARAMETER → Configure interfaces → GSM module"*

| Items        | Parameters       | Defaults  | Description   |
|--------------|------------------|-----------|---|
| GSM enable   | enabled/disabled | enabled   | <b>Notes</b><br><i>"enabled"</i> : The connected external GSM module will be used for communication |
| Phone number | Max. 20 digits   | ((empty)) | Phone number of the (radio) connected mobile phone/device.  |

#### 4.2.6.1.1 GSM Short Message Alarm

When controller detects an alarm, it will send short message to phone automatically (if enabled).



*All shutdown, trip and stop and trip alarms will be sent to the pre-set phone. Warnings are sent to the phone according to the settings.*

#### 4.2.6.1.2 GSM Short Message Remote Control

#### General notes

Users send *"SMS Order"* message to GSM module, then controller will act according to this remote signal and pass back corresponding operation information.



*International area code must be added. E.g. USA 001...*

*"SMS orders" must be typed-in in the form described below e.g. all letters must be capital!*

*If an easYgen model does not support an information or detail, value will be empty.*

The following *"SMS Orders"* are supported:

| SMS Order  | Pass back Information                | Description                              |                  |
|------------|--------------------------------------|--|------------------|
| SMS GENSET | GENSETALARM                          | Shutdown alarm occurred                  | status of genset |
|            | SYSTEM IN STOP MODE GENSET AT REST   | Current mode: STOP<br>Genset: standstill |                  |
|            | SYSTEM IN MANUAL MODE GENSET AT REST | Current mode: MAN<br>Genset: standstill  |                  |
|            | SYSTEM IN AUTO MODE GENSET AT REST   | Current mode: STOP<br>Genset: standstill |                  |

| SMS Order         | Pass back Information                                 | Description   |              |
|-------------------|---|---|--------------|
|                   | SYSTEM IN STOP MODE GENSET IS RUNNING                 | Current mode: STOP<br>Genset: running   |              |
|                   | SYSTEM IN MANUAL MODE GENSET IS RUNNING               | Current mode: STOP<br>Genset: running   |              |
|                   | SYSTEM IN AUTO MODE GENSET AT RUNNING                 | Current mode: STOP<br>Genset: running   |              |
| SMS START         | GENSET ALARM  | Shutdown alarm or trip alarm occurred   | Start genset |
|                   | STOP MODE NOT START                                   | Cannot start in STOP mode   |              |
|                   | SMS START OK  | Start in MAN mode   |              |
|                   | AUTO MODE NOT START                                   | Cannot start in AUTO mode   |              |
| SMSSTOP MODE      | SMS STOP OK   | Current mode: STOP  |              |
| SMS MANUAL MODE   | SMS MANUAL MODE OK                                    | Current mode: MAN   |              |
| SMSAUTO MODE      | SMS AUTO MODE OK                                      | Current mode: AUTO  |              |
| SMS DETAIL        | Pass back information set by controller configuration | Delivers the configured information of the genset:<br><br>Working mode, mains voltage, generator voltage, load current, mains frequency, generator frequency, active power, apparent power, power factor, battery voltage, D+ voltage, water temperature, oil pressure, oil level, engine speed, total running time, genset status, and alarm status. |              |
| SMS INHIBIT START | INHIBIT START OK                                      | Generator START will be inhibited.  |              |
| SMS PERMIT START  | PERMIT START OK                                       | Discharge the inhibit START signal.   |              |

#### 4.2.6.2 Configure Ethernet Interface

##### General Notes

The Ethernet Interface is used for controller monitoring and has two connection modes:

- Network Client mode  
and
- Web Server mode



*Change of controller's network parameters (e.g. IP address, sub network mask) take effect only after controller restart.*

##### 4.2.6.2.1 Network Client Mode

When the controller is used as network client, it can be monitored via network port using TCP ModBus protocol:

##### Connect as Network Client

1. ➤ Set IP address and sub network of the controller.



*The IP address must be in the same network segment as the IP address of monitoring equipment (e.g. PC).*

Example: Monitoring equipment IP address is 192.168.0.16, controller IP can be 192.168.0.18, sub network mask (for both) is 255.255.255.0

## Configuration

Parameters > Configure Interfaces > Configure Ethernet Interfa...

2. ➤ Connect the controller. It can be connected to the monitoring equipment directly using network cable or via a switchboard.
3. ➤ The communication between controller and monitoring equipment is carried out using TCP Modbus protocol.



*This Network Client mode enables to set parameters. A communication protocol is available.*

### 4.2.6.2.2 Web Server Mode

If the controller acts as a web server, it can be controlled via web browser using PC:

#### Connect as Web Serer

1. ➤ Set IP address and sub network of the controller.



*The IP address must be in the same network segment as the IP address of monitoring equipment (e.g. PC).*

Example: Monitoring equipment IP address is 192.168.50.144, controller IP can be 192.168.50.146, sub network mask (for both) is 255.255.255.0

2. ➤ Connect controller to the monitoring equipment directly using network cable or via a switchboard (hub/switch).
3. ➤ In order to monitor the controller, use IP address as URL with a web browser e.g.: `http://192.168.50.146`



*This Web Server mode is for visualization only - no parameter change access.*

*With "Operate → Stop/Manual/Start/Auto" a basic remote control is accessible on the lower right corner.*






Fig. 22: Web Server mode

## 4.2.7 Configure Maintenance

“PARAMETER → Configure maintenance”




Fig. 23: Schedule Maintenance

| Items                                      | Parameters                | Defaults  | Description  |
|--|---------------------------|-----------|--|
| <b>Notes</b> For Maintenance {x} = 1 to 3: |                           |           |  |
| Maintenance {x}                            | enabled/disabled          | disabled  | <b>Notes</b><br>“enabled”: The following related settings will be taken into account |
| Description                                | Text field for 20 letters | ((empty)) | Customer specific sensor name  |
| Enable reset by HMI                        | enabled/disabled          | disabled  | <b>Notes</b><br>“disabled”: Reset via HMI is blocked                                 |
| Maintenance interval                       | 0 to 30000 h              | 10 h      |  |

## Configuration

Parameters > Configure Counters

| Items            | Parameters                                  | Defaults  | Description |
|------------------|---|-----------|-------------|
| Remaining time A | 0 to 30000 h                                | 10 h      | A           |
| Select Action A  | No Action<br>Warn<br>Shutdown<br>Indication | No Action |             |
| Remaining time B | 0 to 30000 h                                | 2 h       | B           |
| Select Action B  | No Action<br>Warn<br>Shutdown<br>Indication | No Action |             |
| Maintenance due  | Display current time                        |           | Overall     |
| Select Action    | No Action<br>Warn<br>Shutdown<br>Indication | No Action |             |

### 4.2.8 Configure Counters

*"PARAMETER → Configure counters"*

| Items                       | Parameters                 | Defaults | Description   |
|-----------------------------|----------------------------|----------|---|
| <b>Engine running hours</b> |                            |          |   |
| Time                        | 0 to 65534 hours           | 0 hours  | Preset value  |
|                             | 0 to 59 min                | 0 min    | Preset value  |
|                             | Set (push button)          |          | PUSH: Preset time is written to the connected easYgen             |
| Start counter               | 0 to 65534                 | 0        | Preset value: Number of starts                                    |
|                             | Set (push button)          |          | PUSH: Preset number of starts is written to the connected easYgen |
| <b>Current module</b>       | Display of device's values |          | Updated with pushing one of the Set buttons above                 |
| Total run time              |                            |          | Total engine run time   |
| Total start times           |                            |          | Total number of starts  |
| <b>Generator energy</b>     |                            |          |   |
| kW                          | 0 to 9999999.9 kW          | 0.0 kW   |   |
|                             | Set (push button)          |          | PUSH: Preset kW value is written to the connected easYgen         |
| kvar                        | 0 to 9999999.9 kvar        | 0.0 kvar |   |
|                             | Set (push button)          |          | PUSH: Preset kvar value is written to the connected easYgen       |
| kVA                         | 0 to 9999999.9 kVA         | 0.0 kVA  |   |
|                             | Set (push button)          |          | PUSH: Preset kVA value is written to the connected easYgen        |
| <b>Current module</b>       | Display of device's values |          | Displaying the device's values                                    |
| kW                          |                            |          | Each updated with pushing the related Set button (above)          |
| Kvar                        |                            |          |   |
| kVA                         |                            |          |   |

| Items             | Parameters                 | Defaults | Description   |
|-------------------|----------------------------|----------|---|
| <b>Total A</b>    |                            |          |   |
| Time              | 0 to 65534 hours           | 0 hours  | Preset value  |
|                   | 0 to 59 min                | 0 min    | Preset value  |
|                   | Set (push button)          |          | PUSH: Preset time is written to the connected easYgen             |
| Start counter     | 0 to 65534                 | 0        | Preset value: Number of starts                                    |
|                   | Set (push button)          |          | PUSH: Preset number of starts is written to the connected easYgen |
| <b>A</b>          | Display of device's values |          | Updated with pushing one of the Set buttons above                 |
| Total run time    |                            |          | Total engine run time   |
| Total start times |                            |          | Total number of starts  |
| kW                | 0 to 9999999.9 kW          | 0.0 kW   | Electric energy consumed  |
|                   | Set (push button)          |          | PUSH: Preset kW value is written to the connected easYgen         |
| <b>Total B</b>    |                            |          |   |
| Time              | 0 to 65534 hours           | 0 hours  | Preset value  |
|                   | 0 to 59 min                | 0 min    | Preset value  |
|                   | Set (push button)          |          | PUSH: Preset time is written to the connected easYgen             |
| Start counter     | 0 to 65534                 | 0        | Preset value: Number of starts                                    |
|                   | Set (push button)          |          | PUSH: Preset number of starts is written to the connected easYgen |
| <b>B</b>          | Display of device's values |          | Updated with pushing one of the Set buttons above                 |
| Total run time    | Total engine run time      |          |   |
| Total start times | Total number of starts     |          |   |
| kW                | 0 to 9999999.9 kW          | 0.0 kW   | Electric energy consumed  |
|                   | Set (push button)          |          | PUSH: Preset kW value is written to the connected easYgen         |

#### 4.2.9 Configure Switchable Parameter Set

*"PARAMETER → Configure switchable parameter sets  
→ Alternative set 1 to 3"*

| Items                   | Parameters  | Defaults                          | Description  |
|-------------------------|---|-----------------------------------|--|
| Enable                  | enabled/disabled  | disabled                          | <b>Notes</b><br>"enabled": The following related settings will be taken into account |
| <b>Mains</b>            |   |                                   |  |
| Mains voltage measuring | 0: 3 Phase, 4 Wire (3Ph4W)<br>1: 3 Phase, 3 Wire (3Ph3W)<br>2: 2 Phase, 3 Wire (2Ph3W)<br>3: Single Phase, 2 Wire (1Ph2W) | 0: <b>3 Phase, 4 Wire (3Ph4W)</b> |  |
| Mains rated voltage     | 30 to 30000 V   | <b>230 V</b>                      |  |

## Configuration

Parameters > Configure Language / Clock

| Items                        | Parameters  | Defaults                          | Description |
|------------------------------|---|-----------------------------------|-------------|
| Mains rated frequency        | 10.0 to 85.0 Hz   | 50.0 Hz                           |             |
| <b>Generator</b>             |   |                                   |             |
| Generator voltage measuring  | 0: 3 Phase, 4 Wire (3Ph4W)<br>1: 3 Phase, 3 Wire (3Ph3W)<br>2: 2 Phase, 3 Wire (2Ph3W)<br>3: Single Phase, 2 Wire (1Ph2W) | 0: <b>3 Phase, 4 Wire (3Ph4W)</b> |             |
| Generator rated voltage      | (30 to 30000) V   | <b>230 V</b>                      |             |
| Generator rated frequency    | 10.0 to 85.0 Hz   | 50.0 Hz                           |             |
| Generator rated current      | 5 to 6000 A   | 500 A                             |             |
| Generator rated active power | 0 to 6000 kW  | 276 kW                            |             |
| Engine rated speed           | 0 to 6000 r/min   | 1500 r/min                        |             |

### 4.2.10 Configure Language / Clock

*"PARAMETER → Configure language / clock"*

| Items                 | Parameters         | Defaults       | Description  |
|-----------------------|--------------------|----------------|--|
| <b>Language</b>       | Simplified Chinese | English        | With "Other" the customer specific (loaded) language (file) will be used for HMI display.<br><br><b>Notes</b><br>To upload a customer specific language file, see ToolKit-SC menu <i>"Language pack"</i> |
|                       | English            |                |  |
|                       | Other              |                |  |
| <b>Date/Time</b>      |                    |                |  |
| <b>Set value</b>      |                    |                |  |
| Date                  | Push icon          | (current date) | Calendar sub module will be opened: DD.MM.YYYY   |
| Time                  | Time display       | (current time) | Time sub module enable comfortable setting time value: hh:mm:ss  |
| Set                   | Push button        |                | Write value to the easYgen device  |
| Use PC time           | Push button        |                | Write PC time to the easYgen device  |
| <b>Current module</b> | Date (YYYY-MM-DD)  | (actual value) | Display device's value   |
|                       | Time (hh:mm:ss)    |                |  |

## 4.2.11 Configure System Management

*"PARAMETER → Configure system management"*

| Items                              | Parameters                            | Defaults  | Description  |
|------------------------------------|---------------------------------------|-----------|--|
| <b>Configure system management</b> |                                       |           |  |
| Device name 1                      | Text field for 10 letters             | ((empty)) | Customer specific device name  |
| Device name 2                      | Text field for 10 letters             | ((empty)) | Customer specific additional/2nd device name   |
| Password                           | enabled/disabled                      | disabled  | Enabled: <ul style="list-style-type: none"> <li>Type in new password</li> <li>"eye symbol": switch between visible number and placeholder stars</li> </ul> |
|                                    | 0 to 9999                             | 0500      | Factory setting for write access from ToolKit-Sc to the easYgen  |
| Startup in mode                    | Stop mode<br>Manual mode<br>Auto mode | Stop mode |  |

## 4.2.12 Configure HMI

*"PARAMETER → Configure HMI"*

| Items                     | Parameters                            | Defaults                 | Description  |
|---------------------------|---------------------------------------|--------------------------|--|
| Mute buzzer               | enabled/disabled                      | disabled                 | Disabled: No acoustic signal with alarm/warning  |
| Activate status bar color | enabled/disabled                      | disabled                 | <b>HMI only:</b><br>Use a contrast background color of information line area at the bottom of the display?   |
| Set display color         | HMI device display color combinations | 13 F(Black)/<br>B(White) | Display color scheme offers combinations of "F" Font color and "B" Background color to be selected:<br>F (color of font and drawing) / B (color of background)<br>The color combinations use the following : <ul style="list-style-type: none"> <li>Black</li> <li>White</li> <li>B = Blue</li> <li>G = Green</li> <li>R = Red</li> <li>B+G or G+B = light blue / turquoise</li> <li>R+B = (together: ) Violet</li> <li>R+G = (together: ) Yellow</li> </ul> |
| Activate start-up logo    | enabled/disabled                      | enabled                  | Enable or disable start-up logo during start-up.   |
| Start-up logo duration    | 0.0 to 20.0 s                         | 3.0 s                    | Duration the user page picture is visible during device start-up.  |
| Set start-up logo         | Push button                           |                          | Push: Opens sub menu to select a picture file (480 x 27 pixels black/white) and transfer it into the device.   |

## Configuration

Selectable Inputs/Outputs/Se... > Programmable Sensors

### 4.3 Selectable Inputs/Outputs/Sensors

#### 4.3.1 Programmable Sensors

##### Selection

| Sensor             | Description   | Remark  |
|--------------------|---|---|
| Temperature Sensor | 0 Not used<br>1 Custom Res Curve<br>2 Reserved<br>3 VDO<br>4 CURTIS<br>5 VOLVO-EC<br>6 DATCON<br><b>7 SGX</b><br>8 SGD<br>9 SGH<br>10 PT100<br>11 SUSUKI<br>12 PRO<br>13 to 15 Reserved   | Defined resistance range is (0 to 6) K $\Omega$ .<br>Default is "7 SGX sensor". |
| Pressure Sensor    | 0 Not used<br>1 Custom Res Curve<br>2 Reserved<br>3 VDO 10 Bar<br>4 CURTIS<br>5 VOLVO-EC<br>6 DATCON 10 Bar<br><b>7 SGX</b><br>8 SGD<br>9 SGH<br>10 VDO 5 Bar<br>11 DATCON 5 Bar<br>12 DATCON 7 Bar<br>13 SUSUKI<br>14 PRO<br>15 Reserved | Defined resistance range is (0 to 6) K $\Omega$ .<br>Default is "7 SGX sensor". |
| Fuel Level Sensor  | 0 Not used<br>1 Custom Res Curve<br>2 Reserved<br>3 SGD<br><b>4 SGH</b><br>5 to 15 Reserved   | Defined resistance range is (0 to 6) K $\Omega$ .<br>Default is "4 SGH sensor". |



### Configuration/Setting

When reselect sensors, the sensor curve will be transferred into the standard value. For example, if temperature sensor is SGX (120°C resistor type), its sensor curve is SGX (120°C resistor type); if select the SGD (120°C resistor type), the temperature sensor curve is SGD curve.

If there is a difference between standard sensor curve and used sensor, user can adjust it in "curve type".

When input the sensor curve values, X value (resistor) must be in sequence from small to large, otherwise, mistake occurs.

If select sensor type as "None", sensor curve is not working.

If corresponding sensor has alarm switch only, user must set this sensor as "None", otherwise, maybe there is shutdown or warning.

## 4.3.2 Programmable Inputs



The programmable inputs are all active, if connected to ground (B-)

Each input needs an alarm type and a release condition definition:

| Alarm type    | description   |
|---------------|---|
| Indication    | indicate only<br>NO warning or shutdown                       |
| Warning       | warn only<br>NO shutdown                                      |
| Shutdown      | alarm and shutdown immediately                                |
| Trip and stop | alarm<br>generator unloads<br>shutdown after hi-speed cooling |
| Trip          | alarm<br>generator unloads<br>NO shutdown                     |

| Release Condition | Description                  |
|-------------------|------------------------------|
| Never             | input inactive               |
| Always            | input is active all the time |

## Configuration

Selectable Inputs/Outputs/Se... > Programmable Inputs

| Release Condition | Description                         |
|-------------------|-------------------------------------|
| From crank        | detecting as soon as start          |
| From safety on    | detecting after safety on run delay |

| No. | Type                        | Description  |
|-----|-----------------------------|--|
| 0   | User defined                | This type offers the following sub selections: <ul style="list-style-type: none"> <li>■ (Adjust to logic)</li> <li>■ (Define alarm type)</li> <li>■ (Release condition)</li> <li>■ Input delay</li> <li>■ (Description)</li> </ul> |
| 1   | -                           | Reserved   |
| 2   | Mute alarm buzzer           | Can prohibit "Horn" output when input is active  |
| 3   | Ext. acknowledge            | Can reset shutdown alarm and trip alarm when input is active   |
| 4   | Enable 60Hz ECU             | Use for CANBUS engine and it is 60 Hz when input is active   |
| 5   | Lamp test                   | All LED indicators are illuminating when input is active   |
| 6   | Lock keypad                 | All buttons in panel is inactive except and there is in the left of first row in LCD when input is active  |
| 7   | -                           | Reserved   |
| 8   | Idle mode                   | Under voltage/frequency/speed protection is inactive   |
| 9   | Inhibit auto stop           | In Auto mode, during generator normal running, when input is active, inhibit generator shutdown automatically  |
| 10  | Inhibit auto start          | In Auto mode, inhibit generator start automatically when input is active   |
| 11  | Inhibit scheduled run       | In Auto mode, inhibit scheduled run genset when input is active  |
| 12  | -                           | Reserved   |
| 13  | GCB closed                  | Connect generator loading switch's Aux. Point  |
| 14  | Inhibit GCB to close        | Prohibit genset switch on when input is active   |
| 15  | MCB closed                  | Connect mains loading switch's Aux. Point  |
| 16  | Inhibit MCB to close        | Prohibit mains switch on when input is active  |
| 17  | Operation mode AUTO lock    | When input is active, controller enters into Auto mode; all the keys except are inactive   |
| 18  | Operation mode AUTO inhibit | When input is active, controller won't work under Auto mode. key and simulate auto key input does not work   |
| 19  | Activate backlight          | The LCD backlight will illuminated when the input is active  |
| 20  | Activate internal buzzer    | Controller buzzer will peal when the input is active   |
| 21  | Override shutdown alarms    | All shutdown alarms are prohibited except emergence stop.(Means battle mode or override mode)  |
| 22  | Annunciator mode            | All outputs are prohibited in this mode  |
| 23  | Reset Maintenance 1         | Controller will set maintenance time and date 1 as default when input is active  |
| 24  | Reset Maintenance 2         | Controller will set maintenance time and date 2 as default when input is active  |
| 25  | Reset Maintenance 3         | Controller will set maintenance time and date 3 as default when input is active  |
| 26  | High temperature            | Connected sensor digital input   |
| 27  | Low oil pressure            | Connected sensor digital input   |
| 28  | Start request in AUTO       | In Auto mode, when input active, genset can be started automatically and take load after genset normal running; when input inactive, genset will stop automatically  |



| No. | Type                             | Description   |
|-----|----------------------------------|---|
| 29  | Start w/o load in AUTO           | In Auto mode, when input is active, genset can be started automatically and NOT take load after genset normal running; when input is inactive, genset will stop automatically |
| 30  | Start request in MANUAL          | In Manual mode, when input active, genset will start automatically; when input inactive, genset will stop automatically   |
| 31  | Remote Start request             | External request to start engine  |
| 32  | -                                | Reserved  |
| 33  | Remote STOP button               | An external button can be connected and pressed as simulate panel   |
| 34  | Remote MANUAL button             | An external button can be connected and pressed as simulate panel   |
| 35  | -                                | Reserved  |
| 36  | Remote AUTO button               | An external button can be connected and pressed as simulate panel   |
| 37  | Remote START button              | An external button can be connected and pressed as simulate panel   |
| 38  | Remote GCB open/close button     | This is simulate G-close key when easYgen controller is applied   |
| 39  | Remote MCB open/close button     | This is simulate M-open key when easYgen controller is applied  |
| 40  | Low coolant level                | Connect with water level sensor digital input port  |
| 41  | Detonation shutdown (Gas engine) | Connect with detection module warn input port   |
| 42  | Middle speed                     | J1939: special speed control signal   |
| 43  | Rated speed                      | J1939: special speed control signal   |
| 44  | First Priority                   | CAN bus communication of two controls in AUTO mode: Priority of this device   |
| 45  | Enforce mains ok                 | In Auto mode, mains are normal when input is active   |
| 46  | Enforce mains fail               | In Auto mode, mains are abnormal when input is active   |
| 47  | Switchable rating 1              | Alternative configuration is active when the input is active. Users can set different parameters to make it easy to select current configuration via input port.              |
| 48  | Switchable rating 2              |   |
| 49  | Switchable rating 3              |   |
| 50  | Gas leakage shutdown             | Connect with detection module warn input port   |
| 51  | Raise speed (ECU)                | Rising edge: Increase speed by one <i>"ECU Inc. / Dec. steps"</i>   |
| 52  | Lower speed (ECU)                | Rising edge: Decrease speed by one <i>"ECU Inc. / Dec. steps"</i>   |

### 4.3.3 Programmable Outputs

| No. | Type          | Description  |
|-----|---------------|--|
| 0   | Not Used      |  |
| 1   | Engine flag 1 | For details please read <a href="#">Chapter 4.2.4.1.2.3.1 "Engine Flags 1 to 6"</a> on page 44 below |
| 2   | Engine flag 2 |  |
| 3   | Engine flag 3 |  |
| 4   | Engine flag 4 |  |
| 5   | Engine flag 5 |  |
| 6   | Engine flag 6 |  |
| 7   | Logic flag 1  |  |
| 8   | Logic flag 2  |  |
| 9   | Logic flag 3  |  |

## Configuration

Selectable Inputs/Outputs/Se... > Programmable Outputs

| No. | Type                     | Description  |
|-----|--------------------------|--|
| 10  | Logic flag 4             |  |
| 11  | Logic flag 5             |  |
| 12  | Logic flag 6             |  |
| 13  | -                        | Reserved   |
| 14  | -                        | Reserved   |
| 15  | Gas choke on             | Action while cranking. Action time is as pre-set   |
| 16  | Gas ignition             | Action when genset starting, and disconnect when engine stopped  |
| 17  | Air flap                 | Action when over speed shutdown and emergence stop. It can close the air inflow to stop the engine as soon as possible                                       |
| 18  | Horn                     | Action when warning, shutdown, trips. Can be connected annunciator externally. When "alarm mute" configurable input port is active, it can remove the alarm. |
| 19  | Ventilation louver       | Action when genset is cranking and disconnect when genset stopped completely   |
| 20  | Fuel pump control        | It is controlled by fuel pump of level sensor's limited threshold  |
| 21  | Heater control           | It is controlled by heating of temperature sensor's limited threshold  |
| 22  | Cooler control           | It is controlled by cooler of temperature sensor's limited threshold   |
| 23  | Oil pre-supply           | Action from "crank on" to "safety on"  |
| 24  | Generator excitation     | Output in start period. If there is no generator frequency during normal running, it outputs for 2 seconds again.  |
| 25  | Pre-lubrication          | Actions in period of pre-heating to safety run   |
| 26  | Remote control bit       | This port is controlled by communication (PC)  |
| 27  | GSM power enable         | Power for GSM module (GSM module is reset when GSM communication failed)   |
| 28  | Open CB                  | Opening a breaker is requested   |
| 29  | Close GCB                | Control generator to take load   |
| 30  | Open GCB                 | Control generator to off load  |
| 31  | Close MCB                | Control mains to take load   |
| 32  | Open MCB                 | Control mains to off load  |
| 33  | Starter                  | Engine start request   |
| 34  | Fuel / Gas               | Action when genset is cranking and disconnect when stopped completely  |
| 35  | Idle control             | Used for engine which has idles. Close before starting and open in warming up delay; Close during stopping idle mode and open when stop is completed         |
| 36  | Raise speed              | Action in warming up delay   |
| 37  | Lower speed              | Action between the period from "stop idle" to "failed to stop"   |
| 38  | Stop solenoid            | Used for engines with ETS electromagnet. Close when stop idle is over and open when pre-set "Stop time of engine" is over.                                   |
| 39  | Pulse ECU to idle speed  | Active 0.1s when controller enters into stop idle, used for control part of ECU dropping to idle speed   |
| 40  | Stop ECU                 | Used for ECU engine and control its stop   |
| 41  | Activate ECU power       | Used for ECU engine and control its power  |
| 42  | Pulse ECU to rated speed | Active 0.1s when controller enters into warming up delay; used for control part of ECU raising to normal speed   |
| 43  | Generator started        | Close when detects a successful start signal   |

## Selectable Inputs/Outputs/Se...&gt; Programmable Outputs

| No.      | Type                            | Description   |
|----------|---------------------------------|---|
| 44       | Generator volt./freq. OK        | Action when generator is normal   |
| 45       | Generator running               | Action in period of generator is normal running to hi-speed cooling<br><b>Notes</b><br>This input was activated only when controller is in both "Normal Running" and "High Speed cooling" |
| 46       | Mains volt./freq. OK            | Action when mains is normal   |
| 47       | -                               | Reserved  |
| 48       | Centralized alarm               | Action when genset common warning, common shutdown, common trips alarm  |
| 49       | Centralized trip and stop alarm | Action when common trip and stop alarm  |
| 50       | Centralized shutdown alarm      | Action when common shutdown alarm   |
| 51       | Centralized trip alarm          | Action when common trips alarm  |
| 52       | Centralized warning alarm       | Action in common warning alarm  |
| 53       | -                               | Reserved  |
| 54       | Battery overvoltage             | Action when battery's over voltage warning alarm  |
| 55       | Battery undervoltage            | Action when battery's low voltage warning alarm   |
| 56       | Charge alternator failure       | Action when charge failure warning alarms   |
| 57       | -                               | Reserved  |
| 58       | -                               | Reserved  |
| 59       | -                               | Reserved  |
| 60       | ECU warning alarm               | Indicate ECU sends a warning signal   |
| 61       | ECU shutdown alarm              | Indicate ECU sends a shutdown signal  |
| 62       | ECU communication failure       | Indicate controller not communicates with ECU   |
| 63       | -                               | Reserved  |
| 64       | -                               | Reserved  |
| 65       | -                               | Reserved  |
| 66       | -                               | Reserved  |
| 67       | -                               | Reserved  |
| 68       | -                               | Reserved  |
| 69       | Discrete input 1 active         | Action when input port 1 is active  |
| 70       | Discrete input 2 active         | Action when input port 2 is active  |
| 71       | Discrete input 3 active         | Action when input port 3 is active  |
| 72       | Discrete input 4 active         | Action when input port 4 is active  |
| 73       | Discrete input 5 active         | Action when input port 5 is active  |
| 74       | Discrete input 6 active         | Action when input port 6 is active  |
| 75       | Discrete input 7 active         | Action when input port 7 is active  |
| 76       | Discrete input 8 active         | Action when input port 8 is active  |
| 77 to 80 | -                               | Reserved  |
| 81       | Ext. discrete input 1 active    | Action when extend digital input port 1 is active   |
| 82       | Ext. discrete input 2 active    | Action when extend digital input port 2 is active   |
| 83       | Ext. discrete input 3 active    | Action when extend digital input port 3 is active   |
| 84       | Ext. discrete input 4 active    | Action when extend digital input port 4 is active   |

## Configuration

Selectable Inputs/Outputs/Se... > Programmable Outputs

| No. | Type                          | Description   |
|-----|-------------------------------|---|
| 85  | Ext. discrete input 5 active  | Action when extend digital input port 5 is active           |
| 86  | Ext. discrete input 6 active  | Action when extend digital input port 6 is active           |
| 87  | Ext. discrete input 7 active  | Action when extend digital input port 7 is active           |
| 88  | Ext. discrete input 8 active  | Action when extend digital input port 8 is active           |
| 89  | Ext. discrete input 9 active  | Action when extend digital input port 9 is active           |
| 90  | Ext. discrete input 10 active | Action when extend digital input port 10 is active          |
| 91  | Ext. discrete input 11 active | Action when extend digital input port 11 is active          |
| 92  | Ext. discrete input 12 active | Action when extend digital input port 12 is active          |
| 93  | Ext. discrete input 13 active | Action when extend digital input port 13 is active          |
| 94  | Ext. discrete input 14 active | Action when extend digital input port 14 is active          |
| 95  | Ext. discrete input 15 active | Action when extend digital input port 15 is active          |
| 96  | Ext. discrete input 16 active | Action when extend digital input port 16 is active          |
| 97  | -                             | Reserved  |
| 98  | -                             | Reserved  |
| 99  | Emergency Stop                | Action when emergency stop alarm                            |
| 100 | Start fail                    | Action when failed start alarm                              |
| 101 | Engine stop malfunction       | Action when failed stop alarm                               |
| 102 | Underspeed warning            | Action when under speed alarm                               |
| 103 | Underspeed shutdown           | Action when under speed shuts down                          |
| 104 | Overspeed warning             | Action when over speed warns                                |
| 105 | Overspeed shutdown            | Action when over speed shutdown alarm                       |
| 106 | -                             | Reserved  |
| 107 | -                             | Reserved  |
| 108 | -                             | Reserved  |
| 109 | Gen. overfrequency warning    | Action when generator over frequency warns                  |
| 110 | Gen. overfrequency shutdown   | Action when generator over frequency shutdown alarm         |
| 111 | Gen. overvoltage warning      | Action when generator over voltage warns                    |
| 112 | Gen. overvoltage shutdown     | Action when generator over voltage shutdown                 |
| 113 | Gen. underfrequency warning   | Action when generator low frequency warns                   |
| 114 | Gen. underfrequency shutdown  | Action when generator low frequency shutdown                |
| 115 | Gen. undervoltage warning     | Action when generator low voltage warns                     |
| 116 | Gen. undervoltage shutdown    | Action when generator low voltage shutdown                  |
| 117 | Gen. voltage asymmetry        | Action when generator loss phase                            |
| 118 | Gen. phase rotation mismatch  | Action when generator reverse phase                         |
| 119 | -                             | Reserved  |
| 120 | Overload                      | Action when controller detects generator have over power    |
| 121 | -                             | Reserved  |
| 122 | Reverse power                 | Action when controller detects generator have reverse power |
| 123 | Overcurrent                   | Action when over current                                    |
| 124 | -                             | Reserved  |
| 125 | Mains failure                 | Status message  |
| 126 | Mains overfrequency           | Status message  |

| No.        | Type                               | Description                                     |
|------------|------------------------------------|---|
| 127        | Mains overvoltage                  | Status message                                  |
| 128        | Mains underfrequency               | Status message                                  |
| 129        | Mains undervoltage                 | Status message                                  |
| 130        | Mains Phase rotation mismatch      | Status message                                  |
| 131        | Mains voltage asymmetry            | Status message                                  |
| 132 to 138 | -                                  | Reserved  |
| 139        | High temperature warning           | Action when hi-temperature warns                |
| 140        | Low temperature warning            | Action when low temperature warns               |
| 141        | High temperature shutdown          | Action when hi-temperature shutdown alarm       |
| 142        | -                                  | Reserved  |
| 143        | Low oil pressure warning           | Action when low oil pressure warns              |
| 144        | Low oil pressure shutdown          | Action when low oil pressure shutdown           |
| 145        | Oil pressure sensor wire break     | Action when oil pressure sensor is open circuit |
| 146        | -                                  | Reserved  |
| 147        | Fuel level low warning             | Action when controller has low oil level alarm  |
| 148        | -                                  | Reserved  |
| 149        | -                                  | Reserved  |
| 150        | Analog input 4 High limit warning  | Status message                                  |
| 151        | Analog input 4 Low limit warning   | Status message                                  |
| 152        | Analog input 4 High limit shutdown | Status message                                  |
| 153        | Analog input 4 Low limit shutdown  | Status message                                  |
| 154        | Analog input 5 High limit warning  | Status message                                  |
| 155        | Analog input 5 Low limit warning   | Status message                                  |
| 156        | Analog input 5 High limit shutdown | Status message                                  |
| 157        | Analog input 5 Low limit shutdown  | Status message                                  |
| 158 to 229 | -                                  | Reserved  |
| 230        | Operation mode STOP                | Action in STOP mode                             |
| 231        | Operation mode MAN                 | Action in MANUAL mode                           |
| 232        | -                                  | Reserved  |
| 233        | Operation mode AUTO                | Action in AUTO mode                             |
| 234        | GCB closed                         | Status message                                  |
| 235        | MCB closed                         | Status message                                  |
| 236 to 299 | -                                  | Reserved  |

## 4.4 Status Menu

### General notes

Both HMI and ToolKit-SC offer status information.

## Configuration

Status Menu > ToolKit-SC Status Screens

### 4.4.1 HMI Status Screens

HMI comes with status screens:

- Status
- Engine
- Gen(erator)
- Load
- Mains
- Alarm
- Log
- Others
- About
- ... and the home screen  
in a loop

### 4.4.2 ToolKit-SC Status Screens

#### General notes

ToolKit-SC enables dedicated access to status information summarized into the following screens:





Fig. 24: easYgen-x800 status screens

#### Generator Status

*"PARAMETER → STATUS MENU → Generator status"*

| Items              | Parameters   | Description                            |
|--------------------|--|--|
| Engine/Sensor info | Engine speed, Engine temp, Oil pressure, Fuel level, Battery volt, Charger volt  |  |
| More info          | Fuel temp, Inlet temp, Exhaust temp, Coolant pressure, Fuel pressure, Turbo pressure, Total fuel consume, Coolant level, Oil temp                            | Selection of ECU data via J1939.       |
| Status and delay   | Gen status, Breaker status, Remote start, Mains status   |  |
| Alarms             |  | Display of current alarms and warnings |
| Digital inputs     | 1 start request in AUTO, 2 High temperature, 3 Low oil pressure, 4 User defined, 5 User-defined, 6 User-defined, 7 Lamp test, 8 User defined, Emergency stop |  |
| Accumulation       | Active power (kW), Reactive power (kvar), Apparent power (kVA)   |  |
| Digital output     | 1 Engine flag 1, 2 Idle control, 3 Close GCB, 4 Close MCB, 5 Stop solenoid, 6 Centralized alarm<br>Fuel relay, Start relay                                   |  |

| Items                 | Parameters   | Description |
|-----------------------|--|-------------|
| Status                | Stop mode, Manual mode, Test mode, Auto mode, Mains available, Mains Closed, Gen available, Gen closed, Alarm indicator, Running indicator |             |
| Current date and time | Date (yyyy-mm-dd), Time (hh:mm:ss)   |             |

**Measured Values***"PARAMETER → STATUS MENU → Measured values"*

| Items                       | Parameters   | Description |
|-----------------------------|--|-------------|
| <b>Electricity quantity</b> |  |             |
| Mains                       | L1, L2, L3, L1-2, L2-3, L3-1, L1Phase, L2Phase, L3Phase, Frequency |             |
| Generator                   | L1, L2, L3, L1-2, L2-3, L3-1, L1Phase, L2Phase, L3Phase, Frequency |             |
| Current (A)                 | L1, L2, L3   |             |
| Active power (kW)           | L1, L2, L3, Total  |             |
| Reactive power (kvar)       | L1, L2, L3, Total  |             |
| Apparent power (kVA)        | L1, L2, L3, Total  |             |
| Power factor                | L1, L2, L3, Avg  |             |

**Ext. Discrete Inputs/Outputs***"PARAMETER → STATUS MENU → Ext. discrete inputs/outputs"*

| Items                             | Parameters            | Description  |
|-----------------------------------|-----------------------|--------------|
| <b>Ext. discrete inputs 1-16</b>  |                       |              |
| Input {X}                         | (contact open/closed) | {X}: 1 or 16 |
| <b>Ext. discrete outputs 1-16</b> |                       |              |
| Output {Y}                        | (Hi/Low)              | {Y}: 1 or 16 |

**Miscellaneous***"PARAMETER → STATUS MENU → Miscellaneous"*

| Items                 | Parameters                              | Description |
|-----------------------|---|-------------|
| Total A               | Run time, Starts, Total energy          |             |
| Total B               | Run time, Starts, Total energy          |             |
| SD card               | Status, Total capacity, Remain capacity |             |
| Earth fault current   | Percent                                 |             |
| Next maintenance time | Maintenance 1 to 3                      |             |

## Configuration

Status Menu > Configure For Using Access...

### Event Log and Version

*"PARAMETER → STATUS MENU → Event log and version"*

| Items       | Parameters   | Description  |
|-------------|--|--|
| Module Info | Model, Hardware Version, Software Version, Issue Date  |  |
| Event log   | <b>Fixed view of:</b><br>No., Event type<br><b>Columns "move behind" visible part of the screen:</b><br>Event Item, Date, Time,<br>Mains Uab (V) / Ubc (V) / Uca (V), Mains Ua (V), Mains Ub (V), Mains Uc (V), Mains f (Hz),<br>Gens Uab (V) ..., Gens Ua (V) ..., Gens f(Hz),<br>Current Ia (A) ...,<br>Power (kW),<br>Speed (r/min),<br>Temp. (°C),<br>Press. (kPa),<br>Volt. (V) | Event log report table. Showing the 99 latest events or - with SD card - the content of the .DAT file(s) |
|             | Read log<br>Clear<br>Export to Txt   | Push buttons to manage logged data (internal or SD card)   |

### SD-Card

*"PARAMETER → STATUS MENU → SD-Card"*



*The SD-Card stores the same information as "Event log and version" but on the inserted SD card in a .DAT file format.*

| Items                                  | Description  |
|--|--|
| Read all log                           | Event table is filled with all stored data   |
| ((number selection boxes))<br>Read log | Read and displayed events can be pre-selected by min and max number e.g. for better overview |
| Export to Txt                          | List of current (selected) events can be saved as .TXT file                                  |

### 4.4.3 Configure For Using Accessories



*For configuration see [Chapter 4.2 "Parameters"](#) on page 37.*



### 4.4.3.1 Digital Input Module WWDIN16

#### General notes




Fig. 25: WWDIN16

Woodward Digital Input Module (WWDIN16) is an expansion module which has 16 auxiliary digital input channels. WWDIN16 data is transmitted to the easYgen via CANBUS.

#### 4.4.3.1.1 Technical Data

| Parameter                      | Contents   |
|--------------------------------|--|
| Working Voltage                | 8.0 to 35.0 V <sub>DC</sub> , continuous power supply  |
| Power Consumption              | <2 W   |
| Programmable relay output 1-16 | 7 A<br>Connected to common output port                 |
| Dimensions                     | 107.6 mm x 89.7 mm x 60.7 mm                           |
| Working conditions             | Temperature : -25 to +70 °C<br>Humidity : 20 to 93 %RH |
| Storage conditions             | Temperature : -25 to 70 °C                             |
| Weight                         | 0.60 kg  |

Table 1: Technical Data

## Configuration

Status Menu > Configure For Using Access... > Digital Input Module WWDIN...

### 4.4.3.1.2 Warnings

#### General notes

Warnings are not shutdown alarms and do not affect the operation of the genset. When WWDIN16 module is enabled and detects the warning signal, the controller will initiate a warning alarm and the corresponding alarm information will be displayed on LCD.

Warning types are as follows

| No. | Items                           | DET Range     | Description  |
|-----|---------------------------------|---------------|--|
| 1   | WWDIN16 Auxiliary Input 1 to 16 | User-defined. | <p>When the controller detects that the WWDIN16 auxiliary input 1 to 16 alarm signal and the action set as "Warning", it will initiate a warning alarm and the corresponding alarm information will be displayed on LCD.</p> <p>Each string of WWDIN16 input can be defined by users, such as input port 1 defined as "High Temp Warning", when it is active, corresponding alarm information will displayed on LCD.</p> |

### 4.4.3.1.3 Shutdown Alarm

#### General notes

When WWDIN16 module is enabled and detects the shutdown signal, the easYgen controller will initiate a shutdown alarm and the corresponding alarm information will be displayed on LCD.

Shutdown alarms are as follows:

| No. | Items                           | DET Range     | Description   |
|-----|---------------------------------|---------------|---|
| 1   | WWDIN16 Auxiliary Input 1 to 16 | User-defined. | <p>When the controller detects that the WWDIN16 auxiliary input 1 to 16 alarm signal and the action set as "Shutdown", it will initiate a shutdown alarm and the corresponding alarm information will be displayed on LCD.</p> <p>Each string of WWDIN16 input can be defined by users, such as input port 1 defined as "High Temp Shutdown", when it is active, corresponding alarm information will displayed on LCD.</p> |




*The types of shutdown alarm of auxiliary input port are effective only when users configure them. Only emergency shutdown and overspeed shutdown work when the controller is in override mode.*

### 4.4.3.1.4 Configuration

#### General notes

Users can set the parameters of WWDIN16 module via easYgen.

Pressing and holding ENTER button  for more than 3 seconds will enter the configuration menu, which allows users to set all WWDIN16 parameters, as follows:



Pressing  can exit setting directly during setting.

| Items             | Range   | Default Values        | Remarks         |
|-------------------|---------|-----------------------|-----------------|
| 1. Input 1 Set    | 0 to 50 | 0 : Not used          | WWDIN16 setting |
| 2. Input 1 Type   | 0 to 1  | 0 : Close to activate | WWDIN16 setting |
| 3. Input 2 Set    | 0 to 50 | 0 : Not used          | WWDIN16 setting |
| 4. Input 2 Type   | 0 to 1  | 0 : Close to activate | WWDIN16 setting |
| 5. Input 3 Set    | 0 to 50 | 0 : Not used          | WWDIN16 setting |
| 6. Input 3 Type   | 0 to 1  | 0 : Close to activate | WWDIN16 setting |
| 7. Input 4 Set    | 0 to 50 | 0 : Not used          | WWDIN16 setting |
| 8. Input 4 Type   | 0 to 1  | 0 : Close to activate | WWDIN16 setting |
| 9. Input 5 Set    | 0 to 50 | 0 : Not used          | WWDIN16 setting |
| 10. Input 5 Type  | 0 to 1  | 0 : Close to activate | WWDIN16 setting |
| 11. Input 6 Set   | 0 to 50 | 0 : Not used          | WWDIN16 setting |
| 12. Input 6 Type  | 0 to 1  | 0 : Close to activate | WWDIN16 setting |
| 13. Input 7 Set   | 0 to 50 | 0 : Not used          | WWDIN16 setting |
| 14. Input 7 Type  | 0 to 1  | 0 : Close to activate | WWDIN16 setting |
| 15. Input 8 Set   | 0 to 50 | 0 : Not used          | WWDIN16 setting |
| 16. Input 8 Type  | 0 to 1  | 0 : Close to activate | WWDIN16 setting |
| 17. Input 9 Set   | 0 to 50 | 0 : Not used          | WWDIN16 setting |
| 18. Input 9 Type  | 0 to 1  | 0 : Close to activate | WWDIN16 setting |
| 19. Input 10 Set  | 0 to 50 | 0 : Not used          | WWDIN16 setting |
| 20. Input 10 Type | 0 to 1  | 0 : Close to activate | WWDIN16 setting |
| 21. Input 11 Set  | 0 to 50 | 0 : Not used          | WWDIN16 setting |
| 22. Input 11 Type | 0 to 1  | 0 : Close to activate | WWDIN16 setting |
| 23. Input 12 Set  | 0 to 50 | 0 : Not used          | WWDIN16 setting |
| 24. Input 12 Type | 0 to 1  | 0 : Close to activate | WWDIN16 setting |
| 25. Input 13 Set  | 0 to 50 | 0 : Not used          | WWDIN16 setting |
| 26. Input 13 Type | 0 to 1  | 0 : Close to activate | WWDIN16 setting |
| 27. Input 14 Set  | 0 to 50 | 0 : Not used          | WWDIN16 setting |
| 28. Input 14 Type | 0 to 1  | 0 : Close to activate | WWDIN16 setting |
| 29. Input 15 Set  | 0 to 50 | 0 : Not used          | WWDIN16 setting |
| 30. Input 15 Type | 0 to 1  | 0 : Close to activate | WWDIN16 setting |
| 31. Input 16 Set  | 0 to 50 | 0 : Not used          | WWDIN16 setting |
| 32. Input 16 Type | 0 to 1  | 0 : Close to activate | WWDIN16 setting |

Table 2: Input Settings (easYgen)

## Configuration

Status Menu > Configure For Using Access... > Digital Input Module WWDIN...

### 4.4.3.1.5 Input Port Configuration

#### Digital Inputs

| No. | Items            | Contents                         | Description   |
|-----|------------------|----------------------------------|---|
| 1   | Function set     | 0 to 50                          | More details please refer to Function Setting                   |
| 2   | Active Type      | 0 to 1                           | 0 : Close to activate<br>1 : Open to activate                   |
| 3   | Effective Range  | 0 to 3                           | 0 : From Safety on<br>1 : From Crank<br>2 : Always<br>3 : Never |
| 4   | Effective Action | 0 to 2                           | 0 : Warn<br>1 : Shutdown<br>2 : Indication                      |
| 5   | Input Delay      | 0.0 to 20.0 s                    |   |
| 6   | Display string   | User-defined names of input port | Input port names can be edited via PC software only.            |

Table 3: Digital Inputs

#### Function Setting

| No. | Contents          | Description   |
|-----|-------------------|---|
| 0   | Not used          |   |
| 1   | User-defined      | Users configured input port settings  |
| 2   | Alarm Mute        | Can prohibit "Horn" output when input is active   |
| 3   | Reset alarm       | Can reset all alarms when input is active   |
| 4   | Raise Speed       | The generator will increase speed by GOV when the input is active   |
| 5   | Drop Speed        | The generator will decrease speed by GOV when the input is active   |
| 6   | Reserved          |   |
| 7   | Reserved          |   |
| 8   | Lamp test         | All LED indicators are illuminating when input is active  |
| 9   | Local mode        | Places generator into its local mode  |
| 10  | Remote mode       | Places generator into its remote mode   |
| 11  | Remote start      | Automatically starts the generator in remote mode when the input is active. Only the active shutdown input will be able to stop the generator. (Inch or hold the button for more than 1s) |
| 12  | Remote stop       | Stops the running generator in remote mode when the input is active   |
| 13  | Remote start/stop | Automatically starts the generator in remote mode; the generator will shut down when this input is deactivated  |
| 14  | Pre-lubricate     | If output is set as pre-lubrication output, the relay disconnects after the set pre-lubrication delay   |
| 15  | Override mode     | Places the generator into its override mode; in override mode only over-speed shutdown and emergency shutdown will stop the engine  |
| 16  | Emergency stop    | The controller shuts down the engine immediately and records occurrence time  |

| No.      | Contents               | Description  |
|----------|------------------------|--|
| 17       | Panel lock             | All buttons in panel is inactive except for and is shown on the right of the first line in LCD status page       |
| 18       | Reserved               |  |
| 19       | Power Change           | Transfers from main battery to standby battery   |
| 20       | Raise Speed Aux. input | Raise speed relay will disconnect when the input is active   |
| 21       | Reserved               |  |
| 22       | Drop Speed Aux. input  | Drop speed relay will disconnect when the input is active  |
| 23       | Water Heating feedback | The feedback signal of water heating output; the screen displays Water Heating feedback when the input is active |
| 24       | Pre-lube feedback      | The feedback signal of Pre-lube output; the screen displays Pre-lube feedback when the input is active           |
| 25       | Charging feedback      | The feedback signal of Charging output; the screen displays Charging feedback when the input is active           |
| 26       | Reserved               |  |
| 27       | Reserved               |  |
| 28       | Quick start            | Cranking will start directly (without preheating) when the input is active                                       |
| 29       | Reserved               |  |
| 30       | 60Hz Select            | Frequency selection of ECU engine  |
| 31       | Turning Chain          | Start inhibition when the input is active  |
| 32       | Cylinder Scavenging    | Starter relay outputs when the input is active   |
| 33       | Reserved               |  |
| 34       | Self-inspection        | Inspect each warning point without crank genset when the input is active   |
| 35 to 50 | Reserved               |  |

Table 4: Function Settings

#### 4.4.3.1.6 Installation

##### General notes




Fig. 26: WWDIN16 terminals

| No. | Function        | Cable Size          | Description   |
|-----|-----------------|---------------------|---|
| 1   | DC input B-     | 2.5 mm <sup>2</sup> | DC power supply negative input.   |
| 2   | DC input B+     | 2.5 mm <sup>2</sup> | DC power supply positive input.   |
| 3   | SCR (CANBUS)    | 0.5 mm <sup>2</sup> | Connect CANbus communication port to expansion CAN port of the easYgen. |
| 4   | CAN(H) (CANBUS) | 0.5 mm <sup>2</sup> |   |

## Configuration

Status Menu > Configure For Using Access... > Digital Input Module WWDIN...

| No.           | Function        | Cable Size          | Description   |
|---------------|-----------------|---------------------|---|
| 5             | CAN(L) (CANBUS) | 0.5 mm <sup>2</sup> | 120-Ω-shielding is implemented (one wire end grounded). If needed, make terminal 5, 6 short circuits. |
| 6             | 120Ω            | 0.5 mm <sup>2</sup> |   |
| 7             | DIN1            | 1.0 mm <sup>2</sup> | Digital input   |
| 8             | DIN2            | 1.0 mm <sup>2</sup> | Digital input   |
| 9             | DIN3            | 1.0 mm <sup>2</sup> | Digital input   |
| 10            | DIN4            | 1.0 mm <sup>2</sup> | Digital input   |
| 11            | DIN5            | 1.0 mm <sup>2</sup> | Digital input   |
| 12            | DIN6            | 1.0 mm <sup>2</sup> | Digital input   |
| 13            | DIN7            | 1.0 mm <sup>2</sup> | Digital input   |
| 14            | DIN8            | 1.0 mm <sup>2</sup> | Digital input   |
| 15            | COM(B-)         | 1.0 mm <sup>2</sup> | Connect to B- is allowed.   |
| 16            | DIN9            | 1.0 mm <sup>2</sup> | Digital input   |
| 17            | DIN10           | 1.0 mm <sup>2</sup> | Digital input   |
| 18            | DIN 11          | 1.0 mm <sup>2</sup> | Digital input   |
| 19            | DIN 12          | 1.0 mm <sup>2</sup> | Digital input   |
| 20            | DIN 13          | 1.0 mm <sup>2</sup> | Digital input   |
| 21            | DIN 14          | 1.0 mm <sup>2</sup> | Digital input   |
| 22            | DIN 15          | 1.0 mm <sup>2</sup> | Digital input   |
| 23            | DIN 16          | 1.0 mm <sup>2</sup> | Digital input   |
| 24            | COM(B-)         | 1.0 mm <sup>2</sup> | Connect to B- is allowed.   |
| LED Indicator | INPUT STATUS    |                     | Active input(s): corresponding LED(s) illuminated   |

Table 5: Terminals

#### 4.4.3.1.7 Typical Application




Fig. 27: Typical application

#### 4.4.3.1.8 DIN Rail Mounting Dimensions




Fig. 28: WWDIN16A dimensions

## Configuration

Status Menu > Configure For Using Access... > Digital Output Module WWDO...

### 4.4.3.1.9 Troubleshooting

| Problem                      | Possible Solution  |
|------------------------------|--|
| No power indication          | Check starting batteries<br>Check controller connection wiring     |
| CANbus communication failure | Check wiring   |
| Auxiliary input alarm        | Check wiring<br>Check if input polarities configuration is correct |

Table 6: Troubleshooting

### 4.4.3.2 Digital Output Module WWDOOUT16

#### General notes




Fig. 29: WWDOOUT16B

Woodward Digital Output Module (WWDOOUT16) is an expansion module which has 16 auxiliary digital output channels. WWDOOUT16 data is transmitted via CANBUS from easYgen to WWDOOUT16 output module.

#### 4.4.3.2.1 Technical Data

| Parameter                      | Contents  |
|--------------------------------|---|
| Working Voltage                | 8.0 to 35.0 V <sub>DC</sub> , continuous power supply |
| Power Consumption              | <5 W  |
| Programmable relay output 1-16 | 7 A<br>Connected to common output port                |
| Dimensions                     | 161.6 mm x 89.7 mm x 60.7 mm                          |
| Working conditions             | Temperature : -25 to +70 °C<br>Humidity : 20 to 93%RH |
| Storage conditions             | Temperature : -25 to 70 °C                            |
| Weight                         | 0.60 kg   |

Table 7: Technical Data



#### 4.4.3.2.2 Configuration

##### General notes

The parameters of WWDOOUT16 module can be set via easYgen. Configuration is stored in the internal storage of the easYgen.

| Parameter          | Range   | default value    | Remarks                           |
|--------------------|---|------------------|-----------------------------------|
| 1. Output 1 Set    | All settings come from the easYgen connected with WWDOOUT16.<br><br>Changing the WWDOOUT16 hardware has no influence to parameter settings. | 0: Not used      | Configurable output port Function |
| 2. Output 1 Type   |   | 0: Normally open | Configurable output type.         |
| 3. Output 2 Set    |   | 0: Not used      | Configurable output port Function |
| 4. Output 2 Type   |   | 0: Normally open | Configurable output type.         |
| 5. Output 3 Set    |   | 0: Not used      | Configurable output port Function |
| 6. Output 3 Type   |   | 0: Normally open | Configurable output type.         |
| 7. Output 4 Set    |   | 0: Not used      | Configurable output port Function |
| 8. Output 4 Type   |   | 0: Normally open | Configurable output type.         |
| 9. Output 5 Set    |   | 0: Not used      | Configurable output port Function |
| 10. Output 5 Type  |   | 0: Normally open | Configurable output type.         |
| 11. Output 6 Set   |   | 0: Not used      | Configurable output port Function |
| 12. Output 6 Type  |   | 0: Normally open | Configurable output type.         |
| 13. Output 7 Set   |   | 0: Not used      | Configurable output port Function |
| 14. Output 7 Type  |   | 0: Normally open | Configurable output type.         |
| 15. Output 8 Set   |   | 0: Not used      | Configurable output port Function |
| 16. Output 8 Type  |   | 0: Normally open | Configurable output type.         |
| 17. Output 9 Set   |   | 0: Not used      | Configurable output port Function |
| 18. Output 9 Type  |   | 0: Normally open | Configurable output type.         |
| 19. Output 10 Set  |   | 0: Not used      | Configurable output port Function |
| 20. Output 10 Type |   | 0: Normally open | Configurable output type.         |
| 21. Output 11 Set  |   | 0: Not used      | Configurable output port Function |
| 22. Output 11 Type |   | 0: Normally open | Configurable output type.         |
| 23. Output 12 Set  |   | 0: Not used      | Configurable output port Function |
| 24. Output 12 Type |   | 0: Normally open | Configurable output type.         |
| 25. Output 13 Set  |   | 0: Not used      | Configurable output port Function |
| 26. Output 13 Type |   | 0: Normally open | Configurable output type.         |
| 27. Output 14 Set  |   | 0: Not used      | Configurable output port Function |
| 28. Output 14 Type |   | 0: Normally open | Configurable output type.         |
| 29. Output 15 Set  |   | 0: Not used      | Configurable output port Function |
| 30. Output 15 Type |   | 0: Normally open | Configurable output type.         |
| 31. Output 16 Set  |   | 0: Not used      | Configurable output port Function |
| 32. Output 16 Type |   | 0: Normally open | Configurable output type.         |

Table 8: Output Settings (easYgen)

## Configuration

Status Menu > Configure For Using Access... > Digital Output Module WWDO...

### 4.4.3.2.3 Installation

#### General notes




Fig. 30: WWDOOUT16 terminals

| No. | Function            | Cable Size          | Description   |
|-----|---------------------|---------------------|---|
| 1.  | DC input B-         | 2.5 mm <sup>2</sup> | DC power supply negative input.   |
| 2.  | DC input B+         | 2.5 mm <sup>2</sup> | DC power supply positive input.   |
| 3.  | CAN(H) (CANBUS)     | 0.5 mm <sup>2</sup> | Connect CANbus communication port to expansion CAN port of the easYgen.<br>120-Ω-shielding is recommended (one wire end grounded) . |
| 4.  | CAN(L) (CANBUS)     |                     |   |
| 5.  | Aux. output port 1  | 1.0 mm <sup>2</sup> | Voltage free output; rated current is 7 A.  |
| 6.  |                     |                     |   |
| 7.  |                     |                     |   |
| 8.  | Aux. output port 2  | 1.0 mm <sup>2</sup> | Voltage free output; rated current is 7 A.  |
| 9.  |                     |                     |   |
| 10. |                     |                     |   |
| 11. | Aux. output port 3  | 1.0 mm <sup>2</sup> | Voltage free output; rated current is 7 A.  |
| 12. |                     |                     |   |
| 13. |                     |                     |   |
| 14. | Aux. output port 4  | 1.0 mm <sup>2</sup> | Voltage free output; rated current is 7 A.  |
| 15. |                     |                     |   |
| 16. |                     |                     |   |
| 17. | Aux. output port 5  | 1.0 mm <sup>2</sup> | Voltage free output; rated current is 7 A.  |
| 18. |                     |                     |   |
| 19. |                     |                     |   |
| 20. | Aux. output port 6  | 1.0 mm <sup>2</sup> | Voltage free output; rated current is 7 A.  |
| 21. |                     |                     |   |
| 22. |                     |                     |   |
| 23. | Aux. output port 7  | 1.0 mm <sup>2</sup> | Voltage free output; rated current is 7 A.  |
| 24. |                     |                     |   |
| 25. |                     |                     |   |
| 26. | Aux. output port 8  | 1.0 mm <sup>2</sup> | Voltage free output; rated current is 7 A.  |
| 27. |                     |                     |   |
| 28. |                     |                     |   |
| 29. | Aux. output port 9  | 1.0 mm <sup>2</sup> | Voltage free output; rated current is 7 A.  |
| 30. |                     |                     |   |
| 31. |                     |                     |   |
| 32. | Aux. output port 10 | 1.0 mm <sup>2</sup> | Voltage free output; rated current is 7 A.  |

| No.   | Function            | Cable Size          | Description                                |
|-------|---------------------|---------------------|--|
| 33.   |                     |                     |  |
| 34.   |                     |                     |  |
| 35.   | Aux. output port 11 | 1.0 mm <sup>2</sup> | Voltage free output; rated current is 7 A. |
| 36.   |                     |                     |  |
| 37.   |                     |                     |  |
| 38.   | Aux. output port 12 | 1.0mm <sup>2</sup>  | Voltage free output; rated current is 7 A. |
| 39.   |                     |                     |  |
| 40.   |                     |                     |  |
| 41.   | Aux. output port 13 | 1.0 mm <sup>2</sup> | Voltage free output; rated current is 7 A. |
| 42.   |                     |                     |  |
| 43.   |                     |                     |  |
| 44.   | Aux. output port 14 | 1.0 mm <sup>2</sup> | Voltage free output; rated current is 7 A. |
| 45.   |                     |                     |  |
| 46.   |                     |                     |  |
| 47.   | Aux. output port 15 | 1.0 mm <sup>2</sup> | Voltage free output; rated current is 7 A. |
| 48.   |                     |                     |  |
| 49.   |                     |                     |  |
| 50.   | Aux. output port 16 | 1.0 mm <sup>2</sup> | Voltage free output; rated current is 7 A. |
| 51.   |                     |                     |  |
| 52.   |                     |                     |  |
| POWER | Power indicator     |                     | Illuminating: power supply is OK           |
| LINK  | Upgrade port        |                     | Software upgrades connection port          |

Table 9: Terminals

#### 4.4.3.2.4 DIN Rail Mounting

##### Dimensions




Fig. 31: WWDOOUT16 dimensions

#### 4.4.3.2.5 Troubleshooting

| Problem                      | Possible Solution                        |
|------------------------------|--|
| No power indication          | Check controller connection wiring       |
| CANbus communication failure | Check wiring                             |
| No output from output port   | Check if output port settings are active |

Table 10: Troubleshooting

## Configuration

---






Status Menu > Configure For Using Access... > Digital Output Module WWDO...

## 5 Operation

### 5.1 Front Panel: Operating and Display Elements



Fig. 32: HMI (front panel) easYgen-1800

| Icons   | Keys                                   | Description  |
|---|--|--|
|  | STOP                                   | Auto/Manual mode: Stop running generator<br>Stop mode: Reset alarm<br>Lamp test (press at least 3 seconds)<br><b>Notes</b><br>During stopping process, press this button again to stop generator immediately.          |
|  | I (START)                              | MANual mode: Start genset  |
|  | MAN (Manual Mode)                      | Press this key and controller enters into MANual mode  |
|  | AUTO (Automatic Mode)                  | Press this key and controller enters into AUTO mode  |
|  | Mute "Horn"/<br>Alarm acknowl-<br>edge | Press once: Alarming sound OFF<br>Second time pressing the button:<br><ul style="list-style-type: none"> <li>■ Alarm is acknowledged</li> <li>■ Alarm LED changes from twinkling to permanently illuminated</li> </ul> |

## Operation

### Front Panel: Operating and D...

| Icons   | Keys             | Description   |
|---|------------------|---|
|    | Gen Open/Close   | MANual mode: Switch Generator breaker ON or OFF                                 |
|   | Mains Open/Close | MANual mode: Switch Mains breaker ON or OFF                                     |
|    | Up/Increase      | 1) Screen scroll<br>2) Setting menu: Up cursor and increase value in            |
|    | Down/Decrease    | 1) Screen scroll<br>2) Setting menu: Down cursor and decrease value             |
|    | Left             | 1) Screen scroll<br>2) Setting menu: Left move cursor                           |
|    | Right            | 1) Screen scroll<br>2) Setting menu: Right move cursor                          |
|    | Set/Confirm      | Select viewing area   |
|    | Exit             | 1) Returns to the main menu<br>2) In settings menu returns to the previous menu |
|  | Warning          |   |
|  | Alarm            |   |
|  | Running          |   |
|  | Genset           |   |
|  | Busbar           |   |
|  | Mains            |   |



#### *In MANual mode:*

*Pressing **MAN** and **I** (START) simultaneously will force generator to crank. Successful start will not be judged according to crank disconnect conditions, operator will have to crank the starter motor manually; when operator decides that the engine has fired, he/she should release the button and start output will be deactivated, safety on delay will start.*

**WARNING!**

Passwords can be changed by user. Please clearly remember the password after changing. If you forget it, please contact Woodward services and send all device information of the controller page "ABOUT" for legitimation.

## 5.2 Warning/Alarm Signaling

The Alarm type and Warning are visualized with - combinations of - both LEDs "Alarm" and "Warning" located beside the display.

| Alarm Indicator LED          | Warning Indicator LED        | Alarm Type                                   |
|------------------------------|------------------------------|--|
| Slow flashing                | Slow flashing                | Warning                                      |
| Fast flashing                | Off                          | Shutdown or Trip Alarm                       |
| Fast flashing                | Slow flashing                | Shutdown or Trip Alarm with Warning          |
| ON (permanently illuminated) | Off                          | Common Alarm, acknowledged                   |
| ON (permanently illuminated) | ON (permanently illuminated) | Shutdown or Trip Warning, Alarm acknowledged |

### 5.2.1 Alarm Acknowledgment

#### General notes

The alarm acknowledge handling is valid for following alarm classes

- Warning
- Shutdown
- Trip/Stop
- Trip

#### Mute Horn

Any new active alarm activates the horn and is visible with the flashing "Alarm" LED.

After pressing the mute/acknowledge button the "horn" is deactivated and the "Alarm" LED changes from flashing to constant active and stays active as long as any alarm is present. An additional active alarm reactivates the horn and the "Alarm LED" starts flashing again.

#### Stop by alarm

The operation mode automatically changes to STOP if a stopping alarm is active ( "Shutdown" or "Trip/Stop").

#### Acknowledge alarm

The alarm reset is done with additional (2<sup>nd</sup> time) pressing the mute/acknowledge button (Alarm LED is no longer flashing).

## 5.3 Operation Modes

### General notes

The easYgen offers three operation modes:

- AUTO
- MANUAL (MAN)
- STOP
- ... and an internal (non) operating phase during starting the device itself

The operation mode can be initiated - if current settings allow this function:

- directly by pressing the according button at the front panel
- directly by click on the according button at the ToolKit-SC remote screen
- via discrete inputs
- via interface

### 5.3.1 Operation Mode AUTO

#### General notes

In operation mode AUTO breakers and genset are under easYgen control. Start and stop of the engine is managed automatically together with open, close, and breaker transition.

Depending on settings and application status, AUTO control can:

- supply load by mains
- supply load by generator
- transition load supply from mains to generator or from generator to mains
- start the engine
- stop the engine

#### Load supply transition from mains to genset

##### Situation

- Mains becomes abnormal because one or more of the parameters below misses its well defined working range:
  - “Overvoltage”
  - “Undervoltage”
  - “Overfrequency”
  - “Underfrequency”
  - “Mains voltage asymmetry”
  - “Mains phase rotation fail”

Start procedure will include breaker handling, engine start, and signaling/warning.

#### Load supply transition from genset (back) to mains

All of the above listed parameters are (back) in normal range.

Stop procedure will include breaker handling, engine stand-by, and signaling/warning.

### 5.3.2 Operation Mode MANual

#### General notes

In operation mode MANual both breakers and genset are independently from each other under easYgen control.



Start and stop of the engine is managed with the same procedure as in AUTO mode but without breaker control. Breakers can be opened and closed without taking care of load, genset, or mains state!

### 5.3.3 Operation Mode STOP

#### General notes

In operation mode STOP breakers are open and engine is not running.



*This is a configurable operation mode, only. This is NO emergency STOP!*

## 5.4 START/STOP Operation

### 5.4.1 Start engine to supply load

#### General notes

##### Pre-Condition

| Mode | Energy            | Breakers      | Genset              |
|------|-------------------|---------------|---------------------|
| AUTO | Mains is "normal" | GCB is open   | Not running         |
|      |                   | MCB is closed | Ready for operation |

##### Situation

- Mains becomes abnormal because one or more of the parameters below misses its well defined working range:
  - “Overvoltage”
  - “Undervoltage”
  - “Overfrequency”
  - “Underfrequency”
  - “Mains voltage asymmetry”
  - “Mains phase rotation fail”

The AUTO Start procedure is going through sub procedures with own timers.

## Operation

---

START/STOP Operation > Start engine to supply load



*If mains is back during the process, re-connecting mains has priority.*

*The remaining time of each of the timers initiated is shown in the display.*

*When started via "Remote Start (off Load)" input, start procedures is the same as described below but generator close relay is deactivated.*

*Because there is no mains control, only the part "Start engine" (green background) is relevant.*




Fig. 33: Transition Mains to Genset including engine start procedure

## Operation

START/STOP Operation > Stop engine after mains su...

### 5.4.2 Stop engine after mains supplying load (again)

#### General notes

##### Pre-Condition

| Mode | Energy              | Breakers      | Genset           |
|------|---------------------|---------------|------------------|
| AUTO | Mains is "abnormal" | GCB is closed | Running          |
|      |                     | MCB is open   | Delivering power |

##### Situation

- Mains becomes normal so all of the parameters below meet their well defined working ranges:
  - “Overvoltage”
  - “Undervoltage”
  - “Overfrequency”
  - “Underfrequency”
  - “Mains voltage asymmetry”
  - “Mains phase rotation fail”

The AUTO Stop procedure is going through sub procedures with own timers.



*If mains becomes abnormal during the process, remaining with generator load has priority.*

*The remaining time of each of the timers initiated is shown in the display.*

*When started via “Remote Stop (off Load)” input, start procedures is the same as described below but generator close relay is deactivated.*






Fig. 34: Transition genset to mains including engine stop/stand-by procedure

### 5.4.3 MANual START/STOP




*Engine control is separated from breaker management. Breaker(s) must be manually opened/closed (supply should be in normal range).*

#### MANual Start

1. ➤ Press MAN button 
  - ⇒ the LED besides the button will illuminate to confirm the operation
2. ➤ Press START button  to start the genset as described above. With high temperature, low oil pressure, over speed and abnormal voltage during generator running, controller can protect genset to stop quickly.

#### MANual Stop

- Press  can stop the running generator as described above.

## 5.5 Transition Procedures

### 5.5.1 Disconnect during Cranking

There are three conditions under control to abort starting the engine:

- speed sensor
- generator frequency
- engine oil pressure

They can be used separately or in combinations.

We recommend to select all three at the same time: engine oil pressure together with speed sensor, and generator frequency. This enables to separate immediately the starter motor from engine. Additionally crank disconnect can be checked exactly.

When set as speed sensor, ensure that the number of flywheel teeth is as same as setting.



**Sensor not used? Make sure it is not selected!**  
*Otherwise "start fail" or "loss speed signal" maybe caused.*



*If speed sensor ("Firing speed RPM") is not selected: Rotating speed displayed in controller is calculated by generator frequency and number of poles.*

*If generator frequency ("Firing speed Hz") is not selected: Relative power quantity will neither be collected not displayed (e.g. water pump application).*

HMI only! In ToolKit-SC frequency, speed, and oil pressure can be enabled/disabled separately; HMI is using a table "Firing speed" instead:

| No. | Setting description                         |
|-----|---|
| 0   | Gen frequency                               |
| 1   | Speed sensor                                |
| 2   | Speed sensor + Gen frequency                |
| 3   | Oil pressure                                |
| 4   | Oil pressure + Gen frequency                |
| 5   | Oil pressure + Speed sensor                 |
| 6   | Oil pressure + Speed sensor + Gen frequency |

## 5.5.2 Manual Breaker Transition

When controller is in MANual mode, the procedures to switch supply between mains and genset will start through manual transfer process by pressing a breaker switch.



### CAUTION!

Neither mains nor generator state is taken into account. Breaker open/close works independent from load.

If generator or mains are "out of range" load can be damaged!

Both breakers GCB and MCB open:

### Taking load

➔ Press breaker switch

⇒ The according breaker will be closed.  
Closing signal will last for the "Closing time"



*During this time all other breaker signals are suppressed.*

### Unload

One of the breakers is closed - open this breaker.

➔ Press breaker switch

⇒ The according breaker will be opened.  
Opening signal will last for the "Opening time"




*During this time all other breaker signals are suppressed.*

## Operation

### Trouble Shooting

#### Transfer load

One of the breakers is closed - close the other breaker.

1. ▶ Press breaker switch  of the open breaker
  - ⇒ The other (closed) breaker will be opened.  
Opening signal will last for the "Opening time"



*During this time all other breaker signals are suppressed.*

2. ▶ After this automatically the other (selected by pressed button) breaker will be closed
  - ⇒ Closing signal will last for the "Closing time"



*During this time all other breaker signals are suppressed.*

## 5.6 Trouble Shooting

| Symptoms                                      | Possible Solutions  |
|---|---|
| Controller no response with power.            | Check starting batteries; Check controller connection wiring; Check DC fuse.  |
| Genset shutdown                               | Check the water/cylinder temperature is too high or not; Check the genset AC voltage; Check DC fuse.  |
| Controller emergency stop                     | Check emergence stop button is correct or not; Check whether the starting battery positive is connected with the emergency stop input; Check whether the circuit is open.   |
| Low oil pressure alarm after crank disconnect | Check the oil pressure sensor and its connections.  |
| High water temp. alarm after crank disconnect | Check the temperature sensor and its connections.   |
| Shutdown Alarm in running                     | Check related switch and its connections according to the information on LCD; Check auxiliary input ports.  |
| Fail to start                                 | Check fuel oil circuit and its connections; Check starting batteries; Check speed sensor and its connections; Refer to engine manual.   |
| Starter no response                           | Check starter connections; Check starting batteries.  |
| Genset running while ATS not transfer         | Check ATS; Check the connections between ATS and controllers.   |
| RS485 communication is abnormal               | Check connections; Check COM port setting is correct or not; Check RS-485 connections of A and B is reverse connect or not; Check RS485 transfer model whether damage or not; Check communication port of PC whether damage or not. |
| ECU communication failed                      | Check connections of CAN high and low polarity; Check if correctly connected of 120 Ω resistor; Check if type of engine correct; Check if connections from controller to engine and output ports setting are correct.               |
| ECU warning or shutdown                       | Get information from LCD of alarm page; If there is detailed alarm, check engine according to description. If not, please refer to engine manual according to SPN alarm code.   |



## 6 Application

### 6.1 Commissioning

Please go to the steps below, before starting normal operation

1. ➤ Ensure all the connections are correct and wires diameter is suitable
2. ➤ Ensure that the controller DC power has fuse, controller's positive and negative connected to start battery are correct
3. ➤ Emergence stop must be connected with positive of start battery via scram button's normal close point and fuse
4. ➤ Take proper action to prevent engine to crank disconnect (e. g. Remove the connection wire of fuel valve). If checking is OK, make the start battery power on; choose manual mode and controller will executive routine
5. ➤ Set controller under manual mode, press start button **I**, genset will start. After the setting times as setting, controller will send signal of Start Fail; then press stop button **STOP** to reset controller
6. ➤ Recover the action of stop engine start (e. g. connect wire of fuel valve), press **I** again, genset will start. If everything goes well, genset will normal run after idle running (if idle run be set). During this time, please watch for engine's running situations and AC generator's voltage and frequency. If abnormal, stop genset running and check all wires connection according to this manual
7. ➤ Select the AUTO mode from controller's panel (**AUTO**), connect mains signal. After the mains normal delay, controller will transfer ATS (if fitted) into mains load. After cooling time, controller will stop genset and make it into "at rest" mode until there is abnormal of mains
8. ➤ When mains is abnormal again, genset will be started automatically and into normal running, then controller send signal to making generator switch on, and control the ATS as generator load. If not like this, please check ATS wires connection of control part according to this manual
9. ➤ If there is any other question, please contact your local Woodward support

## Application

---

Commissioning

## 7 Interfaces and Protocols

### 7.1 J1939

#### Cummins ISB/ISBE

| Terminals of controller | Connector B  | Remark   |
|-------------------------|--|--|
| Fuel relay output       | 39   |  |
| Start relay output      | -  | Connect with starter coil directly                               |
| Auxiliary output port 1 | Expand 30A relay, battery voltage of 01, 07, 12, 13 is supplied by relay | ECU power Set Auxiliary output 1 as "ECU power"                  |
| Terminals of controller | 9 pins connector   | Remark   |
| CAN GND                 | SAE J1939 shield   | CAN communication shielding line(connect with ECU terminal only) |
| CAN(H)                  | SAE J1939 signal   | Impedance 120 $\Omega$ connecting line is recommended.           |
| CAN(L)                  | SAE J1939 return   | Impedance 120 $\Omega$ connecting line is recommended.           |

#### Cummins QSL9 / CM850 engine control module

| Terminals of controller | 50 pins connector  | Remark   |
|-------------------------|--------------------|--|
| Fuel relay output       | 39                 |  |
| Start relay output      | -                  | Connect to starter coil directly                                 |
| Terminals of controller | 9 pins connector   | Remark   |
| CAN GND                 | SAE J1939 shield-E | CAN communication shielding line(connect with ECU terminal only) |
| CAN(H)                  | SAE J1939 signal-C | Impedance 120 $\Omega$ connecting line is recommended.           |
| CAN(L)                  | SAE J1939 return-D | Impedance 120 $\Omega$ connecting line is recommended.           |

#### Cummins QSM 11 (Import) / CM570 engine control module

| Terminals of controller | C1 connector               | Remark  |
|-------------------------|----------------------------|---|
| Fuel relay output       | 5&8                        | Outside expand relay, when fuel output, making port 5 and port 8 of C1 be connected |
| Start relay output      | -                          | Connect to starter coil directly  |
| Terminals of controller | 3 pins data link connector | Remark  |
| CAN GND                 | C                          | CAN communication shielding line(connect with ECU terminal only)                    |
| CAN(H)                  | A                          | Impedance 120 $\Omega$ connecting line is recommended.                              |
| CAN(L)                  | B                          | Impedance 120 $\Omega$ connecting line is recommended.                              |

#### Cummins QSX15-CM570

| Terminals of controller | 50 pins connector  | Remark   |
|-------------------------|--------------------|--|
| Fuel relay output       | 38                 | Oil spout switch   |
| Start relay output      | -                  | Connect to starter coil directly                                 |
| Terminals of controller | 9 pins connector   | Remark   |
| CAN GND                 | SAE J1939 shield-E | CAN communication shielding line(connect with ECU terminal only) |

## Interfaces and Protocols

J1939

| Terminals of controller | 50 pins connector  | Remark   |
|-------------------------|--------------------|--|
| CAN(H)                  | SAE J1939 signal-C | Impedance 120 $\Omega$ connecting line is recommended. |
| CAN(L)                  | SAE J1939 return-D | Impedance 120 $\Omega$ connecting line is recommended. |

### Cummins GCS-Modbus / QSX15, QST30, QSK23-45-60-78-... via RS-485 Modbus

| Terminals of controller | D-SUB connector 06 | Remark  |
|-------------------------|--------------------|---|
| Fuel relay output       | 5&8                | Outside expand relay, when fuel output, making port 05 and 08 of the connector 06 be connected. |
| Start relay output      | -                  | Connect to starter coil directly  |
| Terminals of controller | D-SUB connector 06 | Remark  |
| RS485 GND               | 20                 | CAN communication shielding line(connect with ECU terminal only)                                |
| RS485+                  | 21                 | Impedance 120 $\Omega$ connecting line is recommended.  |
| RS485-                  | 18                 | Impedance 120 $\Omega$ connecting line is recommended.  |

### Cummins QSM11 / Common J1939

| Terminals of controller | OEM connector of engine | Remark   |
|-------------------------|-------------------------|--|
| Fuel relay output       | 38                      |  |
| Start relay output      | -                       | Connect with starter coil directly   |
| CAN GND                 | -                       | CAN communication shielding line(connect with controller's this terminal only) |
| CAN(H)                  | 46                      | Impedance 120 $\Omega$ connecting line is recommended.                         |
| CAN(L)                  | 37                      | Impedance 120 $\Omega$ connecting line is recommended.                         |

### Cummins QSZ13 / Common J1939

| Terminals of controller | OEM connector of engine | Remark   |
|-------------------------|-------------------------|--|
| Fuel relay output       | 45                      |  |
| Start relay output      | -                       | Connect to starter coil directly   |
| Auxiliary output 1      | 16&41                   | Setting to idle speed control; normally close output. Making 16 connect to 41 during high-speed running of controller via external expansion relay.                  |
| Auxiliary output 2      | 19&41                   | Setting to pulse raise speed control; normally open output. Making 19 connect with 41 for 0.1s during high-speed warming of controller via external expansion relay. |
| CAN GND                 | -                       | CAN communication shielding line(connect with controller's this terminal only)   |
| CAN(H)                  | 1                       | Impedance 120 $\Omega$ connecting line is recommended.   |
| CAN(L)                  | 21                      | Impedance 120 $\Omega$ connecting line is recommended.   |

### Detroit Diesel DDEC III-IV / Common J1939

| Terminals of controller | CAN port of engine   | Remark  |
|-------------------------|--|---|
| Fuel relay output       | Expand 30A relay; battery voltage of ECU is supplied by relay. |   |
| Start relay output      | -  | Connect to starter coil directly  |
| CAN GND                 | -  | CAN communication shielding line(connect with controller's terminal only) |
| CAN(H)                  | CAN(H)   | Impedance 120 $\Omega$ connecting line is recommended.                    |
| CAN(L)                  | CAN(L)   | Impedance 120 $\Omega$ connecting line is recommended.                    |

### Deutz EMR2 / Volvo EDC4

| Terminals of controller | F connector   | Remark  |
|-------------------------|---|---|
| Fuel relay output       | Expand 30A relay; battery voltage of terminal 14 is supplied by relay. Fuse is 16A. |   |
| Start relay output      | -   | Connect to starter coil directly  |
| -                       | 1   | Connect to battery negative pole  |
| CAN GND                 | -   | CAN communication shielding line(connect with controller's terminal only) |
| CAN(H)                  | 12  | Impedance 120 $\Omega$ connecting line is recommended.                    |
| CAN(L)                  | 13  | Impedance 120 $\Omega$ connecting line is recommended.                    |

### John Deere

| Terminals of controller | 21 pins connector | Remark  |
|-------------------------|-------------------|---|
| Fuel relay output       | G, J              |   |
| Start relay output      | D                 |   |
| CAN GND                 | -                 | CAN communication shielding line(connect with controller's terminal only) |
| CAN(H)                  | V                 | Impedance 120 $\Omega$ connecting line is recommended.                    |
| CAN(L)                  | U                 | Impedance 120 $\Omega$ connecting line is recommended.                    |

### MTU ADEC (Smart Module) / ECU8

| Terminals of controller | ADEC (X1port)   | Remark   |
|-------------------------|-----------------|--|
| Fuel relay output       | X1 10           | X1 Terminal 9 Connected to negative of battery                               |
| Start relay output      | X1 34           | X1 Terminal 33 Connected to negative of battery                              |
| Terminals of controller | SMART (X4 port) | Remark   |
| CAN GND                 | X4 3            | CAN communication shielding line(connect to controller's this terminal only) |
| CAN(H)                  | X4 1            | Impedance 120 $\Omega$ connecting line is recommended.                       |
| CAN(L)                  | X4 2            | Impedance 120 $\Omega$ connecting line is recommended.                       |

## Interfaces and Protocols

J1939

### MTU ADEC (SAM Module) / ECU7, common J1939

| Terminals of controller | ADEC (X1port)  | Remark   |
|-------------------------|----------------|--|
| Fuel relay output       | X1 43          | X1 Terminal 28 Connected to negative of battery                                |
| Start relay output      | X1 37          | X1 Terminal 22 Connected to negative of battery                                |
| Terminals of controller | SAM (X23 port) | Remark   |
| CAN GND                 | X23 3          | CAN communication shielding line(connect with controller's this terminal only) |
| CAN(H)                  | X23 2          | Impedance 120 $\Omega$ connecting line is recommended.                         |
| CAN(L)                  | X23 1          | Impedance 120 $\Omega$ connecting line is recommended.                         |

### Perkins / ADEM3, ADEM4 with 2306, 2506, 2206, 1106, and 2806

| Terminals of controller | Connector   | Remark  |
|-------------------------|-------------|---|
| Fuel relay output       | 110.153.334 |   |
| Start relay output      | -           | Connect to starter coil directly  |
| CAN GND                 | -           | CAN communication shielding line(connect with controller's terminal only) |
| CAN(H)                  | 31          | Impedance 120 $\Omega$ connecting line is recommended.                    |
| CAN(L)                  | 32          | Impedance 120 $\Omega$ connecting line is recommended.                    |

### Scania / S6 with DC9, DC12, and DC16

| Terminals of controller | B1 connector | Remark  |
|-------------------------|--------------|---|
| Fuel relay output       | 3            |   |
| Start relay output      | -            | Connect to starter coil directly  |
| CAN GND                 | -            | CAN communication shielding line(connect with controller's terminal only) |
| CAN(H)                  | 9            | Impedance 120 $\Omega$ connecting line is recommended.                    |
| CAN(L)                  | 10           | Impedance 120 $\Omega$ connecting line is recommended.                    |

**Volvo EDC3 / TAD1240, TAD1241, TAD1242**

*When this engine type is selected, preheating time should be set to at least 3 seconds.*

| Terminals of controller | “Stand alone” connector | Remark  |
|-------------------------|-------------------------|---|
| Fuel relay output       | H                       |   |
| Start relay output      | E                       |   |
| Auxiliary output 1      | P                       | ECU power Set Auxiliary output 1 as “ECU power” |

| Terminals of controller | “Data bus” connector | Remark  |
|-------------------------|----------------------|---|
| CAN GND                 | -                    | CAN communication shielding line(connect with controller’s terminal only) |
| CAN(H)                  | 1                    | Impedance 120 $\Omega$ connecting line is recommended.                    |
| CAN(L)                  | 2                    | Impedance 120 $\Omega$ connecting line is recommended.                    |

**Volvo EDC4 / TD520, TAD520 (optional), TD720, TAD720 (optional), TAD721, TAD722, and TAD732**

| Terminals of controller | Connector   | Remark  |
|-------------------------|---|---|
| Fuel relay output       | Expand 30A relay; battery voltage of terminal 14 is supplied by relay. Fuse is 16A. |   |
| Start relay output      | -   | Connect to starter coil directly  |
|                         | 1   | Connected to negative of battery  |
| CAN GND                 | -   | CAN communication shielding line(connect with controller’s terminal only) |
| CAN(H)                  | 12  | Impedance 120 $\Omega$ connecting line is recommended.                    |
| CAN(L)                  | 13  | Impedance 120 $\Omega$ connecting line is recommended.                    |

**Volvo EMS2 / TAD734, TAD940, TAD941, TAD1640, TAD1641, and TAD1642.**

*When this engine type is selected, preheating time should be set to at least 3 seconds.*

| Terminals of controller | Engine’s CAN port | Remark  |
|-------------------------|-------------------|---|
| Auxiliary output 1      | 6                 | ECU stop Set Auxiliary output 1 as “ECU Stop”                             |
| Auxiliary output 2      | 5                 | ECU power Set Auxiliary output 2 as “ECU power”                           |
|                         | 3                 | Negative power  |
|                         | 4                 | Positive power  |
| CAN GND                 | -                 | CAN communication shielding line(connect with controller’s terminal only) |

## Interfaces and Protocols

J1939

| Terminals of controller | Engine's CAN port | Remark   |
|-------------------------|-------------------|--|
| CAN(H)                  | 1(Hi)             | Impedance 120 $\Omega$ connecting line is recommended. |
| CAN(L)                  | 2(Lo)             | Impedance 120 $\Omega$ connecting line is recommended. |

### Yuchai / BOSCH

| Terminals of controller | Engine 42 pins port | Remark   |
|-------------------------|---------------------|--|
| Fuel relay output       | 1,40                | Connect to engine ignition lock  |
| Start relay output      | -                   | Connect to starter coil directly   |
| CAN GND                 | -                   | CAN communication shielding line(connect with controller's this terminal only) |
| CAN(H)                  | 1,35                | Impedance 120 $\Omega$ connecting line is recommended.                         |
| CAN(L)                  | 1,34                | Impedance 120 $\Omega$ connecting line is recommended.                         |
| Battery                 | Engine 2 pins       | Remark   |
| Battery negative        | 1                   | Wire diameter 2.5mm <sup>2</sup>   |
| Battery positive        | 2                   | Wire diameter 2.5mm <sup>2</sup>   |

### Weichai / GTSC1 with BOSCH

| Terminals of controller | Engine port | Remark   |
|-------------------------|-------------|--|
| Fuel relay output       | 1,40        | Connect to engine ignition lock  |
| Start relay output      | 1,61        |  |
| CAN GND                 | -           | CAN communication shielding line(connect to the controller at this end only) |
| CAN(H)                  | 1,35        | Impedance 120 $\Omega$ connecting line is recommended.                       |
| CAN(L)                  | 1,34        | Impedance 120 $\Omega$ connecting line is recommended.                       |



## 8 Technical Specifications

### Ambient

| Items                                   |                                      | Contents  |
|---|--------------------------------------|---|
| Power Supply                            | Operating Voltage                    | 8.0 V <sub>DC</sub> to 35.0 V <sub>DC</sub> , Continuous Power Supply.<br>Reverse polarity protected        |
|   | Maximum supply voltage               | Short Time 80 V (5-10 s)<br>Long Time 50 V  |
|   | Minimum supply voltage               | 6.5 V   |
|   | Maximum operating current            | (All relays closed, LCD bright)<br>380 mA (12 V);<br>188 mA (24 V)  |
|   | Maximum standby current              | (All relays closed, LCD dimm)<br>90 mA (12 V);<br>42 mA (24 V)  |
| Power Consumption                       |                                      | <4 W (standby ≤ 2 W)  |
| Battery voltage measurement Accuracy    |                                      | 1% (12V/24V)  |
| Alternator Input Range                  | 3-Phase 4-Wire                       | AC15V-AC 360V (ph-N)  |
|   | 3-Phase 3-Wire                       | AC30V - AC620V (ph-ph)  |
|   | Single-Phase 2-Wire                  | AC15V - AC360V (ph-N)   |
|   | 2-Phase 3-Wire                       | AC15V - AC360V (ph-N)   |
| AC-Measurement                          | Voltage Accuracy (400/480 V % rated) | Phase-phase: 100 .. 624 V : 1%; 50 .. 100 V : 1.5 %<br>Phase-neutral: 100 .. 360 V : 1% 50 .. 100 V : 1.5 % |
|   | Minimum frequency                    | Generator: 10 Hz<br>Mains: 27 Hz  |
|   | Maximum frequency                    | Generator: 99.5 Hz<br>Mains: 99.5 Hz  |
|   | Frequency resolution                 | 0.1 Hz (10 .. 99 Hz)  |
|   | Frequency accuracy                   | ±0.1 Hz   |
|   | Nominal CT secondary rating          | 5 A   |
|   | Overload Measurement                 | Max.: 10 A  |
|   | Current Accuracy                     | 1 %   |
| Alternator Frequency                    |                                      | 50 Hz/60 Hz   |
| Case Dimension                          |                                      | 237 mm x 172 mm x 45 mm   |
| Panel Cutout                            |                                      | 214 mm x 160 mm   |
| Working Conditions                      |                                      | Temperature: (-25 to +70) °C;<br>Humidity: (20 to 93) %RH   |
| Storage Condition                       |                                      | Temperature: (-25 to +70) °C  |
| Protection Level against water and dust |                                      | Front: IP65 by using mounting material delivered with device<br>Back: IP20                                  |

## Technical Specifications

| Items                | Contents  |
|----------------------|---|
| Insulating Intensity | Apply 2.2 kV <sub>AC</sub> voltage between high voltage terminal and low voltage terminal.<br>The leakage current is not more than 3 mA within 1 min. |
| Net Weight           | 0.85 kg   |

## Inputs/Outputs

| Items                           | Contents                      |                       |
|---------------------------------|-------------------------------|-----------------------|
| Speed Sensor                    | Voltage                       | 1.0 V to 24.0 V (RMS) |
|                                 | Frequency                     | 10,000 Hz (max.)      |
| Excitation current D+           | 110 mA (12 V)                 |                       |
|                                 | 230 mA (24 V)                 |                       |
| Start Relay Output              | 16A DC28V supply output       |                       |
| Fuel Relay Output               | 16A DC28V supply output       |                       |
| Auxiliary Relay Output (1 .. 3) | 7A DC28V supply output        |                       |
| Auxiliary Relay Output (4 .. 6) | 7A AC250V voltage free output |                       |
|                                 |                               |                       |
| Digital Inputs                  | Low level threshold           | Approx. 1.3 V         |
|                                 | Maximum input voltage         | 60V                   |
|                                 | Minimum input voltage         | 0 V                   |
|                                 | High level threshold          | 1.7 V                 |
| CAN port (isolated)             | Baud rate                     | 250 K                 |
|                                 |                               |                       |
| Ethernet port                   | available                     |                       |
| USB Port                        | Max. allowed cable length     | 1.5 m                 |
|                                 |                               |                       |
| RS485 Serial port (isolated)    | Baud rate                     | 9600                  |
|                                 | Duplex                        | Half                  |
|                                 | Max. allowed cable length     | 1000 m                |

## Approvals

|               |  |
|---------------|--|
| EMC test (CE) | Tested according to applicable EMC standards |
| Listings      | CE marking<br>UL6200/cUL<br>NFPA110          |

## Display

- 480 x 272 TFT LCD with backlight, multilingual interface (including English, Chinese or other languages) which can be chosen at the site, making commissioning convenient for factory personnel
- LCD wear-resistance and scratch resistance due to hard screen acrylic;

**Housing**

- Silicon panel and pushbuttons for better operation in high-temperature environment;
- Waterproof security level IP55 due to rubber seal installed between the controller enclosure and panel fascia
- Metal fixing clips enable perfect in high temperature environment
- Modular design, self-extinguishing ABS plastic enclosure, plug-gable connection terminals and embedded installation way; compact structure with easy mounting

**Interfaces**

- RS485 communication port enabling:
  - remote control
  - remote measuring
  - remote communication via ModBus protocol
- CANbus port and can communicate with J1939 genset:
  - Monitoring frequently-used data (such as water temperature, oil pressure, speed, fuel consumption and so on) of ECU
  - Control START, STOP, raising speed, and speed droop

**Phase Configuration**

- Suitable for 3-phase 4-wire, 3-phase 3-wire, single phase 2-wire, and 2-phase 3-wire systems with
  - voltage 120/240 V and
  - frequency 50/60 Hz

## 8.1 Measuring and Monitoring

- Measures and monitors
  - 3-phase voltage, current, power parameter, and frequency of
  - generator or mains.

**Mains**

- Line voltage ( $U_{ab}$ ,  $U_{bc}$ , and  $U_{ca}$ )
- Phase voltage ( $U_a$ ,  $U_b$ , and  $U_c$ )
- Phase sequence
- Frequency Hz
- For Mains, controller has over and under voltage, over and under frequency, loss of phase and phase sequence wrong detection functions

**Generator**

- Line voltage ( $U_{ab}$ ,  $U_{bc}$ , and  $U_{ca}$ )
- Phase voltage ( $U_a$ ,  $U_b$ , and  $U_c$ )
- Phase sequence
- Frequency Hz
- For generator, controller has over and under voltage, over and under frequency, loss of phase, phase sequence wrong, over and reverse power, over current functions

## Technical Specifications

---

### Measuring and Monitoring

#### Load

- Current IA, IB, IC
- Each phase and total active power kW
- Each phase and total reactive power kvar
- Each phase and total apparent power kVA
- Each phase and average power factor PF
- Accumulate total generator power kWh, kvarh, kVAh
- Earth current A

#### Miscellaneous

- 3 fixed analog sensors (temperature, oil pressure and fuel level)
- 2 flexible sensors can be set as temperature sensor, oil pressure sensor or level sensor
- Precision measure and display parameters about Engine:
  - Temp. (WT) °C/°F both be displayed
  - Oil pressure (OP) kPa/psi/bar all be displayed
  - Fuel level (FL) %(unit)
  - Speed (SPD) r/min (unit)
  - Battery Voltage (VB) V (unit)
  - Charger Voltage (VD) V (unit)
- Hour count (HC) can accumulate to max. 65535 hours.
- Start times can accumulate to max. 65535 times

## 9 Appendix

### 9.1 Alarms and Warnings

#### 9.1.1 Alarm Classes

| Alarm class | Visible in the display  | LED and horn | Open GCB    | Shut-down engine | Engine blocked until acknowledge |
|-------------|---|--------------|-------------|------------------|----------------------------------|
| Warn        | X   | X            |             |                  |                                  |
|             | This alarm does not interrupt the unit operation. An output of the centralized alarm occurs and the command "Horn" is issued. Alarm text + flashing LED + Relay centralized alarm (horn)  |              |             |                  |                                  |
| Shutdown    | X   | X            | Immediately | Immediately      | X                                |
|             | With this alarm the GCB is opened immediately and the engine is stopped. Alarm text + flashing LED + Relay centralized alarm (horn) + GCB open + Engine stop.                             |              |             |                  |                                  |
| Trip/shut   | x   | x            | Immediately | Cool down time   | X                                |
|             | With this alarm the GCB is opened immediately and the engine is stopped after cool down. Alarm text + flashing LED + Relay centralized alarm (horn) + GCB open + Cool down + Engine stop. |              |             |                  |                                  |
| Trip        | X   | X            | X           |                  |                                  |
|             | With this alarm the GCB is opened immediately but does not interrupt the unit operation. Alarm text + flashing LED + Relay centralized alarm (horn) + GCB open.                           |              |             |                  |                                  |
| Indication  | X   |              |             |                  |                                  |
|             | This alarm does not interrupt the unit operation. A message output without a centralized alarm occurs. Alarm text   |              |             |                  |                                  |

#### 9.1.2 Warnings

| No | Type                          | Description  |
|----|-------------------------------|--|
| 1  | Overspeed                     | When the controller detects that the engine speed has exceeded the pre-set value, it will initiate a warning alarm.                                |
| 2  | Underspeed                    | When the controller detects that the engine speed has fallen below the pre-set value, it will initiate a warning alarm.                            |
| 3  | Loss of speed signal          | When the controller detects that the engine speed is 0 and the action select "Warn", it will initiate a warning alarm.                             |
| 4  | Gen. overfrequency            | When the controller detects that the genset frequency has exceeded the pre-set value, it will initiate a warning alarm.                            |
| 5  | Gen. underfrequency           | When the controller detects that the genset frequency has fallen below the pre-set value, it will initiate a warning alarm.                        |
| 6  | Gen. overvoltage              | When the controller detects that the generator voltage has exceeded the pre-set value, the controller will initiate a warning alarm.               |
| 7  | Gen. undervoltage             | When the controller detects that the genset voltage has fallen below the pre-set value, it will initiate a warning alarm.                          |
| 8  | Gen. overcurrent              | When the controller detects that the genset current has exceeded the pre-set value and the action select "Warn", it will initiate a warning alarm. |
| 9  | Fail to stop                  | After "Stop solenoid hold" delay, if genset does not stop completely, it will initiate a warning alarm.  |
| 10 | Charge alternator low voltage | When the controller detects that charger voltage has fallen below the pre-set value, it will initiate a warning alarm.                             |
| 11 | Battery undervoltage          | When the controller detects that start battery voltage has fallen below the pre-set value, it will initiate a warning alarm.                       |
| 12 | Battery overvoltage           | When the controller detects that start battery voltage has exceeded the pre-set value, it will initiate a warning alarm.                           |
| 13 | Maintenance due               | When count down time is 0 and the action select "Warn", it will initiate a warning alarm.  |

## Appendix

### Alarms and Warnings > Shutdown Alarms

| No | Type                           | Description  |
|----|--------------------------------|--|
| 14 | Gen. reverse power             | If reverse power detection is enabled, when the controller detects that the reverse power value (power is negative) has fallen below the pre-set value and the action select "Warn", it will initiate a warning alarm. |
| 15 | Overload                       | If over power detection is enabled, when the controller detects that the over power value (power is positive) has exceeded the pre-set value and the action select "Warn", it will initiate a warning alarm.           |
| 16 | ECU warning alarm              | If an error message is received from ECU via J1939, it will initiate a warning alarm.  |
| 17 | Gen. loss of phase             | If loss of phase detection is enabled, When controller detects the generator loss phase, it will initiate a warning alarm.   |
| 18 | Gen. phase rotation mismatch   | When the controller detects a phase rotation error, it will initiate a warning alarm.  |
| 19 | Breaker open/close fail        | When the controller detects that the breaker close or open failure occurs, and the action select "Warn", it will initiate a warning alarm.   |
| 20 | Temperature sensor wire break  | When the controller detects that the temperature sensor is open circuit and the action select "Warn", it will initiate a warning alarm.  |
| 21 | High temperature               | When the controller detects that engine temperature has exceeded the pre-set value, it will initiate a warning alarm.  |
| 22 | Low temperature                | When the controller detects that engine temperature has fallen below the pre-set value, it will initiate a warning alarm.  |
| 23 | Oil pressure sensor wire break | When the controller detects that the oil pressure sensor is open circuit and the action select "Warn", it will initiate a warning alarm.   |
| 24 | Low oil pressure               | When the controller detects that the oil pressure has fallen below the pre-set value, it will initiate a warning alarm.  |
| 25 | Fuel level sensor wire break   | When the controller detects that the level sensor is open circuit and the action select "Warn", it will initiate a warning alarm.  |
| 26 | Low fuel level                 | When the controller detects that the fuel level has fallen below the pre-set value, it will initiate a warning alarm.  |
| 27 | Analog input 4 Wire break      | When the controller detects that the flexible sensor 1 is open circuit and the action select "Warn", it will initiate a warning alarm.   |
| 28 | Analog input 4 High limit      | When the controller detects that the sensor 1 value has exceeded the pre-set value, it will initiate a warning alarm.  |
| 29 | Analog input 4 Low limit       | When the controller detects that the sensor 1 value has fallen below the pre-set value, it will initiate a warning alarm.  |
| 30 | Analog input 5 Wire break      | When the controller detects that the flexible sensor 2 is open circuit and the action select "Warn", it will initiate a warning alarm.   |
| 31 | Analog input 5 High limit      | When the controller detects that the sensor 2 value has exceeded the pre-set value, it will initiate a warning alarm.  |
| 32 | Analog input 5 Low limit       | When the controller detects that the sensor 2 value has fallen below the pre-set value, it will initiate a warning alarm.  |
| 33 | Discrete input xyz             | When digit input port is set as warning and the alarm is active, it will initiate a warning alarm.   |
| 34 | GSM Communication fail         | When select GSM enable but the controller couldn't detect GSM model, controller sends corresponding warning signal.  |
| 35 | Ground fault                   | If earth fault detection is enabled, when the controller detects that the earth fault current has exceeded the pre-set value and the action select "Warn", it will initiate a warning alarm.                           |

### 9.1.3 Shutdown Alarms

When controller detects shutdown alarm, it will send signal to open breaker and shuts down generator.

| No | Type                           | Description   |
|----|--------------------------------|---|
| 1  | Emergency stop                 | When the controller detects an emergency stop alarm signal, it will initiate a shutdown alarm.  |
| 2  | Overspeed                      | When the controller detects that the generator speed has exceeded the pre-set value, it will initiate a shutdown alarm.   |
| 3  | Underspeed                     | When the controller detects that the generator speed has fallen below the pre-set value, it will initiate a shutdown alarm.   |
| 4  | Loss of speed signal           | When the controller detects that the engine speed is 0 and the action select "Shutdown", it will initiate a shutdown alarm.   |
| 5  | Gen. overfrequency             | When the controller detects that the genset frequency has exceeded the pre-set value, it will initiate a shutdown alarm.  |
| 6  | Gen. underfrequency            | When the controller detects that the genset frequency has fallen below the pre-set value, it will initiate a shutdown alarm.  |
| 7  | Gen. overvoltage               | When the controller detects that the generator voltage has exceeded the pre-set value, the controller will initiate a shutdown alarm.   |
| 8  | Gen. undervoltage              | When the controller detects that the genset voltage has fallen below the pre-set value, it will initiate a shutdown alarm.  |
| 9  | Fail to stop                   | If the engine does not fire after the pre-set number of attempts, it will initiate a shutdown alarm.  |
| 10 | Gen. overcurrent               | When the controller detects that the genset current has exceeded the pre-set value and the action select "Shutdown", it will initiate a shutdown alarm.   |
| 11 | Maintenance due                | When count down time is 0 and the action select "Shutdown", it will initiate a shutdown alarm.  |
| 12 | ECU shutdown alarm             | If an error message is received from ECU via J1939, it will initiate a shutdown alarm.  |
| 13 | ECU communication fail         | If the module does not detect the ECU data, it will initiate a shutdown alarm.  |
| 14 | Gen. reverse power             | If reverse power detection is enabled, when the controller detects that the reverse power value (power is negative) has fallen below the pre-set value and the action select "Shutdown", it will initiate a shutdown alarm. |
| 15 | Overload                       | If over power detection is enabled, when the controller detects that the over power value (power is positive) has exceeded the pre-set value and the action select "Shutdown", it will initiate a shutdown alarm.           |
| 16 | Temperature sensor wire break  | When the controller detects that the temperature sensor is open circuit and the action select "Shutdown", it will initiate a shutdown alarm.  |
| 17 | High temperature               | When the controller detects that engine temperature has exceeded the pre-set value, it will initiate a shutdown alarm.  |
| 18 | Oil pressure sensor wire break | When the controller detects that the oil pressure sensor is open circuit and the action select "Shutdown", it will initiate a shutdown alarm.   |
| 19 | Low oil pressure               | When the controller detects that the oil pressure has fallen below the pre-set value, it will initiate a shutdown alarm.  |
| 20 | Level sensor wire break        | When the controller detects that the level sensor is open circuit and the action select "Shutdown", it will initiate a shutdown alarm.  |
| 21 | Analog input 4 Wire break      | When the controller detects that the flexible sensor 1 is open circuit and the action select "Shutdown", it will initiate a shutdown alarm.   |
| 22 | Analog input 4 High limit      | When the controller detects that the sensor 1 value has exceeded the pre-set value, it will initiate a shutdown alarm.  |
| 23 | Analog input 4 Low limit       | When the controller detects that the sensor 1 value has fallen below the pre-set value, it will initiate a shutdown alarm.  |
| 24 | Analog input 5 Wire break      | When the controller detects that the flexible sensor 2 is open circuit and the action select "Shutdown", it will initiate a shutdown alarm.   |
| 25 | Analog input 5 High limit      | When the controller detects that the sensor 2 value has exceeded the pre-set value, it will initiate a shutdown alarm.  |
| 26 | Analog input 5 Low limit       | When the controller detects that the sensor 2 value has fallen below the pre-set value, it will initiate a shutdown alarm.  |
| 27 | Discrete input                 | When digit input port is set as shutdown and the alarm is active, it will initiate a shutdown alarm.  |

## Appendix

### Alarms and Warnings > Trip Alarms

| No | Type                             | Description   |
|----|----------------------------------|---|
| 28 | Ground fault                     | If earth fault detection is enabled, when the controller detects that the earth fault current has exceeded the pre-set value and the action select "Shutdown", it will initiate a shutdown alarm. |
| 29 | Low coolant level                | Controller initiate shutdown alarm after digital input port been configured as low coolant level shutdown ( is active).   |
| 30 | Detonation shutdown (Gas engine) | Controller initiate shutdown alarm after digital input port been configured as detonation shutdown ( is active).  |
| 31 | Gas leak shutdown                | Controller initiate shutdown alarm after digital input port been configured as gas leak shutdown ( is active).  |

#### 9.1.4 Trip and Stop Alarms

On initiation of the trip and stop condition the controller will de-energize the 'Close Generator' Output to remove the load from the generator. Once this has occurred the controller will start the Cooling delay and allow the engine to cool before shutting down the engine.

| No | Type               | Description   |
|----|--------------------|---|
| 1  | Gen. overcurrent   | When the controller detects that the genset current has exceeded the pre-set value and the action select "Trip and Stop", it will initiate a trip and stop alarm.   |
| 2  | Maintenance due    | When count down time is 0 and the action select "Trip and Stop", it will initiate a trip and stop alarm.  |
| 3  | Gen. reverse power | If reverse power detection is enabled, when the controller detects that the reverse power value (power is negative) has fallen below the pre-set value and the action select "Trip and Stop", it will initiate a trip and stop alarm. |
| 4  | Overload           | If over power detection is enabled, when the controller detects that the over power value (power is positive) has exceeded the pre-set value and the action select "Trip and Stop", it will initiate a trip and stop alarm.           |
| 5  | Discrete input     | When digit input port is set as "Trip and Stop" and the alarm is active, it will initiate a trip and stop alarm.  |
| 6  | Ground fault       | If earth fault detection is enabled, when the controller detects that the earth fault current has exceeded the pre-set value and the action select "Trip and Stop", it will initiate a trip and stop alarm.                           |

#### 9.1.5 Trip Alarms

On initiation of the trip condition the controller will de-energize the 'Close Generator' Output without stop the generator.

| No | Type               | Description   |
|----|--------------------|---|
| 1  | Gen. overcurrent   | When the controller detects that the genset current has exceeded the pre-set value and the action select "Trip", it will initiate a trip alarm.   |
| 2  | Gen. reverse power | If reverse power detection is enabled, when the controller detects that the reverse power value (power is negative) has fallen below the pre-set value and the action select "Trip", it will initiate a trip alarm. |
| 3  | Overload           | If over power detection is enabled, when the controller detects that the over power value (power is positive) has exceeded the pre-set value and the action select "Trip", it will initiate a trip alarm.           |



| No | Type           | Description   |
|----|----------------|---|
| 4  | Discrete Input | When digit input port is set as "Trip" and the alarm is active, it will initiate a trip alarm.  |
| 5  | Ground fault   | If earth fault detection is enabled, when the controller detects that the earth fault current has exceeded the pre-set value and the action select "Trip", it will initiate a trip alarm. |

## 9.2 Trouble Shooting

| Symptoms                                      | Possible Solutions  |
|---|---|
| Controller no response with power.            | Check starting batteries; Check controller connection wiring; Check DC fuse.  |
| Genset shutdown                               | Check the water/cylinder temperature is too high or not; Check the genset AC voltage; Check DC fuse.  |
| Controller emergency stop                     | Check emergence stop button is correct or not; Check whether the starting battery positive is connected with the emergency stop input; Check whether the circuit is open.   |
| Low oil pressure alarm after crank disconnect | Check the oil pressure sensor and its connections.  |
| High water temp. alarm after crank disconnect | Check the temperature sensor and its connections.   |
| Shutdown Alarm in running                     | Check related switch and its connections according to the information on LCD; Check auxiliary input ports.  |
| Fail to start                                 | Check fuel oil circuit and its connections; Check starting batteries; Check speed sensor and its connections; Refer to engine manual.   |
| Starter no response                           | Check starter connections; Check starting batteries.  |
| Genset running while ATS not transfer         | Check ATS; Check the connections between ATS and controllers.   |
| RS485 communication is abnormal               | Check connections; Check COM port setting is correct or not; Check RS-485 connections of A and B is reverse connect or not; Check RS485 transfer model whether damage or not; Check communication port of PC whether damage or not. |
| ECU communication failed                      | Check connections of CAN high and low polarity; Check if correctly connected of 120 $\Omega$ resistor; Check if type of engine correct; Check if connections from controller to engine and output ports setting are correct.        |
| ECU warning or shutdown                       | Get information from LCD of alarm page; If there is detailed alarm, check engine according to description. If not, please refer to engine manual according to SPN alarm code.   |

## 9.3 Data Telegrams

### General Notes

This protocol describes read and write command format of PC serial port and the definition of internal information data for the third-party to develop and use.

MODBUS communication protocol allows the module to transfer information and data effectively with PLC, RTU, SCADA system of international brands (such as, Schneider, Siemens, and Modicon), and DCS or third-party monitoring system compatible with MODBUS. The monitoring system can be set up if only adding central communication master software (such as Kingview, Intouch, FIX, Synal) basing on PC (or IPC).

### 9.3.1 Modbus Basics

- All communication loops should follow the master-slave mode. If so, data can be transferred between a master (e.g. PC) and 32 slaves.
- No communication can start from slaves.

## Appendix

### Data Telegrams > Modbus Basics > Information Frame Format

- In communication loop, all communication should be transmitted in information frame.
- If received information frame contains unknown command, no response will be given.

1) All communication loops should follow the master-slave mode. If so, data can be transferred between a master (e.g. PC) and 32 slaves. 2) No communication can start from slaves. 3) In communication loop, all communication should be transmitted in information frame. 4) If received information frame contains unknown command, no response will be given.

#### 9.3.1.1 Data Frame Format

Communication is asynchronously transferred, using byte (data frame) as unit. Between master and slave, every transmitted data frame is 10-bit (stop bit: 1) or 11-bit (stop bit: 2) serial data stream. Data frame format is:

|                  |                            |
|------------------|----------------------------|
| <b>Start bit</b> | <b>1-bit</b>               |
| Data bit         | 8-bit                      |
| Parity bit       | No parity                  |
| Stop bit         | 1-bit or 2-bit can be set. |
| Baud rate        | 9600bps                    |

#### 9.3.1.2 Modbus Communication Protocol

When communication command is sent to the slave, corresponding slave receives the communication command, then removes address code, and read the information. If no mistakes, it will execute commands, and sends the result back to the master. Response information includes address code, function code, data and error check code (CRC). If an error occurred in receipt of the command, it will send no information.

#### 9.3.1.3 Information Frame Format

| Initiating structure          | Address code | Function code | Data field      | CRC            | End structure                 |
|-------------------------------|--------------|---------------|-----------------|----------------|-------------------------------|
| Delay (equivalent to 4 bytes) | 1 byte 8-bit | 1 byte 8-bit  | N bytes N*8-bit | 2 bytes 16-bit | Delay (equivalent to 4 bytes) |

### 9.3.1.4 Address Code

Address code is the first data frame (8-bit) in each transmitted information frame. Device address range is 1 to 255, this byte shows that the slave defined by users will receive the information sent by the master. Each slave has a unique address code, and responses begin with the address code. A master addresses a slave by placing the slave address in the address field of the message. When the slave sends its response, it places its own address in this address field of the response to let the master know which slave is responding.

### 9.3.1.5 Function Code

This is the second byte of each transmission. ModBus communication protocol defined function code as 1 to 255 (01H\_hex to 0FFH\_hex). This easYgen controllers use part of it. Master sends the request and the slave executes actions according to the function code. If the function code sent by slave is same as that sent by master, it means the response is active. But if the function code MSB is 1 (function code range > 127), it means there is no response or response has error. The following table shows the specific signification and operation of function code.

| Function code | Definition             | Operation                                       |
|---------------|------------------------|---|
| 03_hex        | Read Holding Registers | Reads the contents of holding registers         |
| 05_hex        | Force Single Coil      | Forces a single coil to either ON or OFF.       |
| 06_hex        | Preset Single Register | Presets a value into a single holding register. |

#### 03\_hex Read Holding Registers

With function code 03\_hex command, the master can read the numerical registers inside the device (numerical registers contains various analog and parameter setting values). Input register values of function code 03\_hex mapping data field are 16 bits (2 bytes). So, from the device reads registers values are 2 bytes. Maximum number of readable registers is 125 each time. The slave received command format is slave address, function code, data field and the CRC code. The data of data field is in double bytes with every two bytes for a group, and high byte is in advance.

#### 05\_hex Force Single Coil

Master uses this command to save a single coil data into bit registers in the device (such as ATS transfer control). The slave also uses this function code to foldback information to the master.

#### 06\_hex Preset Single register

Master uses this command to save a single register data into registers in the device. The register data in the response message are packed as two bytes per register, with the binary contents right justified within each byte. For each register, the first byte contains the high order bits and the second contains the low order bits. The slave received command format is slave address, function code, data field and the CRC code.

## Appendix

Data Telegrams &gt; Modbus Basics &gt; Error Check Code (CRC)

## 9.3.1.6 Data Field

Data field varies with different function codes.

## Function # 03(03\_hex) – Read Holding Registers

| Request:           |                  |                |
|--------------------|------------------|----------------|
| Data sequence      | 1                | 2              |
| Data signification | Starting address | Read registers |
| Byte count         | 2                | 2              |

| Response:          |                     |                   |
|--------------------|---------------------|-------------------|
| Data sequence      | 1                   | 2                 |
| Data signification | Loopback byte count | N - register data |
| Byte count         | 1                   | N                 |

## Function # 05 (05\_hex) – Force Single Coil

| Request:           |              |                          |
|--------------------|--------------|--------------------------|
| Data sequence      | 1            | 2                        |
| Data signification | Coil address | Forced single coil value |
| Byte count         | 2            | 2                        |

| Response:          |              |                   |
|--------------------|--------------|-------------------|
| Data sequence      | 1            | 2                 |
| Data signification | Coil address | Single coil value |
| Byte count         | 2            | 2                 |

## Function # 06 (06\_hex) – Preset Single Register

| Request:           |                  |                         |
|--------------------|------------------|-------------------------|
| Data sequence      | 1                | 2                       |
| Data signification | Register address | Register value (2-byte) |
| Byte count         | 2                | 2                       |

| Response:          |                  |                         |
|--------------------|------------------|-------------------------|
| Data sequence      | 1                | 2                       |
| Data signification | Register address | Register value (2-byte) |
| Byte count         | 2                | 2                       |

## 9.3.1.7 Error Check Code (CRC)

The Error Check Code allows the receiving device to detect a packet that has been corrupted with transmission errors. Sometimes, the transmission information occurs imperceptible changes due to electronic noise and other interference and the CRC code ensure the error information does not work to increase the system's safety and efficiency. When the CRC is appended to the message, the low-order byte is appended first, followed by the high-order byte.



*All information frame format are same:*

*address code, function code, data area and CRC code. The CRC field is two bytes, containing a 16-bit binary value. The CRC value is calculated by the transmitting device, which appends the CRC to the message. The receiving device recalculates a CRC during receipt of the message, and compares the calculated value to the actual value that received in the CRC field. If the two values are not equal, an error will result.*

The CRC is started by first preloading a 16-bit register to all 1's. Then a process begins of applying successive 8-bit bytes of the message to the current contents of the register. Only the eight bits of data in each character are used for generating the CRC. Start and stop bits do not apply to the CRC. During generation of the CRC, each 8-bit character is exclusive OR'ed with the register contents. Then the result is shifted in the direction of the least significant bit (LSB), with a zero filled into the most significant bit (MSB) position. The LSB is extracted and examined. If the LSB was a 1, the register is then exclusive OR'ed with a preset, fixed value. If the LSB was a 0, no exclusive OR takes place. This process is repeated until eight shifts have been performed. After the last (eighth) shift, the next 8-bit byte is exclusive OR'ed with the register's current value, and the process repeats for eight more shifts as described above. The final contents of the register, after all the bytes of the message have been applied, is the CRC value.

#### **A procedure for generating a CRC-16 is:**

1. ➤ Load a 16-bit register with FFFF hex (all 1's). Call this the CRC register.
2. ➤ Exclusive OR the first 8-bit byte of the message with the low-order byte of the 16-bit CRC register, putting the result in the CRC register. Shift the CRC register one bit to the right (toward the LSB), zero-filling the MSB. Extract and examine the LSB.
3. ➤ (If the LSB was 0): Repeat Step 3 (another shift).  
(If the LSB was 1): Exclusive OR the CRC register with the polynomial value A001 hex (1010 0000 0000 0001).
4. ➤ Repeat Steps 3 and 4 until 8 shifts have been performed. When this is done, a complete 8-bit byte will have been processed. Repeat Steps 2 through 5 for the next 8-bit byte of the message. Continue doing this until all bytes have been processed.
5. ➤ The final contents of the CRC register are the CRC value. Least Significant Byte first. When the 16-bit CRC (two 8-bit bytes) is transmitted in the message, the low-order byte will be transmitted first, followed by the high-order byte.



*The calculating of CRC code starts from [slave address] and except for all bytes of [CRC code].*

## Appendix

Data Telegrams &gt; Modbus Basics &gt; Error Check Code (CRC)

**Example: Read 3 holding registers @ Function Code 03\_hex (slave address 01\_hex, starting address 0026\_hex)**

| Address  | Data(Hex) |
|----------|-----------|
| 0026_hex | 14        |
| 0027_hex | 14        |
| 0028_hex | 5         |

| Request          | Bytes | Example (Hex)                             |
|------------------|-------|---|
| Slave address    | 1     | 01 Send to the slave 01                   |
| Function code    | 1     | 03 Read Holding Registers                 |
| Starting address | 2     | 00 Starting address is 0026_hex<br>26     |
| No. of Points    | 2     | 00 Read 3 registers (total 6 bytes)<br>03 |
| CRC code         | 2     | E4 CRC code which calculated by PC<br>00  |

| Response      | Bytes | Example (Hex)                               |
|---------------|-------|---|
| Slave address | 1     | 01 Respond to the slave 01                  |
| Function code | 1     | 03 Read register                            |
| Read count    | 1     | 06 3 registers (total 6 bytes)              |
| Data 1        | 2     | 00 The content of address 0026_hex<br>14    |
| Data 2        | 2     | 00 The content of address 0027_hex<br>14    |
| Data 3        | 2     | 00 The content of address 0028_hex<br>05    |
| CRC code      | 2     | 91 CRC code which calculated by slave<br>71 |

**Example: Read coil @ Function Code 05\_hex (slave address 01\_hex, starting address 0002\_hex is addressed as 1.)**

| Address | Data(Hex) |
|---------|-----------|
| 0000    | 0         |
| 0001    | 1         |
| 0002    | 0         |

| Request          | Bytes | Example (Hex)                                |
|------------------|-------|--|
| Slave address    | 1     | 01 Send to the slave 01                      |
| Function code    | 1     | 05 Force Single Coils                        |
| Starting address | 2     | FF Set coil as 1<br>00                       |
| Data             | 2     | 00 Read 3 registers<br>(total 6 bytes)<br>03 |
| CRC code         | 2     | CD CRC code which<br>calculated by PC<br>FB  |

| Response         | Bytes | Example (Hex)                                  |
|------------------|-------|--|
| Slave address    | 1     | 01 Respond to the<br>slave 01                  |
| Function code    | 1     | 05 Force Single Coils                          |
| Starting address | 2     | 00 Starting address is<br>0000_hex<br>00       |
| Data             | 2     | FF Set coil as 1<br>00                         |
| CRC code         | 2     | CD CRC code which<br>calculated by slave<br>FB |

## Appendix

Data Telegrams &gt; Modbus Basics &gt; Error Handling

**Example: Preset register as 0002\_hex @ Function Code 06\_hex (slave address 01\_hex, starting address 00E3\_hex)**

| Request          | Bytes | Example (Hex)                            |
|------------------|-------|--|
| Slave address    | 1     | 01 Send to the slave 01                  |
| Function code    | 1     | 06 Preset Single Register                |
| Starting address | 2     | 00 Starting address is 00E3_hex<br>E3    |
| Data             | 2     | 00 Preset Register Data (2 bytes)<br>02  |
| CRC code         | 2     | F9 CRC code which calculated by PC<br>FD |

| Response         | Bytes | Example (Hex)                               |
|------------------|-------|---|
| Slave address    | 1     | 01 Respond to the slave 01                  |
| Function code    | 1     | 06 Preset Single Register                   |
| Starting address | 2     | 00 Starting address is 00E3_hex<br>E3       |
| Data             | 2     | 00 Preset Register Data (2 bytes)<br>02     |
| CRC code         | 2     | F9 CRC code which calculated by slave<br>FD |

### 9.3.1.8 Error Handling

#### General Notes

When device detected other errors except the CRC code, the slave must send information to the master. The function code MSB is 1, which means the response function code by slave should add 128 based on the function code.

The following codes show that unexpected errors have occurred. CRC error received from the master will be ignored by the device.

The frame format of error code that responds by slave is as follows (CRC excluded):

|                     |                   |
|---------------------|-------------------|
| <b>Address code</b> | <b>1 byte</b>     |
| Function code       | 1 byte (MSB is 1) |
| Error code          | 1 byte            |
| CRC code            | 2 bytes           |



## Error codes

## 01 - illegal function code

The function code received in the query is NO allowed slave action

## 02 - illegal data address

The data address received in the query is NO allowed slave address

## 03 - illegal data value

A value contained in the query data field is NO allowed slave value

### 9.3.2 Read Holding Registers 03\_hex



*If an easYgen model does not support an information or detail, value will be empty.*

| Address | Items                             | Description        | Bytes Count |
|---------|-----------------------------------|--------------------|-------------|
| 0       | Common Alarm                      | 1 for active (LSB) | 1bit        |
|         | Common Shutdown                   | 1 for active       | 1bit        |
|         | Common Alarm                      | 1 for active       | 1bit        |
|         | Common Trip and Stop              | 1 for active       | 1bit        |
|         | Common Trip                       | 1 for active       | 1bit        |
|         | Common ELE Trip & Common Shutdown | 1 for active       | 1bit        |
|         | Reserved                          | 1 for active       | 1bit        |
|         | Reserved                          | 1 for active       | 1bit        |
|         | In Test Mode                      | 1 for active       | 1bit        |
|         | In Auto Mode                      | 1 for active       | 1bit        |
|         | In Manual Mode                    | 1 for active       | 1bit        |
|         | In Stop Mode                      | 1 for active       | 1bit        |
|         | Reserved                          | 1 for active       | 1bit        |
|         | Reserved                          | 1 for active       | 1bit        |
|         | Reserved                          | 1 for active       | 1bit        |
|         | Reserved                          | 1 for active (MSB) | 1bit        |
| 1       | Emergency Stop                    | 1 for active       | 1bit        |
|         | Over Speed                        | 1 for active       | 1bit        |
|         | Under Speed                       | 1 for active       | 1bit        |
|         | Loss of Speed Signal              | 1 for active       | 1bit        |
|         | Over Frequency                    | 1 for active       | 1bit        |
|         | Under Frequency                   | 1 for active       | 1bit        |
|         | Over Voltage                      | 1 for active       | 1bit        |
|         | Under Voltage                     | 1 for active       | 1bit        |

## Appendix

Data Telegrams &gt; Read Holding Registers 03\_...

| Address | Items                            | Description  | Bytes Count |
|---------|----------------------------------|--------------|-------------|
|         | Fail to Start                    | 1 for active | 1bit        |
|         | Over Current                     | 1 for active | 1bit        |
|         | Maintenance Due                  | 1 for active | 1bit        |
|         | ECU                              | 1 for active | 1bit        |
|         | Reverse Power Shutdown           | 1 for active | 1bit        |
|         | Over Power Shutdown              | 1 for active | 1bit        |
|         | Aux High Temp Shutdown           | 1 for active | 1bit        |
|         | Aux Low OP Shutdown              | 1 for active | 1bit        |
| 2       | ECU Com Fail Shutdown            | 1 for active | 1bit        |
|         | Reserved                         | 1 for active | 1bit        |
|         | Reserved                         | 1 for active | 1bit        |
|         | Reserved                         | 1 for active | 1bit        |
|         | Reserved                         | 1 for active | 1bit        |
|         | Negative Seq Current             | 1 for active | 1bit        |
|         | Earth Fault                      | 1 for active | 1bit        |
|         | Loss of Exciting                 | 1 for active | 1bit        |
|         | Temp Sensor Open                 | 1 for active | 1bit        |
|         | High Temp Shutdown               | 1 for active | 1bit        |
|         | Reserved                         | 1 for active | 1bit        |
|         | Reserved                         | 1 for active | 1bit        |
|         | Pressure Sensor Open             | 1 for active | 1bit        |
|         | Reserved                         | 1 for active | 1bit        |
|         | Low OP Shutdown                  | 1 for active | 1bit        |
|         | Reserved                         | 1 for active | 1bit        |
| 3       | Level Sensor Open                | 1 for active | 1bit        |
|         | Reserved                         | 1 for active | 1bit        |
|         | Reserved                         | 1 for active | 1bit        |
|         | Reserved                         | 1 for active | 1bit        |
|         | Flexible Sensor 1 Open           | 1 for active | 1bit        |
|         | Flexible Sensor 1 High           | 1 for active | 1bit        |
|         | Flexible Sensor 1 Low            | 1 for active | 1bit        |
|         | Reserved                         | 1 for active | 1bit        |
|         | Flexible Sensor 2 Open           | 1 for active | 1bit        |
|         | Flexible Sensor 2 High           | 1 for active | 1bit        |
|         | Flexible Sensor 2 Low            | 1 for active | 1bit        |
|         | Reserved                         | 1 for active | 1bit        |
|         | Reserved                         | 1 for active | 1bit        |
|         | Reserved                         | 1 for active | 1bit        |
|         | Reserved                         | 1 for active | 1bit        |
|         | Input Module2 Cylinder Temp High | 1 for active | 1bit        |
| 4       | Input Module1 Com Fail           | 1 for active | 1bit        |
|         | Input Module1 Venting Temp High  | 1 for active | 1bit        |

| Address                     | Items                           | Description                | Bytes Count  |
|-----------------------------|---------------------------------|----------------------------|--------------|
|                             | Input Module1 Sensor15 Open     | 1 for active               | 1bit         |
|                             | Input Module1 Sensor15 High     | 1 for active               | 1bit         |
|                             | Input Module1 Sensor15 Low      | 1 for active               | 1bit         |
|                             | Input Module1 Sensor16 Open     | 1 for active               | 1bit         |
|                             | Input Module1 Sensor16 High     | 1 for active               | 1bit         |
|                             | Input Module1 Sensor16 Low      | 1 for active               | 1bit         |
|                             | Input Module1 Sensor17 Open     | 1 for active               | 1bit         |
|                             | Input Module1 Sensor17 High     | 1 for active               | 1bit         |
|                             | Input Module1 Sensor17 Low      |                            |              |
|                             | Input Module1 Sensor18 Open     |                            |              |
|                             | Input Module1 Sensor18 High     |                            |              |
|                             | Input Module1 Sensor18 Low      |                            |              |
|                             | Input Module1 Sensor19 Open     |                            |              |
|                             | Input Module1 Sensor19 High     | 1 for active               | 1bit         |
|                             | 5                               | Input Module1 Sensor19 Low | 1 for active |
| Input Module1 Sensor20 Open |                                 | 1 for active               | 1bit         |
| Input Module1 Sensor20 High |                                 | 1 for active               | 1bit         |
| Input Module1 Sensor20 Low  |                                 | 1 for active               | 1bit         |
| Input Module1 Sensor21 Open |                                 | 1 for active               | 1bit         |
| Input Module1 Sensor21 High |                                 |                            |              |
| Input Module1 Sensor21 Low  |                                 |                            |              |
| Input Module1 Sensor22 Open |                                 |                            |              |
| Input Module1 Sensor22 High |                                 |                            |              |
| Input Module1 Sensor22 Low  |                                 |                            |              |
| Input Module1 Sensor23 Open |                                 |                            |              |
| Input Module1 Sensor23 High |                                 |                            |              |
| Input Module1 Sensor23 Low  |                                 |                            |              |
| Input Module1 Sensor24 Open |                                 |                            |              |
| Input Module1 Sensor24 High |                                 |                            |              |
| Input Module1 Sensor24 Low  |                                 |                            |              |
| 6                           | Input Module2 Com Fail          |                            |              |
|                             | Input Module2 Venting Temp High |                            |              |
|                             | Input Module2Sensor15 Open      |                            |              |
|                             | Input Module2 Sensor15 High     |                            |              |
|                             | Input Module2 Sensor15 Low      |                            |              |
|                             | Input Module2 Sensor16 Open     |                            |              |
|                             | Input Module2 Sensor16 High     |                            |              |
|                             | Input Module2 Sensor16 Low      |                            |              |
|                             | Input Module2 Sensor17 Open     |                            |              |

## Appendix

Data Telegrams &gt; Read Holding Registers 03\_...

| Address                     | Items                       | Description  | Bytes Count |
|-----------------------------|-----------------------------|--------------|-------------|
|                             | Input Module2 Sensor17 High |              |             |
|                             | Input Module2 Sensor17 Low  |              |             |
|                             | Input Module2 Sensor18 Open |              |             |
|                             | Input Module2 Sensor18 High |              |             |
|                             | Input Module2 Sensor18 Low  |              |             |
|                             | Input Module2 Sensor19 Open |              |             |
|                             | Input Module2 Sensor19 High |              |             |
| 7                           | Input Module2 Sensor19 Low  |              |             |
|                             | Input Module2 Sensor20 Open |              |             |
|                             | Input Module2 Sensor20 High |              |             |
|                             | Input Module2 Sensor20 Low  |              |             |
|                             | Input Module2 Sensor21 Open |              |             |
|                             | Input Module2 Sensor21 High |              |             |
|                             | Input Module2 Sensor21 Low  |              |             |
|                             | Input Module2 Sensor22 Open |              |             |
|                             | Input Module2 Sensor22 High |              |             |
|                             | Input Module2 Sensor22 Low  |              |             |
|                             | Input Module2 Sensor23 Open |              |             |
|                             | Input Module2 Sensor23 High |              |             |
|                             | Input Module2 Sensor23 Low  |              |             |
|                             | Input Module2 Sensor24 Open |              |             |
| Input Module2 Sensor24 High |                             |              |             |
| Input Module2 Sensor24 Low  |                             |              |             |
| 8                           | Aux Input 1 Shutdown        | 1 for active | 1bit        |
|                             | Aux Input 2 Shutdown        | 1 for active | 1bit        |
|                             | Aux Input 3 Shutdown        | 1 for active | 1bit        |
|                             | Aux Input 4 Shutdown        | 1 for active | 1bit        |
|                             | Aux Input 5 Shutdown        | 1 for active | 1bit        |
|                             | Aux Input 6 Shutdown        | 1 for active | 1bit        |
|                             | Aux Input 7 Shutdown        | 1 for active | 1bit        |
|                             | Reserved                    | 1 for active | 1bit        |
|                             | Reserved                    | 1 for active | 1bit        |
|                             | Reserved                    | 1 for active | 1bit        |
|                             | Reserved                    | 1 for active | 1bit        |
|                             | Reserved                    | 1 for active | 1bit        |
|                             | Reserved                    |              | 1bit        |
|                             | Reserved                    |              | 1bit        |
| Reserved                    |                             | 1bit         |             |

| Address                          | Items                    | Description | Bytes Count |
|----------------------------------|--------------------------|-------------|-------------|
|                                  | Reserved                 |             | 1bit        |
| 9                                | Reserved                 |             | 2Bytes      |
|                                  | Reserved                 |             |             |
|                                  | Reserved                 |             |             |
|                                  | Reserved                 |             |             |
|                                  | Reserved                 |             |             |
|                                  | Reserved                 |             |             |
|                                  | Reserved                 |             |             |
|                                  | Reserved                 |             |             |
|                                  | Reserved                 |             |             |
|                                  | Reserved                 |             |             |
|                                  | Reserved                 |             |             |
|                                  | Reserved                 |             |             |
|                                  | Reserved                 |             |             |
|                                  | Reserved                 |             |             |
|                                  | Reserved                 |             |             |
|                                  | 10                       | Reserved    |             |
| Reserved                         |                          |             |             |
| Expansion Switch Input Com Fail  |                          |             |             |
| Expansion Switch Output Com Fail |                          |             |             |
| Expansion Switch Input1          |                          |             |             |
| Expansion Switch Input2          |                          |             |             |
| Expansion Switch Input3          |                          |             |             |
| Expansion Switch Input4          |                          |             |             |
| Expansion Switch Input5          |                          |             |             |
| Expansion Switch Input6          |                          |             |             |
| Expansion Switch Input7          |                          |             |             |
| Expansion Switch Input8          |                          |             |             |
| Expansion Switch Input9          |                          |             |             |
| Expansion Switch Input10         |                          |             |             |
| Expansion Switch Input11         |                          |             |             |
| Expansion Switch Input12         |                          |             |             |
| 11                               | Expansion Switch Input13 |             |             |
|                                  | Expansion Switch Input14 |             |             |
|                                  | Expansion Switch Input15 |             |             |
|                                  | Expansion Switch Input16 |             |             |

## Appendix

Data Telegrams &gt; Read Holding Registers 03\_...

| Address  | Items  | Description  | Bytes Count |
|----------|--|--------------|-------------|
|          | Input Module1 Cylinder Temp Difference Large |              |             |
|          | Input Module1 Cylinder Temp High             |              |             |
|          | Input Module2 Cylinder Temp Difference Large |              |             |
|          | Input Module2 Cylinder Temp High             |              |             |
|          | Reserved                                     |              |             |
|          | Reserved                                     |              |             |
|          | Reserved                                     |              |             |
|          | Reserved                                     |              |             |
|          | Reserved                                     |              |             |
|          | Reserved                                     |              |             |
|          | Reserved                                     |              |             |
|          | Reserved                                     |              |             |
| 12       | Over Current ELE Trip                        | 1 for active | 1bit        |
|          | Maintenance Due ELE Trip                     | 1 for active | 1bit        |
|          | Reverse Power ELE Trip                       | 1 for active | 1bit        |
|          | Over Power ELE Trip                          | 1 for active | 1bit        |
|          | Input 1 ELE Trip                             | 1 for active | 1bit        |
|          | Input 2 ELE Trip                             | 1 for active | 1bit        |
|          | Input 3 ELE Trip                             | 1 for active | 1bit        |
|          | Input 4 ELE Trip                             | 1 for active | 1bit        |
|          | Input 5 ELE Trip                             | 1 for active | 1bit        |
|          | Input 6 ELE Trip                             | 1 for active | 1bit        |
|          | Input 7 ELE Trip                             | 1 for active | 1bit        |
|          | Input 8 ELE Trip                             | 1 for active | 1bit        |
|          | Reserved                                     | 1 for active | 1bit        |
|          | Reserved                                     | 1 for active | 1bit        |
|          | Expansion Switch Input Com Fail              | 1 for active | 1bit        |
|          | Expansion Switch Output Com Fail             | 1 for active | 1bit        |
|          | 13   | Reserved     |             |
| Reserved |  |              |             |
| Reserved |  |              |             |
| Reserved |  |              |             |
| Reserved |  |              |             |
| Reserved |  |              |             |
| Reserved |  |              |             |
| Reserved |  |              |             |
| Reserved |  |              |             |
| Reserved |  |              |             |
| Reserved |  |              |             |
| Reserved |  |              |             |

| Address                 | Items                    | Description | Bytes Count |
|-------------------------|--------------------------|-------------|-------------|
|                         | Reserved                 |             |             |
|                         | Reserved                 |             |             |
|                         | Reserved                 |             |             |
|                         | Reserved                 |             |             |
|                         | Reserved                 |             |             |
| 14                      | Reserved                 |             |             |
|                         | Reserved                 |             |             |
|                         | Reserved                 |             |             |
|                         | Reserved                 |             |             |
|                         | Reserved                 |             |             |
|                         | Reserved                 |             |             |
|                         | Expansion Switch Input1  |             |             |
|                         | Expansion Switch Input2  |             |             |
|                         | Expansion Switch Input3  |             |             |
|                         | Expansion Switch Input4  |             |             |
|                         | Expansion Switch Input5  |             |             |
|                         | Expansion Switch Input6  |             |             |
|                         | Expansion Switch Input7  |             |             |
|                         | Expansion Switch Input8  |             |             |
| Expansion Switch Input9 |                          |             |             |
| 15                      | Expansion Switch Input1  |             |             |
|                         | Expansion Switch Input11 |             |             |
|                         | Expansion Switch Input12 |             |             |
|                         | Expansion Switch Input13 |             |             |
|                         | Expansion Switch Input14 |             |             |
|                         | Expansion Switch Input15 |             |             |
|                         | Expansion Switch Input16 |             |             |
|                         | Reserved                 |             |             |
|                         | Reserved                 |             |             |
|                         | Reserved                 |             |             |
|                         | Reserved                 |             |             |
|                         | Reserved                 |             |             |
|                         | Reserved                 |             |             |
|                         | Reserved                 |             |             |
| Loss of Exciting        |                          |             |             |
| Earth Fault             |                          |             |             |
| Negative Seq Current    |                          |             |             |

## Appendix

Data Telegrams &gt; Read Holding Registers 03\_...

| Address | Items                            | Description  | Bytes Count |
|---------|----------------------------------|--------------|-------------|
| 16      | Over Current Trip                | 1 for active | 1bit        |
|         | Maintenance Due Trip             | 1 for active | 1bit        |
|         | Reverse Power Trip               | 1 for active | 1bit        |
|         | Over Power Trip                  | 1 for active | 1bit        |
|         | Input 1 Trip                     | 1 for active | 1bit        |
|         | Input 2 Trip                     | 1 for active | 1bit        |
|         | Input 3 Trip                     | 1 for active | 1bit        |
|         | Input 4 Trip                     | 1 for active | 1bit        |
|         | Input 5 Trip                     | 1 for active | 1bit        |
|         | Input 6 Trip                     | 1 for active | 1bit        |
|         | Input 7 Trip                     | 1 for active | 1bit        |
|         | Input 8 Trip                     | 1 for active | 1bit        |
|         | Reserved                         | 1 for active | 1bit        |
|         | Reserved                         | 1 for active | 1bit        |
|         | Expansion Switch Input Com Fail  | 1 for active | 1bit        |
|         | Expansion Switch Output Com Fail | 1 for active | 1bit        |
| 17      | PLC 1                            |              |             |
|         | PLC 2                            |              |             |
|         | PLC 3                            |              |             |
|         | PLC 4                            |              |             |
|         | PLC 5                            |              |             |
|         | PLC 6                            |              |             |
|         | PLC 7                            |              |             |
|         | PLC 8                            |              |             |
|         | PLC 9                            |              |             |
|         | PLC 10                           |              |             |
|         | PLC 11                           |              |             |
|         | PLC 12                           |              |             |
|         | PLC 13                           |              |             |
|         | PLC 14                           |              |             |
|         | PLC 15                           |              |             |
|         | PLC 16                           |              |             |
| 18      | PLC 17                           |              |             |
|         | PLC 18                           |              |             |
|         | PLC 19                           |              |             |
|         | PLC 20                           |              |             |
|         | Reserved                         |              |             |
|         | Reserved                         |              |             |
|         | Expansion Switch Input1          |              |             |



| Address              | Items                     | Description  | Bytes Count |
|----------------------|---------------------------|--------------|-------------|
|                      | Expansion Switch Input2   |              |             |
|                      | Expansion Switch Input3   |              |             |
|                      | Expansion Switch Input4   |              |             |
|                      | Expansion Switch Input5   |              |             |
|                      | Expansion Switch Input6   |              |             |
|                      | Expansion Switch Input7   |              |             |
|                      | Expansion Switch Input8   |              |             |
|                      | Expansion Switch Input9   |              |             |
|                      | Expansion Switch Input1   |              |             |
| 19                   | Expansion Switch Input11  |              | 2Bytes      |
|                      | Expansion Switch Input12  |              |             |
|                      | Expansion Switch Input13  |              |             |
|                      | Expansion Switch Input14  |              |             |
|                      | Expansion Switch Input15  |              |             |
|                      | Expansion Switch Input16  |              |             |
|                      | Reserved                  |              |             |
|                      | Reserved                  |              |             |
|                      | Reserved                  |              |             |
|                      | Reserved                  |              |             |
|                      | Reserved                  |              |             |
|                      | Reserved                  |              |             |
|                      | Reserved                  |              |             |
|                      | Loss of Exciting          |              |             |
|                      | Earth Fault               |              |             |
| Negative Seq Current |                           |              |             |
| Reserved             |                           |              |             |
| 20                   | Gen Over Speed Warn       | 1 for active | 1bit        |
|                      | Gen Under Speed Warn      | 1 for active | 1bit        |
|                      | Gen Loss Of Speed Warn    | 1 for active | 1bit        |
|                      | Gen Over Frequency Warn   | 1 for active | 1bit        |
|                      | Gen Under Frequency Warn  | 1 for active | 1bit        |
|                      | Gen Over Voltage Warn     | 1 for active | 1bit        |
|                      | Gen Under Voltage Warn    | 1 for active | 1bit        |
|                      | Gen Over Current Warn     | 1 for active | 1bit        |
|                      | Fail to Stop Warn         | 1 for active | 1bit        |
|                      | Charge Alt Fail Warn      | 1 for active | 1bit        |
|                      | Battery High Voltage Warn | 1 for active | 1bit        |
|                      | Battery Low Voltage Warn  | 1 for active | 1bit        |
|                      | Maintenance Due Warn      | 1 for active | 1bit        |
|                      | Reverse Power Warn        | 1 for active | 1bit        |

## Appendix

Data Telegrams &gt; Read Holding Registers 03\_...

| Address | Items                            | Description  | Bytes Count |
|---------|----------------------------------|--------------|-------------|
|         | Over Power Warn                  | 1 for active | 1bit        |
|         | ECU                              | 1 for active | 1bit        |
| 21      | Gen Loss of Phase Warn           | 1 for active | 1bit        |
|         | Gen Phase Seq Wrong              | 1 for active | 1bit        |
|         | Reserved                         | 1 for active | 1bit        |
|         | Negative Seq Current             | 1 for active | 1bit        |
|         | Earth Fault                      | 1 for active | 1bit        |
|         | Loss of Exciting                 | 1 for active | 1bit        |
|         | Reserved                         | 1 for active | 1bit        |
|         | Breaker Warn                     | 1 for active | 1bit        |
|         | Temp Sensor Open Warn            | 1 for active | 1bit        |
|         | High Temp Warn                   | 1 for active | 1bit        |
|         | Low Temp Warn                    | 1 for active | 1bit        |
|         | Reserved                         | 1 for active | 1bit        |
|         | Pressure Sensor Open Warn        | 1 for active | 1bit        |
|         | Reserved                         | 1 for active | 1bit        |
|         | Low OP Warn                      | 1 for active | 1bit        |
|         | Reserved                         | 1 for active | 1bit        |
| 22      | Level Sensor Open                | 1 for active | 1bit        |
|         | Reserved                         | 1 for active | 1bit        |
|         | Low Level Warn                   | 1 for active | 1bit        |
|         | Reserved                         | 1 for active | 1bit        |
|         | Flexible Sensor 1 Open Warn      | 1 for active | 1bit        |
|         | Flexible Sensor 1 High Warn      | 1 for active | 1bit        |
|         | Flexible Sensor 1 Low Warn       | 1 for active | 1bit        |
|         | Reserved                         | 1 for active | 1bit        |
|         | Flexible Sensor 2 Open Warn      | 1 for active | 1bit        |
|         | Flexible Sensor 2 High Warn      | 1 for active | 1bit        |
|         | Flexible Sensor 2 Low Warn       | 1 for active | 1bit        |
|         | Reserved                         | 1 for active | 1bit        |
|         | Reserved                         | 1 for active | 1bit        |
|         | Reserved                         | 1 for active | 1bit        |
|         | Reserved                         | 1 for active | 1bit        |
|         | Input Module2 Cylinder Temp High | 1 for active | 1bit        |
| 23      | Input Module1 Com Fail           |              |             |
|         | Input Module1 Venting Temp High  |              |             |
|         | Input Module1 Sensor15 Open      |              |             |
|         | Input Module1 Sensor15 High      |              |             |
|         | Input Module1 Sensor15 Low       |              |             |
|         | Input Module1 Sensor16 Open      |              |             |
|         | Input Module1 Sensor16 High      |              |             |

| Address | Items                           | Description | Bytes Count |
|---------|---------------------------------|-------------|-------------|
|         | Input Module1 Sensor16 Low      |             |             |
|         | Input Module1 Sensor17 Open     |             |             |
|         | Input Module1 Sensor17 High     |             |             |
|         | Input Module1 Sensor17 Low      |             |             |
|         | Input Module1 Sensor18 Open     |             |             |
|         | Input Module1 Sensor18 High     |             |             |
|         | Input Module1 Sensor18 Low      |             |             |
|         | Input Module1 Sensor19 Open     |             |             |
| 24      | Input Module1 Sensor19 High     |             |             |
|         | Input Module1 Sensor19 Low      |             |             |
|         | Input Module1 Sensor20 Open     |             |             |
|         | Input Module1 Sensor20 High     |             |             |
|         | Input Module1 Sensor20 Low      |             |             |
|         | Input Module1 Sensor21 Open     |             |             |
|         | Input Module1 Sensor21 High     |             |             |
|         | Input Module1 Sensor21 Low      |             |             |
|         | Input Module1 Sensor22 Open     |             |             |
|         | Input Module1 Sensor22 High     |             |             |
|         | Input Module1 Sensor22 Low      |             |             |
|         | Input Module1 Sensor23 Open     |             |             |
|         | Input Module1 Sensor23 High     |             |             |
|         | Input Module1 Sensor23 Low      |             |             |
|         | Input Module1 Sensor24 Open     |             |             |
|         | Input Module1 Sensor24 High     |             |             |
| 25      | Input Module1 Sensor24 Low      |             |             |
|         | Input Module2 Com Fail          |             |             |
|         | Input Module2 Venting Temp High |             |             |
|         | Input Module2Sensor15 Open      |             |             |
|         | Input Module2 Sensor15 High     |             |             |
|         | Input Module2 Sensor15 Low      |             |             |
|         | Input Module2 Sensor16 Open     |             |             |
|         | Input Module2 Sensor16 High     |             |             |
|         | Input Module2 Sensor16 Low      |             |             |
|         | Input Module2 Sensor17 Open     |             |             |
|         | Input Module2 Sensor17 High     |             |             |
|         | Input Module2 Sensor17 Low      |             |             |
|         | Input Module2 Sensor18 Open     |             |             |

## Appendix

Data Telegrams &gt; Read Holding Registers 03\_...

| Address                  | Items                            | Description  | Bytes Count |
|--------------------------|----------------------------------|--------------|-------------|
|                          | Input Module2 Sensor18 High      |              |             |
|                          | Input Module2 Sensor18 Low       |              |             |
|                          | Input Module2 Sensor19 Open      |              |             |
| 26                       | Input Module2 Sensor19 High      |              |             |
|                          | Input Module2 Sensor19 Low       |              |             |
|                          | Input Module2 Sensor20 Open      |              |             |
|                          | Input Module2 Sensor20 High      |              |             |
|                          | Input Module2 Sensor20 Low       |              |             |
|                          | Input Module2 Sensor21 Open      |              |             |
|                          | Input Module2 Sensor21 High      |              |             |
|                          | Input Module2 Sensor21 Low       |              |             |
|                          | Input Module2 Sensor22 Open      |              |             |
|                          | Input Module2 Sensor22 High      |              |             |
|                          | Input Module2 Sensor22 Low       |              |             |
|                          | Input Module2 Sensor23 Open      |              |             |
|                          | Input Module2 Sensor23 High      |              |             |
|                          | Input Module2 Sensor23 Low       |              |             |
|                          | Input Module2 Sensor24 Open      |              |             |
|                          | Input Module2 Sensor24 High      |              |             |
| 27                       | Reserved                         | 1 for active | 1bit        |
|                          | Expansion Switch Input Com Fail  | 1 for active | 1bit        |
|                          | Expansion Switch Output Com Fail | 1 for active | 1bit        |
|                          | Expansion Switch Input1          | 1 for active | 1bit        |
|                          | Expansion Switch Input2          | 1 for active | 1bit        |
|                          | Expansion Switch Input3          | 1 for active | 1bit        |
|                          | Expansion Switch Input4          | 1 for active | 1bit        |
|                          | Expansion Switch Input5          | 1 for active | 1bit        |
|                          | Expansion Switch Input6          | 1 for active | 1bit        |
|                          | Expansion Switch Input7          | 1 for active | 1bit        |
|                          | Expansion Switch Input8          | 1 for active | 1bit        |
|                          | Expansion Switch Input9          | 1 for active | 1bit        |
|                          | Expansion Switch Input10         | 1 for active | 1bit        |
|                          | Expansion Switch Input11         | 1 for active | 1bit        |
|                          | Expansion Switch Input12         | 1 for active | 1bit        |
| Expansion Switch Input13 | 1 for active                     | 1bit         |             |
| 28                       | Expansion Switch Input14         |              |             |
|                          | Expansion Switch Input15         |              |             |
|                          | Expansion Switch Input16         |              |             |
|                          | Reserved                         |              |             |

| Address          | Items  | Description      | Bytes Count  |      |
|------------------|--|------------------|--------------|------|
|                  | Reserved                                     |                  |              |      |
|                  | Reserved                                     |                  |              |      |
|                  | Reserved                                     |                  |              |      |
|                  | Reserved                                     |                  |              |      |
|                  | Reserved                                     |                  |              |      |
|                  | Reserved                                     |                  |              |      |
|                  | Reserved                                     |                  |              |      |
|                  | Input Module1 Cylinder Temp Difference Large |                  |              |      |
|                  | Input Module1 Cylinder Temp High             |                  |              |      |
|                  | Input Module2 Cylinder Temp Difference Large |                  |              |      |
|                  | Input Module2 Cylinder Temp High             |                  |              |      |
|                  | Reserved                                     |                  |              |      |
|                  | 29   | Aux Input 1 Warn | 1 for active | 1bit |
|                  |  | Aux Input 2 Warn | 1 for active | 1bit |
| Aux Input 3 Warn |  | 1 for active     | 1bit         |      |
| Aux Input 4 Warn |  | 1 for active     | 1bit         |      |
| Aux Input 5 Warn |  | 1 for active     | 1bit         |      |
| Aux Input 6 Warn |  | 1 for active     | 1bit         |      |
| Aux Input 7 Warn |  | 1 for active     | 1bit         |      |
| Aux Input 8 Warn |  | 1 for active     | 1bit         |      |
| Reserved         |  |                  | 1bit         |      |
| Reserved         |  |                  | 1bit         |      |
| Reserved         |  |                  | 1bit         |      |
| Reserved         |  |                  | 1bit         |      |
| Reserved         |  |                  | 1bit         |      |
| Reserved         |  |                  | 1bit         |      |
| Reserved         |  | 1bit             |              |      |
| 30               | Reserved                                     |                  | 1bit         |      |
|                  | Reserved                                     |                  | 1bit         |      |
|                  | Reserved                                     |                  | 1bit         |      |
|                  | Reserved                                     |                  | 1bit         |      |
|                  | Reserved                                     |                  | 1bit         |      |
|                  | Reserved                                     |                  | 1bit         |      |
|                  | Reserved                                     |                  | 1bit         |      |
|                  | Reserved                                     |                  | 1bit         |      |
|                  | Reserved                                     |                  | 1bit         |      |
|                  | Reserved                                     |                  | 1bit         |      |
|                  | Reserved                                     |                  | 1bit         |      |

## Appendix

Data Telegrams &gt; Read Holding Registers 03\_...

| Address | Items                       | Description  | Bytes Count |
|---------|-----------------------------|--------------|-------------|
|         | Reserved                    |              | 1bit        |
|         | Reserved                    |              | 1bit        |
|         | Reserved                    |              | 1bit        |
|         | Reserved                    |              | 1bit        |
|         | Reserved                    |              | 1bit        |
|         | Reserved                    |              | 1bit        |
| 31      | Reserved                    |              | 2Bytes      |
| 32      | Reserved                    |              | 2Bytes      |
| 33      | Reserved                    |              | 2Bytes      |
| 34      | Reserved                    |              | 2Bytes      |
| 35      | Emergency Stop Input Status | 1 for active | 1bit        |
|         | Digital Input 1 Status      | 1 for active | 1bit        |
|         | Digital Input 2 Status      | 1 for active | 1bit        |
|         | Digital Input 3 Status      | 1 for active | 1bit        |
|         | Digital Input 4 Status      | 1 for active | 1bit        |
|         | Digital Input 5 Status      | 1 for active | 1bit        |
|         | Digital Input 6 Status      | 1 for active | 1bit        |
|         | Digital Input 7 Status      | 1 for active | 1bit        |
|         | Digital Input 8 Status      | 1 for active | 1bit        |
|         | Reserved                    | 1 for active | 1bit        |
|         | Reserved                    | 1 for active | 1bit        |
|         | Reserved                    | 1 for active | 1bit        |
|         | Reserved                    | 1 for active | 1bit        |
|         | Reserved                    | 1 for active | 1bit        |
|         | Reserved                    | 1 for active | 1bit        |
| 36      | Reserved                    |              | 2Bytes      |
| 37      | Fuel Relay Output Status    | 1 for active | 1bit        |
|         | Start Relay Output Status   | 1 for active | 1bit        |
|         | Digital Output 1 Status     | 1 for active | 1bit        |
|         | Digital Output 2 Status     | 1 for active | 1bit        |
|         | Digital Output 3 Status     | 1 for active | 1bit        |
|         | Digital Output 4 Status     | 1 for active | 1bit        |
|         | Digital Output 5 Status     | 1 for active | 1bit        |
|         | Digital Output 6 Status     | 1 for active | 1bit        |
|         | Reserved                    | 1 for active | 1bit        |
|         | Reserved                    | 1 for active | 1bit        |
|         | Reserved                    | 1 for active | 1bit        |
|         | Reserved                    | 1 for active | 1bit        |
|         | Reserved                    | 1 for active | 1bit        |

| Address | Items                 | Description  | Bytes Count |
|---------|-----------------------|--------------|-------------|
|         | Reserved              | 1 for active | 1bit        |
|         | Reserved              | 1 for active | 1bit        |
|         | Reserved              | 1 for active | 1bit        |
| 38      | Reserved              |              | 2Bytes      |
| 39      | Reserved              |              | 2Bytes      |
| 40      | Reserved              |              | 2Bytes      |
| 41      | Reserved              |              | 2Bytes      |
| 42      | Reserved              |              | 2Bytes      |
| 43      | Mains OK              | 1 for active | 1bit        |
|         | Close Mains           | 1 for active | 1bit        |
|         | Generator OK          | 1 for active | 1bit        |
|         | Gen Closed            | 1 for active | 1bit        |
|         | Alarm Indicator       | 1 for active | 1bit        |
|         | Running Indicator     | 1 for active | 1bit        |
|         | Reserved              | 1 for active | 1bit        |
|         | Reserved              | 1 for active | 1bit        |
|         | Reserved              | 1 for active | 1bit        |
|         | Reserved              | 1 for active | 1bit        |
|         | Reserved              | 1 for active | 1bit        |
|         | Reserved              | 1 for active | 1bit        |
|         | Reserved              | 1 for active | 1bit        |
|         | Reserved              | 1 for active | 1bit        |
|         | Reserved              | 1 for active | 1bit        |
| 44      | Mains Abnormal        | 1 for active | 1bit        |
|         | Mains Over Voltage    | 1 for active | 1bit        |
|         | Mains Under Voltage   | 1 for active | 1bit        |
|         | Mains Over Freq       | 1 for active | 1bit        |
|         | Mains Under Freq      | 1 for active | 1bit        |
|         | Mains Loss of Phase   | 1 for active | 1bit        |
|         | Mains Phase Seq Wrong | 1 for active | 1bit        |
|         | Mains Inactive        | 1 for active | 1bit        |
|         | Reserved              | 1 for active | 1bit        |
|         | Reserved              | 1 for active | 1bit        |
|         | Reserved              | 1 for active | 1bit        |
|         | Reserved              | 1 for active | 1bit        |
|         | Reserved              | 1 for active | 1bit        |
|         | Reserved              | 1 for active | 1bit        |
|         | Reserved              | 1 for active | 1bit        |
| 45      | Aux Input 1 Active    | 1 for active | 1bit        |

## Appendix

Data Telegrams &gt; Read Holding Registers 03\_...

| Address | Items              | Description  | Bytes Count |
|---------|--------------------|--------------|-------------|
|         | Aux Input 2 Active | 1 for active | 1bit        |
|         | Aux Input 3 Active | 1 for active | 1bit        |
|         | Aux Input 4 Active | 1 for active | 1bit        |
|         | Aux Input 5 Active | 1 for active | 1bit        |
|         | Aux Input 6 Active | 1 for active | 1bit        |
|         | Aux Input 7 Active | 1 for active | 1bit        |
|         | Aux Input 8 Active | 1 for active | 1bit        |
|         | Reserved           | 1 for active | 1bit        |
|         | Reserved           | 1 for active | 1bit        |
|         | Reserved           | 1 for active | 1bit        |
|         | Reserved           | 1 for active | 1bit        |
|         | Reserved           | 1 for active | 1bit        |
|         | Reserved           | 1 for active | 1bit        |
|         | Reserved           | 1 for active | 1bit        |
|         | Reserved           | 1 for active | 1bit        |
| 46      | Reserved           |              | 2Bytes      |
| 47      | Reserved           |              | 2Bytes      |
| 48      | Reserved           |              | 2Bytes      |
| 49      | Reserved           |              | 2Bytes      |
| 50      | Reserved           |              | 2Bytes      |
| 51      | Reserved           |              | 2Bytes      |
| 52      | Reserved           |              | 2Bytes      |
| 53      | Reserved           |              | 2Bytes      |
| 54      | Reserved           |              | 2Bytes      |
| 55      | Mains UAB          |              | 2Bytes      |
| 56      | Mains UBC          |              | 2Bytes      |
| 57      | Mains UCA          |              | 2Bytes      |
| 58      | Mains UA           |              | 2Bytes      |
| 59      | Mains UB           |              | 2Bytes      |
| 60      | Mains UC           |              | 2Bytes      |
| 61      | Mains UA Phase     | Signed       | 2Bytes      |
| 62      | Mains UB Phase     | Signed       | 2Bytes      |
| 63      | Mains UC Phase     | Signed       | 2Bytes      |
| 64      | Mains Freq         | (*10)        | 2Bytes      |
| 65      | Reserved           |              | 2Bytes      |
| 66      | Reserved           |              | 2Bytes      |
| 67      | Reserved           |              | 2Bytes      |
| 68      | Reserved           |              | 2Bytes      |
| 69      | Reserved           |              | 2Bytes      |



| Address   | Items                  | Description   | Bytes Count |
|-----------|------------------------|---------------|-------------|
| 70        | Reserved               |               | 2Bytes      |
| 71        | Reserved               |               | 2Bytes      |
| 72        | Reserved               |               | 2Bytes      |
| 73        | Reserved               |               | 2Bytes      |
| 74        | Reserved               |               | 2Bytes      |
| 75        | Gen UAB                |               | 2Bytes      |
| 76        | Gen UBC                |               | 2Bytes      |
| 77        | Gen UCA                |               | 2Bytes      |
| 78        | Gen UA                 |               | 2Bytes      |
| 79        | Gen UB                 |               | 2Bytes      |
| 80        | Gen UC                 |               | 2Bytes      |
| 81        | Gen UA Phase           | Signed        | 2Bytes      |
| 82        | Gen UB Phase           | Signed        | 2Bytes      |
| 83        | Gen UC Phase           | Signed        | 2Bytes      |
| 84        | Gen Freq               | (*10)         | 2Bytes      |
| 85        | Reserved               | Signed        | 2Bytes      |
| 86        | Reserved               | Signed (*100) | 2Bytes      |
| 87        | Reserved               | Signed (*10)  | 2Bytes      |
| 88        | Reserved               | Signed (*10)  | 2Bytes      |
| 89        | Reserved               | Signed (*10)  | 2Bytes      |
| 90        | Reserved               | Signed (*10)  | 2Bytes      |
| 91        | Reserved               | Signed (*10)  | 2Bytes      |
| 92        | Reserved               | Signed (*10)  | 2Bytes      |
| 93        | Reserved               | Signed (*10)  | 2Bytes      |
| 94        | Reserved               |               | 2Bytes      |
| 95        | A-phase Current        | (*10)         | 2Bytes      |
| 96        | B-phase Current        | (*10)         | 2Bytes      |
| 97        | C-phase Current        | (*10)         | 2Bytes      |
| 98        | Earth Current          | (*10)         | 2Bytes      |
| 99        | Reserved               |               | 2Bytes      |
| 100       | Reserved               |               | 2Bytes      |
| 101       | Reserved               |               | 2Bytes      |
| 102       | Reserved               |               | 2Bytes      |
| 0103 0104 | A-phase Active Power   | Signed (*10)  | 4Bytes      |
| 0105 0106 | B-phase Active Power   | Signed (*10)  | 4Bytes      |
| 0107 0108 | C-phase Active Power   | Signed (*10)  | 4Bytes      |
| 0109 0110 | Total Active Power     | Signed (*10)  | 4Bytes      |
| 0111 0112 | A-phase Reactive Power | Signed (*10)  | 4Bytes      |
| 0113 0114 | B-phase Reactive Power | Signed (*10)  | 4Bytes      |
| 0115 0116 | C-phase Reactive Power | Signed (*10)  | 4Bytes      |

## Appendix

Data Telegrams &gt; Read Holding Registers 03\_...

| Address   | Items                            | Description    | Bytes Count |
|-----------|----------------------------------|----------------|-------------|
| 0117 0118 | Total Reactive Power             | Signed (*10)   | 4Bytes      |
| 0119 0120 | A-phase Apparent Power           | Signed (*10)   | 4Bytes      |
| 0121 0122 | B-phase Apparent Power           | Signed (*10)   | 4Bytes      |
| 0123 0124 | C-phase Apparent Power           | Signed (*10)   | 4Bytes      |
| 0125 0126 | Total Apparent Power             | Signed (*10)   | 4Bytes      |
| 127       | A-phase Power Factor             | Signed (*100)  | 2Bytes      |
| 128       | B-phase Power Factor             | Signed (*100)  | 2Bytes      |
| 129       | C-phase Power Factor             | Signed (*100)  | 2Bytes      |
| 130       | Average Power Factor             | Signed (*100)  | 2Bytes      |
| 131       | Reserved                         |                | 2Bytes      |
| 132       | Reserved                         |                | 2Bytes      |
| 133       | Reserved                         |                | 2Bytes      |
| 134       | Reserved                         |                | 2Bytes      |
| 135       | Reserved                         |                | 2Bytes      |
| 136       | Reserved                         |                | 2Bytes      |
| 137       | Reserved                         |                | 2Bytes      |
| 138       | Reserved                         |                | 2Bytes      |
| 139       | Reserved                         |                | 2Bytes      |
| 140       | Reserved                         |                | 2Bytes      |
| 141       | Engine Speed                     |                | 2Bytes      |
| 142       | Battery Voltage                  | (*10)          | 2Bytes      |
| 143       | Charger Voltage                  | (*10)          | 2Bytes      |
| 144       | GSM Signal strength              |                | 2Bytes      |
| 145       | Reserved                         |                | 2Bytes      |
| 146       | Reserved                         |                | 2Bytes      |
| 147       | Reserved                         |                | 2Bytes      |
| 148       | Temp Sensor Resistance Value     | Unsigned (*10) | 2Bytes      |
| 149       | Temp Sensor Value                | Signed         | 2Bytes      |
| 150       | Pressure Sensor Resistance Value | Unsigned (*10) | 2Bytes      |
| 151       | Pressure Sensor Value            | Signed         | 2Bytes      |
| 152       | Level Sensor Resistance Value    | Unsigned (*10) | 2Bytes      |
| 153       | Level Sensor Value               | Signed         | 2Bytes      |
| 154       | Config Sensor 1 Resistance Value | Unsigned (*10) | 2Bytes      |
| 155       | Config Sensor 1 Value            | Signed         | 2Bytes      |
| 156       | Config Sensor 2 Resistance Value | Unsigned (*10) | 2Bytes      |
| 157       | Config Sensor 2 Value            | Signed         | 2Bytes      |
| 158       | Reserved                         |                | 2Bytes      |
| 159       | Reserved                         |                | 2Bytes      |
| 160       | Reserved                         |                | 2Bytes      |

| Address | Items                  | Description  | Bytes Count |
|---------|------------------------|--|-------------|
| 161     | Reserved               |  | 2Bytes      |
| 162     | Coolant Level          | Signed; These items are<br>-Reserved if ECU is NOT used. | 2Bytes      |
| 163     | Oil Temperature        |  | 2Bytes      |
| 164     | Coolant Pressure       |  | 2Bytes      |
| 165     | Fuel Pressure          |  | 2Bytes      |
| 166     | Fuel Temperature       |  | 2Bytes      |
| 167     | Inlet Temperature      |  | 2Bytes      |
| 168     | Exhaust Temperature    |  | 2Bytes      |
| 169     | Turbo Pressure         |  | 2Bytes      |
| 170     | Fuel Consumption       |  | 2Bytes      |
| 171     | Total Fuel Consumption |  | 4Bytes      |
| 172     |                        |  |             |
| 173     | Reserved               |  | 2Bytes      |
| 174     | Reserved               |  | 2Bytes      |
| 175     | Reserved               |  | 2Bytes      |
| 176     | Reserved               |  | 2Bytes      |
| 177     | Reserved               |  | 2Bytes      |
| 178     | Reserved               |  | 2Bytes      |
| 179     | Reserved               |  | 2Bytes      |
| 180     | Reserved               |  | 2Bytes      |
| 181     | Reserved               |  | 2Bytes      |
| 182     | Reserved               |  | 2Bytes      |
| 183     | Reserved               |  | 2Bytes      |
| 184     | Reserved               |  | 2Bytes      |
| 185     | Reserved               |  | 2Bytes      |
| 186     | Reserved               |  | 2Bytes      |
| 187     | Reserved               |  | 2Bytes      |
| 188     | Reserved               |  | 2Bytes      |
| 189     | Gen Status             | Generator Status Form                                    | 2Bytes      |
| 190     | Gen Delay              |  | 2Bytes      |
| 191     | Remote Start Status    | Remote Start Status Form                                 | 2Bytes      |
| 192     | Remote Start Delay     |  | 2Bytes      |
| 193     | Breaker Status         | Breaker Status Form                                      | 2Bytes      |
| 194     | Transfer Rest          |  | 2Bytes      |
| 195     | Mains Status           | Mains Status Form  | 2Bytes      |
| 196     | Mains Delay            |  | 2Bytes      |
| 197     | Reserved               |  | 2Bytes      |

## Appendix

Data Telegrams &gt; Read Holding Registers 03\_...

| Address   | Items                          | Description                    | Bytes Count |
|-----------|--------------------------------|--------------------------------|-------------|
| 198       | Reserved                       |                                | 2Bytes      |
| 199       | Run Time (HH)                  |                                | 2Bytes      |
| 200       | Run Time (MM)                  |                                | 2Bytes      |
| 201       | Run Time (SS)                  |                                | 2Bytes      |
| 202       | Accumulated Start Times        |                                | 2Bytes      |
| 0203 0204 | Accumulated Energy kWh         |                                | 4Bytes      |
| 0205 0206 | Accumulated Energy kVarh       |                                | 4Bytes      |
| 0207 0208 | Accumulated Energy kVAh        |                                | 4Bytes      |
| 0209 0210 | Reserved                       |                                | 4Bytes      |
| 211       | Maintenance Remain Time (HH)   |                                | 2Bytes      |
| 212       | Maintenance Remain Time (MM)   |                                | 2Bytes      |
| 213       | Maintenance Remain Time (SS)   |                                | 2Bytes      |
| 214       | Reserved                       |                                | 2Bytes      |
| 215       | Reserved                       |                                | 2Bytes      |
| 216       | Reserved                       |                                | 2Bytes      |
| 217       | Model                          |                                | 2Bytes      |
| 218       | Software Version               | (*10)                          | 2Bytes      |
| 219       | Hardware Version               | (*10)                          | 2Bytes      |
| 220       | Issue Date (YY)                | Save the last two digits only. | 2Bytes      |
| 221       | Issue Date (MM)                |                                | 2Bytes      |
| 222       | Issue Date (DD)                |                                | 2Bytes      |
| 223       | Reserved                       |                                | 2Bytes      |
| 224       | Reserved                       |                                | 2Bytes      |
| 225       | Controller Current Time (YY)   | Save the last two digits only. | 2Bytes      |
| 226       | Controller Current Time (MM)   |                                | 2Bytes      |
| 227       | Controller Current Time (DD)   |                                | 2Bytes      |
| 228       | Controller Current Time (Week) |                                | 2Bytes      |
| 229       | Controller Current Time (HH)   |                                | 2Bytes      |
| 230       | Controller Current Time (MM)   |                                | 2Bytes      |
| 231       | Controller Current Time (SS)   |                                | 2Bytes      |
| 232       | Reserved                       |                                | 2Bytes      |
| 233       | Reserved                       |                                | 2Bytes      |
| 234       | Reserved                       |                                | 2Bytes      |
| 235       | Reserved                       |                                | 2Bytes      |
| 236       | Reserved                       |                                | 2Bytes      |
| 237       | Reserved                       |                                | 2Bytes      |
| 238       | Reserved                       |                                | 2Bytes      |

| Address | Items    | Description | Bytes Count |
|---------|----------|-------------|-------------|
| 239     | Reserved |             | 2Bytes      |
| 240     | Reserved |             | 2Bytes      |
| 241     | Reserved |             | 2Bytes      |
| 242     | Reserved |             | 2Bytes      |
| 243     | Reserved |             | 2Bytes      |
| 244     | Reserved |             | 2Bytes      |
| 245     | Reserved |             | 2Bytes      |
| 246     | Reserved |             | 2Bytes      |
| 247     | Reserved |             | 2Bytes      |
| 248     | Reserved |             | 2Bytes      |
| 249     | Reserved |             | 2Bytes      |
| 250     | Reserved |             | 2Bytes      |
| 251     | Reserved |             | 2Bytes      |
| 252     | Reserved |             | 2Bytes      |
| 253     | Reserved |             | 2Bytes      |
| 254     | Reserved |             | 2Bytes      |
| 255     | Reserved |             | 2Bytes      |
| 256     | Reserved |             | 2Bytes      |
| 257     | Reserved |             | 2Bytes      |
| 258     | Reserved |             | 2Bytes      |
| 259     | Reserved |             | 2Bytes      |
| 260     | Reserved |             | 2Bytes      |
| 261     | Reserved |             | 2Bytes      |
| 262     | Reserved |             | 2Bytes      |
| 263     | Reserved |             | 2Bytes      |
| 264     | Reserved |             | 2Bytes      |
| 265     | Reserved |             | 2Bytes      |
| 266     | Reserved |             | 2Bytes      |
| 267     | Reserved |             | 2Bytes      |
| 268     | Reserved |             | 2Bytes      |
| 269     | Reserved |             | 2Bytes      |
| 270     | Reserved |             | 2Bytes      |
| 271     | Reserved |             | 2Bytes      |
| 272     | Reserved |             | 2Bytes      |
| 273     | Reserved |             | 2Bytes      |
| 274     | Reserved |             | 2Bytes      |
| 275     | Reserved |             | 2Bytes      |

## Appendix

Data Telegrams &gt; Read Holding Registers 03\_...

| Address | Items    | Description | Bytes Count |
|---------|----------|-------------|-------------|
| 276     | Reserved |             | 2Bytes      |
| 277     | Reserved |             | 2Bytes      |
| 278     | Reserved |             | 2Bytes      |
| 279     | Reserved |             | 2Bytes      |
| 280     | Reserved |             | 2Bytes      |
| 281     | Reserved |             | 2Bytes      |
| 282     | Reserved |             | 2Bytes      |
| 283     | Reserved |             | 2Bytes      |
| 284     | Reserved |             | 2Bytes      |
| 285     | Reserved |             | 2Bytes      |
| 286     | Reserved |             | 2Bytes      |
| 287     | Reserved |             | 2Bytes      |
| 288     | Reserved |             | 2Bytes      |
| 289     | Reserved |             | 2Bytes      |
| 290     | Reserved |             | 2Bytes      |
| 291     | Reserved |             | 2Bytes      |
| 292     | Reserved |             | 2Bytes      |
| 293     | Reserved |             | 2Bytes      |
| 294     | Reserved |             | 2Bytes      |
| 295     | Reserved |             | 2Bytes      |
| 296     | Reserved |             | 2Bytes      |
| 297     | Reserved |             | 2Bytes      |
| 298     | Reserved |             | 2Bytes      |
| 299     | Reserved |             | 2Bytes      |
| 300     | Reserved |             | 2Bytes      |
| 301     | Reserved |             | 2Bytes      |
| 302     | Reserved |             | 2Bytes      |
| 303     | Reserved |             | 2Bytes      |
| 304     | Reserved |             | 2Bytes      |
| 305     | Reserved |             | 2Bytes      |
| 306     | Reserved |             | 2Bytes      |
| 307     | Reserved |             | 2Bytes      |
| 308     | Reserved |             | 2Bytes      |
| 309     | Reserved |             | 2Bytes      |
| 310     | Reserved |             | 2Bytes      |
| 311     | Reserved |             | 2Bytes      |
| 312     | Reserved |             | 2Bytes      |

### 9.3.3 Force Single Coil 05H\_hex



*If an easYgen model does not support an information or detail, value will be empty.*

| Address | Item                            | Description                  |
|---------|---------------------------------|------------------------------|
| 0       | Remote Start Key                | 1 for active                 |
| 1       | Remote Stop Key                 | 1 for active                 |
| 2       | Reserved                        | 1 for active                 |
| 3       | Remote Auto Key                 | 1 for active                 |
| 4       | Remote Manual Key               | 1 for active                 |
| 5       | Remote Mains Close/Open Key     | 1 for active                 |
| 6       | Remote Generator Close/Open Key | 1 for active                 |
| 7       | Remote Up Key                   | 1 for active                 |
| 8       | Remote Down Key                 | 1 for active                 |
| 9       | Remote Left Key                 | 1 for active                 |
| 10      | Remote Right Key                | 1 for active                 |
| 11      | Remote Confirm Key              | 1 for active                 |
| 12      | Remote Mute Key                 | 1 for active                 |
| 13      | Reserved                        | 1 for active                 |
| 14      | Reserved                        | 1 for active                 |
| 15      | Remote Fast Stop Key            | 1 for active                 |
| 16      | Reserved                        | 1 for active                 |
| 17      | Reserved                        | 1 for active                 |
| 18      | Reserved                        | 1 for active                 |
| 19      | Remote Output 1                 | 1 for active; 0 for inactive |
| 20      | Remote Output 2                 | 1 for active; 0 for inactive |
| 21      | Remote Output 3                 | 1 for active; 0 for inactive |
| 22      | Remote Output 4                 | 1 for active; 0 for inactive |
| 23      | Remote Output 5                 | 1 for active; 0 for inactive |
| 24      | Remote Output 6                 | 1 for active; 0 for inactive |
| 25      | Reserved                        | 1 for active                 |
| 26      | Reserved                        | 1 for active                 |
| 27      | Reserved                        | 1 for active                 |
| 28      | Reserved                        | 1 for active                 |

## Appendix

Data Telegrams &gt; Preset Single Register 06H... &gt; Remote Start Status

## 9.3.4 Preset Single Register 06H\_hex

## 9.3.4.1 Generator Status



*If an easYgen model does not support an information or detail, value will be empty.*

| No. | Items            | Description                     |
|-----|------------------|---------------------------------|
| 0   | At Rest          | This status has no –delay value |
| 1   | Pre-heating      |                                 |
| 2   | Fuel On          | This status has no –delay value |
| 3   | Cranking         |                                 |
| 4   | Crank Rest       |                                 |
| 5   | Safety On        |                                 |
| 6   | Start Idle       |                                 |
| 7   | Warming Up       |                                 |
| 8   | Waiting for Load | This status has no –delay value |
| 9   | Normal Running   | This status has no –delay value |
| 10  | Cooling Down     |                                 |
| 11  | Stop Idle        |                                 |
| 12  | ETS Hold         |                                 |
| 13  | Wait for Stop    |                                 |
| 14  | After Stop       |                                 |
| 15  | Failed to Stop   | This status has no –delay value |

## 9.3.4.2 Remote Start Status

| No. | Items       | Description                     |
|-----|-------------|---------------------------------|
| 0   | No Delay    | This status has no –delay value |
| 1   | Start Delay |                                 |
| 2   | Stop Delay  |                                 |



### 9.3.4.3 Breaker Status



*If an easYgen model does not support an information or detail, value will be empty.*

| No. | Items                 | Description                     |
|-----|-----------------------|---------------------------------|
| 0   | Load Off              | This status has no –delay value |
| 1   | Mains Closed          | This status has no –delay value |
| 2   | Gen Closed            | This status has no –delay value |
| 3   | Opening               |                                 |
| 4   | Transfer Rest         |                                 |
| 5   | Closing Mains         |                                 |
| 6   | Closing Gen           |                                 |
| 7   | Wait for Opened       | This status has no –delay value |
| 8   | Wait for Gen Closed   | This status has no –delay value |
| 9   | Wait for Mains Closed | This status has no –delay value |
| 10  | OK                    | This status has no –delay value |

### 9.3.4.3.1 Mains Status



*If an easYgen model does not support an information or detail, value will be empty.*

| No. | Items          | Description                     |
|-----|----------------|---------------------------------|
| 0   | Mains OK       | This status has no –delay value |
| 1   | Normal Delay   |                                 |
| 2   | Mains Abnormal | This status has no –delay value |
| 3   | Abnormal Delay |                                 |

## Appendix

Data Telegrams > Preset Single Register 06H... > Breaker Status

---

## 10 Glossary And List Of Abbreviations

|                  |  |
|------------------|--|
| <b>AM</b>        | AnalogManager  |
| <b>BDEW</b>      | German community of 1,800 companies represented by the German Association of Energy and Water Industries (Bundesverband der Energie- und Wasserwirtschaft)   |
| <b>CB</b>        | Circuit Breaker  |
| <b>CL</b>        | Code Level   |
| <b>CT</b>        | Current Transformer  |
| <b>DI</b>        | Discrete Input   |
| <b>DO</b>        | Discrete (Relay) Output  |
| <b>ECU</b>       | Engine Control Unit  |
| <b>FMI</b>       | Failure Mode Indicator   |
| <b>GAP</b>       | Graphical Application Programming (GAP™)   |
| <b>GCB</b>       | Generator Circuit Breaker  |
| <b>GCP</b>       | Woodward device series (Genset Control) - not preferred for new design!  |
| <b>GGB</b>       | Generator Group Breaker  |
| <b>GOV</b>       | (speed) Governor; rpm regulator  |
| <b>HMI</b>       | Human Machine Interface e.g., a front panel with display and buttons for interaction   |
| <b>I</b>         | Current  |
| <b>IOP</b>       | Islanded Operation in Parallel ("Islanded Parallel Operation")   |
| <b>LDSS</b>      | Load-Dependent Start/Stop operation  |
| <b>LM</b>        | LogicsManager©   |
| <b>LSG</b>       | Woodward device: Load Share Gateway (communication converter)  |
| <b>MCB</b>       | Mains Circuit Breaker  |
| <b>MFR</b>       | Woodward device series (multifunctional relays) - not preferred for new design!  |
| <b>MOP</b>       | Mains Operation in Parallel  |
| <b>MPU</b>       | Magnetic Pickup Unit   |
| <b>N.C.</b>      | Normally Closed (break) contact  |
| <b>N.O.</b>      | Normally Open (make) contact   |
| <b>NC</b>        | Neutral Contactor  |
| <b>OC</b>        | Occurrence Count   |
| <b>Operation</b> | In (general) operation.<br><br>State when the genset is running according to the selected mode, all parameters are in allowed values and ranges, and without OPEN requests or alarms. Somehow "waiting for next occurrence". |
| <b>P</b>         | Real power   |
| <b>P/N</b>       | Part Number  |
| <b>PF</b>        | Power Factor   |
| <b>PID</b>       | Proportional Integral Derivative controller  |

## Glossary And List Of Abbreviations

---

|                  |  |
|------------------|--|
| <b>PLC</b>       | Programmable Logic Control   |
| <b>PT</b>        | Potential (Voltage) Transformer  |
| <b>Q</b>         | Reactive power   |
| <b>S</b>         | Apparent power   |
| <b>S/N</b>       | Serial Number  |
| <b>Sequencer</b> | A sequencer file is carrying specific settings e.g. to enable communication with and/or control of an expansion module.<br>Such files can be prepared by Woodward. |
| <b>SPN</b>       | Suspect Parameter Number   |
| <b>V</b>         | Voltage  |

## 11 Index

### C

Contact person ..... 11

Customer Service ..... 11

### I

Intended use ..... 11, 20

### P

Personnel ..... 12

### S

Service ..... 11

Symbols

    in the instructions ..... 9

### U

Use ..... 11, 20

### W

Warranty ..... 11







Designed in Europe

**Woodward GmbH**

Handwerkstrasse 29

70565 Stuttgart

Germany

Phone +49 (0) 711 789 54-510

Fax +49 (0) 711 789 54-101

Stgt-Doku@woodward.com