

InteliLite 9

Controller for single gen-set applications

SW version 1.6.0

| | |
|---------------------------------|-----|
| 1 Document information | 4 |
| 2 System overview | 9 |
| 3 Applications overview | 14 |
| 4 Installation and wiring | 16 |
| 5 Controller setup | 55 |
| 6 Communication | 130 |
| 7 Technical data | 157 |
| 8 Appendix | 158 |

Table of contents

| | | | |
|--|-----------|--|-----------|
| 1 Document information | 4 | 4.2 Controller installation | 16 |
| 1.1 Clarification of Notation | 4 | 4.2.1 Dimensions | 16 |
| 1.2 About this New Features List | 4 | 4.2.2 Mounting | 17 |
| 1.3 Legal notice | 4 | 4.3 Terminal Diagram | 18 |
| 1.4 General warnings | 6 | 4.4 Recommended wiring | 19 |
| 1.4.1 Remote control and programing | 6 | 4.4.1 General | 20 |
| 1.4.2 SW and HW versions compatibility | 6 | 4.4.2 Grounding | 20 |
| 1.4.3 Dangerous voltage | 6 | 4.4.3 Power supply | 20 |
| 1.4.4 Adjust the setpoints | 6 | 4.4.4 Measurement wiring | 21 |
| 1.5 Functions and protections | 7 | 4.4.5 Magnetic pick-up | 41 |
| 1.6 Certifications and standards | 7 | 4.4.6 Binary inputs | 42 |
| 1.7 Document history | 7 | 4.4.7 Binary Outputs | 43 |
| 1.8 Symbols in this manual | 8 | 4.4.8 Emergency stop | 43 |
| | | 4.4.9 Analog inputs | 44 |
| 2 System overview | 9 | 4.4.10 CAN bus | 48 |
| 2.1 General description | 9 | 4.4.11 USB | 50 |
| 2.1.1 The key features of IntelliLite 9 | 9 | 4.4.12 Example of AMF Wiring | 51 |
| 2.2 True RMS measurement | 9 | 4.4.13 Example of MRS Wiring | 52 |
| 2.3 Configurability and monitoring | 9 | 4.5 Plug-in module installation | 53 |
| 2.3.1 Supported configuration and monitoring tools | 9 | 4.5.1 Installation | 53 |
| 2.3.2 Configuration parts | 10 | | |
| 2.4 PC Tools | 11 | 5 Controller setup | 55 |
| 2.4.1 IntelliConfig | 11 | 5.1 Default configuration | 55 |
| 2.4.2 WinScope | 11 | 5.1.1 Binary inputs AMF | 55 |
| 2.5 Plug-in Modules | 11 | 5.1.2 Binary outputs AMF | 55 |
| 2.5.1 CM-Ethernet | 11 | 5.1.3 Binary inputs MRS | 55 |
| 2.5.2 CM-4G-GPS | 12 | 5.1.4 Binary outputs MRS | 56 |
| 2.5.3 CM-GPRS | 12 | 5.1.5 Analog inputs | 56 |
| 2.5.4 CM-RS232-485 | 12 | 5.2 Controller configuration and PC tools connection | 56 |
| 2.5.5 EM-BIO8-EFCP | 13 | 5.2.1 USB | 56 |
| | | 5.2.2 RS232/RS485 | 57 |
| 3 Applications overview | 14 | 5.2.3 Ethernet | 59 |
| 3.1 AMF – Automatic Mains Failure Start | 14 | 5.3 Operator Guide | 61 |
| 3.2 MRS – Manual Remote Start | 14 | 5.3.1 Front panel elements | 61 |
| | | 5.3.2 Display screens and pages structure | 63 |
| 4 Installation and wiring | 16 | 5.3.3 Browsing alarms | 75 |
| 4.1 Package content | 16 | | |

| | | | |
|--|------------|--|------------|
| 5.3.4 Password | 76 | 6.1 PC | 130 |
| 5.3.5 Information screen | 82 | 6.1.1 Direct communication | 130 |
| 5.3.6 Language selection | 83 | 6.1.2 Remote communication | 132 |
| 5.3.7 Display contrast adjustment | 85 | 6.2 Connection to 3rd party systems | 143 |
| 5.4 Remote Display | 85 | 6.2.1 MODBUS-RTU, MODBUS/TCP | 143 |
| 5.4.1 General description | 85 | 7 Technical data | 157 |
| 5.4.2 IL3-RD Firmware installation | 85 | 8 Appendix | 158 |
| 5.4.3 Wiring | 86 | 8.1 Controller objects | 158 |
| 5.4.4 Interconnection variants | 86 | 8.1.1 List of controller objects types | 158 |
| 5.4.5 Connection process | 87 | 8.1.2 Setpoints | 158 |
| 5.4.6 Connection troubleshooting | 88 | 8.1.3 Values | 271 |
| 5.4.7 Function description | 88 | 8.1.4 Logical binary inputs | 307 |
| 5.4.8 Firmware compatibility | 89 | 8.1.5 Logical binary outputs | 329 |
| 5.5 Functions | 89 | 8.1.6 Logical analog inputs | 365 |
| 5.5.1 Start-stop sequence | 90 | 8.2 Alarms | 372 |
| 5.5.2 AMF sequence | 92 | 8.2.1 Alarm levels in the controller | 372 |
| 5.5.3 Operating Modes | 93 | 8.2.2 Alarms level 1 | 372 |
| 5.5.4 Engine start | 94 | 8.2.3 Alarms level 2 | 392 |
| 5.5.5 Stabilization | 97 | 8.2.4 Fail sensor and other types | 401 |
| 5.5.6 Connecting to load | 97 | 8.3 Modules | 403 |
| 5.5.7 MRS operation | 97 | 8.3.1 Plug-in modules | 403 |
| 5.5.8 AMF operation | 98 | 📄 back to Table of contents | |
| 5.5.9 Engine cool down and stop | 99 | | |
| 5.5.10 Alarm management | 99 | | |
| 5.5.11 History log | 105 | | |
| 5.5.12 Breaker control | 107 | | |
| 5.5.13 Exercise timer | 110 | | |
| 5.5.14 Service timers | 117 | | |
| 5.5.15 Additional running engine indications | 117 | | |
| 5.5.16 Voltage phase sequence detection | 117 | | |
| 5.5.17 Gen-set operation states | 118 | | |
| 5.5.18 Sensor curves | 120 | | |
| 5.5.19 Tier 4 Final | 121 | | |
| 5.5.20 Alternate configuration | 124 | | |
| 5.5.21 E-Stop | 124 | | |
| 5.5.22 ECU Frequency selection | 125 | | |
| 5.5.23 Cybernetic security | 126 | | |
| 6 Communication | 130 | | |

1 Document information

| | |
|--|---|
| 1.1 Clarification of Notation | 4 |
| 1.2 About this New Features List | 4 |
| 1.3 Legal notice | 4 |
| 1.4 General warnings | 6 |
| 1.5 Functions and protections | 7 |
| 1.6 Certifications and standards | 7 |
| 1.7 Document history | 7 |
| 1.8 Symbols in this manual | 8 |

 [back to Table of contents](#)

1.1 Clarification of Notation

Note: This type of paragraph calls the reader's attention to a notice or related theme.

IMPORTANT: This type of paragraph highlights a procedure, adjustment etc., which can cause a damage or improper function of the equipment if not performed correctly and may not be clear at first sight.

Example: This type of paragraph contains information that is used to illustrate how a specific function works.

1.2 About this New Features List

This manual contains important instructions for IntelliLite 9 controllers family that shall be followed during installation and maintenance of the controllers.

This manual provides general information how to install and operate IntelliLite 9 controllers.

This manual is dedicated for:

- > Operators of Gen-sets
- > Gen-set control panel builders
- > For everybody who is concerned with installation, operation and maintenance of the Gen-set

1.3 Legal notice

This End User's Guide/Manual as part of the Documentation is an inseparable part of ComAp's Product and may be used exclusively according to the conditions defined in the "END USER or Distributor LICENSE AGREEMENT CONDITIONS – COMAP CONTROL SYSTEMS SOFTWARE" (License Agreement) and/or in the "ComAp a.s. Global terms and conditions for sale of Products and provision of Services" (Terms) and/or in the "Standardní podmínky projektů komplexního řešení ke smlouvě o dílo, Standard Conditions for Supply of Complete Solutions" (Conditions) as applicable.

ComAp's License Agreement is governed by the Czech Civil Code 89/2012 Col., by the Authorship Act 121/2000 Col., by international treaties and by other relevant legal documents regulating protection of the intellectual properties (TRIPS).

The End User and/or ComAp's Distributor shall only be permitted to use this End User's Guide/Manual with ComAp Control System Registered Products. The Documentation is not intended and applicable for any other purpose.

Official version of the ComAp's End User's Guide/Manual is the version published in English. ComAp reserves the right to update this End User's Guide/Manual at any time. ComAp does not assume any responsibility for its use outside of the scope of the Terms or the Conditions and the License Agreement.

Licensed End User is entitled to make only necessary number of copies of the End User's Guide/Manual. Any translation of this End User's Guide/Manual without the prior written consent of ComAp is expressly prohibited!

Even if the prior written consent from ComAp is acquired, ComAp does not take any responsibility for the content, trustworthiness and quality of any such translation. ComAp will deem a translation equal to this End User's Guide/Manual only if it agrees to verify such translation. The terms and conditions of such verification must be agreed in the written form and in advance.

For more details relating to the Ownership, Extent of Permitted Reproductions Term of Use of the Documentation and to the Confidentiality rules please review and comply with the ComAp's License Agreement, Terms and Conditions available on www.comap-control.com.

Security Risk Disclaimer

Pay attention to the following recommendations and measures to increase the level of security of ComAp products and services.

Please note that possible cyber-attacks cannot be fully avoided by the below mentioned recommendations and set of measures already performed by ComAp, but by following them the cyber-attacks can be considerably reduced and thereby to reduce the risk of damage. ComAp does not take any responsibility for the actions of persons responsible for cyber-attacks, nor for any damage caused by the cyber-attack. However, ComAp is prepared to provide technical support to resolve problems arising from such actions, including but not limited to restoring settings prior to the cyber-attacks, backing up data, recommending other preventive measures against any further attacks.

Warning: Some forms of technical support may be provided against payment. There is no legal or factual entitlement for technical services provided in connection to resolving problems arising from cyber-attack or other unauthorized accesses to ComAp's Products or Services.

General security recommendations and set of measures

1. AccessCode

- Change the AccessCode BEFORE the device is connected to a network.
- Use a secure AccessCode – ideally a random string of 8 characters containing lowercase, uppercase letters and digits.
- For each device use a different AccessCode.

2. Password

- Change the password BEFORE the device enters a regular operation.
- Do not leave displays or PC tools unattended if an user, especially administrator, is logged in.

3. Controller Web interface

- The controller web interface at port TCP/80 is based on http, not https, and thus it is intended to be used only in closed private network infrastructures.
- Avoid exposing the port TCP/80 to the public Internet.

4. MODBUS/TCP

- The MODBUS/TCP protocol (port TCP/502) is an instrumentation protocol designed to exchange data between locally connected devices like sensors, I/O modules, controllers etc. From it's nature it does not contain any kind of security – neither encryption nor authentication. Thus it is intended to be used only in closed private network infrastructures.

- Avoid exposing the port TCP/502 to the public Internet.

5. SNMP

- The SNMP protocol (port UDP/161) version 1,2 is not encrypted. Thus it is intended to be used only in closed private network infrastructures.
- Avoid exposing the port UDP/161 to the public Internet.

Used Open Source Software: mBed-TLS

<https://www.mbed.com/en/development/software/mbed-tls/>

<http://www.apache.org/licenses/LICENSE-2.0>

Used Font: zpix-pixel-font

WEBLINK to the license conditions: <https://github.com/SolidZORO/zpax-pixel-font>

Copyright (c) [2019] [Jason Fung]

1.4 General warnings

1.4.1 Remote control and programming

Controller can be remotely controlled. In the event that maintenance of Gen-set has to be done, or controller has to be programmed, check the following points to ensure that the engine cannot be started or any other parts of the system cannot be effected.

To be sure:

- > Disconnect remote control
- > Disconnect binary outputs

1.4.2 SW and HW versions compatibility

Be aware to use proper combination of SW and HW versions.

1.4.3 Dangerous voltage

In no case touch the terminals for voltage and current measurement!
Always connect grounding terminals!
In any case do not disconnect controller CT terminals!



1.4.4 Adjust the setpoints

All parameters are adjusted to their typical values. However the setpoints has to be checked and adjusted to their real values before the first starting of the Gen-set.

IMPORTANT: Wrong adjustment of setpoints can destroy the Gen-set.

Note: The controller contains a large number of configurable setpoints, because of this it is impossible to describe all of its functions. Some functions can be changed or have different behavior in different SW versions. Always check the Global guide and New feature list for SW version which is used in controller. This manual only describes the product and is not guaranteed to be set for your application.

IMPORTANT: Be aware that the binary outputs can change state during and after software reprogramming (before the controller is used again ensure that the proper configuration and setpoint settings are set in the controller).

The following instructions are for qualified personnel only. To avoid personal injury do not perform any action not specified in related guides for product.




1.5 Functions and protections

Support of functions and protections as defined by ANSI (American National Standards Institute):

| Description | ANSI code | Description | ANSI code |
|--|-----------|---------------------------------|-----------|
| Master unit | 1 | Incomplete sequence relay | 48 |
| Stopping device | 5 | Overcurrent | 50/50TD |
| Multi-function device | 11 | Breaker failure | 50BF |
| Overspeed | 12 | Over voltage | 59 |
| Underspeed | 14 | Aux Over Voltage | 59X |
| Starting-to-running transition contactor | 19 | Pressure switch | 63 |
| Thermal relay | 26 | Liquid level switch | 71 |
| Undervoltage | 27 | Alarm relay** | 74 |
| Aux Battery Under Voltage | 27X | Overfrequency | 81O |
| Annunciator | 30 | Underfrequency | 81U |
| Overload | 32P | Auto selective control/transfer | 83 |
| Master sequence device | 34 | | |

** Extension module IGL-RA15 required


























































1.6 Certifications and standards

| | | |
|--|--|---|
| <ul style="list-style-type: none"> > EN 61000-6-2 > EN 61000-6-4 > EN 61010-1 > EN 60068-2-1 (-20 °C/16 h for std, -40 °C/16 h for LT version) > EN 60068-2-2 (70 °C/16 h) | <ul style="list-style-type: none"> > EN 60068-2-6 (2÷25 Hz / ±1,6 mm; 25÷100 Hz / 4.0 g) > EN 60068-2-27 (a=500 m/s²; T=6 ms) > EN 60068-2-30:2005 25/55°C, RH 95%, 48hours > EN 60529 (front panel IP65, back side IP20) > UL 6200 |    |
|--|--|---|

1.7 Document history

| Revision number | Related sw. version | Date | Author |
|-----------------|---------------------|------------|----------------|
| 4 | 1.6.0 | 27.12.2021 | Michal Slavata |
| 3 | 1.3.0 | 20.7.2020 | Michal Slavata |
| 2 | 1.1.0 | 12.9.2018 | Michal Slavata |
| 1 | 1.0.0 | 2.1.2017 | Daniel Švanda |

1.8 Symbols in this manual

| | | | | | | | |
|--|-----------------------|---|-----------------------|---|------------------------------|---|-------------------------------------|
|  3x | 3 x Phases |  | Connector - male |  | Grounding |  | Resistor adjustable |
|  | Active current sensor |  | Contact |  | GSM |  | Resistive sensor RPTC |
|  | AirGate |  | Contactor |  | GSM modem |  | RS 232 male |
|  | Alternating current |  | Controller simplified |  | IG-AVRi |  | RS 232 female |
|  | Analog modem |  | Module simplified |  | IG-AVRi TRANS |  | Starter |
|  | Battery |  | Current measuring |  | Jumper |  | Switch - manually operated |
|  | Binary output |  | Current measuring |  | Load |  | Transformer |
|  | Breaker contact |  | Diode |  | Mains |  | USB type B male |
|  | Breaker contact |  | Ethernet male |  | Mains |  | USB type B female |
|  | Breaker |  | Ethernet female |  | Mobile provider |  | Voltage measuring |
|  | Breaker |  | Fuel solenoid |  | Passive current sensor |  | Wifi / WAN / LAN |
|  | Breaker |  | Fuse |  | Pick - up |  | back to Document information |
|  | Capacitor |  | Fuse switch |  | Relay coil | | |
|  | Coil |  | Generator |  | Relay coil of slow-operating | | |
|  | Connector - female |  | Generator schematic |  | Resistor | | |

2 System overview

| | |
|--|----|
| 2.1 General description | 9 |
| 2.2 True RMS measurement | 9 |
| 2.3 Configurability and monitoring | 9 |
| 2.4 PC Tools | 11 |
| 2.5 Plug-in Modules | 11 |

▲ [back to Table of contents](#)

2.1 General description

InteliLite 9 Family controllers is comprehensive Gen-set controllers for single Gen-set operating in stand-by (MRS) or back-up (AMF) applications. A modular construction allows upgrades to different levels of complexity in order to provide the best solution for various customer applications.

2.1.1 The key features of InteliLite 9

- Easy-to-use operation and installation. The factory default configuration covers most applications
- Various customizations are possible thanks to its configurability
- Excellent remote communication capabilities
- High level of support for EFI engines (most world producers)
- High reliability

2.2 True RMS measurement

This controller measures AC values based on True RMS principle. This principle corresponds exactly to the physical definition of alternating voltage effective values. Under normal circumstances the voltage should have a pure sinusoidal waveform. However some nonlinear elements of load produce harmonic waveforms with frequencies of multiplies of the basic frequency and this may result in deformation of the voltage waveforms. The True RMS measurement gives accurate readings of effective values not only for pure sinusoidal waveforms, but also for deformed waveforms.

2.3 Configurability and monitoring

One of the key features of the controller is the system's high level of adaptability to the needs of each individual application and wide possibilities for monitoring. This can be achieved by configuring and using the powerful PC/mobile tools.

2.3.1 Supported configuration and monitoring tools

- IntelliConfig – complete configuration and single Gen-set monitoring
- WinScope – special graphical monitoring software

Note: Use the IntelliConfig PC software to read, view and modify configuration from the controller or disk and write the new configuration to the controller or disk.

The firmware of controller contains a large number of binary inputs and outputs needed for all necessary functions available. However, not all functions are required at the same time on the same Gen-set and also the controller hardware does not have so many input and output terminals. One of the main tasks of the

configuration is mapping of "logical" firmware inputs and outputs to the "physical" hardware inputs and outputs.

2.3.2 Configuration parts

- Mapping of logical binary inputs (functions) or assigning alarms to physical binary input terminals
- Mapping of logical binary outputs (functions) to physical binary output terminals
- Assigning sensor characteristics (curves) and alarms to analog inputs
- Selection of peripheral modules, which are connected to the controller, and doing the same (as mentioned above) for them
- Selection of ECU type, if an ECU is connected
- Changing the language of the controller interface




Image 2.1 Principle of binary inputs and outputs configuration

The controller is shipped with a default configuration, which should be suitable for most standard applications. This default configuration can be changed only by using a PC with the IntelliConfig software. See IntelliConfig documentation for details.

Once the configuration is modified, it can be saved to a file for later usage with another controller or for backup purposes. The file is called archive and has the file extension .ail3. An archive contains a full image of the controller at the time of saving (if the controller is online for the PC) except the firmware. Besides configuration it also contains current adjustment of all setpoints, all measured values, a copy of the history log and a copy of the alarm list.

The archive can be simply used for cloning controllers, i.e. preparing controllers with identical configuration and settings.

2.4 PC Tools

2.4.1 IntelliConfig

Configuration and monitoring tool for IntelliConfig controllers. See more in IntelliConfig Reference Guide.

This tool provides the following functions:

- Direct or internet communication with the controller
- Offline or online controller configuration
- Controller firmware upgrade
- Reading/writing/adjustment of setpoints
- Reading of measured values
- Browsing of controller history records
- Exporting data into a XLS file
- Controller language translation




2.4.2 WinScope

Special graphical controller monitoring software used mainly for commissioning and Gen-set troubleshooting. See more in the WinScope Reference guide.

This tool provides the following functions:

- Monitoring and archiving of ComAp controller's parameters and values
- View of actual / historical trends in controller
- On-line change of controllers' parameters for easy regulator setup




2.5 Plug-in Modules

2.5.1 CM-Ethernet

Internet/Ethernet module including web server.

- 10/100 Mbit ethernet interface in RJ45 socket
- Web interface for monitoring and adjustment of the controller
- Direct IP connection for remote access from IntelliConfig
- MODBUS/TCP and SNMP protocols for integration of the controller into building management systems or other remote monitoring purposes
- Sending of active emails




2.5.2 CM-4G-GPS

- Wireless integrated solution
- Quick and easy installation
- Instant alarm SMS notification
- System control over SMS
- Quad Band GPRS/EDGE modem, 850/900/1800/1900 MHz, FDD LTE: Band 1, Band 2, Band 3, Band 4, Band 5, Band 7, Band 8, Band 20, all bands with diversity, WCDMA/HSDPA/HSUPA/HSPA+: Band 1, Band 2, Band 5, Band 8, all bands with diversity



2.5.3 CM-GPRS


- Wireless integrated solution
- Quick and easy installation
- Instant alarm SMS notification
- System control over SMS
- Quad Band GPRS/EDGE modem, 850/900/1800/1900 MHz
- GPRS multi-slot class 10



2.5.4 CM-RS232-485

Communication module with two communication ports.

- RS232 and RS485 interface
- Modbus
- Serial connection to IntelliConfig



2.5.5 EM-BIO8-EFCP

Hybrid current input and binary input/output extension module.

- Up to 8 additional configurable binary inputs or outputs



⏪ back to System overview

3 Applications overview

3.1 AMF – Automatic Mains Failure Start 14
 3.2 MRS – Manual Remote Start 14

🔍 back to Table of contents

3.1 AMF – Automatic Mains Failure Start

The typical scheme of Automatic Mains Failure Start application is shown below. The controller controls two breakers – a mains breaker and a generator breaker. Feedback from both breakers isn't necessary. IntelliLite 9 controllers can also work without breaker feedbacks.




Image 3.1 AMF application overview

3.2 MRS – Manual Remote Start

The typical scheme of Manual Remote Start application is shown below. The controller controls one breaker – a generator breaker. Feedback from breaker isn't necessary. IntelliLite 9 controllers can also work without breaker feedback.




Image 3.2 MRS application overview

[back to Applications overview](#)

4 Installation and wiring

- 4.1 Package content 16
- 4.2 Controller installation 16
- 4.3 Terminal Diagram 18
- 4.4 Recommended wiring 19
- 4.5 Plug-in module installation 53

🔍 back to Table of contents

4.1 Package content


The package contains:

- > Controller
- > Mounting holders
- > Terminal blocks

Note: The package does not contain a communication or extension modules. The required modules should be ordered separately.

4.2 Controller installation


4.2.1 Dimensions



⊙ Plug-in module

Note: Dimension x depends on plug-in module

Note: Dimensions are in millimeters.




Note: Cutout is in millimeters.

4.2.2 Mounting

The controller is to be mounted onto the switchboard door. Requested cutout size is 172 × 112 mm. Use the screw holders delivered with the controller to fix the controller into the door as described on pictures below. Recommended torque for holders is 0.15 N·m.

Panel door mounting



Note: Cutout is in millimeters.

Note: Enclosure Type rating with mounting instruction – For use on a Flat surface of a type 1 enclosure.

4.3 Terminal Diagram

| ① POWER SUPPLY, D+ | | ② BINARY OUTPUTS | | ③ BINARY INPUTS | | ④ CAN | |
|--------------------|-------|------------------|-------|-----------------|---------|-------|---------|
| T01 | BATT- | T09 | ESTOP | T20 | RPM GND | T36 | CAN L |
| T02 | D+ | T10 | BOUT1 | T21 | RPM IN | T37 | CAN COM |
| T03 | BATT+ | T11 | BOUT2 | T22 | BIN1 | T38 | CAN H |
| | | T12 | BOUT3 | T23 | BIN2 | | |
| | | T13 | BOUT4 | T24 | BIN3 | | |
| | | T14 | BOUT5 | T25 | BIN4 | | |
| | | T15 | BOUT6 | T26 | BIN5 | | |
| | | | | T27 | BIN6 | | |





Image 4.1 Terminal diagram for Intelilite 9

| ⑤ ANALOG INPUTS | | ⑥ GENERATOR CURRENT MEASUREMENT | | ⑦ GENERATOR VOLTAGE MEASUREMENT | | ⑧ MAINS VOLTAGE MEASUREMENT | |
|-----------------|---------|---------------------------------|-----|---------------------------------|----|-----------------------------|----|
| T39 | AIN COM | T48 | COM | T53 | N | T61 | N |
| T40 | AIN1 | T49 | L1 | T55 | L1 | T63 | L1 |
| T41 | AIN2 | T50 | L2 | T57 | L2 | T65 | L2 |
| T42 | AIN3 | T51 | L3 | T59 | L3 | T67 | L3 |

4.4 Recommended wiring




| | | | |
|---|--------------------------|-------------|---|
| 1 | Power supply | "+", D, "-" | Power supply (page 20) |
| 2 | Binary outputs | 09 - 15 | Binary Outputs (page 43) Note: T09 is dedicated for <i>Emergency stop</i> (page 43) |
| 3 | Binary inputs | 22 - 27 | Binary inputs (page 42) |
| 4 | CAN bus | H, COM, L | CAN bus (page 48) |
| 5 | Analog inputs | 39 - 42 | Analog inputs (page 44) |
| 6 | Current inputs | 48 - 51 | Current measurement wiring (page 22) |
| 7 | Generator voltage inputs | 53 - 59 | Voltage measurement AMF wiring (page 26) Voltage measurement MRS wiring (page 34) |
| 8 | Mains voltage inputs | 61 - 67 | Voltage measurement AMF wiring (page 26) |
| 9 | USB | | USB (page 50) |

Note: Wiring terminal markings to included tightening torque: 0.5 N-m (4.5 lb-in)., and wire size: 2 mm² (12-26 AWG).

4.4.1 General

To ensure proper function:

- Use grounding terminals.
- Wiring for binary inputs and analog inputs must not be wired with power cables.
- Analog and binary inputs should be wired with shielded cables, especially when the length is more than 3 m.

| Tightening torque, allowable wire size and type, for the Field-Wiring Terminals: | |
|--|---|
| Example of used connectors: |  |
| For Mains and Generator Voltage, and for Current terminals: | Use only diameter 0.5 – 2.0 mm ² (AWG 12–26) conductor, rated for 90 °C minimum. |
| For other controller field wiring terminals: | Use only diameter 0.5 - 2.0 mm ² (AWG 12–26) conductor, rated for 75 °C minimum. |
| Specified tightening torque is 0.56 N·m (5.0 In-lb). | |
| Use copper conductors only. | |

4.4.2 Grounding

The shortest possible length of wire should be used for controller grounding. Use cable min. 2.5 mm².

The negative "-" battery terminal must be properly grounded.

Switchboard and engine must be grounded at common point. Use as short cable as possible to the grounding point.

4.4.3 Power supply

To ensure proper function:


- Use power supply cable min. 1.5 mm²

Maximum continuous DC power supply voltage is 36 V DC. The controller's power supply terminals are protected against large pulse power disturbances. When there is a potential risk of the controller being subjected to conditions outside its capabilities, an outside protection device should be used.

It is necessary to ensure that potential difference between generator current COM terminal and battery "-" terminal is maximally ±2 V. Therefore is strongly recommended to interconnect these two terminals together.

Note: The controller should be grounded properly in order to protect against lightning strikes. The maximum allowable current through the controller's negative terminal is 4 A (this is dependent on binary output load).

For the connections with 12 V DC power supply, the controller includes internal capacitors that allow the controller to continue in operation during cranking if the batter voltage dip occurs. If the voltage dip goes during cranking to 0 V and after 50 ms it recovers to 4 V, the controller continues operating. This cycle can repeat several times. During this voltage dip the controller screen backlight can turn off.



Note: Recommended fusing is 3 A fuse.

Note: In case of the dip to 0 V the high-side binary outputs will be temporarily switched off and after recovering to 4 V back on.

IMPORTANT: When the controller is power up only by USB and the USB is disconnected then the actual statistics can be lost.


Note: Suitable conductor protection shall be provided in accordance with NFPA 70, Article 240.

Note: Low voltage circuits (35 volts or less) shall be supplied from the engine starting battery or an isolated secondary circuit.

Note: It is also possible to further support the controller by connecting the external capacitor and separating diode. The capacitor size depends on required time. It shall be approximately thousands of μF . The capacitor size should be 5 000 μF to withstand 150 ms voltage dip under following conditions: Voltage before dip is 12 V, after 150 ms the voltage recovers to min. allowed voltage, i.e. 8 V. Diode should be able to withstand at least 1 kV.

Power supply fusing

Controller should never be connected directly to the starting battery. A 3 A fuse should be connected in-line with the battery positive terminal to the controller and CAN modules. Fuse value and type depends on number of connected devices and wire length. Recommended fuse (not fast) type – T3 A. Not fast due to internal capacitors charging during power up.



Note: Recommended fusing is 3 A fuse.

4.4.4 Measurement wiring

Use 1.5 mm² cables for voltage connection and 2.5 mm² for current transformers connection. Adjust Connection type (page 165), Nominal Voltage Ph-N (page 166), Nominal Voltage Ph-Ph (page 167), Nominal Current (page 163), PT Ratio (page 167), Vm PT Ratio (page 167) and CT Ratio (page 164) by appropriate setpoints in the Basic Settings group.

IMPORTANT: Risk of personal injury due to electric shock when manipulating voltage terminals under voltage. Be sure the terminals are not under voltage before touching them.
Do not open the secondary circuit of current transformers when the primary circuit is closed.
Open the primary circuit first.

CT Location




Image 4.2 CT Location

There are three options of CT location.

- > Load
- > Gen-set
- > None

Note: The current measurement protections are active only when the Gen-set is running.

If the CT Location is set to Load the **Short Circuit BOC (page 208)** protection is enabled only when GCB is closed.

Current measurement wiring

The number of CT's is automatically selected based on selected value of setpoint **Connection type (page 165)** [3Ph4Wire / High Leg D / 3Ph3Wire / SplPhL1L2 / SplPhL1L3 / Mono Ph].

Generator currents and power measurement is suppressed if current level is below $<1\%$ of CT range.

To ensure proper function:

- > Use cables of 2.5 mm^2
- > Use transformers to 5 A
- > Connect CT according to following drawings:

3 phase application




Image 4.3 3 phase application

IMPORTANT: It is necessary to ensure that potential difference between current COM terminal and power supply "-" terminal is maximally ± 2 V. To do so ground properly both terminals.




Image 4.4 3 phase application

IMPORTANT: It is necessary to ensure that potential difference between current COM terminal and power supply "-" terminal is maximally ± 2 V. To do so interconnect these two terminals.

Note: This wiring is recommended for India market.

SpIPL1L2 application




Image 4.5 Split phase application

IMPORTANT: It is necessary to ensure that potential difference between current COM terminal and power supply "-" terminal is maximally ± 2 V. To do so ground properly both terminals.




Image 4.6 3 phase application

IMPORTANT: It is necessary to ensure that potential difference between current COM terminal and power supply "-" terminal is maximally ± 2 V. To do so interconnect these two terminals.

Note: This wiring is recommended for India market.

SpIPL1L3 application




Image 4.7 Split phase application

IMPORTANT: The second phase of split phase connection is connected to the terminal, where is normally connected the third phase.

IMPORTANT: It is necessary to ensure that potential difference between current COM terminal and power supply "-" terminal is maximally ± 2 V. To do so ground properly both terminals.




Image 4.8 3 phase application

IMPORTANT: The second phase of split phase connection is connected to the terminal, where is normally connected the third phase.

IMPORTANT: It is necessary to ensure that potential difference between current COM terminal and power supply "-" terminal is maximally ± 2 V. To do so interconnect these two terminals.

Note: This wiring is recommended for India market.

Mono phase application

Connect CT according to following drawings. Terminals phase 2 and phase 3 are opened.




Image 4.9 Mono phase application

IMPORTANT: It is necessary to ensure that potential difference between current COM terminal and power supply "-" terminal is maximally ± 2 V. To do so ground properly both terminals.




Image 4.10 3 phase application

IMPORTANT: It is necessary to ensure that potential difference between current COM terminal and power supply "-" terminal is maximally ± 2 V. To do so interconnect these two terminals.

Note: This wiring is recommended for India market.

Voltage measurement AMF wiring

There are 4 voltage measurement Connection Type (setpoint **Connection type (page 165)** [3Ph4Wire / High Leg D / 3Ph3Wire / SpIPhL1L2 / SpIPhL1L3 / Mono Ph] options, every type matches to corresponding generator connection type.

Note: For fusing of voltage measurement input use T1A or T2A fuse.

The generator protections are evaluated from different voltages based on **Connection type (page 165)** setting:

- > 3Ph 4W – Ph-Ph voltage, Ph-N voltage
- > High Leg D – Ph-Ph voltage
- > 3Ph 3W – Ph-Ph voltage
- > SpIPhL1L2 – Ph-N voltage
- > SpIPhL1L3 – Ph-N voltage
- > Mono Ph – Ph-N voltage

ConnectionType: 3 Phase 4 Wires




Image 4.11 3 phase application with neutral

Note: Fuse on "N" wire is not obligatory but recommended.




Image 4.12 Typical 3 Phase 4 Wires generator wiring

ConnectionType: High Leg D




Image 4.13 High Leg Delta application

Note: Fuse on "N" wire is not obligatory but recommended.




Image 4.14 Typical High Leg D generator wiring

ConnectionType: 3 Phase 3 Wires




Image 4.15 3 phase application without neutral

Note: Fuse on "N" wire is not obligatory but recommended.




Image 4.16 Typical 3 Phase 3 Wires generator wiring

ConnectionType: SpIPhL1L2




Image 4.17 Split phase L1L2 application

Note: Fuse on "N" wire is not obligatory but recommended.

DOUBLE DELTA Connection




Image 4.18 Typical Split Phase generator wiring

ZIG ZAG (DOG LEG) Connection




Image 4.19 Typical Split Phase generator wiring

ConnectionType: SpIPhL1L3




Image 4.20 Split phase L1L3 application

Note: Fuse on "N" wire is not obligatory but recommended.

IMPORTANT: The second phase of split phase connection is connected to the terminal, where is usually connected the third phase.

DOUBLE DELTA Connection




Image 4.21 Typical Split Phase generator wiring

ZIG ZAG (DOG LEG) Connection




Image 4.22 Typical Split Phase generator wiring

ConnectionType: Mono Phase




Image 4.23 Mono phase application

Note: Fuse on "N" wire is not obligatory but recommended.




Image 4.24 Typical Mono Phase generator wiring

Voltage measurement MRS wiring

There are 4 voltage measurement Connection Type (setpoint **Connection type (page 165)** [3Ph4Wire / High Leg D / 3Ph3Wire / SpIPhL1L2 / SpIPhL1L3 / Mono Ph] options, every type matches to corresponding generator connection type.

Note: For fusing of voltage measurement input use T1A or T2A fuse.

The generator protections are evaluated from different voltages based on **Connection type (page 165)** setting:

- > 3Ph 4W – Ph-Ph voltage, Ph-N voltage
- > High Leg D – Ph-Ph voltage
- > 3Ph 3W – Ph-Ph voltage
- > SpIPhL1L2 – Ph-N voltage
- > SpIPhL1L3 – Ph-N voltage
- > Mono Ph – Ph-N voltage

ConnectionType: 3 Phase 4 Wires




Image 4.25 3 phase application with neutral

Note: Fuse on "N" wire is not obligatory but recommended.




Image 4.26 Typical 3 Phase 4 Wires generator wiring

ConnectionType: High Leg D




Image 4.27 High Leg Delta application

Note: Fuse on "N" wire is not obligatory but recommended.




Image 4.28 Typical High Leg D generator wiring

ConnectionType: 3 Phase 3 Wires




Image 4.29 3 phase application without neutral

Note: Fuse on "N" wire is not obligatory but recommended.




Image 4.30 Typical 3 Phase 3 Wires generator wiring

ConnectionType: SpIPhL1L2




Image 4.31 Split phase L1L2 application

Note: Fuse on "N" wire is not obligatory but recommended.

DOUBLE DELTA Connection




Image 4.32 Typical Split Phase generator wiring

ZIG ZAG (DOG LEG) Connection




Image 4.33 Typical Split Phase generator wiring

ConnectionType: SpIPhL1L3




Image 4.34 Split phase L1L3 application

Note: Fuse on "N" wire is not obligatory but recommended.

IMPORTANT: The second phase of split phase connection is connected to the terminal, where is usually connected the third phase.

DOUBLE DELTA Connection




Image 4.35 Typical Split Phase generator wiring

ZIG ZAG (DOG LEG) Connection




Image 4.36 Typical Split Phase generator wiring

ConnectionType: Mono Phase




Image 4.37 Mono phase application

Note: Fuse on "N" wire is not obligatory but recommended.





Image 4.38 Typical Mono Phase generator wiring

4.4.5 Magnetic pick-up

A magnetic speed sensor (pickup) is the most common method of engine speed measurement. To use this method, mount the pickup opposite to the engine flywheel, connect the cable to the controller as shown on the picture below and adjust the setpoint **Gear Teeth (page 168)** according to the number of teeth on the flywheel.

For the details about the pick-up input parameters see **Technical data on page 157**

IMPORTANT: To ensure proper function use a shielded cable.



If engine will not start:

- > Check ground connection from pick-up to controllers, eventually disconnect ground connection to one of them.

Note: In some cases the controller will measure a RPM value even though the gen-set is not running: RPM is measured from the generator voltage (Gear Teeth = 0). Controller is measuring some voltage value on input terminals due to open fusing. If RPM > 0 the controller will be put into a Not ready state and the engine will not be allowed to start.

4.4.6 Binary inputs

Use minimally 1 mm² cables for wiring of Binary inputs.




Image 4.39 Wiring binary inputs

Note: The name and function or alarm type for each binary input have to be assigned during the configuration.

4.4.7 Binary Outputs

Use min. 1 mm² cables for wiring of binary outputs. Use external relays as indicated on the schematic below for all outputs except those where low-current loads are connected (signalization etc...).

IMPORTANT: Use suppression diodes on all relays and other inductive loads!





Image 4.40 Binary outputs wiring

Note: Every single low current binary output can provide up to 0.5 A of steady current.

Note: Binary output 1 (terminal 10) and binary output 2 (terminal 11) are high current outputs (5 A for long term).

IMPORTANT: When operating temperature is higher than 60 °C it is strongly recommended to limit output current of high current binary outputs (terminal 10 and terminal 11) to 4 A (each).



4.4.8 Emergency stop

E-Stop has dedicated terminal T09. Power supply of binary output 1 (terminals 10) and binary output 2 (terminals 11) is internally connected (in controller) to E-Stop terminal. It means higher security and faster disconnection of these outputs. More information about E-Stop functions **see E-Stop on page 124**.

Note: This function has the same behavior as binary input **EMERGENCY STOP (PAGE 319)**.




Image 4.41 E-Stop wiring

Note: Recommended fusing is 12 A fuse.

Note: Grey dashed line symbolizes internal connection between E-Stop and binary outputs 1 and 2.

Note: For proper functionality of E-Stop, the terminal T09 must be always wired. Terminal can be connected to battery+ or to terminal T03 (BATT+)

IMPORTANT: Suppression diodes are not indicated, but required.

4.4.9 Analog inputs

The analog inputs are designed for resistive automotive type sensors like VDO or DATCON. The sensors are connected either by one wire (the second pole is the sensor body) or by two wires.

- In the case of grounded sensors, connect the AI COM terminal to the engine body as near to the sensors as possible.
- In the case of isolated sensors, connect the AI COM terminal to the negative power supply terminal of the controller as well as one pole of each sensor.

Analog inputs are typically used for: Oil Pressure, Coolant Temperature and Fuel Level. All of these parameters are connected with relevant protections.




Image 4.42 Grounded sensors




Image 4.43 Isolated sensors

Note: Schemes show only analog input connection overview, not actual wiring.

Note: The name, sensor characteristic and alarm types for each analog input have to be assigned during configuration.

Analog inputs with voltage & current sensors

On each analog input, there is a possibility to connect voltage or current output sensor instead of resistive one. Recommended wiring connection for these measurements and recommended curves are bellow.

Voltage sensors

| Sensor's output range (V) | R1 (Ω) | R2 (Ω) |
|---------------------------|-----------------|-----------------|
| 0 - 10 | 390 | 100 |
| 0 - 30 | 1500 | 100 |
| 0 - 70 | 3300 | 100 |




Image 4.44 Wiring of analog input with voltage sensor

| 0 – 10 V | | | | | | | | | | | |
|----------|----|----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| V | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 |
| Ω | 80 | 98 | 119 | 143 | 172 | 208 | 251 | 306 | 378 | 474 | 611 |

| 0 – 30 V | | | | | | | | |
|----------|-----|-----|-----|-----|-----|-----|-----|-----|
| V | 0 | 2 | 4 | 6 | 8 | 10 | 12 | 14 |
| Ω | 94 | 105 | 118 | 131 | 147 | 163 | 182 | 202 |
| V | 16 | 18 | 20 | 22 | 24 | 26 | 28 | 30 |
| Ω | 226 | 252 | 282 | 317 | 358 | 405 | 463 | 533 |

| 0 – 70 V | | | | | | | | | | | | |
|----------|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| V | 0 | 2 | 4 | 6 | 8 | 10 | 12 | 14 | 16 | 18 | 20 | 22 |
| Ω | 97 | 102 | 108 | 114 | 120 | 126 | 133 | 140 | 147 | 154 | 162 | 170 |
| V | 24 | 26 | 28 | 30 | 32 | 34 | 36 | 38 | 40 | 42 | 44 | 46 |
| Ω | 179 | 188 | 198 | 208 | 219 | 231 | 243 | 256 | 269 | 284 | 300 | 316 |
| V | 48 | 50 | 52 | 54 | 56 | 58 | 60 | 62 | 64 | 66 | 68 | 70 |
| Ω | 334 | 354 | 375 | 398 | 422 | 449 | 479 | 511 | 547 | 587 | 631 | 681 |

Note: This is a conversion of voltage from voltage sensor to appropriate resistance value. Use resistance values in IntelliConfig to create your specific curve. These values should be used in "Ohm" column.

Current sensors

| Sensor's output range (mA) | R (Ω) |
|----------------------------|-------|
| 0-20 | 100 |




Image 4.45 Wiring of analog input with current sensor

| 0 – 22 mA | | | | | | | | | | | | |
|-----------|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| mA | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 |
| Ω | 100 | 110 | 120 | 130 | 141 | 154 | 168 | 182 | 198 | 216 | 235 | 256 |
| mA | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | |
| Ω | 280 | 306 | 336 | 370 | 409 | 453 | 505 | 566 | 640 | 730 | 842 | |

Note: This is a conversion of current from current sensor to appropriate resistance value. Use resistance values in IntelliConfig to create your specific curve. These values should be used in "Ohm" column.

Analog as binary or tristate inputs

Analog inputs can be used also as binary or tri-state, i.e. for contact sensors without or with circuit check. The threshold level is 750 Ω. In the case of tri-state, values lower than 10 Ω and values over 2400 Ω are evaluated as sensor failure (short or open circuit).




Image 4.46 Analog inputs as tristate




Image 4.47 Analog inputs as binary

Note: The name, sensor characteristic and alarm types for each analog input have to be assigned during configuration.

Note: Tristate and binary sensors are not suitable for Analog Switch functions.

4.4.10 CAN bus

CAN bus wiring

The wiring of the CAN bus should be provided in such a way that the following rules are observed:

- The maximum length of the CAN bus depends on the communication speed. For a speed of 250 kbps, which is used on the CAN1 bus (, ECU), the maximum length is 200 m.
- The bus must be wired in linear form with termination resistors at both ends. No nodes are allowed except on the controller terminals.
- Shielded cable¹ has to be used, shielding has to be connected to the terminal T01 (Grounding).
- External units can be connected on the CAN bus line in any order, but keeping line arrangement (no tails, no star) is necessary.
- The CAN bus has to be terminated by 120Ω resistors at both ends use a cable with following parameters:

| | |
|-----------------------------|---------------------------|
| Cable type | Shielded twisted pair |
| Impedance | 120 Ω |
| Propagation velocity | ≥ 75 % (delay ≤ 4.4 ns/m) |

¹Recommended data cables: BELDEN (<http://www.belden.com>) – for shorter distances: 3105A Paired - EIA Industrial RS-485 PLTC/CM (1x2 conductors); for longer distances: 3106A Paired - EIA Industrial RS-485 PLTC/CM (1x2+1 conductors)

| | |
|----------------------------|-------------------------------------|
| Wire crosscut | $\geq 0.25 \text{ mm}^2$ |
| Attenuation (@1MHz) | $\leq 2 \text{ dB} / 100 \text{ m}$ |

Note: Communication circuits shall be connected to communication circuits of Listed equipment.

Note: A termination resistor at the CAN (120 Ω) is already implemented on the PCB. For connecting, close the jumper near the appropriate CAN terminal.




Image 4.48 CAN bus topology

> For shorter distances (connection within one building)




Image 4.49 CAN bus wiring for shorter distances

> For longer distances or in case of surge hazard (connection out of building, in case of storm etc.)




Image 4.50 CAN bus wiring for longer distances

Ⓞ Recommended PT5-HF-12DC-ST¹

4.4.11 USB

This is required for computer connection. Use the shielded USB A-B cable.





Image 4.51 USB connection

Controller can be also powered by USB (only for service purpose like a uploading firmware, change of configuration etc.).


IMPORTANT: Power supply by USB is only for service purpose. Binary inputs and outputs are in logical 0. Also plug-in modules are not working.

¹Protections recommended: Phoenix Contact (<http://www.phoenixcontact.com>): PT 5-HF-12DC-ST with PT2x2-BE (base element) or Saltek (<http://www.saltek.cz>): DM-012/2 R DJ

4.4.12 Example of AMF Wiring




4.4.13 Example of MRS Wiring




4.5 Plug-in module installation

4.5.1 Installation


Remove the back cover. To do this, press four holders which are located in corners.



After removing back cover insert the plug-in module. Plug-in module has to be inserted under holders. Start with holders marked by symbol 1. On the controller are also arrows for better navigation. After inserting plug-in module under holders 1 press it down to holders marked by symbol 2 which locks the module.



After locking the plug-in module into holders, place back the back cover (small cover for connectors has to be removed from back cover). Finally insert the small cover for connectors. Small covers are unique for each plug-in module.



[◀ back to Installation and wiring](#)

5 Controller setup

| | |
|--|----|
| 5.1 Default configuration | 55 |
| 5.2 Controller configuration and PC tools connection | 56 |
| 5.3 Operator Guide | 61 |
| 5.4 Remote Display | 85 |
| 5.5 Functions | 89 |

[▲ back to Table of contents](#)

5.1 Default configuration

5.1.1 Binary inputs AMF

| Number | Description | Configured function |
|-------------|-------------------------------------|------------------------------------|
| BIN1 | Generator circuit breaker feedback | GCB FEEDBACK (PAGE 321) |
| BIN2 | Mains circuit breaker feedback | MCB FEEDBACK (PAGE 323) |
| BIN3 | Switch controller to OFF mode | REMOTE OFF (PAGE 325) |
| BIN4 | Switch controller to TEST mode | REMOTE TEST (PAGE 327) |
| BIN5 | Suppression of alarms | SD OVERRIDE (PAGE 328) |
| BIN6 | Binary input function used as alarm | BIN PROTECTION 1 (PAGE 309) |

5.1.2 Binary outputs AMF

| Number | Description | Function |
|--------------|--|----------------------------------|
| BOUT1 | Starter motor control | STARTER (PAGE 361) |
| BOUT2 | Fuel solenoid valve | FUEL SOLENOID (PAGE 342) |
| BOUT3 | Generator circuit breaker control | GCB CLOSE/OPEN (PAGE 343) |
| BOUT4 | Mains circuit breaker control | MCB CLOSE/OPEN (PAGE 351) |
| BOUT5 | Activation of any devices before start | PRESTART (PAGE 357) |
| BOUT6 | Indication of unconfirmed alarm | ALARM (PAGE 337) |

5.1.3 Binary inputs MRS

| Number | Description | Configured function |
|-------------|---|-------------------------------------|
| BIN1 | Start and stop the Gen-set in AUTO mode | REMOTE START/STOP (PAGE 326) |
| BIN2 | Generator circuit breaker feedback | GCB FEEDBACK (PAGE 321) |
| BIN3 | Switch controller to OFF mode | REMOTE OFF (PAGE 325) |
| BIN4 | Switch controller to AUTO mode | REMOTE AUTO (PAGE 325) |
| BIN5 | Suppression of alarms | SD OVERRIDE (PAGE 328) |
| BIN6 | Binary input function used as alarm | BIN PROTECTION 1 (PAGE 309) |

5.1.4 Binary outputs MRS

| Number | Description | Function |
|--------|--|---------------------------|
| BOUT1 | Starter motor control | STARTER (PAGE 361) |
| BOUT2 | Fuel solenoid valve | FUEL SOLENOID (PAGE 342) |
| BOUT3 | Generator circuit breaker control | GCB CLOSE/OPEN (PAGE 343) |
| BOUT4 | Activation of any devices before start | PRESTART (PAGE 357) |
| BOUT5 | Gen-set can be connected to load | READY TO LOAD (PAGE 359) |
| BOUT6 | Indication of unconfirmed alarm | ALARM (PAGE 337) |

5.1.5 Analog inputs

| Number | Configured sensor | Function |
|--------|-------------------|-------------------------|
| AIN1 | VDO 10 Bar | OIL PRESSURE (PAGE 371) |
| AIN2 | VDO40-120°C | COOLANT TEMP (PAGE 369) |
| AIN3 | VDOLevel % | FUEL LEVEL (PAGE 369) |

5.2 Controller configuration and PC tools connection

| | |
|-------------------------|----|
| 5.2.1 USB | 56 |
| 5.2.2 RS232/RS485 | 57 |
| 5.2.3 Ethernet | 59 |

back to Controller setup

This chapter contains brief introduction into the specifics of firmware and archive upload and connection of various PC tools to the controller. If you require detailed information on each PC tool please use the included Help in those PC tools or download their Reference Guides.

5.2.1 USB

You may connect to the controller using the USB port. In this case standard USB A to B cable should be used.

Connection using IntelliConfig




Image 5.1 First screen of IntelliConfig – select connect to controller



Image 5.2 Second screen of IntelliConfig – select detected controllers

Connection using WinScope




Image 5.3 WinScope screen – select direct connection

5.2.2 RS232/RS485

It is possible to connect to the controller using RS232 or RS485 direct connection (serial port or USB to RS232/RS485 converter may be used). The following settings need to be checked in the controller:

- > **COM1 Mode (page 237) = Direct**
- > **Controller Address** has to be set to the same value as in the PC tool

Connection using IntelliConfig




Image 5.4 First screen of IntelliConfig – select connect to controller




Image 5.5 Second screen of IntelliConfig – select Serial link

Connection using WinScope




Image 5.6 WinScope screen – select direct connection

Note: WinScope supports only 19200, 38400, 57600 speeds.

5.2.3 Ethernet

It is possible to connect to the controller using Ethernet port.

Direct connection

When you use direct connection the controller needs to be reachable directly from the PC you use (i.e. one LAN or WAN without any firewalls and other points that may not allow the connection). The following settings need to be checked in the controller:

- **Controller Address (page 171)** has to be set to the same value as in the PC tool
- **IP Address Mode (page 253)** can be set to AUTOMATIC when there is DHCP service is available. Otherwise it needs to be set to FIXED
- **IP Address (page 253)** is either set automatically or it can be adjusted to a specific requested value
- **Subnet Mask (page 254)** is either set automatically or it can be adjusted to a specific requested
- **Gateway IP (page 254)** can be set here when it is used

Connection using IntelliConfig




Image 5.7 First screen of IntelliConfig – select connect to controller




Image 5.8 Second screen of IntelliConfig – select Internet / Ethernet

Connection using WinScope

Open Connection

Quick Connection | Site Connection

USB AirGate Ethernet Serial link

IP Address:

Access Code:

Username:

Controller Address:

Password:

Open

Image 5.9 WinScope screen

5.3 Operator Guide

| | |
|---|----|
| 5.3.1 Front panel elements | 61 |
| 5.3.2 Display screens and pages structure | 63 |
| 5.3.3 Browsing alarms | 75 |
| 5.3.4 Password | 76 |
| 5.3.5 Information screen | 82 |
| 5.3.6 Language selection | 83 |
| 5.3.7 Display contrast adjustment | 85 |

5.3.1 Front panel elements
















Image 5.10 Operator interface of IntelliLite 9

| Control buttons | | |
|-----------------|---|--|
| Position | Picture | Description |
| 1 |  | <p>LEFT button. Use this button to move left or to change the mode. The button can change the mode only if the main screen with the indicator of currently selected mode is displayed.</p> <p><i>Note: This button will not change the mode if the controller mode is forced by one of binary inputs listed in the Reference Guide – "Operating modes" chapter.</i></p> |
| 2 |  | <p>RIGHT button. Use this button to move right or to change the mode. The button can change the mode only if the main screen with the indicator of currently selected mode is displayed.</p> |

| | | |
|----|---|---|
| | | Note: This button will not change the mode if the controller mode is forced by one of binary inputs listed in the Reference Guide – "Operating modes" chapter. |
| 3 |  | HORN RESET button. Use this button to deactivate the horn output without acknowledging the alarms. |
| 4 |  | FAULT RESET button. Use this button to acknowledge alarms and deactivate the horn output. Inactive alarms will disappear immediately and status of active alarms will be changed to "confirmed" so they will disappear as soon as their reasons dismiss. |
| 5 |  | UP button. Use this button to move up or increase value. |
| 6 |  | PAGE button. Use this button to switch over display pages. |
| 7 |  | DOWN button. Use this button to move down or decrease value. |
| 8 |  | ENTER button. Use this button to finish editing a setpoint or moving right in the history page. |
| 9 |  | START button. Works in MAN mode only. Press this button to initiate the start sequence of the engine. |
| 10 |  | STOP button. Works in MAN mode only. Press this button to initiate the stop sequence of the Gen-set. Repeated pressing of button will cancel current phase of stop sequence (like cooling) and next phase will continue. |
| 11 |  | GCB button. Works in MAN mode only. Press this button to open or close the GCB. |
| 12 |  | MCB button. Works in MAN mode only. Press this button to open or close the MCB. |

Indicators and others

| Position | Description |
|----------|--|
| 13 | GENERATOR status indicator. There are two states – Gen-set OK (indicator is green) and Gen-set failure (indicator is red). Green LED is on if the generator voltage and frequency is present and within limits. Red LED starts flashing when Gen-set failure occurs. After FAULT RESET button is pressed, goes to steady light (if an alarm is still active) or is off (if no alarm is active). |
| 14 | MAINS status indicator. There are two states – Mains OK (indicator is green) and Mains failure (indicator is red). Green LED is on, if mains is present and within limits. Red LED starts blinking when the mains failure is detected and after the Gen-set has started and connected to the load it lights permanently until the mains failure disappears. |

| | |
|-----------|---|
| 15 | Graphic B/W display, 132 × 64 px. |
| 16 | GCB Status. Green LED is on if GCB is closed. It is driven by GCB CLOSE/OPEN output or by GCB feedback signal. |
| 17 | MCB Status. Green LED is on if MCB is closed. It is driven by MCB CLOSE/OPEN output or by MCB feedback signal. |

5.3.2 Display screens and pages structure

The displayed information is structured into "pages" and "screens". Use PAGE button to switch over the pages.

- > The page Measurement consists of screens which display measured values like voltages, current, oil pressure etc., computed values like i.e. gen-set power, statistic data and the alarm list on the last screen.
- > The page Setpoints contains all setpoints organized to groups and also a special group for entering password.
- > The page History log shows the history log in the order that the last record is displayed first.



Main Screen



Symbols


- > Padlock – active when LBI ACCESS LOCK is active
- > R – active when there is active remote connection to controller
- > Exclamation mark – active when there is any alarm in alarmlist

Measurement Screens



Note: Use Up and Down button to move between measurement pages.

| Generator | | | |
|----------------|------|------|--------|
| L1N | 230V | L1L2 | 400V |
| L2N | 230V | L2L3 | 400V |
| L3N | 230V | L3L1 | 400V |
| Generator Freq | | | 50.0Hz |



Note: Use Up and Down button to move between measurement pages.

| Generator Current | |
|-------------------|------|
| L1 | 130A |
| L2 | 130A |
| L3 | 130A |





Note: Use Up and Down button to move between measurement pages.


| Analog Inputs 1/2 | |
|-------------------|----------|
| Oil Pressure | #####Bar |
| Coolant Temp | ##### °C |
| Fuel Level | #####% |




Note: Use Up and Down button to move between measurement pages.




Note: Use Up and Down button to move between measurement pages.



Note: Use Up and Down button to move between measurement pages.




Note: Use Up and Down button to move between measurement pages.




Note: Use Up and Down button to move between measurement pages.

| Binary Outputs 2/2 | |
|--------------------|--------|
| | 000000 |
| 6 Output | 0 |



Note: Use Up and Down button to move between measurement pages.


| EM-BIOS-EFCP 1/2 | |
|------------------|----------|
| | 10101010 |
| IN: Input | 1 |
| Not Used | 0 |
| OUT: Output | 1 |
| IN: Input | 0 |
| OUT: Output | 1 |



Note: Use Up and Down button to move between measurement pages.

Note: Available only with plug-in module.

| EM-BIOS-EFCP 2/2 | |
|------------------|----------|
| | 00101010 |
| OUT: Output | 0 |
| OUT: Output | 1 |
| OUT: Output | 0 |



Note: Use Up and Down button to move between measurement pages.

Note: Available only with plug-in module.

| Gen-Set Power | | | |
|---------------|----|-------|-----|
| | kW | PF | kVA |
| L1 | 0 | 0.000 | 0 |
| L2 | 0 | 0.000 | 0 |
| L3 | 0 | 0.000 | 0 |
| Σ | 0 | 0.000 | 0 |




Note: Use Up and Down button to move between measurement pages.

| ECU Values | |
|-------------|----------|
| Fuel Rate | #####l/h |
| CoolantTemp | ##### °C |
| IntakeTemp | ##### °C |
| Oil Press | #####bar |
| Boost Press | #####bar |
| Load | #####% |




Note: Use Up and Down button to move between measurement pages.

| Statistics 1/2 | |
|----------------|---|
| Genset kWh | 0 |
| Genset kVArh | 0 |
| Mains kWh | 0 |
| Mains kVArh | 0 |
| Running Hours | 0 |
| Num Starts | 0 |



Note: Use Up and Down button to move between measurement pages.

| Statistics 2/2 | |
|----------------|---|
| Num E-Stops | 0 |
| Shutdowns | 0 |
| Maintenance 1 | 0 |
| Maintenance 2 | 0 |
| Maintenance 3 | 0 |



Note: Use Up and Down button to move between measurement pages.

| CM-4G-GPS 1/2 | |
|-----------------|-------------|
| Cell Signal Lev | 93% |
| Cell ErrorRate | 12% |
| Cell Status | / |
| Cell Diag Code | 12 |
| Operator | T-Mobile CZ |
| Connection Type | 4G |




Note: Use Up and Down button to move between measurement pages.

Note: Available only with plug-in module.

```

CM-4G-GPS  2/2
Latitude    0.1234
Longitude   0.1234
Altitude    123m
HomePosDist 123km
Satelites   1

```




Note: Use Up and Down button to move between measurement pages.

Note: Available only with plug-in module.

```

CM-GPRS
Cell Signal Lev  93%
Cell ErrorRate   12%
Cell Status      /
Cell Diag Code   12
Operator         T-Mobile CZ

```



Note: Use Up and Down button to move between measurement pages.

```

CM-Ethernet
Current IP Address
123.123.123.123
ETH Interface Status
Connected

```



Note: Use Up and Down button to move between measurement pages.

```

Aftertreatment


```

| | | | |
|--|--|--|--|
| | | | |
| | | | |





Note: Use Up and Down button to move between measurement pages.

Note: Available only with ECU supported by TIER4F



Note: Use Up and Down button to move between measurement pages.




Note: Use Up and Down button to move between measurement pages.


Note: From all of these pages it is possible to switch seamlessly to the setpoint group page by pressing Page button.

Note: There can be some additional screens and also some screens can be hidden. Screen's visibility depends on actual configuration (usage of extension or communication modules, ECU etc.).

Setpoint Screens




Note: From all measurement pages we can fluently go to the setpoint group page by pressing Page button.




Note: Use Up and Down button to select required setpoint group.



Note: Use Enter button to enter selected setpoint group.




Note: Use Up and Down button to select required setpoint.



Note: Use Left and Right button to select required setpoint.



Note: Use Enter button to enter selected setpoint.



Note: Use Up and Down button to set required value of selected setpoint.




Note: Use Enter button to confirm adjusted value of setpoint.




Note: Use Page button to discard changes, to set setpoint to previous value and to return to the list of setpoints of selected group.

IMPORTANT: Cannot change setpoint? Setpoints marked with an padlock are password protected. Enter password as described in the chapter Password (page 76).

History Log



Note: From all measurement pages we can fluently go to the setpoint group page by pressing Page button.




Note: From setpoint group page we can fluently go to the history log pages by pressing Page button.



Note: Use Up and Down button to select required alarm reason.



Note: Use Enter button to move to the next page of history log.



Note: Use Up and Down button to select required alarm reason.



Note: Use Enter button to move to the next page of history log.

| RPM | Pwr | Q |
|-----------------|------|------|
| 1500 | 15.0 | 15.0 |
| 0 | 0.0 | 0.0 |
| 0 | 0.0 | 0.0 |
| 1500 | 15.0 | 15.0 |
| 1500 | 15.0 | 15.0 |
| -002 MCB Opened | | |



Note: Use Up and Down button to select required alarm reason.



Note: Use Enter button to move to the next page of history log.

| PF | LChr | GFra |
|-----------------|------|------|
| 0.75 | C | 50.0 |
| 0.00 | C | 0.0 |
| 0.00 | C | 0.0 |
| 0.73 | C | 50.0 |
| 0.74 | C | 50.0 |
| -002 MCB Opened | | |



Note: Use Up and Down button to select required alarm reason.



Note: Use Enter button to move to the next page of history log.

| Ug1 | Ug2 | Ug3 |
|-----------------|-----|-----|
| 230 | 230 | 230 |
| 0 | 0 | 0 |
| 0 | 0 | 0 |
| 230 | 230 | 230 |
| 230 | 230 | 230 |
| -002 MCB Opened | | |



Note: Use Up and Down button to select required alarm reason.



Note: Use Enter button to move to the next page of history log.

| Ug12 | Ug23 | Ug31 |
|-----------------|------|------|
| 230 | 230 | 230 |
| 0 | 0 | 0 |
| 0 | 0 | 0 |
| 230 | 230 | 230 |
| 230 | 230 | 230 |
| -002 MCB Opened | | |



Note: Use Up and Down button to select required alarm reason.



Note: Use Enter button to move to the next page of history log.

| IL1 | IL2 | IL3 |
|-----|-----|-----|
| 30 | 30 | 30 |
| 0 | 0 | 0 |
| 0 | 0 | 0 |
| 30 | 30 | 30 |
| 30 | 30 | 30 |



Note: Use Up and Down button to select required alarm reason.



Note: Use Enter button to move to the next page of history log.

| Um1 | Um2 | Um3 |
|-----|-----|-----|
| 230 | 230 | 230 |
| 0 | 0 | 0 |
| 0 | 0 | 0 |
| 230 | 230 | 230 |
| 230 | 230 | 230 |



Note: Use Up and Down button to select required alarm reason.



Note: Use Enter button to move to the next page of history log.

| Um12 | Um23 | Um31 |
|------|------|------|
| 230 | 230 | 230 |
| 0 | 0 | 0 |
| 0 | 0 | 0 |
| 230 | 230 | 230 |
| 230 | 230 | 230 |



Note: Use Up and Down button to select required alarm reason.



Note: Use Enter button to move to the next page of history log.

| FC | FMI |
|----|-----|
| 0 | 0 |
| 0 | 0 |
| 0 | 0 |
| 0 | 0 |
| 0 | 0 |



Note: Use Up and Down button to select required alarm reason.



Note: Use Enter button to move to the next page of history log.

| MFrq | UBat | OilP |
|------|------|------|
| 50.0 | 23.2 | 3.2 |
| 0.0 | 0.0 | 0.0 |
| 0.0 | 23.2 | 0.0 |
| 50.0 | 23.3 | 3.2 |
| 50.0 | 23.3 | 3.2 |



Note: Use Up and Down button to select required alarm reason.



Note: Use Enter button to move to the next page of history log.

| EngT | FLvl | Ain4 |
|------|------|------|
| 30.0 | 50 | 00.0 |
| 22.0 | 20 | 00.0 |
| 23.0 | 30 | 00.0 |
| 23.0 | 30 | 00.0 |
| 23.0 | 50 | 00.0 |



Note: Use Up and Down button to select required alarm reason.



Note: Use Enter button to move to the next page of history log.

| BIN | BOUT |
|----------|----------|
| 01101000 | 11000011 |
| 11001001 | 01001010 |
| 01010100 | 01010100 |
| 11010000 | 01101000 |
| 11000011 | 01010100 |



Note: Use Up and Down button to select required alarm reason.



Note: Use Enter button to move to the next page of history log.

| Mode |
|------|
| MAN |
| MAN |
| MAN |
| MAN |
| MAN |



Note: Use Up and Down button to select required alarm reason.




Note: Use Enter button to move to the first page of history log.


IMPORTANT: The records are numbered in reverse order, i.e. the latest (newest) record is "0" and older records have "-1", "-2" etc.

Note: This is only basic history record. There can be some additional screens in case that in controller is extension module or ECU is configured. Also it depends on connection type.

5.3.3 Browsing alarms



Note: Use Up button to move to alarmlist from main measurement screen.




- Active alarms are displayed as white text on black background. It means the alarm is still active, i.e. the appropriate alarm conditions are still present.
- Inactive alarms are displayed as black text on white background. It means the alarm is no more active, i.e. the appropriate alarm conditions are gone.
- Not confirmed alarms are displayed with an asterisk. It means the alarm is still not acknowledged (confirmed).
- ECU alarms: SPN/FMI/OC/SC
 - SPN – Suspect parameter number
 - FMI – type of protection
 - OC – number of errors
 - SC – source of error




5.3.4 Password

Enter password




Note: From all measurement pages we can fluently go to the setpoint group page by pressing Page button.



Note: Use Up and Down button to select setpoint group Password.



Note: Use Enter button to enter setpoint group Password.




Note: Use Up and Down button to select Enter Password.



Note: Use Enter button to enter selected setpoint.



Note: Use Up and Down button to set required value of selected setpoint.



Note: Use Left and Right button to move between digits.




Note: Use Enter button to confirm the password or Page button to cancel entering the password.




Note: In case that invalid password is entered, the controller shows Invalid password screen. Use Page button to go back to menu.

Change password




Note: From all measurement pages we can fluently go to the setpoint group page by pressing Page button.



Note: Use Up and Down button to select setpoint group Password.




Note: Use Enter button to enter setpoint group Password.



Note: Use Up and Down button to select Change Password.



Note: Use Enter button to enter selected setpoint.



Note: Use Up and Down button to select required level of password.



Note: Use Enter button to enter selected setpoint.



Note: Use Up and Down button to set required value of password.

Note: Use Left and Right button to move between digits.



Note: After setting new password use Enter button to confirm adjusted password.



Note: Use Up and Down button to set required value of password again.

Note: Use Left and Right button to move between digits.




Note: After setting new password again use Enter button to confirm adjusted password or Page button to discard changes and to cancel changing password.




Note: Before changing the password controller has to be unlocked. In case that controller is locked, the controller shows Password required screen. In that case the password has to be entered before changing the password.

Log out from controller




Note: From all measurement pages we can fluently go to the setpoint group page by pressing Page button.



Note: Use Up and Down button to select setpoint group Password.



Note: Use Enter button to enter setpoint group Password.




Note: Use Up and Down button to select Enter Password.



Note: Use Enter button to enter selected setpoint.



Note: Use Up and Down button to set required value of selected setpoint.



Note: Use Left and Right button to move between digits.

Note: Enter invalid password to log out from controller.



Note: In case that invalid password is entered, the controller shows Invalid password screen. Use Page button to go back to menu.

Password security

Controller will be shipped with default password that is not secure and for that reason it is highly recommended to change it. If the controller will be used with the default password warning **Wrn Default Credentials** (page 381) will appear and will continue being active until a different password is configured.

Wrong archive protection

In case there is an incorrect archive uploaded to the controller it will display: "Waiting for programming of compatible configuration table."


This message will be removed as soon as correct archive is uploaded to the controller.

Password break protection

The controller password is protected against breaking by brute force. The protection works at every controller interface separately.

1. When an invalid password is entered 5 times after each other, independently on the time period elapsed between the attempts, the controller will be blocked after the 5th unsuccessful attempt for 1 minute at the particular interface.
2. While the controller is blocked it refuses any further attempts to enter password.
3. When unblocked again the controller accepts one attempt to enter password. If the password is incorrect again the controller will be blocked for 2 minutes.
4. Each further attempt to enter invalid password will double the blocking time, but maximum blocking time is 20 minutes.
5. When incorrect password is entered 100-times after each other the controller is blocked forever and the password reset procedure is required to unblock it.

5.3.5 Information screen



Note: On Main measurement screen press Enter and Page button together. Enter button has to be pressed first.



Note: Use Page button to move to the next page.

```

About Controller 1/2
  IntelliLite
  ComAp 2015
  Controller Name

Application:      AMF25
Branch:          Standard
  
```



Note: Use Page button to move to the next page.

```

About Controller 2/2
SW Version:      1.0.0.00
HW Version:      1.0
Serial:          12345678
Pwd.Dec.:        1212345678
  
```



Note: Use Up button to move back to main measurement screen.

5.3.6 Language selection

```

OFF  MAN  AUTO TEST  OR?
┌───────────┬───────────┐
│  ┌───┐     │ EmergManual │
│  │   │     │ Mains Fail  │
│  │   │     │ PF      0.00  │
│  │   │     │ RPM      0    │
│  │   │     │ ReturnDelay │
│  │   │     │ 00:00:00    │
│  └───┘     └───────────┘
│ 0 kW      │
└───────────┘
  
```



Note: On Main measurement screen press Enter and Page button together. Enter button has to be pressed first.

```
Intelilite
ComAp
www.comap-control.com
```



Note: Use Page button to move to the next page.

```
About Controller 1/2
Intelilite
ComAp 2015
Controller Name
Application:      AMF25
Branch:          Standard
```



Note: Use Page button to move to the next page.

```
About Controller 2/2
SW Version:      1.0.0.00
HW Version:      1.0
Serial:          12345678
Pwd.Dec.:        1212345678
```



Note: Use Page button to move to the next page.

```
LANGUAGES
Language1
Language2
Language3
```




Note: Use Up and down button to select required language.





Note: Use Enter button to confirm selected language.

5.3.7 Display contrast adjustment



Note: On any measurement screen press Enter and Up button together for higher contrast.

Note: On any measurement screen press Enter and Down button together for lower contrast.



Note: After setting a contrast, no another action is needed.

5.4 Remote Display

This chapter describes Remote display firmware IL3-RD, which is designed as a remote signaling and control software for IntelliLite 9 family controllers. It is the optional software which is possible to upload into controller instead of standard controller's firmware.

5.4.1 General description


Remote display software works as "remote display and control" for the Master IntelliLite 9 family controller. Gen-set can be controlled using Remote display and Master controller simultaneously and independently. All Remote display screens (Measurement screens, Setpoint screens and History Log) displays the same data as Master controller. Front panel buttons on both controllers work the same way. All remote display LEDs shows the same state as corresponding LEDs on Master controller.

Note: Some settings are not shared between display and control unit (setpoint Backlight Timeout Backlight Timeout (page 172), Controller language and Controller user mode).

5.4.2 IL3-RD Firmware installation

The IL3-RD Remote display firmware is installed in the same way as any other IntelliLite 9 firmware using IntelliConfig PC tool. Reverting Remote display controller back to regular Gen-set controller is carried out the same way.

Note: *InteliConfig shows the most compatible and the most recent firmware as default option. Thus, it is necessary use "More options" (...) button to pick IL3-RD firmware for uploading to controller. (See details on picture below.)*



Note: *IL3-RD consists firmware only, there is no archive included.*

Note: *When IL3-RD firmware is uploaded to controller there is only possible connect InteliConfig using USB connection. InteliConfig serves only for firmware update when connected to Remote display. There is no Master controller SCADA displayed, no possibility to adjust setpoints, display Values etc.*


Note: *Please refer to [InteliConfig Global Guide](#) for details about firmware uploading to controller.*

5.4.3 Wiring

IL3-RD can be connected to any InteliLite 9 family controller via external RS232 or RS485 communication port on CM-232-485 communication module. It is possible to connect only up to two Remote displays to one Master controller, if they are using different communication COMs. To connect two or more remote displays to one communication line (e.g. RS485) is not possible. Using one Remote display it is possible to monitor only one Master controller at the time.

5.4.4 Interconnection variants

RS232




It is necessary to use CM-RS232-485 communication module on both Master controller and Remote display. COM 1 communication channel is used with these settings:

- > COM 1 Mode: Direct
- > COM 1 Communication Speed: 57600 or 115200 bps
- > Controller Address: 1 – 32

The maximal distance between Master controller and Remote display is 10 m for RS-232 connection. It is recommended to use standard Null modem cable (crossover cable), although three wires (TxD, RxD, GND) RS-232 connection is enough for communication.

RS485



IL3 can connect as a remote display to any controller in IL3 family. If IG200 controller is connected, onboard RS485 can be used.


COM 2 communication channel is used with these settings:

- > COM 2 Mode: Direct
- > COM 2 Communication Speed: 57600 or 115200 bps
- > Controller Address: 1 – 32

The maximal distance between Master controller and Remote display is 1200 m for RS485 connection. It is recommended to use shielded twisted-pair cables that comply with the EIA RS-485 standard to reduce interference and to achieve maximal distance.

RS232 + RS485

It is possible to combine two previous ways of interconnection and connect two Remote display to one Master controller concurrently. All the parameters and settings are the same as mentioned above.



5.4.5 Connection process

Remote display after power on automatically tries connect to last known Master (if such configuration exist in Remote display). Otherwise Remote display starts to search for any Master controller connected. It starts to

search on COM 2 (RS485) using Master controller address 1 – 32 and continues with COM 1 (RS232). Remote display tries two communication speeds 57600 bps and 115200 bps.

During this autodetection process the message "Trying to connect" is displayed on screen. This process takes approx. one minute.

When incompatible configuration type is found in detected controller, the message "Unknown cfg format COM x Addr yy" is displayed on screen for 5 seconds and detecting continues with next address in the range.

When detecting finishes with no compatible Master controller found, the message "No connection" is displayed on screen for 5 seconds and detecting process starts from the beginning and continues until compatible master controller is found.

Not supported types of controllers or controllers that are not properly communicating are skipped during the search.

5.4.6 Connection troubleshooting

There are few reasons why Remote display cannot connect to Master controller:

- Not supported type of Master controller is connected.
- Not supported firmware in Master controller.
- Configuration table error in Master controller.
- Wrong settings of setpoint COM x Mode in master controller.
- Wrong settings of setpoint COM x Communication Speed in master controller.
- Wrong connection, wiring, communication fail.

5.4.7 Function description

Remote display software works as "remote display and control" for the Master IntelliLite 9 family controller. Gen-set can be controlled using Remote display and Master controller simultaneously and independently. All Remote display screens (Information screens, Measurement screens, Setpoint screens and History Log) displays the same data as Master controller. Front panel buttons on both controllers work the same way. All remote display LEDs shows the same state as corresponding LEDs on Master controller. User can switch screens, enter or set password, adjust setpoints, change language, change Configuration Level, change display contrast and view history records.

Note: *It is recommended to use the same type and model of controller for Master and for Remote display. Only in such case is assured the proper function of all buttons, LED diodes and display.*

Example: When AMF controller HW type is used as a Master controller and MRS controller HW type is used for Remote display there is no possibility to control MCB in MAN mode as there is no MCB button on MRS controller. However, in general all this not recommended combinations works with similar to above mentioned limitation considered.

Master device is always able to work without connected Remote display. Disconnecting of the serial line between Master controller and Remote display has no effect to the Master controller.

When the serial line between Master controller and Remote display is disconnected, or communication cannot be established, Remote display shows it's own Init screen and message "Trying to connect" and all LEDs are off.

Once remote display finds compatible master it shows message "Cfg processing" and downloads configuration table from master controller. After the configuration from Master controller is downloaded

Remote display is reinitiated, jump to master controllers Main measurement screen and regular operation is started.

It is possible to switch to Remote display's own Init screen to check IL3-RD FW version and serial number of used controller and communication status by press and hold Page button for more than 3 seconds.

5.4.8 Firmware compatibility

Remote Display

IL3-RD FW is possible to upload into following controllers:

- > InteliLite AMF 25
- > InteliLite AMF 20
- > InteliLite MRS 16
- > InteliLite MRS 11
- > InteliLite 9

Remote Display vs. Master controller

| Remote Display | Master controller | | | |
|----------------|-------------------|---------------------------|---------------|---------------|
| | RD FW ver. | InteliLite (all versions) | InteliLite 9 | InteliGen 200 |
| 1.0.0 | | FW ver. 1.5.x | FW ver. 1.1.x | FW ver. 1.1.x |
| | | FW ver. 1.6.x | FW ver. 1.2.x | FW ver. 1.2.x |
| | | FW ver. 1.7.x | FW ver. 1.3.x | FW ver. 1.3.x |
| | | FW ver. 1.8.x | FW ver. 1.4.x | FW ver. 1.4.x |
| | | FW ver. 1.9.x | FW ver. 1.5.x | FW ver. 1.5.x |
| | | FW ver. 1.10.x | FW ver. 1.6.x | FW ver. 1.6.x |
| | | FW ver. 1.11.x | | FW ver. 1.7.x |
| | | FW ver. 1.12.x | | FW ver. 1.8.x |
| | | FW ver. 1.13.x | | |
| | | FW ver. 1.14.x | | |
| | | FW ver. 1.15.x | | |

5.5 Functions

| | |
|---------------------------------------|----|
| 5.5.1 Start-stop sequence | 90 |
| 5.5.2 AMF sequence | 92 |
| 5.5.3 Operating Modes | 93 |
| 5.5.4 Engine start | 94 |
| 5.5.5 Stabilization | 97 |
| 5.5.6 Connecting to load | 97 |
| 5.5.7 MRS operation | 97 |
| 5.5.8 AMF operation | 98 |
| 5.5.9 Engine cool down and stop | 99 |
| 5.5.10 Alarm management | 99 |

| | |
|--|-----|
| 5.5.11 History log | 105 |
| 5.5.12 Breaker control | 107 |
| 5.5.13 Exercise timer | 110 |
| 5.5.14 Service timers | 117 |
| 5.5.15 Additional running engine indications | 117 |
| 5.5.16 Voltage phase sequence detection | 117 |
| 5.5.17 Gen-set operation states | 118 |
| 5.5.18 Sensor curves | 120 |
| 5.5.19 Tier 4 Final | 121 |
| 5.5.20 Alternate configuration | 124 |
| 5.5.21 E-Stop | 124 |
| 5.5.22 ECU Frequency selection | 125 |
| 5.5.23 Cybernetic security | 126 |

 [back to Controller setup](#)

5.5.1 Start-stop sequence

| State | Condition of the transition | Action | Next state |
|-----------|--|---|------------------|
| Ready | Start request | PRESTART (PAGE 357) on Prestart Time (page 177) counter started | Prestart |
| | RPM > 2 or Oil pressure > Starting Oil Pressure (page 178) or Generator voltage > 10V or D+ voltage is higher than D+ Threshold (page 184) | | Stop (Stop fail) |
| | OFF Mode selected or Shutdown alarm active | | Not Ready |
| Not Ready | RPM < 2, Oil pressure not detected, Generator voltage < 10 V, D+ not Active no shutdown alarm active, other than OFF Mode selected | | Ready |
| Prestart | Prestart time elapsed | FUEL SOLENOID (PAGE 342) on, STARTER (PAGE 361) on, Maximum Cranking Time (page 176) counter started | Cranking |
| Cranking | RPM > Starting RPM | STARTER (PAGE 361) off, PRESTART (PAGE 357) off | Starting |
| | D+ input activated or oil pressure detected or Generator voltage > 25% Nominal voltage | STARTER (PAGE 361) off, PRESTART (PAGE 357) off | Cranking |
| | Maximum Cranking Time (page 176) , 1st attempt | STARTER (PAGE 361) off, FUEL SOLENOID (PAGE 342) off, STOP SOLENOID (PAGE 362) on, | Crank pause |

| | | | |
|-------------|--|--|--------------------------|
| | | Cranking Fail Pause (page 176) timer started | |
| | Maximum Cranking Time (page 176) elapsed, last attempt | STARTER (PAGE 361) off, PRESTART (PAGE 357) off | Shutdown (Start fail) |
| | all cranking attempts elapsed | FUEL SOLENOID (PAGE 342) off, STOP SOLENOID (PAGE 362) on | Shutdown (Start fail) |
| Crank pause | Cranking Fail Pause (page 176) elapsed | STARTER (PAGE 361) off, FUEL SOLENOID (PAGE 342) on, STOP SOLENOID (PAGE 362) off, Maximum Cranking Time (page 176) counter started | Cranking |
| Starting | Idle Time (page 186) elapsed | Minimal Stabilization Time (page 188) and Maximal Stabilization Time (page 189) counter started | Running |
| | any shutdown condition | FUEL SOLENOID (PAGE 342) off, STOP SOLENOID (PAGE 362) on | Shutdown |
| Running | Stop request | READY TO LOAD (PAGE 359) off, Cooling Time (page 190) counter started | Cooling |
| | RPM = 0 or any other shutdown condition | READY TO LOAD (PAGE 359) off, FUEL SOLENOID (PAGE 342) off | Shutdown |
| | GCB CLOSE/OPEN (PAGE 343) closed | | Loaded |
| Loaded | GCB CLOSE/OPEN (PAGE 343) opened | | Running |
| | RPM = 0 or any other shutdown condition | FUEL SOLENOID (PAGE 342) off, STOP SOLENOID (PAGE 362) on, READY TO LOAD (PAGE 359) off, | Shutdown |
| Cooling | Cooling Time (page 190) elapsed | FUEL SOLENOID (PAGE 342) off, STOP SOLENOID (PAGE 362) on | Stop |
| | RPM = 0 or any other shutdown condition | FUEL SOLENOID (PAGE 342) off, STOP SOLENOID (PAGE 362) on | Shutdown |
| | Start request | READY TO LOAD (PAGE 359) on | Running |
| Stop | RPM = 0, Oil pressure not detected, Generator voltage <10 V, D+ not active | | Ready |
| | If at least one of engine running indication is detected when Stop Time (page 190) elapsed. | | Stop (Stop fail) |

Note: If all generator parameters are OK and **Minimal Stabilization Time (page 188)** elapsed, indicates that GCB is possible to close. In AUTO Mode GCB is closed in this moment automatically.

Note: The start-up sequence can be interrupted in any time by stop request.

5.5.2 AMF sequence



| State | Condition of the transition | Action | Next state |
|------------------|---|---|------------------|
| Mains operation | Mains failed or MCB FEEDBACK (PAGE 323) dropout, MCB Opens On (page 223) = Mains Fail | MCB CLOSE/OPEN (PAGE 351) off, Emergency Start Delay (page 216) timer started | Mains failure |
| | Mains failed or MCB FEEDBACK (PAGE 323) dropout, MCB Opens On (page 223) = Gen Run | Emergency Start Delay (page 216) timer started | Mains failure |
| Mains failure | Mains voltage and frequency OK, MCB Opens On (page 223) = Mains Fail | After elapsing MCB Close Delay (page 218) MCB CLOSE/OPEN (PAGE 351) on | Mains operation |
| | Mains voltage and frequency OK, MCB Opens On (page 223) = Gen Run | None | Mains operation |
| | Emergency Start Delay (page 216) elapsed, MCB Opens On (page 223) = Mains Fail | Engine start sequence performed, then GCB CLOSE/OPEN (PAGE 343) on | Island operation |
| | Emergency Start Delay (page 216) elapsed, MCB Opens On (page 223) = Gen Run | Engine start sequence performed, then MCB CLOSE/OPEN (PAGE 351) off, time delay Transfer Delay (page 217) performed and GCB CLOSE/OPEN (PAGE 343) on | Island operation |
| Island operation | Mains voltage and frequency OK | Mains Return Delay (page 216) timer started | Mains return |
| Mains return | Mains failed | | Island operation |
| | Mains Return Delay (page 216) elapsed | GCB CLOSE/OPEN (PAGE 343) off, then after Transfer Delay (page 217) MCB CLOSE/OPEN (PAGE 351) on and then engine stop sequence performed | Mains operation |

Note: Mains failed means mains over/under -voltage, over/under -frequency, voltage asymmetry is issued (preset delay must elapse).

Note: If during start-up sequence mains returns, then MCB is reclosed with delay **MCB Close Delay (page 218)** (if opened, depending on **MCB Opens On (page 223)** setpoint) and start-up sequence is interrupted.

Note: If mains fails during stop procedure (cooling) again, stop sequence is interrupted, MCB opened and GCB re-closed with **Transfer Delay (page 217)**.

5.5.3 Operating Modes

Selecting the operating mode is done through Left  and Right  buttons on the front panel or by changing the **Controller Mode (page 169)** setpoint (from the front panel or remotely).

Note: If this setpoint is configured as password-protected, the correct password must be entered prior to attempting to change the mode.





Note: The mode cannot be changed if Access Lock input is active.

The following binary inputs can be used to force one respective operating mode independent of the mode setpoint selection:

- > Remote OFF (page 325)
- > Remote TEST (page 327)
- > Remote MAN (page 325)
- > Remote AUTO (page 325)



If the respective input is active the controller will change the mode to the respective position according to the active input. If multiple inputs are active, the mode will be changed according to priorities of the inputs. The priorities match the order in the list above. If all inputs are deactivated, the mode will return to the original position given by the setpoint.

OFF mode – AMF

No start of the Gen-set is possible. Controller stays in Not ready status and cannot be started any way. The MCB is closed permanently (MCB Opens On (page 223) = GENRUN) or is open or closed according to whether the mains is present or not (MCB Opens On (page 223) = MAINSFAIL). No AMF function will be performed. The buttons MCB , GCB , Start  and Stop  including the appropriate binary inputs for external buttons are not active.





IMPORTANT: When engine is running, it is not possible to switch Gen-set to OFF mode.

MAN mode – AMF

The engine can be started and stopped manually using the Start  and Stop  buttons (or external buttons wired to the appropriate binary inputs) in MAN mode. When the engine is running, GCB can be closed. Also MCB can be closed and opened manually using the MCB button, regardless of whether the mains are present or not. No auto start is performed.

Note: The controller provides interlock between GCB and MCB, it means it is never possible to close both CB together.

AUTO mode – AMF

The controller does not respond to buttons Start , Stop , MCB ON/OFF  and GCB ON/OFF .

Engine start/stop request is evaluated from Mains failure/return.

Note: When the AMF function will start the engine than the engine will be running at least for the time which is defined in Mains Return Delay (page 216) setpoint, even if the mains would return in the meantime.




TEST mode – AMF only

The Gen-set will be started when the controller is put to TEST mode and will remain running unloaded. If a mains failure occurs, the MCB will be opened and after **Transfer Delay (page 217)** the GCB will be closed and the Gen-set will supply the load. After the mains have recovered, the delay **Mains Return Delay (page 216)** will count down and if it elapses and the mains is still OK, the controller will transfer the load back to the mains after **Transfer Delay (page 217)** and the Gen-set will remain running unloaded again until the mode is changed.

Remote test on load



When binary input is active, the controller automatically transfers load from the mains to the Gen-set. See LBI **REM TEST ON LOAD (PAGE 326)**.

OFF mode – MRS

No start of the Gen-set is possible. Controller stays in Not ready status and cannot be started any way. The buttons GCB , Start  and Stop  including the appropriate binary inputs for external buttons are not active.

IMPORTANT: When engine is running, it is not possible to switch Gen-set to OFF mode.

MAN mode – MRS

The engine can be started and stopped manually using the Start  and Stop  buttons (or external buttons wired to the appropriate binary inputs) in MAN mode. When the engine is running, GCB can be closed.

AUTO mode – MRS

The controller does not respond to buttons Start , Stop  and GCB ON/OFF . Engine start/stop request is given by binary input **Remote Start/Stop (page 326)**.

5.5.4 Engine start

Diesel engine

- After the command for start is issued (pressing Start button in MAN mode, auto start condition is fulfilled in AUTO mode or controller is switched to TEST mode), outputs **PRESTART (PAGE 357)** and **GLOW PLUGS (PAGE 348)** are energized for time period given by the setpoints **Prestart Time (page 177)** and **Glow Plugs Time (page 178)**.
- After **Prestart Time (page 177)** and **Glow Plugs Time (page 178)**, the output **FUEL SOLENOID (PAGE 342)** is energized and after **Fuel Solenoid Lead (page 186)** the starter of motor is activated by energizing the output **STARTER (PAGE 361)**.
- When one or more of following conditions are met, the starter output is de-energized:
 - The engine speed exceeds the value of **Starting RPM (page 177)**, or
 - One of **Additional running engine indications (page 117)** signals is active.
- The controller remains in the Starting phase until the engine speed exceeds the value of **Starting RPM (page 177)**, after that it is considered as started and the Idle period will follow.
- The maximum duration that the output **STARTER (PAGE 361)** is energized is determined by the setpoint **Maximum Cranking Time (page 176)**. If the engine does not start within this period, the output **STARTER**

(PAGE 361) is de-energized and a pause with length determined by **Cranking Fail Pause (page 176)** will follow. **PRESTART (PAGE 357)** and **GLOW PLUGS (PAGE 348)** outputs are active during the pause. After the pause has elapsed, the next start attempt is executed. The number of start attempts is given by the setpoint **Cranking Attempts (page 176)**.

- Once the engine is started, the Idle period follows. The binary output **IDLE/NOMINAL (PAGE 351)** remains inactive (as it was during the start). The idle period duration is adjusted by the setpoint **Idle Time (page 186)**.
- After the idle period has finished, the output **IDLE/NOMINAL (PAGE 351)** is activated and the start-up sequence is finished. The **Stabilization (page 97)** phase follows.




Image 5.11 Flowchart of start of diesel engine

5.5.5 Stabilization

When the **Engine start (page 94)** sequence is finished, the Gen-set goes into the stabilization phase. There are two timers (setpoints) in this phase:

- **Minimal Stabilization Time (page 188)** starts to count down just after the idle period has finished. Generator voltage and frequency are not checked (respective protections are not evaluated) and the GCB cannot be closed even if the generator voltage and frequency are within limits.
- **Maximal Stabilization Time (page 189)** starts to count down just after the idle period has finished. Generator voltage and frequency are not checked (respective protections are not evaluated) but, opposite to the previous timer, the GCB can be closed if generator voltage and frequency are within limits.

In situations where the GCB is closed automatically (AUTO, TEST modes), the closing of GCB will occur in the first moment when the generator voltage and frequency will get into limits and the **Minimal Stabilization Time (page 188)** has already elapsed.

In the event that the generator voltage or frequency are not within limits within the **Maximal Stabilization Time (page 189)** period, the appropriate protection(s) will be activated and the Gen-set will be cooled down and stopped.

Note: The limits for the generator voltage and frequency are given by setpoints in the **Group: Generator settings (page 207)**.

Note: The value of the **Minimal Stabilization Time (page 188)** setpoint has to be lower than the value of **Maximal Stabilization Time (page 189)** setpoint.

5.5.6 Connecting to load

When the **Stabilization (page 97)** phase is finished, the Gen-set can be connected to the load.

The command for connecting the Gen-set to the load is issued either automatically (AUTO, TEST modes) or manually by pressing the GCB button. The following conditions must be valid:

- The Gen-set is running and the **Minimal Stabilization Time (page 188)** timer has elapsed.
- The Gen-set voltage and frequency are within limits.

5.5.7 MRS operation

The "MRS function" represents manual or remote start of Gen-set. It is ideal for prime power applications.

The MRS procedure

When the start command is detected, the following steps are performed:

- The Gen-set is started.
- GCB is closed and the Gen-set begins to supply the load (in AUTO mode, otherwise GCB button has to be pressed)

When the stop command is detected, the following steps are performed:

- GCB is opened and the Gen-set stops supply the load.
- After GCB is opened, the Gen-set cools down and a stop.

5.5.8 AMF operation

The "AMF function" represents the automatic start in the event that the mains have failed and stop after the mains have been restored. The automatic start can be enabled or disabled by binary inputs **AMF START BLOCK (PAGE 309)** or **MAINS FAIL BLOCK (PAGE 322)**.

Note: *The AMF function works only in AUTO mode.*

Mains failure detection

The mains are considered as faulty when one or more of the following conditions are valid:

- The mains voltage is out of the limits given by the setpoints **Mains Undervoltage (page 219)** and **Mains Overvoltage (page 218)** for a time period longer than **Mains <> Voltage Delay (page 219)**.
- The mains frequency is out of the limits given by the setpoints **Mains Underfrequency (page 220)** and **Mains Overfrequency (page 219)** for a time period longer than **Mains < > Frequency Delay (page 220)**.
- The MCB close command was not successful and the alarm **Wrn MCB Fail (page 389)** was not reset.
- Phase rotation is incorrect.

Healthy mains detection

The mains are considered to be healthy when all of following conditions are valid:

- The mains voltage is within the limits given by the setpoints **Mains Undervoltage (page 219)** and **Mains Overvoltage (page 218)**.
- The mains frequency is within the limits given by the setpoints **Mains Underfrequency (page 220)** and **Mains Overfrequency (page 219)**.
- The alarm **Wrn MCB Fail (page 389)** is not active (if MCB feedback is active). This condition is not required if MCB is open (MCB feedback is inactive).
- Phase rotation is correct.

The AMF procedure

When the mains failure is detected, the following steps are performed:

- If the setpoint **MCB Opens On (page 223)** is set to Mains Fail, the MCB is opened
- The timer for automatic start of the Gen-set **Emergency Start Delay (page 216)** begins to count down.
- After the timer has elapsed, the Gen-set is started.

Note: *The automatic start of the Gen-set due to AMF function can be disabled by the binary inputs **AMF START BLOCK (PAGE 309)** or **MAINS FAIL BLOCK (PAGE 322)**.*

- If the setpoint **MCB Opens On (page 223)** is set to Gen Run, the MCB is opened once the generator voltage is within limits (after **Minimal Stabilization Time (page 188)** elapses).

Note: *If the mains are restored to health and the Gen-set is still not connected to the load, the controller interrupts the startup process and closes back the MCB.*

- After **Transfer Delay (page 217)** elapses, the GCB is closed and the Gen-set begins to supply the load.
- After the mains restored to normal, the timer **Mains Return Delay (page 216)** begins to count down.
- Maximum time between closing of MCB and opening GCB is given by the setpoint **Transfer Delay (page 217)**. After GCB is opened, the Gen-set cools down and a stops.

5.5.9 Engine cool down and stop

The cool down phase follows after the stop command has been issued and the GCB has been opened.

- Duration of the cool down phase is determined by the setpoint **Cooling Time (page 190)**.
- Cooling is performed either at nominal speed (generator voltage and frequency protections are evaluated) or at idle speed (generator voltage and frequency protections are not evaluated). Selection of the speed is done by the setpoint **Cooling Speed (page 190)**.
- The cool down can be finished manually in MAN mode by pressing the STOP button.
- If a new start request comes, the cool down will be interrupted and the Gen-set will go back to the stabilization phase. If the cooling was at nominal speed, the stabilization timers will not count down again so the GCB is ready to be closed (after 2 seconds delay).

When the cool down is finished, the output **FUEL SOLENOID (PAGE 342)** is de-energized and **STOP SOLENOID (PAGE 362)** is energized. The engine will stop within the time period determined by the setpoint **Stop Time (page 190)**. If the engine does not stop within this time, the alarm **Wrn Stop Fail (page 390)** will be issued.

The output **STOP SOLENOID (PAGE 362)** is energized until the engine is stopped, but at least for the duration of **Stop Time (page 190)**. If the **Stop Time (page 190)** has elapsed and the engine has still not stopped, the **STOP SOLENOID (PAGE 362)** is de-energized for 5 s and then energized again for **Stop Time (page 190)** and this repeats until the engine is stopped.

Stopped Gen-set evaluation

The Gen-set is considered as stopped when all of following conditions are valid:

- The engine speed is lower than 2 RPM.
- The generator voltage in all phases is lower than 10 V.
- None of **Additional running engine indications (page 117)** signals is active.

5.5.10 Alarm management

The controller evaluates two levels of alarms. Level 1 – yellow alarm – is a pre-critical alarm that is only informative and does not take any action regarding Gen-set control. Level 2 – red alarm – represents a critical situation, where an action must be taken to prevent damage of the Gen-set or technology.

- One alarm of any type can be assigned to each binary input.
- Two alarms (one yellow and one red type) can be assigned to each analog input.
- There are also **Built-in alarms (page 103)** with fixed alarm types.
- Each alarm is written to the **Alarmlist (page 103)**.
- Each alarm causes a record to be written into the history log.
- Each alarm activates the Alarm and Horn output.
- Each alarm can cause sending of a SMS message or an email.

Analog input alarm evaluation principle




Image 5.12 Analog input alarm evaluation principle

Alarm handling

There are three different alarm categories regarding the period when the alarms are evaluated. The category is selectable for alarms assigned to binary/analog inputs and fixed for built-in alarms. The categories are the following:

- The alarm is evaluated all the time when the controller is switched on.
- The alarm is evaluated only when the engine is running. This type should be used for e.g. oil pressure. These alarms begin to be evaluated after the engine has been started with the delay given by the setpoint **Protection Hold Off (page 189)**.
- The alarm is evaluated only when the generator is excited. These alarms begin to be evaluated after the engine has been started and **Maximal Stabilization Time (page 189)** has elapsed or the GCB has been closed. They remain evaluated until cooling has finished. Only Generator under/overvoltage and Generator under/overfrequency belong to this category. This category is not configurable to binary and analog input alarms.

If an alarm is being evaluated and the appropriate alarm condition is fulfilled, the delay of evaluation will start to run. The delay is adjustable by a setpoint (in the case of built-in alarms, analog input alarms) or is adjusted via configuration window in IntelliConfig (in the case of binary input alarms). If the conditions persist, the alarm will activate. The alarm will not activate if the condition is dismissed while the delay is still running.

After pressing the Fault reset button or activating the binary input **FAULT RESET BUTTON (PAGE 320)**, all active alarms change to confirmed state. Confirmed alarms will disappear from the Alarmlist as soon as the respective condition dismisses. If the condition is dismissed before acknowledging the alarm, the alarm will remain in the Alarmlist as Inactive.

Note: The input **SD OVERRIDE (PAGE 328)** can be used for temporary disabling of red alarms to shutdown the engine. This input may be used in situations where providing the power is extremely important – e.g. if the Gen-set drives pumps for fire extinguishers (sprinklers).

Alarm states

An alarm can have following states:

- Active alarm: the alarm condition persists, alarm delay has elapsed.
- Inactive alarm: the alarm condition has disappeared, but the alarm has not been confirmed.
- Confirmed alarm: the alarm condition persists, but the alarm has already been confirmed.



Image 5.13 Alarm List

Alarm types – Level 1

The level 1 alarm indicates that a value or parameter is out of normal limits, but has still not reached critical level. This alarm does not cause any actions regarding the Gen-set control.

Warning (Wrn)

The alarm appears in the Alarmlist and is recorded into the history log. Activates the output **AL COMMON WRN** (PAGE 333) as well as the standard alarm outputs (**HORN** (PAGE 350) and **ALARM** (PAGE 337)).

Alarm indication only (AL Indic)

The alarm indication only alarm does not perform any actions regarding Gen-set control. Alarm is only displayed in alarmlist.

History record only (HistRecOnl)

The event is recorded into the history. Standard alarm outputs (**HORN** (PAGE 350) and **ALARM** (PAGE 337)) are not activated.

Alarm types – Level 2

The level 2 level alarm indicates that a critical level of the respective value or parameter has been reached.

Note: *It is not possible to start the engine if any red level protection is active or not confirmed.*

IMPORTANT: The Gen-set can start by itself after acknowledging the alarms if there is no longer an active red alarm and the controller is in AUTO or TEST mode!

Shutdown (Sd)

The alarm appears in the alarmlist and is recorded into the history log. It causes immediate stop of the Gen-set without cooling phase. Also GCB breaker is open. The Gen-set cannot be started again while there is a shutdown alarm in the alarmlist. Activates the output **AL COMMON Sd** (PAGE 333) as well as the standard alarm outputs (**HORN** (PAGE 350) and **ALARM** (PAGE 337)).

Breaker open and cool down (BOC)

The event appears in the alarmlist and is recorded into the history log. It causes immediate opening of the GCB and then the standard stop sequence with cooling follows. The Gen-set cannot be started again while there is a BOC alarm in the alarmlist. Activates the output **AL COMMON BOC (PAGE 333)** as well as the standard alarm outputs (**HORN (PAGE 350)** and **ALARM (PAGE 337)**).

IMPORTANT: In case there is no feedback from breakers configured Breaker open and cool down will be replaced by shutdown alarm type.

Note: When there is no control of breakers, the type of protection is Sd not BOC.

Sensor fail detection (FLS)

If the measured resistance on an analog input exceeds the valid range, a sensor fail will be detected and a sensor fail message will appear in the **Alarmlist (page 103)**. The valid range is defined by the most-left (RL) and most-right (RH) points of the sensor characteristic $\pm 12.5\%$ from RH-RL.

Note: Sometimes there can be problem with lower limit of valid range which can be counted as negative number. In this case the lower limit is set as one half of the RL point of the sensor curve characteristic.




Image 5.14 Sensor fail detection principle

Remote alarm messaging

If communication plug-in module is connected to the controller, the controller can send SMS messages and emails at the moment when a new alarm appears in the **Alarmlist (page 103)** or new event is written in **History log (page 105)**. The message will contain a copy of the **Alarmlist (page 103)** or reasons from **History log (page 105)**. To enable this function, adjust setpoints **Event Message (page 249)**, **Wrn Message (page 250)**, **BOC Message (page 250)** and **Sd Messages (page 251)** to ON. Also enter a valid GSM phone number or email address to the setpoints **Telephone Number 1 (page 247)**, **Email Address 1 (page 248)**, .

The list of all supported terminals shows the table below:

| Terminal | Event SMS | Warning SMS | BOC SMS | Shutdown SMS | Event email | Warning email | BOC email | Shutdown email |
|--------------|-----------|-------------|---------|--------------|-------------|---------------|-----------|----------------|
| CM-RS232-485 | no | no | no | no | no | no | no | no |
| CM-Ethernet | no | no | no | no | yes | yes | yes | yes |
| CM-GPRS | yes | yes | yes | yes | no | no | no | no |
| CM-4G-GPS | yes | yes | yes | yes | no | no | no | no |

Alarmlist

Alarmlist is a container of active and inactive alarms. It will appear automatically on the controller display, if a new alarm occurs, or can be displayed manually from the display menu.

Active alarms are shown as inverted, not yet confirmed alarms are marked with asterisk before them.

Alarmlist contains three types of alarms:

- > Controller built-in alarms
- > User configured alarms on binary or analog inputs
- > ECU alarms

Controller built-in alarms

An alarm message in the alarmlist begins with a prefix, which represents the alarm type (e.g. Wrn, Sd, BOC, MP, MPR). Then the alarm name follows. In some cases the prefix can be omitted.

User configured alarms

An alarm message in the alarmlist begins with a prefix, which represents the alarm type (e.g. Wrn, Sd, BOC). Alarm type is selected by user during the configuration of binary or analog user protection. Then the alarm name follows, which can be adjusted by user during the configuration.

ECU alarms

The ECU alarms are received from the ECU. The alarms are represented by the Diagnostic Trouble Code, which contains information about the subsystem where the alarm occurred, the alarm type and the alarm occurrence counter.

The most common fault codes are translated into text form. Other fault codes are displayed as a numeric code and the engine fault codes list must be used to determine the reason.

Built-in alarms

| Events specification | Protection type | Description |
|----------------------|-----------------|--|
| Analog Input 1 Wrn | WRN | Value measured on analog input 1 is </> than Analog Protection 1 Wrn (page 223) setpoint. |
| Analog Input 1 Sd | SD | Value measured on analog input 1 is </> than Analog Protection 1 Sd (page 224) setpoint. |
| Analog Input 2 Wrn | WRN | Value measured on analog input 2 is </> than Analog |

| Events specification | Protection type | Description |
|--|-----------------|---|
| | | Protection 2 Wrn (page 225) setpoint. |
| Analog Input 2 Sd | SD | Value measured on analog input 2 is </> than Analog Protection 2 Sd (page 225) setpoint. |
| Analog Input 3 Wrn | WRN | Value measured on analog input 3 is </> than Analog Protection 3 Wrn (page 226) setpoint. |
| Analog Input 3 Sd | SD | Value measured on analog input 3 is </> than Analog Protection 3 Sd (page 227) setpoint. |
| Wrn Battery Voltage | WRN | Battery voltage is out of limits given by Battery Undervoltage (page 204) and Battery Overvoltage (page 204) setpoints. |
| Binary input | | Configurable Warning/BOC/Shutdown alarms on the binary inputs. |
| Sd Battery Flat | SD | If the controller switches off during starting sequence (STARTER (PAGE 361) output is active) it doesn't try to start again and activates this protection (controller assumes bad battery condition). |
| Sd Start Fail | SD | Gen-set start failed. All crank attempts were tried without success. |
| Parameters Fail | NONE | Wrong check-sum of parameters. Happens typically after downloading new firmware or changing of the parameter. The controller stays in INIT mode. Check all parameters, change value of at least one parameter. |
| Sd Gen Lx Undervoltage BOC Gen Lx Overvoltage (where x=1,2,3) | SD BOC | The generator voltage is out of limits given by Generator Undervoltage BOC (page 210) and Generator Overvoltage Sd (page 209) setpoints. |
| BOC Gen >, <Frequency | BOC | The generator frequency is out of limits given by Generator Overfrequency BOC (page 211) and Generator Underfrequency BOC (page 212) setpoints. |
| BOC Overload | BOC | The load is greater than the value given by Overload BOC (page 207) setpoint. |
| Sd Overspeed | SD | The protection comes active if the speed is greater than Overspeed Sd (page 192) setpoint. |
| Sd Underspeed | SD | During starting of the engine when the RPM reach the value of Starting RPM (page 177) setpoint the starter is switched off and the speed of the engine can drop under Starting RPM (page 177) again. Then the Underspeed protection is active. Protection evaluation starts 5 seconds after reaching Starting RPM (page 177) . |
| Emergency Stop | SD | If the input Emergency Stop is active shutdown is immediately activated. |

| Events specification | Protection type | Description |
|-------------------------|-----------------|---|
| GCB Fail | SD | Failure of generator circuit breaker. |
| MCB Fail | WRN | Failure of mains circuit breaker. |
| Sd RPM Measurement Fail | SD | Failure of magnetic pick-up sensor for speed measurement. This alarm appears, if starter was disengaged for other reason than over-crossing Starting RPM (page 177) (like oil pressure or D+) and at the end of timer Maximum Cranking Time (page 176) there are no RPMs > Starting RPM (page 177) detected. |
| Wrn Stop Fail | WRN | Gen-set stop failed. See description at Gen-set Operation States chapter. |
| Wrn Maintenance 1 | WRN | The period for servicing is set by the Maintenance Timer 1 (page 203) setpoint. The protection comes if counter reaches zero. |
| Wrn Maintenance 2 | WRN | The period for servicing is set by the Maintenance Timer 2 (page 203) setpoint. The protection comes if counter reaches zero. |
| Wrn Maintenance 3 | WRN | The period for servicing is set by the Maintenance Timer 3 (page 204) setpoint. The protection comes if counter reaches zero. |
| Charge Alternator Fail | WRN | Failure of alternator for charging the battery. |
| Sd Override | WRN | The protection is active if the output Sd Override is active. |
| Mains CCW Rot | WRN | Mains voltage phases are not wired correctly. MCB closing is prohibited by controller. |
| Generator CCW Rot | WRN | Gen-set voltage phases are not wired correctly. GCB closing is prohibited by controller. |

Note: This table does not contain all alarms in controller. It is only list of the most common alarms.

5.5.11 History log

The history log is an area in the controller's non-volatile memory that records "snapshots" of the system at moments when important events occur. The history log is important especially for diagnostics of failures and problems. When the history file is full, the oldest records are removed.

Each record has the same structure and contains:

- The event which caused the record (e.g. "Overspeed alarm" or "GCB closed")
- The date and time when it was recorded
- All important data values like RPM, kW, voltages, etc. from the moment that the event occurred.

Record structure

| Name | Abbreviation | Description |
|---------------------|--------------|---|
| Number | No. | Row number (0 corresponds to the last record, -1 to the previous one, etc.) |
| Reason | Reason | Reason for history record (any event or alarm related to the gen-set) |
| Time | Time | Time |
| Date | Date | Date |
| RPM | RPM | Engine rotations per minute |
| Power | Pwr | Generator active power |
| Reactive power | Q | Generator reactive power |
| Power Factor | PF | Generator power factor |
| Load Character | LChr | Generator load character |
| Generator Frequency | Gfrq | Generator Frequency |
| Generator Voltage | Vg1 | Generator voltage Ph1 |
| Generator Voltage | Vg2 | Generator voltage Ph2 |
| Generator Voltage | Vg3 | Generator voltage Ph3 |
| Generator Voltage | Vg12 | Generator voltage Ph12 |
| Generator Voltage | Vg23 | Generator voltage Ph23 |
| Generator Voltage | Vg31 | Generator voltage Ph31 |
| Generator Current | Ig1 | Generator current Ph1 |
| Generator Current | Ig2 | Generator current Ph2 |
| Generator Current | Ig3 | Generator current Ph3 |
| Mains Frequency | Mfrq | Mains Frequency |
| Mains Voltage | Vm1 | Mains voltage Ph1 |
| Mains Voltage | Vm2 | Mains voltage Ph2 |
| Mains Voltage | Vm3 | Mains voltage Ph3 |
| Mains Voltage | Vm12 | Mains voltage Ph12 |
| Mains Voltage | Vm23 | Mains voltage Ph23 |
| Mains Voltage | Vm31 | Mains voltage Ph31 |
| Voltage Battery | VBat | Voltage of battery |
| Analog Input 1 | Ain1 | Analog input 1 |
| Analog Input 2 | Ain2 | Analog input 2 |
| Analog Input 3 | Ain3 | Analog input 3 |
| Binary Inputs | BIN | Controller binary inputs |
| E-Stop | E-Stop | State of dedicated E-Stop input |
| Binary Outputs | BOUT | Controller binary outputs |
| Controller Mode | Mode | Controller mode |

Note: When some setpoint is changed, in history log is written its number of communication object.

5.5.12 Breaker control

The following power switches are controlled by the controller:

- The generator circuit breaker or contactor – GCB
- The Mains circuit breaker or contactor – MCB

It is possible to use either a motorized circuit breaker or contactor. Below is a list of available control outputs that should fit all types of contactors or breakers. The following rules must be kept to when designing the wiring of power switches:

- The control outputs must be configured and wiring of the power switches must be provided in such a way, that the controller has full control over the breakers – i.e. the controller can open and close the breaker at any time.
- The breaker must respond within max. 5 seconds to a close and open command. Special attention should be paid to opening of motorized circuit breakers, as it could take more than 5 seconds on some types. In such cases it is necessary to use an undervoltage coil for fast opening.
- After opening the breaker, there is internal delay for another closing of breaker. Delay is 6 seconds – 5 seconds for OFF coil and 1 second for UV coil. After these 6 seconds, breaker can be closed again. For opening of breaker there is no delay.

Breaker control outputs

| | |
|-------------------|--|
| Close/Open | An output for control of a contactor. Its state represents the breaker position requested by the controller. The breaker must react within 5 seconds to a close or open command, otherwise an alarm is issued. |
| ON coil | An output giving a 5 second pulse in the moment the breaker has to be closed. The output is intended for control of close coils of circuit breakers. |
| OFF coil | An output giving a pulse in the moment the breaker has to be opened. The pulse lasts until the feedback deactivates, but at least for 5 seconds. The output is intended for control of open coils of circuit breakers. |
| UV coil | The GCB UV coil output is active the whole time the Gen-set is running (not in idle or cooling). The MCB UV coil output is active when the controller is switched on. The output is deactivated for at least 5 seconds in the moment the breaker has to be switched off. The output is intended for control of undervoltage coils of circuit breakers. |




Image 5.15 Breaker control outputs

MCB special requirements

- If a contactor is used on the MCB position, it is recommended that the wiring be provided in such a way that the contactor will be normally closed and will open if the logical binary output **MCB CLOSE/OPEN (PAGE 351)** is activated. This behavior is called "negative logic" and can be adjusted by the setpoint **MCB Logic (page 221)**. The negative logic will prevent accidental opening of the MCB when the controller is switched off.
- If a contactor is used on the MCB position, it will open itself immediately after the mains have failed, because it will lose power for the coil. That is why the following adjustment is necessary to prevent triggering the **Wrn MCB Fail (page 389)** alarm: **MCB Opens On (page 223) = Mains Fail, Mains <> Voltage Delay (page 219) ≤ 1**.
- If a 230 V motor driven circuit breaker is used on the MCB position and an undervoltage coil is not fitted, it is not possible to open the breaker after the mains have failed, because there is no power for the motor drive until the Gen-set is started and providing voltage. Adjusting the setpoint **MCB Opens On (page 223) = Gen Run** will prevent triggering the **Wrn MCB Fail (page 389)** alarm.

Breaker fail detection

Breaker fail detection is based on binary output breaker close/open comparing with binary input breaker feedback.

IMPORTANT: It is necessary to configure breaker feedback to use this function.

IMPORTANT: Also it is possible to use breakers without feedbacks. In this case there is no check of breaker real state.

There are three different time delays for breaker fail detection – see following diagrams.

When binary output breaker close/open is in steady state and breaker feedback is changed the breaker fail is detected immediately (no delay).




Image 5.16 Breaker fail – breaker close/open in steady position – open




Image 5.17 Breaker fail – breaker close/open in steady position – close

When binary output breaker close/open opens there is 5 sec delay for breaker fail detection.




Image 5.18 Breaker fail – breaker close/open opens

When binary output breaker close/open closes there is 5 sec delay for breaker fail detection.




Image 5.19 Breaker fail – breaker close/open closes

5.5.13 Exercise timer

The exercise (general-purpose) timer in controller intended for scheduling of any operations such as e.g. periodic tests of the Gen-set, scheduled transfer of the load to the Gen-set prior to an expected disconnection of the mains etc.

Related setpoints for timer 1 are:

- > **Timer 1 Function (page 230)**
 - > **Timer 1 Repetition (page 231)**
 - > **Timer 1 First Occur. Date (page 232)**
 - > **Timer 1 First Occur. Time (page 232)**
 - > **Timer 1 Duration (page 232)**
 - > **Timer 1 Repeated (page 233)**
 - > **Timer 1 Repeat Day (page 236)**
- > **Timer 1 Day (page 235)**
 - > **Timer 1 Repeated Day In Week (page 236)**
 - > **Timer 1 Repeat Day In Month (page 236)**
 - > **Timer 1 Repeat Week In Month (page 237)**
 - > **Timer 1 Refresh Period (page 234)**
 - > **Timer 1 Weekends (page 235)**

Available modes of timer:

| | |
|---------------------|---|
| Once | This is a single shot mode. The timer will be activated only once at preset date/time for preset duration. |
| Daily | The timer is activated every "x-th" day. The day period "x" is adjustable. Weekends can be excluded. E.g. the timer can be adjusted to every 2nd day excluding Saturdays and Sundays. |
| Weekly | The timer is activated every "x-th" week on selected weekdays. The week period "x" is adjustable. E.g. the timer can be adjusted to every 2nd week on Monday and Friday. |
| Monthly | The timer is activated every "x-th" month on the selected day. The requested day can be selected either as "y-th" day in the month or as "y-th" weekday in the month. E.g. the timer can be adjusted to every 1st month on 1st Tuesday. |
| Short period | The timer is repeated with adjusted period (hh:mm). The timer duration is included in the period. |

Once mode

Set-up via IntelliConfig

To set-up timer via IntelliConfig go to the setpoint ribbon, setpoint group scheduler and setpoint *Timer 1 Setup*.

Note: First of all function of timer has to be adjusted via setpoint *Timer 1 Function* (page 230).




Image 5.20 Once mode – IntelliConfig

In timer mode select Once. In timer settings adjust date and time of occurrence of timer. Also adjust the duration of timer.

Set-up via controller interface

In controller go to the Scheduler setpoint group. Select the function of timer via **Timer 1 Function** (page 230) setpoint. Then go to *Timer 1 Setup* and press enter button. In **Timer 1 Repetition** (page 231) setpoint select Once mode. Then adjust **Timer 1 First Occur. Date** (page 232), **Timer 1 First Occur. Time** (page 232) and **Timer 1 Duration** (page 232).

Note: Use left and right buttons to move between timer setpoints.

Daily mode

Set-up via IntelliConfig

To set-up timer via IntelliConfig go to the setpoint ribbon, setpoint group scheduler and setpoint *Timer 1 Setup*.

Note: First of all function of timer has to be adjusted via setpoint *Timer 1 Function* (page 230).




Image 5.21 Daily mode – IntelConfig

In timer mode select Repeat. In repetition type select Daily. In timer settings adjust date and time of first occurrence of timer. Also adjust the duration of each occurrence of timer. Then select the x-th day of repetition (**Timer 1 Refresh Period (page 234)**) and behavior of timer on weekends (**Timer 1 Weekends (page 235)**).

Example: On image example first start of timer will be 1/1/2016 at 12:00. Duration will be 1 hour. Timer will be again activated every 3rd day at 12:00 for 1 hour including weekends.

Set-up via controller interface

In controller go to the Scheduler setpoint group. Select the function of timer via **Timer 1 Function (page 230)** setpoint. Then go to *Timer 1 Setup* and press enter button. In **Timer 1 Repetition (page 231)** setpoint select Repeated mode. Then adjust **Timer 1 First Occur. Date (page 232)**, **Timer 1 First Occur. Time (page 232)** and **Timer 1 Duration (page 232)**. In setpoint **Timer 1 Repeated (page 233)** select Daily and adjust **Timer 1 Refresh Period (page 234)** (x-th day of repetition) and **Timer 1 Weekends (page 235)** (behavior of timer on weekends).

Note: Use left and right buttons to move between timer setpoints.

Weekly mode

Set-up via IntelConfig

To set-up timer via IntelConfig go to the setpoint ribbon, setpoint group scheduler and setpoint *Timer 1 Setup*.

Note: First of all function of timer has to be adjusted via setpoint **Timer 1 Function (page 230)**.




Image 5.22 Weekly mode – IntelConfig

In timer mode select Repeat. In repetition type select Weekly. In timer settings adjust date and time of first occurrence of timer. Also adjust the duration of each occurrence of timer. Then select the x-th week of repetition (**Timer 1 Refresh Period (page 234)**) and days when timer should be active (**Timer 1 Day (page 235)**).

Example: On image example first start of timer will be 1/1/2016 at 12:00. Duration will be 1 hour. Timer will be again activated every 2nd week on Monday, Wednesday and Friday at 12:00 for 1 hour.

Set-up via controller interface

In controller go to the Scheduler setpoint group. Select the function of timer via **Timer 1 Function (page 230)** setpoint. Then go to *Timer 1 Setup* and press enter button. In **Timer 1 Repetition (page 231)** setpoint select Repeated mode. Then adjust **Timer 1 First Occur. Date (page 232)**, **Timer 1 First Occur. Time (page 232)** and **Timer 1 Duration (page 232)**. In setpoint **Timer 1 Repeated (page 233)** select Weekly and adjust **Timer 1 Day (page 235)** (days when timer should be active) and **Timer 1 Refresh Period (page 234)** (x-th week of repetition).

Note: Use left and right buttons to move between timer setpoints.

Monthly mode

Set-up via IntelConfig

To set-up timer via IntelConfig go to the setpoint ribbon, setpoint group scheduler and setpoint *Timer 1 Setup*.

Note: First of all function of timer has to be adjusted via setpoint **Timer 1 Function (page 230)**.

There are two types of monthly repetition. First of them is based on repeating one day in month.




Image 5.23 Monthly mode – IntelIConfig

In timer mode select Repeat. In repetition type select Monthly. In timer settings adjust date and time of first occurrence of timer. Also adjust the duration of each occurrence of timer. Than select the type of monthly repetition and the x-th day of repetition (**Timer 1 Repeat Day In Month (page 236)**). Than select the x-th month of repetition.

Example: On image example first start of timer will be 1/1/2016 at 12:00. Duration will be 1 hour. Timer will be again activated every 2nd day in 2nd month at 12:00 for 1 hour.

Second type of monthly repetition is based on repeating days in week in month.




Image 5.24 Monthly mode – IntelIconfig

In timer mode select Repeat. In repetition type select Monthly. In timer settings adjust date and time of first occurrence of timer. Also adjust the duration of each occurrence of timer. Than select the type of monthly repetition, the x-th week of repetition and days in week. Than select the x-th month of repetition.

Example: On image example first start of timer will be 1/1/2016 at 12:00. Duration will be 1 hour. Timer will be again activated every 2nd week in 2nd month on Monday, Wednesday and Friday at 12:00 for 1 hour.

Set-up via controller interface

There are two types of monthly repetition. First of them is based on repeating one day in month.

In controller go to the Scheduler setpoint group. Select the function of timer via **Timer 1 Function (page 230)** setpoint. Than go to *Timer 1 Setup* and press enter button. In **Timer 1 Repetition (page 231)** setpoint select Repeated mode. Than adjust **Timer 1 First Occur. Date (page 232)**, **Timer 1 First Occur. Time (page 232)** and **Timer 1 Duration (page 232)**. In setpoint **Timer 1 Repeated (page 233)** select Monthly and adjust type of monthly repetition via **Timer 1 Repeat Day (page 236)**, **Timer 1 Refresh Period (page 234)** (x-th month of repetition) and **Timer 1 Repeat Day In Month (page 236)** (concrete day in repeated months).

Second type of monthly repetition is based on repeating days in week in month.

In controller go to the Scheduler setpoint group. Select the function of timer via **Timer 1 Function (page 230)** setpoint. Than go to *Timer 1 Setup* and press enter button. In **Timer 1 Repetition (page 231)** setpoint select Repeated mode. Than adjust **Timer 1 First Occur. Date (page 232)**, **Timer 1 First Occur. Time (page 232)** and **Timer 1 Duration (page 232)**. In setpoint **Timer 1 Repeated (page 233)** select Monthly and adjust type of monthly repetition via **Timer 1 Repeat Day (page 236)**, **Timer 1 Refresh Period (page 234)** (x-th month of repetition), **Timer 1 Repeated Day In Week (page 236)** (days in week when timer is active) and **Timer 1 Repeat Week In Month (page 237)** (concrete week in repeated months).

Note: Use left and right buttons to move between timer setpoints.

Short period mode

Set-up via IntelliConfig

To set-up timer via IntelliConfig go to the setpoint ribbon, setpoint group scheduler and setpoint *Timer 1 Setup*.

Note: First of all function of timer has to be adjusted via setpoint *Timer 1 Function* (page 230).




Image 5.25 Short period mode – IntelliConfig

In timer mode select Repeat. In repetition type select Short period. In timer settings adjust date and time of first occurrence of timer. Also adjust the duration of each occurrence of timer. Then select the interval of repetition (shorter than 1 day).

Example: On image example first start of timer will be 1/1/2016 at 12:00. Duration will be 1 hour. Timer will be again activated every 4th hour for 1 hour.

Set-up via controller interface

In controller go to the Scheduler setpoint group. Select the function of timer via **Timer 1 Function** (page 230) setpoint. Then go to *Timer 1 Setup* and press enter button. In **Timer 1 Repetition** (page 231) setpoint select Repeated mode. Then adjust **Timer 1 First Occur. Date** (page 232), **Timer 1 First Occur. Time** (page 232) and **Timer 1 Duration** (page 232). In setpoint **Timer 1 Repeated** (page 233) select Short Period and adjust **Timer 1 Refresh Period** (page 234) (interval of repetition).

Note: Use left and right buttons to move between timer setpoints.

5.5.14 Service timers

Running hours counters

Service timers are used as maintenance interval counters. Counters can be set by setpoints – **Maintenance Timer 1 (page 203)**, **Maintenance Timer 2 (page 203)**, **Maintenance Timer 3 (page 204)**. All of them work the same way – their values are decremented every hour when the Gen-set is running.

Actual values of the counters are available as the same setpoints **Maintenance Timer 1 (page 203)**, **Maintenance Timer 2 (page 203)**, **Maintenance Timer 3 (page 204)** or as values **Maintenance 1 (page 290)**, **Maintenance 2 (page 291)** and **Maintenance 3 (page 291)**.

When the value of counter reaches 0, the alarm **Wrn Maintenance 1 (page 388)** or **Wrn Maintenance 2 (page 388)** or **Wrn Maintenance 3 (page 389)** is active until the respective counter reset is done.

Unused counter has to be adjusted to maximal value 10000 (Disabled).

5.5.15 Additional running engine indications

It is helpful to have information other than speed (RPM), whether the engine is rotating or not, especially if RPM is measured from the generator frequency instead of magnetic pickup. The generator frequency measurement can be unreliable at very low speeds and/or may have a delayed reaction to sudden and big changes (i.e. in the moment that the engine has just started...).

The following conditions are evaluated as additional running engine indication:

- Voltage on the D+ input is higher than the **D+ Threshold (page 184)** of battery voltage. Connect this input to the D+ (L) terminal of the charging alternator and enable the D+ function by the setpoint **D+ Threshold (page 184)**. If D+ terminal is not available, leave the input unconnected and disable the function.
- The pickup is not used and frequency is not detected on the pickup input. Connect the pickup input to the W terminal of the charging alternator if you do not use pickup and the W terminal is available. If not, leave the input unconnected.
- Oil pressure > **Starting Oil Pressure (page 178)** setpoint. The oil pressure is evaluated from the analog input or from the ECU if an ECU is configured.
- Binary input **OIL PRESSURE (PAGE 324)** is in logical 0.
- At least one phase of generator voltage is >25 % of nominal voltage.

These signals are used during start for powering down the starter motor even if still no RPM is measured and also during stop in order to evaluate if the engine is really stopped.

5.5.16 Voltage phase sequence detection

Controller detects phase sequence voltage terminals. This protection is important after controller installation to avoid wrong voltage phase connection. There is fix defined phase sequence in controller L1, L2, L3. When the phases are connected in different order (e.g. L1,L3,L2 or L2,L1,L3) following alarms are detected:

- **Generator CCW Rotation (page 390)**
- **Mains CCW Rotation (page 391)**

5.5.17 Gen-set operation states

Engine state machine

| | |
|------------------|--|
| Init | Autotest during controller power on. Note: Sometimes controller stays in Init mode after FW upgrade. It means that there are new parameters which should be checked by user. It is possible to disable this control via IntelliConfig. |
| Not ready | Gen-set is not ready to start. Example: When shutdown alarm is active or unit is in OFF mode. |
| Prestart | Prestart sequence in process, PRESTART (PAGE 357) output is active. Example: Usually used for preheating or processes executed prior Gen-set start. |
| Cranking | Engine is cranking, STARTER (PAGE 361) output is active. |
| Pause | Pause between start attempts. |
| Starting | Starting speed is reached and the Idle timer is running. |
| Running | Gen-set is running at nominal speed. |
| Loaded | Gen-set is running at nominal speed and GCB CLOSE/OPEN (PAGE 343) is active. |
| Stop | Stop. Example: Automatic or manual stop command was issued, engine is stopping. |
| Shutdown | Shut-down alarm activated. |
| Ready | Gen-set is ready to run. |
| Cooling | Gen-set is cooling before stop. |

Engine started conditions

- Engine speed (RPM) > **Starting RPM (page 177)** or
- Oil pressure > **Starting Oil Pressure (page 178)** or
- Binary input **OIL PRESSURE (PAGE 324)** is in logical 0 or
- D+ terminal active (reached **D+ Threshold (page 184)** of supply voltage) for minimum 1 s or
- Generator voltage > 25 % of **Nominal Voltage Ph-N (page 166)** or **Nominal Voltage Ph-Ph (page 167)** (any phase)

Note: Any of these condition will disconnect starter of the engine, however for transition to next state RPM needs to be higher than **Starting RPM (page 177)**.

Engine running conditions

- Engine speed (RPM) > **Starting RPM (page 177)** or
- Oil pressure > **Starting Oil Pressure (page 178)** or
- Binary input **OIL PRESSURE (PAGE 324)** is in logical 0 or
- Generator voltage > 25 % of **Nominal Voltage Ph-N (page 166)**

Still engine conditions

- > Engine speed (RPM) < **Starting RPM (page 177)** and
- > Oil pressure < **Starting Oil Pressure (page 178)** and
- > Binary input **OIL PRESSURE (PAGE 324)** is in logical 1 and
- > Generator voltage < 50 V (all phases)

Note: When the engine was running before and all above conditions are fulfilled, additional 2 s delay is necessary to confirm "still engine".

When any engine running conditions are appeared on still engine than the **Wrn Stop Fail (page 390)** is activated with following delay:

- > For generator voltage from 10 V to < 50 % of nominal voltage, Wrn Stop Fail has delay 1 s
- > For generator voltage > 50 % of nominal voltage, Wrn Stop Fail has delay 200 ms
- > Oil pressure > **Starting Oil Pressure (page 178)**, Wrn Stop Fail has delay 1 s
- > Binary input **OIL PRESSURE (PAGE 324)** is in logical 0, Wrn Stop Fail has delay 1 s
- > For detected RPM, there is no delay.

Stop engine conditions

If no engine running conditions are validated than the controller will wait extra 12 s before leaving the Machine state Stop and than it will release the **STOP SOLENOID (PAGE 362)** output.




Image 5.26 Engine stops in **Stop Time (page 190)**

When the total time of stopping will exceed setpoint **Stop Time (page 190)** then the **Wrn Stop Fail (page 390)** and binary outputs for stopping are activated. The controller will continuously try to stop the engine.




Image 5.27 Engine stops after first **Stop Time** (page 190)

Electric state machine

| | |
|------------------|--|
| MainsOper | Mains is present and all its values are within limits. ■ Example: MCB is closed, GCB is opened |
| MainsFlt | Mains fails |
| IsOper | Island operation ■ Example: MCB is opened, GCB is closed |
| MainsRet | Mains recover |
| BrksOff | GCB, MCB opened |

5.5.18 Sensor curves

Default sensor curves

There are 16 default resistive curves available. The following table provides information on minimum/maximum values of respective sensors. Actual values especially of temperature curves may differ. Meaning is to prolong curve to the lower temperature values, so the cold engine will not raise alarm fail sensor.

| Curve | Min [Ω] | Max [Ω] | Units |
|----------------------|------------------|------------------|----------|
| VDO 10 Bar 0-2400ohm | 0 | 2400 | Bar |
| VDO40-120°C0-2400ohm | 0 | 2400 | °C |
| VDOLevel%0-2400ohm | 0 | 2400 | % |
| General line 1 | 0 | 1000 | Ω |
| General line 2 | 0 | 1000 | Ω |
| General line 3 | 0 | 1000 | Ω |
| General line 4 | 0 | 1000 | Ω |
| General line 5 | 0 | 1000 | Ω |

| | | | |
|-----------------|---|------|---|
| General line 6 | 0 | 1000 | Ω |
| General line 7 | 0 | 1000 | Ω |
| General line 8 | 0 | 1000 | Ω |
| General line 9 | 0 | 1000 | Ω |
| General line 10 | 0 | 1000 | Ω |
| General line 11 | 0 | 1000 | Ω |
| General line 12 | 0 | 1000 | Ω |
| General line 13 | 0 | 1000 | Ω |

Note: Curves can be modified via IntelliConfig. In IntelliConfig are also prepared some standard curves.

IMPORTANT: For right behavior of function Total Fuel Consumption, curve for analog input FUEL LEVEL (PAGE 369) has to be in percentage.

5.5.19 Tier 4 Final

Tier 4 Final support generally provides monitoring and control of after-treatment system installed on generators engine. The requirements are defined as:

- Providing After-Treatment status information by
 - Displaying universal lamps (icons)
 - Displaying analog and binary values
- Control of After-Treatment regeneration function by
 - Transmitting commands to the ECU

Providing After-treatment status information

After-Treatment screen

This screen is shown with configured ECU which supports Tier 4 Final. After-Treatment screen is automatically shown, once any of selected lamps gets active or change status. Deactivating of the lamp will not trigger showing the screen. The screen is then shown until operator switch it to another one. Alarmlist screen has lower priority so even new alarm appears, After-treatment screen is still displayed. To avoid displaying blank screen, inactive lamps are represented by "dotted" icons. For no active lamp the screen shows all dotted icons. Please see examples below:



Image 5.28 Example of active Tier 4 Final screen




Image 5.29 Example of inactive Tier 4 Final screen







Universal lamps (icons)

Universal lamp icons are shown on the After-Treatment screen. Based on specific value read in specific frame with specific SPN is every lamp icon either:

- > shown
- > hidden
- > blinking slow (1 Hz)
- > blinking fast (2 Hz)

Note: Lamp icon blinking is defined as displaying active lamp icon and inverse colored active lamp icon in required frequency.

| Lamp name | Active icon | Inactive icon | Notes |
|--------------------------------------|-------------|---------------|--|
| Amber warning lamp | | | Note: This value can light or blink on both frequencies. |
| Red stop lamp | | | Note: This value can light or blink on both frequencies. |
| Engine wait to start lamp | | | |
| DPF/SCR lamp command | | | Note: Indicates the After-Treatment filter needs to be regenerated. This lamp also activates alarm ATT Filter Lamp (page 377). |
| Exhaust system high temperature lamp | | | Note: This lamp also activates alarm After-Treatment (page 374). |

| Lamp name | Active icon | Inactive icon | Notes |
|--------------------------------|---|---|--|
| Malfunction indicator lamp |  |  | Note: This value can light or blink on both frequencies. This lamp also activates alarm After-Treatment (page 374) . |
| Fluid tank low level indicator |  |  | Note: This lamp also activates alarm After-Treatment (page 374) . |
| DPF regeneration inhibited |  |  | Note: Indicates the state of diesel particulate filter active regeneration inhibition. This lamp also activates alarm After-Treatment (page 374) . |

Note: ECU Yellow Lamp, ECU Red Lamp, ECU Wait To Start Lamp can be disabled during prestart phase. Checkbox: Ignore ECU lamps during prestart is located in IntelliConfig -> Controller Configuration -> Modules -> ECU module -> Electronic control unit settings.

Note: Aftertreatment support can be disabled. Aftertreatment HMI Screen is hidden and alarms related to aftertreatment are not shown. Use the checkbox: Disable aftertreatment support located in IntelliConfig -> Controller Configuration -> Modules -> ECU module -> Electronic control unit settings.

Analog values

Supported analog values:

- > DPF Ash Load (page 274)
- > DPF Soot Load (page 274)
- > DEF Level (page 274)

Control of After-Treatment regeneration function

User can force or inhibit regeneration process by activating appropriate binary inputs of the controller. Please see the list of binary inputs below:

- > FORCE REGENERATION (PAGE 320)
- > REGENERATION INHIB (PAGE 324)

5.5.20 Alternate configuration

In controller are 3 sets of configuration.

| Configuration set 1 | Configuration set 2 | Configuration set 3 |
|--|--|--|
| Nominal Power Split Phase 1 (page 258) | Nominal Power Split Phase 2 (page 262) | Nominal Power Split Phase 3 (page 266) |
| Nominal Power 1 (page 258) | Nominal Power 2 (page 262) | Nominal Power 3 (page 267) |
| Nominal RPM 1 (page 256) | Nominal RPM 2 (page 260) | Nominal RPM 3 (page 264) |
| Nominal Frequency 1 (page 257) | Nominal Frequency 2 (page 261) | Nominal Frequency 3 (page 265) |
| Nominal Voltage Ph-N 1 (page 257) | Nominal Voltage Ph-N 2 (page 261) | Nominal Voltage Ph-N 3 (page 265) |
| Nominal Voltage Ph-Ph 1 (page 257) | Nominal Voltage Ph-Ph 2 (page 261) | Nominal Voltage Ph-Ph 3 (page 265) |
| Nominal Current 1 (page 259) | Nominal Current 2 (page 263) | Nominal Current 3 (page 267) |
| Connection Type 1 (page 259) | Connection type 2 (page 263) | Connection type 3 (page 267) |
| ECU Speed Adjustment 1 (page 269) | ECU Speed Adjustment 2 (page 269) | ECU Speed Adjustment 3 (page 270) |

Configuration sets can be changed via logical binary inputs CONFIGURATION 2 (PAGE 317) and CONFIGURATION 3 (PAGE 317). Configuration set 1 is active when there is no input activated. In case that inputs CONFIGURATION 2 (PAGE 317) and CONFIGURATION 3 (PAGE 317) are active at the same time, the configuration set 3 is taken into account.

| CONFIGURATION 2 (PAGE 317) | CONFIGURATION 3 (PAGE 317) | Active configuration set |
|----------------------------|----------------------------|--------------------------|
| 0 | 0 | 1 |
| 1 | 0 | 2 |
| 0 | 1 | 3 |
| 1 | 1 | 3 |

IMPORTANT: If LBO ECU POWER RELAY (PAGE 340) is used, change of alternate configuration can be made only in prestart phase. So prestart has to be set up for enough long time.

5.5.21 E-Stop

Binary outputs for the control of some essential functions are internally wired as "safe", it means, that their deactivation is directly bind with the dedicated Input E-STOP (not evaluated as the LBI in the controller). This BO are fully configurable and are used e.g. for the Starter and Fuel control.

- > The emergency stop circuit must be secured.
- > The power supply of the associated binary outputs (BOUT1 and BOUT2) is supplied by the E-STOP input, not by the + battery voltage.

Note: There is no difference in the way of configuration of all binary outputs. Binary outputs BO1 (Starter), BO2 (Fuel Solenoid) are intended for these functions (not dedicated).

There is a measuring of E-STOP input voltage analogically and setting the binary value (representing emergency stop input level) based on comparison of the measured voltage to two analog levels, which are derived from the controller supply voltage (battery voltage) perceptually.




Image 5.30 SW principle of E-STOP

- > If the input voltage of E-stop is higher than high comparison level (for ex. higher than 80% of the supply voltage), then E-stop is not activated.
- > If the input voltage of E-stop is lower than low comparison level (for ex. lower than 60% of the supply voltage), then E-stop is activated.

If the input voltage of E-stop is located somewhere between low and high comparison levels (for ex. between 60 and 80 %of the supply voltage), then E-stop binary value will stay on its previous state (means E-stop binary value will not change).

Visualization on CU screen

- > 1 – E-STOP has voltage – state is OK
- > 0 – E-STOP has no voltage – protection is active

For more information about connection **see Emergency stop on page 43.**

5.5.22 ECU Frequency selection

Setpoint *ECU Freq Select* is no longer in use. However **ECU Frequency Select (page 277)** value was kept and the value can be calculated from **Nominal Frequency (page 168)** setpoint. Sequence for frequency change is executed automatically (engine must be in still condition and ECU is powered on – ECU Power Relay is not configured) in following steps:

1. Starting of the engine is blocked (state: Not Ready)
2. Wait 100 ms
3. *ECU Stop Pulse* is set for 1000 ms (standard Stop Pulse duration)
4. Wait 3000 ms
5. Frequency selection is changed to a new value
6. Wait 2000 ms
7. *ECU Stop Pulse* is set for 1000 ms (standard Stop Pulse duration)
8. Wait 2000 ms
9. Come back from start blocking state

This sequence does not control LBO **ECU POWER RELAY (PAGE 340)** anyhow.

Note: If LBO ECU POWER RELAY (PAGE 340) is used, this change can be made only in prestart phase. So prestart has to be set up for enough long time.

5.5.23 Cybernetic security

The cybernetic security is formed by:

- Protection against a brute-force attack to the password
- Secure method to reset the password
- A new technology of encryption of the remote communication
- Web interface can be disabled

IMPORTANT: Due to this, we do not recommend performing a rollback from FW 1.8.0 to FW version 1.7.2 or older.

Hardening the storage of a credentials

The user credentials (passwords and access code) have been moved to a hardened storage to prevent the credentials to leak out of the hardware.

IMPORTANT: If a firmware rollback is inevitable, please keep in mind, when the firmware is first time updated to the new firmware (which uses hardened storage) a seamless transfer of the credentials into the hardened storage is performed. However, if the rollback to any previous firmware (which does not use hardened storage) is performed the credentials are NOT transferred back, so the previous firmware will not "see" any change of the credentials made through the new firmware. Moreover, as the transfer of the credentials into the hardened storage is performed only during very first update from an "old" to a "new" firmware, no change of the credentials performed in the "old" firmware after the rollback will be visible in the "new" firmware after a next update to the "new" firmware.

Protection against the brute force attack

Protection against the brute force will take a place when an invalid password is entered repeatedly.

- If the invalid password is entered 5 times, the controller gets blocked for entering password for a while.
- Each further entering of the invalid password cause the consequent blocking time is increased.
- If the invalid password is entered repeatedly the controller gets blocked for entering the password permanently and the password must be reset to a default value as described below.


Note: Blocking of the controller for entering the password have no influence to controller / Gen-setoperation

Note: Permanent blocking cannot occur accidentally, just by user mistake. It can be practically triggered only by a focused activity.

Resetting the administrator password


If the administrator password is lost or controller is permanently locked due to brute-force attack protection, proceed according to a procedure described below:

IMPORTANT: There is a backup e-mail address defined in the controller to which and only which ComAp will send the "password reset action code". Please be sure, that you have adjusted this e-mail address correctly. Use IntelliConfig to adjust the backup e-mail address



Reset password procedure

1. Connect IntelConfig. You may connect remotely if you know Access Code.
2. Get the password reset request code and send it via e-mail to support@comap-control.com



3. Once you receive the reply from ComAp, copy the code from the e-mail (all characters inside the box as indicated below)



Dear customer,


ComAp has received your request for resetting the password in the controller **N/A**, serial number **99990000**. Please perform following steps to finish the action.

- 1) Connect your PC application to the controller
- 2) Copy the action code stated below to the clipboard
- 3) Paste the clipboard content into the appropriate field in the PC application and press the "Reset" button. Password will be reset to the default value.
- 4) Adjust and remember new password

Code:

```
AHIU/LNxy6sHWxdq/0fpxDCdQCMkgSdHcFp2mny8B9McK4bV48VepeasJZSJoZf90rWA  
Kmi4V4QYcDOvJunVwm64U94q5ddq2EaJi8zsoPDjBFBqiK0LViw+7m0a81n3QWkAIw9Q  
hdxal0kWO117Hz/+Ljd+mV717QT95ITCKocL98soEwQzvzWjkCjJYSboHJO6cbCd05WE  
2faWVh9Ab7rWMcaTW3fkvqL/VTkUn9FiDh6B1X5AC0cZiFFMLOJuaMewdjVwew/7bHJ  
NtLy+tmcc8s20kuNjZZ+XLe/SQ64CHQK2LYwSVHawWVr1m/9GVtPGGemqjhzXpaEKCzc  
XZQ=
```


4. Paste the code into the password reset window



Encryption of the communication

New technology "CCS v.1" is used for an authentication and an encryption of the ComAp protocol via Internet/ethernet/AirGate. This technology is based on strong and proven cryptographic algorithms and has passed successfully penetration tests and cybersecurity audit.

Web interface can be disabled

A setpoint has been added to disable the CM-Ethernet built-in web interface.

IMPORTANT: As the web interface is using HTTP protocol it is recommended to disable the web interface unless the controller is connected into a trusted secure network.

⬆️ back to Functions

⬆️ back to Controller setup

6 Communication

| | |
|---|-----|
| 6.1 PC | 130 |
| 6.2 Connection to 3rd party systems | 143 |

🔍 back to Table of contents

6.1 PC

| | |
|----------------------------------|-----|
| 6.1.1 Direct communication | 130 |
| 6.1.2 Remote communication | 132 |

6.1.1 Direct communication

A RS232, USB, RS485 or ethernet interface can be used for direct cable connection to a PC.

Connection via RS232

A plug-in communication module CM-RS232-485 is necessary for communication via RS232 connection.

The module is plugged into the slot located on the rear side of the controller. To find more information about installation of the modules **see Plug-in module installation on page 53**.

RS232 interface uses **COM1 Mode (page 237)** port of the controller. Use a cross-wired serial communication cable with DB9 female connectors and signals Rx, Tx, GND.

Note: Also USB-RS232 convertor can be used.




Image 6.1 Cross-wired RS232 cable is used




Image 6.2 Cross-wired RS232 cable and USB is used

Connection via RS485

A plug-in communication module CM-RS232-485 is necessary for communication via RS485 connection.

The module is plugged into the slot located on the rear side of the controller. To find more information about installation of the modules **see Plug-in module installation on page 53**.

RS485 interface uses **COM2 Mode (page 239)** port of the controller.

Note: Also USB-RS485 convertor can be used.




Image 6.3 Plug-in module CM RS232-485 is used

Connection via Ethernet

A plug-in communication module CM-Ethernet is necessary for Ethernet connection.

The module is plugged into the slot located on the rear side of the controller. To find more information about installation of the modules **see Plug-in module installation on page 53**.

This connection type is used for communication with the controller from IntelliConfig or any other PC tool. . Only three remote clients can be connected at the same time.

To connect your PC tool to the controller use the INTERNET connection type and just put the CM-Ethernet IP address into the gen-set address box in the PC tool.




Image 6.4 Ethernet cable is used

Connection via USB

USB interface uses HID profile.




Image 6.5 Shielded USB type A cable is used

6.1.2 Remote communication

IMPORTANT: Factory default password and access code are "0". It is highly recommended to change these parameters.

Ethernet LAN connection

Direct IP LAN connection is intended to be used if the CM-Ethernet module is reachable from the client computer by specifying the IP address at which the module can be contacted.

- If direct IP connection is to be used within a local network the CM-Ethernet must have static IP address in the respective local network.




Image 6.6 Ethernet LAN connection

Setting-up static IP address

There are two basic ways to get the static IP address.

First way is to switch the CM-Ethernet to manual IP address mode. Adjust the setpoint **IP Address Mode** (page 253) to **FIXED**. In that case all setpoints of IP settings (**IP Address** (page 253), **Subnet Mask** (page 254), **Gateway IP** (page 254), **DNS Mode** (page 255)) have to be adjusted manually. If this method is used several basic rules should be kept to avoid conflicts with the remaining network infrastructure:

- The static IP used in the controller must be selected in accordance with the local network in which CM-Ethernet is connected.
- The static IP used in the controller must be excluded from the pool of addresses which is assigned by DHCP server, which is in charge of the respective local network.
- The local infrastructure must generally allow using devices with manually assigned IP addresses.
- There must not be any other device using the same static IP address. This can be tested from a computer connected to the same network using "ping <required_ip_address>" command issued from the command line. The IP address is not occupied if there is not any response to the ping command.

Note: The list above contains only basic rules. Other specific restrictions/rules may take place depending on the local network security policy, technology used, topology etc.


Next way is to switch the CM-Ethernet to automatic IP address mode. Adjust the setpoint **IP Address Mode** (page 253) to **AUTOMATIC**. In that case all IP settings are assigned by DHCP server. Then configure the DHCP server to assign always the same IP address (i.e. static IP address) to the particular CM-Ethernet according to it's MAC address.

Internet connection

Public static IP

If public static IP connection is to be used from the Internet, the IP address, which is entered into the client computer, must be static and public in scope of the Internet.

- > If CM-Ethernet is connected to Internet via a local Ethernet network then in most cases port forwarding must be created from the public IP address of the network gateway to the local IP address of CM-Ethernet at the port specified for ComAp protocol. Different port numbers can be used to create multiple port forwarding rules in the same local network.



SMS

Event SMS

The IntelliLite 9 controller equipped with the CM-GPRS or CM-4G-GPS communication module is able to send Event SMS according to the setting of setpoint:

- > **Event Message (page 249)**

Note: Setpoint Telephone Number 1 (page 247) has to be adjusted to enable this function.

The following events can be received by mobile phone:

- > Engine Start/Stop
 - » Manual Start/Stop
 - » Remote Start/Stop
 - » AMF Start/Stop (as Automatic Mains Failure Start/Stop)
 - » Test Start/Stop Gen-set
- > Mains Fail
- > Mains Returned
- > Load on Mains
- > Load on Gen-set
- > Test On Load

Message structure:

- > Gen-set Name (hh:mm:ss dd.mm.yyyy)
- > hh:mm:ss Mains Fail
- > hh:mm:ss AMF Start
- > hh:mm:ss Load on Gen-set
- > hh:mm:ss Mains Returned
- > hh:mm:ss Load on Mains
- > hh:mm:ss AMF Stop

Alarm SMS

The IntelliLite 9 controller equipped with the CM-GPRS or CM-4G-GPS communication module is able to send Alarm SMS according to the setting of setpoints:

- > **Wrn Message (page 250)**
- > **Sd Messages (page 251)**
- > **BOC Message (page 250)**

Note: *Setpoint Telephone Number 1 (page 247) has to be adjusted to enable this function.*

Message structure:

- > Gen-set Name
- > AL=(Alarm 1, Alarm 2, Alarm x)

Note: *Asterisk means that alarm is unconfirmed and exclamation mark means that alarm is active.*

SMS commands

To control the Gen-set equipped with IntelliLite 9 controller and CM-GPRS or CM-4G-GPS communication module (or modem) via SMS requests, send an SMS in the structure of:

xxxx, yyyy, zzzz, etc.

SMS send to the telephone number of the SIM card in your CM-GPRS module. Where the "#" mark means the controller access code, "xxxx" means the Command 1, "yyyy" is Command 2, "zzzz" is Command 3, etc.

Note: *Access code is set up via IntelliConfig.*

IMPORTANT: If wrong controller access code is set, then only help command is working.

| | |
|-------------|--|
| start | Start the engine in MAN mode. |
| stop | Stop the engine in MAN mode. |
| fault reset | Acknowledging alarms and deactivating the horn output. |
| gcb close | Closing GCB in MAN and TEST mode. |
| gcb open | Opening GCB in MAN and TEST mode. |
| mcb close | Closing MCB in MAN and TEST mode |
| mcb open | Opening MCB in MAN and TEST mode |
| off | Switching to OFF mode. |
| man | Switching to MAN mode. |
| auto | Switching to AUTO mode. |
| test | Switching to TEST mode. |
| status | Get status information from controller unit. |
| help | Get a list of available SMS requests. |

Note: Between commands are internal delays adjusted due to system requirements.

Example: When the controller, in AUTO mode, with a controller name of "InteliLite 9-Test", with the CM-GPRS module and access code "0" receives the SMS:

0 man, start, gcb close, gcb open, stop, auto

Controller mode will be changed to MANUAL mode. The engine will be started and GCB will close. Then GCB will open, the engine will stop and it will go into AUTO mode again.

The controller will send back the SMS (controller will respond to SMS after every command has been finished, not sooner.):

#InteliLite 9-Test: <OK>,<OK>,<OK>, <OK>,<OK>, <OK>

The value <OK> or <ERROR> means if the command has been performed successfully or not.

Emails

Event Email

The InteliLite 9 controller equipped with the CM-Ethernet communication module is able to send Event Email according to the setting of setpoint:

➤ **Event Message (page 249)**

Note: Setpoints *Email Address 1 (page 248)* and *SMTP Sender Address (page 252)* (for CM-Ethernet) have to be adjusted to enable this function.

Note: *Summer Time Mode (page 229)* and *Time Zone (page 249)* have to be adjusted for correct time in emails.

Message structure:

Controller

Name: XXX

Serial number: XXX

SW branch: XXX

SW version: XXX

Application: XXX

Appl. version: XXX

Date: dd/mm/yyyy

Time: hh:mm:ss

Alarm list

Alarm 1

Alarm 2

Alarm 3

Events

hh:mm:ss Event 1

hh:mm:ss Event 2

hh:mm:ss Event 3

Alarm Email

The IntelliLite 9 controller equipped with the CM-Ethernet communication module is able to send Alarm Emails according to the setting of setpoints:

- > **Wrn Message (page 250)**
- > **Sd Messages (page 251)**
- > **BOC Message (page 250)**

Note: *Setpoints Email Address 1 (page 248) and SMTP Sender Address (page 252) (for CM-Ethernet) have to be adjusted to enable this function.*

Note: *Summer Time Mode (page 229) and Time Zone (page 249) have to be adjusted for correct time in emails.*

Message structure:

Controller

Name: XXX

Serial number: XXX

SW branch: XXX

SW version: XXX

Application: XXX

Appl. version: XXX

Date: dd/mm/yyyy

Time: hh:mm:ss

Alarm list

Alarm 1

Alarm 2

Alarm 3

History events

0 dd/mm/yyyy hh:mm:ss.0 Event 1

-1 dd/mm/yyyy hh:mm:ss.0 Event 2

-2 dd/mm/yyyy hh:mm:ss.0 Event 3

Note: Asterisk means that alarm is unconfirmed and exclamation mark means that alarm is active.

Web Server

IMPORTANT: The web interface is based on HTTP protocol and is intended to be used only in private networks. It is not recommended to expose the web interface to the public Internet.

The Web Server is designed for basic monitoring and adjustment of the controller using a web browser. Just put the controller IP address into the browser to display the main controller web page like <http://192.168.1.254>. You will be asked for the controller access code prior to entering the web pages.

IMPORTANT: Do not use the browser navigation buttons as "Back", "Forward" or "Reload". Use the links and the reload button located in the toolbar instead.

Note: Only two remote clients can be connected to the Web Server at one moment. If you close your web browser without disconnecting from the CM-Ethernet ("Exit" button at the web pages), the connection will be blocked for next 5 minutes.




Image 6.7 Web Server main screen

SCADA

Click to the SCADA link in the toolbar to display the SCADA page. The SCADA page is also the main page which is displayed by default if you just put the CM-Ethernet address into the browser (after entering the right access code).




Image 6.8 Web Server – SCADA screen

Measurement

Click to the MEASUREMENT link in the toolbar to display the measurement page. Then click to the required group name in the left box to display values of the group in the right box.

Note: The measurement page is automatically refreshed every 60 seconds (this time cannot be changed).




Image 6.9 Web Server – measurement screen

Setpoints

Click to the SETPOINTS link in the toolbar to display the setpoints page.

Click to the required group name in the left box to display setpoints of the group in the right box.

Click to the required setpoint name or value to change the value. If the respective setpoint is protected by password, which is indicated by a lock icon by the setpoint name, you have to click on the "Controller password" icon located in the toolbar and then enter valid password.




Image 6.10 Web Server – Setpoints screen

History

Click to the HISTORY link in the toolbar to display the history page.

Use the control buttons to move within the history file.

Note: The history page is automatically refreshed every 60 seconds. If a new record appears in the controller, the web page will not show it immediately as e.g. IntelliConfig.

| No. | Reason | Time | Date | RPM | Pwr | Q | PF | LChr | Gfrq | Vg1 | Vg2 | Vg3 | Vg12 | Vg23 | Vg31 | IL1 | IL2 | IL3 | Mfrq | Vm1 | Vm2 | Vm |
|-----|------------------|-------------|----------|-----|-----|---|------|------|------|-----|-----|-----|------|------|------|-----|-----|-----|------|-----|-----|----|
| 0 | Hst AIN Protec 1 | 16:11:07.00 | 18/01/00 | 0 | 0 | 0 | 0.00 | | 0.0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 50.0 | 238 | 0 | 0 |
| -1 | Hst AIN Protec 1 | 16:11:05.00 | 18/01/00 | 0 | 0 | 0 | 0.00 | | 0.0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 50.0 | 238 | 0 | 0 |
| -2 | Hst AIN Protec 1 | 16:11:03.08 | 18/01/00 | 0 | 0 | 0 | 0.00 | | 0.0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 50.0 | 238 | 0 | 0 |
| -3 | Hst AIN Protec 1 | 16:10:59.09 | 18/01/00 | 0 | 0 | 0 | 0.00 | | 0.0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 50.0 | 238 | 0 | 0 |
| -4 | Hst AIN Protec 1 | 16:10:59.04 | 18/01/00 | 0 | 0 | 0 | 0.00 | | 0.0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 50.0 | 238 | 0 | 0 |
| -5 | Hst AIN Protec 1 | 16:10:56.03 | 18/01/00 | 0 | 0 | 0 | 0.00 | | 0.0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 50.0 | 237 | 0 | 0 |
| -6 | Hst AIN Protec 1 | 16:10:55.06 | 18/01/00 | 0 | 0 | 0 | 0.00 | | 0.0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 50.0 | 237 | 0 | 0 |
| -7 | Hst AIN Protec 1 | 16:10:52.00 | 18/01/00 | 0 | 0 | 0 | 0.00 | | 0.0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 50.0 | 238 | 0 | 0 |
| -8 | Hst AIN Protec 1 | 16:10:51.02 | 18/01/00 | 0 | 0 | 0 | 0.00 | | 0.0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 50.0 | 238 | 0 | 0 |
| -9 | Hst AIN Protec 1 | 16:10:48.00 | 18/01/00 | 0 | 0 | 0 | 0.00 | | 0.0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 50.0 | 238 | 0 | 0 |
| -10 | Hst AIN Protec 1 | 16:10:43.06 | 18/01/00 | 0 | 0 | 0 | 0.00 | | 0.0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 50.0 | 238 | 0 | 0 |
| -11 | Hst AIN Protec 1 | 16:10:41.07 | 18/01/00 | 0 | 0 | 0 | 0.00 | | 0.0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 50.0 | 238 | 0 | 0 |
| -12 | Hst AIN Protec 1 | 16:10:41.03 | 18/01/00 | 0 | 0 | 0 | 0.00 | | 0.0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 50.0 | 238 | 0 | 0 |

Image 6.11 Web Server – History screen

Web Server Adjustment

Click to the "Web Server settings" icon in the toolbar to display the settings page.

Select the controller language the web pages will appear in.

Select the rate of automatic refresh of the SCADA page.




Image 6.12 Web Server – Adjustment screen

6.2 Connection to 3rd party systems

6.2.1 MODBUS-RTU, MODBUS/TCP

MODBUS protocol is used for integration of the controller into a building management system or for remote monitoring via 3rd party monitoring tools.

- MODBUS-RTU can be used on serial interfaces (CM-RS232-485 module is required). The MODBUS-RTU server must be activated by switching the setpoint **COM1 Mode (page 237)** or **COM2 Mode (page 239)** into the Modbus position. The serial speed for MODBUS-RTU communication is to be adjusted by the setpoint **COM1 MODBUS Communication Speed (page 238)** or **COM2 MODBUS Communication Speed (page 240)**.
- MODBUS/TCP can be used on the Ethernet interface (CM-Ethernet module is required). Up to 2 clients can be connected simultaneously. The MODBUS/TCP server must be activated by the setpoint **MODBUS Server (page 256)**.

MODBUS, MODBUS/TCP protocol can be used simultaneously with Web connection and direct Ethernet connection.

IMPORTANT: Do not write setpoint repeatedly (e.g. power control form a PLC repeated writing of baseload setpoint via Modbus). The setpoints are stored in EEPROM memory. which can be overwritten up to 10⁵ times without risk of damage or data loss, but may become damaged, when the allowed number of writing cycles is exceeded!

Note: Modbus-RTU serial communication mode is 8-N-1 – startbit 1, 8 data bits, no parity and 1 stopbit.

Address space

The object address space is separated into several areas as described in the table below. The actual mapping of specific controller data objects to specific Modbus addresses, which depends on configuration, can be exported into a text file from the appropriate controller archive using IntelliConfig. There are several special registers with fixed meaning (reserved registers) which are listed in a separate table in this chapter.

| MODBUS address | Meaning | Access | MODICON object type | MODBUS function |
|-----------------|--------------------|---|--------------------------------------|-------------------------------|
| 0000 .. 0999 | Binary objects | Read only | Discrete Inputs | Read: 01, 02 |
| 1000 .. 2999 | Values | Read only | Input Registers | Read: 03, 04 |
| 3000 .. 3999 | Setpoints | Read/Write | Holding Registers | Read: 03, 04 Write: 06, 16 |
| 4200 .. 7167 | Reserved registers | Read/Write, depends on each specific register | Input Registers Holding Registers | Read: 03, 04 Write: 06, 16 |

Mapping data types to registers

As there are multiple data types in the controller but only one data type in MODBUS (the register, which is 2 byte long), a mapping table is necessary to compose and decompose the MODBUS messages correctly.

| Data type | Meaning | Number of registers | Data mapping |
|------------|-------------------------|---------------------|--|
| Integer8 | 1-byte signed integer | 1 | MSB = sign extension LSB = value |
| Unsigned8 | 1-byte unsigned integer | 1 | MSB = 0 LSB = value |
| Integer16 | 2-byte signed integer | 1 | MSB = value, MSB LSB = value, LSB |
| Unsigned16 | 2-byte unsigned integer | 1 | MSB = value, MSB LSB = value, LSB |
| Integer32 | 4-byte signed integer | 2 | MSB1 = value, byte 3 (MSB) LSB1 = value, byte 2 MSB2 = value, byte 1 LSB2 = value, byte 0 (LSB) |
| Unsigned32 | 4-byte unsigned integer | 2 | MSB1 = value, byte 3 (MSB) |

| Data type | Meaning | Number of registers | Data mapping |
|------------------|--|----------------------------|---|
| | | | LSB1 = value, byte 2 MSB2 = value, byte 1 LSB2 = value, byte 0 (LSB) |
| Binary8 | 8-bit binary value | 1 | MSB = 0 LSB = value, bits 0-7 |
| Binary16 | 16-bit binary value | 1 | MSB = value, bits 8-15 LSB = value, bits 0-7 |
| Binary32 | 32-bit binary value | 2 | MSB1 = value, bits 24-31 LSB1 = value, bits 16-23 MSB2 = value, bits 8-15 LSB2 = value, bits 0-7 |
| Char | 1-byte ASCII character | 1 | MSB = 0 LSB = ASCII value of the character |
| StrList | Index into a list of strings | 1 | MSB = 0 LSB = index into the list |
| ShortStr | Zero-terminated string of max 15 ASCII characters. | 8 | MSB1 = ASCII value of the 1. character LSB1 = ASCII value of the 2. character MSB2 = ASCII value of the 3. character LSB2 = ASCII value of the 4. character ... |
| LongStr | Zero-terminated string of max 31 ASCII characters. | 16 | MSB1 = ASCII value of the 1. character LSB1 = ASCII value of the 2. character MSB2 = ASCII value of the 3. character LSB2 = ASCII value of the 4. character ... |

| Data type | Meaning | Number of registers | Data mapping |
|-----------|--------------------------|---------------------|--|
| Date | Date (dd-mm-yy) | 2 | MSB1 = BCD (dd) LSB1 = BCD (mm) MSB2 = BCD (yy) LSB2 = 0 |
| Time | Time (hh-mm-ss) | 2 | MSB1 = BCD (hh) LSB1 = BCD (mm) MSB2 = BCD (ss) LSB2 = 0 |
| Alarm | An item of the Alarmlist | 27 | MSB1 = reserved for future use LSB1 = reserved for future use MSB2 = Alarm level *) LSB2 = Alarm status **) MSB3 = alarm string ***) LSB3 = alarm string MSB4 = alarm string LSB5 = alarm string ... |

Note:

- *) 1 .. level 1 (yellow), 2 .. level 2 (red), 3 .. sensor fail
- **) Bit0 – alarm is active, Bit1 – alarm is confirmed
- ***) String encoding is UTF-8

Error codes (exception codes)

Exception code is returned by the controller (server) if the query sent from the client could not be completed successfully.

The controller responds with the error codes in as follows:

- > 01 – Illegal function is returned if an incompatible type of operation is applied for a specific object, e.g. if function 03 is applied to a binary object.
- > 02 – illegal address is returned if the client tries to perform an operation with a object address that is not related to any existing object or that is located inside an object which is composed by multiple addresses (registers).
- > 04 – device error is returned in all other erroneous situations. More detailed specification of the problem can be consequently obtained by reading the registers 4205 – 4206.

Reserved registers

There are several registers with specific meaning. These registers are available in all controllers regardless of the configuration.

| Register addresses | Number of registers | Access | Data type | Meaning |
|--------------------|---------------------|------------|------------|--|
| 4200 - 4201 | 2 | read/write | Time | RTC Time in BCD code |
| 4202 - 4203 | 2 | read/write | Date | RTC Date in BCD code |
| 4204 | 1 | read/write | Unsigned8 | Index of the language that is used for text data provided by MODBUS (e.g. alarmlist messages). |
| 4205 - 4206 | 2 | read | Unsigned32 | Last application error. To be read after the device returns the exception code 04. It contains specific information about the error. |
| 4207 - 4208 | 2 | read/write | Unsigned32 | Writing: command argument Reading: command return value |
| 4209 | 1 | write | Unsigned16 | Command code |
| 4010 | 1 | - | - | Not implemented |
| 4211 | 1 | write | Unsigned16 | Password |
| 4212 - 4213 | 2 | read | Unsigned32 | Communication status |
| 4214 | 1 | read | Unsigned8 | Number of items in the Alarmlist |
| 4215 - 4241 | 27 | read | Alarm | 1. record in alarm list |
| 4242 - 4268 | 27 | read | Alarm | 2. record in alarm list |
| 4269 - 4295 | 27 | read | Alarm | 3. record in alarm list |
| 4296 - 4322 | 27 | read | Alarm | 4. record in alarm list |
| 4323 - 4349 | 27 | read | Alarm | 5. record in alarm list |
| 4350 - 4376 | 27 | read | Alarm | 6. record in alarm list |
| 4377 - 4403 | 27 | read | Alarm | 7. record in alarm list |
| 4404 - 4430 | 27 | read | Alarm | 8. record in alarm list |
| 4431 - 4457 | 27 | read | Alarm | 9. record in alarm list |
| 4458 - 4484 | 27 | read | Alarm | 10. record in alarm list |
| 4485 - 4511 | 27 | read | Alarm | 11. record in alarm list |
| 4512 - 4538 | 27 | read | Alarm | 12. record in alarm list |
| 4539 - 4565 | 27 | read | Alarm | 13. record in alarm list |
| 4566 - 4592 | 27 | read | Alarm | 14. record in alarm list |
| 4593 - 4619 | 27 | read | Alarm | 15. record in alarm list |
| 4620 - 4646 | 27 | read | Alarm | 16. record in alarm list |

List of commands and arguments

"Commands" are used to invoke a specific action in the controller via the communication channel. The list of available actions is in the table below. The general procedure of writing a command via Modbus is as follows:

1. (Optional) Write required level of password into the register 44212 (register address 4211). Use function 6. If the password is required or not depends on configuration of access rules. It can be adjusted/modified by IntelliConfig.

2. Write the command argument into the registers 44208-44209 (register addresses 4207-4208). Use function 16.
3. Write the command code into the register 44210 (register address 4209). Use function 6.
4. (Optional) Read the command return value from the registers 44208-44209 (register addresses 4207-4208). Use function 3.
5. If the command was executed the return value is as listed in the table. If the command was accepted but there was an error during execution the return value indicates the reason:
 - a. 0x00000001 – invalid argument
 - b. 0x00000002 – command refused (e.g. controller not in MAN, breaker can not be closed in the specific situation etc.)

| Action | Command code | Argument | Return value |
|-----------------|--------------|------------|--------------|
| Engine start *) | 0x01 | 0x01FE0000 | 0x000001FF |
| Engine stop *) | 0x01 | 0x02FD0000 | 0x000002FE |
| Fault reset *) | 0x01 | 0x08F70000 | 0x000008F8 |
| Horn reset *) | 0x01 | 0x04FB0000 | 0x000004FC |
| GCB toggle *) | 0x02 | 0x11EE0000 | 0x000011EF |
| GCB on | 0x02 | 0x11EF0000 | 0x000011F0 |
| GCB off | 0x02 | 0x11F00000 | 0x000011F1 |
| MCB toggle *) | 0x02 | 0x12ED0000 | 0x000012EE |
| MCB on | 0x02 | 0x12EE0000 | 0x000012EF |
| MCB off | 0x02 | 0x12EF0000 | 0x000012F0 |

Note: *)

This action is an equivalent of pressing the front panel button

MODBUS examples

Modbus RTU examples

- > Reading of Battery voltage
 - >> Export table of values from InteliConfig

| Table: Values | | | | | | | | | |
|----------------------------------|----------|-----------------------|-----------|---------|-----|----------|-----|-----|----------------|
| Allowed Modbus functions: 03, 04 | | | | | | | | | |
| Register (s) | Com.Obj. | Name | Dimension | Type | Len | Dec | Min | Max | Group |
| 01053 | 8213 | BatteryVoltage | V | Integer | 2 | 1 | 0 | 400 | Controller I/O |

| Request: (Numbers in Hex) | | | | | | | |
|---------------------------|-----------------|---|----|---------------------|----|-----|----|
| 01 | 03 | 04 | 1D | 00 | 01 | 15 | 3C |
| Controller address | Modbus function | Register address 041D _{hex} = 1053 _{dec} | | Number of registers | | CRC | |

| Response: (Numbers in Hex) | | | | | | |
|----------------------------|-----------------|---|--|----|-----|----|
| 01 | 03 | 02 | 00 | F0 | B8 | 00 |
| Controller address | Modbus function | Length of data 02 _{hex} = 2 bytes read | Data 00F0 _{hex} = 240 _{dec} | | CRC | |

We read value 240 from register 01053. From table of Modbus registers we get dimension of read value and "Dec". Dec=1 means shift one decimal place to the right. So battery voltage is **24.0 V**.

- > Reading Nominal power
 - >> Export table of values from IntelliConfig

| Table: Values | | | | | | | | | |
|----------------------------------|----------|----------------------|-----------|---------|-----|----------|-----|-------|-----------|
| Allowed MODBUS functions: 03, 04 | | | | | | | | | |
| Register (s) | Com.Obj. | Name | Dimension | Type | Len | Dec | Min | Max | Group |
| 01228 | 9018 | Nominal Power | kW | Integer | 2 | 0 | 0 | 32767 | Generator |

| Request: (Numbers in Hex) | | | | | | | |
|---------------------------|-----------------|---|----|---------------------|----|-----|----|
| 01 | 03 | 04 | CC | 00 | 01 | 45 | 05 |
| Controller address | Modbus function | Register address $04CC_{hex} = 1228_{dec}$ | | Number of registers | | CRC | |

| Response: (Numbers in Hex) | | | | | | |
|----------------------------|-----------------|---|----------------------------------|----|-----|----|
| 01 | 03 | 02 | 00 | C8 | B9 | D2 |
| Controller address | Modbus function | Length of data $02_{hex} = 2 \text{ bytes read}$ | Data $00C8_{hex} = 200_{dec}$ | | CRC | |

Read nominal power is 200 kW.

> Reading all binary inputs as Modbus register

| Table: Values | | | | | | | | | |
|----------------------------------|----------|----------------------|-----------|----------|-----|----------|-----|-----|----------------|
| Allowed Modbus functions: 03, 04 | | | | | | | | | |
| Register (s) | Com.Obj. | Name | Dimension | Type | Len | Dec | Min | Max | Group |
| 01068 | 8235 | Binary Inputs | | Binary#2 | 2 | 0 | - | - | Controller I/O |

| Request: (Numbers in Hex) | | | | | | | | | |
|---------------------------|-----------------|--|----|---------------------|----|----|-----|--|--|
| 01 | 03 | 04 | 2C | 00 | 01 | 44 | F3 | | |
| Controller address | Modbus function | Register address 042C _{hex} = 1068 _{dec} | | Number of registers | | | CRC | | |

| Response: (Numbers in Hex) | | | | | | | | | |
|----------------------------|-----------------|--|--|----|----|-----|--|--|--|
| 01 | 03 | 02 | 00 | 12 | 38 | 49 | | | |
| Controller address | Modbus function | Length of data 02 _{hex} = 2 bytes read | Data 0012 _{hex} = 00010010 _{bin} | | | CRC | | | |

Binary inputs is 00010010. It means Binary input 2 and binary input 5 are active.

Note: You can use Modbus function 4 instead of 3, rest of data remain same (CRC differs).

➤ Reading binary inputs as coil status.

| Table: Binaries | | | | | | |
|--|------------------------------|------------------|-----------------------------------|-------|---|----------------|
| Allowed Modbus functions: 01, 02 | | | | | | |
| Addresses Modbus Addr. Prot. Addr. | Source = Value = State | C.O.# State # | Name of Value Name of State | Bit # | Bit Name Activated by protection (s): | Group |
| 00000 | Value | 8235 | Binary Inputs | 1 | GCB Feedback | Controller I/O |
| 00001 | Value | 8235 | Binary Inputs | 2 | MCB Feedback | Controller I/O |
| 00002 | Value | 8235 | Binary Inputs | 3 | Emergency Stop | Controller I/O |

We will read state of MCB Feedback binary input.

| Request: (Numbers in Hex) | | | | | | | |
|---------------------------|-----------------|--|----|---------------------|----|-----|----|
| 01 | 01 | 00 | 01 | 00 | 01 | AC | 0A |
| Controller address | Modbus function | Register address 0001 _{hex} = 0001 _{dec} | | Number of registers | | CRC | |

| Response: (Numbers in Hex) | | | | | |
|----------------------------|-----------------|---|------------------------------------|-----|----|
| 01 | 01 | 01 | 01 | 90 | 48 |
| Controller address | Modbus function | Length of data 01 _{hex} = 1 byte read | Data 01 _{hex} = active | CRC | |

The read data is 01, it means this binary input is active.

Note: You can use Modbus function 2 instead of 1, rest of data remains same (CRC differs).

➤ Starting the engine

Before starting engine you may need to write password. Depends on your settings in controller.

Table **Reserved registers (page 146)**

| Register addresses | Number of registers | Access | Data type | Meaning |
|--------------------|---------------------|------------|------------|---|
| 4207 - 4208 | 2 | read/write | Unsigned32 | Writing:command argument Reading: command return value |
| 4209 | 1 | write | Unsigned16 | Command code |

Table **List of commands and arguments (page 147)**

| Action | Command code | Argument | Return value |
|--------------|--------------|------------|--------------|
| Engine start | 0x01 | 0x01FE0000 | 0x000001FF |
| Engine stop | 0x01 | 0x02FD0000 | 0x000002FE |

| Request 1/2: (Numbers in Hex) | | | | | | |
|-------------------------------|--|---|---------------------|----|----------------------|----|
| 01 | 10 | 10 | 6F | 00 | 03 | 06 |
| Controller address | Modbus function 10 _{hex} = 16 _{dec} | Register address 106F _{hex} = 4207 _{dec} | Number of registers | | Data length in bytes | |

| Request 2/2: (Numbers in Hex) | | | | | | | |
|-------------------------------|----|----|----|--------------|----|-----|----|
| 01 | FE | 00 | 00 | 00 | 01 | 68 | 0B |
| Argument | | | | Command code | | CRC | |

Note: Command and argument may be written as one "packet" (function 16) or you can split it and write argument (function 16) and after that write command code (function 6).

> Password

This password is the same as in IntelliConfig or directly in controller.

Table **Reserved registers (page 146)**

| Register addresses | Number of registers | Access | Data type | Meaning |
|--------------------|---------------------|--------|------------|----------|
| 4211 | 1 | write | Unsigned16 | Password |

Note: Default password is "0".

In this example the password is "1234".

| Request: (Numbers in Hex) | | | | | | | |
|---------------------------|-----------------|--|----|--|----|-----|----|
| 01 | 06 | 10 | 73 | 04 | D2 | 7C | D1 |
| Controller address | Modbus function | Register address 1073 _{hex} = 4211 _{dec} | | Password 04D2 _{hex} = 1234 _{dec} | | CRC | |

| Response for success: (Numbers in Hex) | | | | | | | |
|--|-----------------|---|----|--------------|----|-----|----|
| 01 | 06 | 10 | 73 | 00 | 00 | 7C | D1 |
| Controller address | Modbus function | Register address 1073 _{hex} = 4211 _{dec} | | Always zero. | | CRC | |

| Response for bad password: (Numbers in Hex) | | | | | | | |
|---|----------------------------------|---|--|--|--|-----|----|
| 01 | 86 | 04 | | | | 43 | A3 |
| Controller address | Modbus exception for function 6. | 04 – device error see Error codes (exception codes) on page 146 | | | | CRC | |

> Nominal Power – writing

| Table: Setpoints | | | | | | | | | |
|--|----------|----------------------|-----------|----------|-----|----------|-----|------|----------------|
| Allowed Modbus functions: 03, 04, 06, 16 | | | | | | | | | |
| Register (s) | Com.Obj. | Name | Dimension | Type | Len | Dec | Min | Max | Group |
| 03008 | 8276 | Nominal Power | kW | Unsigned | 2 | 0 | 1 | 5000 | Basic Settings |

| Request: (Numbers in Hex) | | | | | | | | | |
|---------------------------|-----------------|---|----|---|----|-----|----|--|--|
| 01 | 06 | 0B | C0 | 00 | 64 | 8A | 39 | | |
| Controller address | Modbus function | Register address 0BC0 _{hex} = 3008 _{dec} | | Data 0064 _{hex} = 100 _{dec} | | CRC | | | |

| Response: (Numbers in Hex) | | | | | | | | | |
|----------------------------|-----------------|---|----|-------------|----|-----|----|--|--|
| 01 | 06 | 0B | C0 | 00 | 00 | 8B | D2 | | |
| Controller address | Modbus function | Register address 0BC0 _{hex} = 3008 _{dec} | | Always zero | | CRC | | | |

Written setpoint nominal power is 100 kW.

> CRC calculation

The check field allows the receiver to check the validity of the message. The check field value is the Cyclical Redundancy Check (CRC) based on the polynomial $x^{16}+x^{15}+x^2+1$. CRC is counted from all message bytes preceding the check field.

Online CRC calculator: <http://www.lammertbies.nl/comm/info/crc-calculation.html> Use CRC-16 (Modbus)

Write LSB first.

For writing nominal power 100 kW the CRC is calculated from this data: 01060BC00064_{hex}

Modbus TCP examples

- > Reading of Battery voltage
 - >> Export table of values from IntelliConfig

| Table: Values | | | | | | | | | |
|----------------------------------|----------|-----------------------|-----------|---------|-----|----------|-----|-----|----------------|
| Allowed Modbus functions: 03, 04 | | | | | | | | | |
| Register (s) | Com.Obj. | Name | Dimension | Type | Len | Dec | Min | Max | Group |
| 01053 | 8213 | BatteryVoltage | V | Integer | 2 | 1 | 0 | 400 | Controller I/O |

| Request: (Numbers in Hex) | | | | | | | | | | | |
|------------------------------------|----|---------------------------------|----|--------------------------------|----|--------------------|-----------------|---|----|---------------------|----|
| 00 | 00 | 00 | 00 | 00 | 06 | 01 | 03 | 04 | 1D | 00 | 01 |
| transaction identifier (usually 0) | | protocol identifier (usually 0) | | Length of data bytes following | | Controller address | Modbus function | Register address 041D _{hex} = 1053 _{dec} | | Number of registers | |

| Response: (Numbers in Hex) | | | | | | | | | | | |
|------------------------------------|----|---------------------------------|----|--------------------------------|----|--------------------|-----------------|---|----|--|--|
| 00 | 00 | 00 | 00 | 00 | 05 | 01 | 03 | 02 | 00 | F0 | |
| transaction identifier (usually 0) | | protocol identifier (usually 0) | | Length of data bytes following | | Controller address | Modbus function | Length of data 02 _{hex} = 2 bytes read | | Data 00F0 _{hex} = 240 _{dec} | |

We read value 240 from register 01053. From table of Modbus registers we get dimension of read value and "Dec". Dec=1 means shift one decimal place to the right. So battery voltage is **24.0 V**.

🔍 [back to Communication](#)

7 Technical data

Power supply

| | |
|-------------------------------|-----------------|
| Power supply range | 8-36 VDC |
| Power consumption | 394 mA / 8 VDC |
| | 255 mA / 12 VDC |
| | 140 mA / 24 VDC |
| | 97 mA / 36 VDC |
| Power terminal fusing | Max. 3 A |
| Max. Power Dissipation | 3.5 W |

Operating conditions

| | |
|---|--|
| Protection degree (front panel) | IP 65 |
| Operating temperature | -20 °C to +70 °C |
| Storage temperature | -30 °C to +80 °C |
| Operating humidity | 95 % w/o condensation (EN 60068-2-30) |
| Vibration | 5-25 Hz, ± 1.6 mm |
| | 25-100 Hz, a = 4 g |
| Shocks | a = 500 m/s ² |
| Surrounding air temperature rating 70 °C Suitable for pollution degree | |

D+ terminal

| | |
|--------------------------------|---------------|
| Max. output current | 250 mA / 36 V |
| Charging fail threshold | Adjustable |

Voltage measurement

| | |
|--|---------------------------------|
| Measurement inputs | 3ph-n Gen voltage , 3ph-n Mains |
| Measurement range | 277 V AC / 480 V AC (EU) |
| | 346 V AC / 600 V AC (US/Canada) |
| Linear measurement and protection range | 381 V / 660 V |
| Accuracy | 1 % |
| Frequency range | 40-70 Hz (accuracy 0.1 Hz) |
| Input impedance | 0.72 MΩ ph-ph , 0.36 MΩ ph-n |

Display

| | |
|-------------------|-----------------------------|
| Display | Build-in monochromatic 3.2" |
| Resolution | 132 × 64 px |

Communications

| | |
|-----------------|--|
| USB port | B-connector, non-isolated |
| CAN 1 | CAN bus, 250 kbps, max 200 m, 120 Ω termination option, non-isolated |

Current measurement

| | |
|-----------------------------|---|
| Measurement inputs | 3ph Gen current |
| Measurement range | 5 A |
| Max. allowed current | 10 A |
| Accuracy | 1.5 % for full temperature range (1 % from 0 °C to 50 °C) |
| Input impedance | <0.1 Ω |

Binary inputs

| | |
|------------------------------|--|
| Number | 6, non-isolated |
| Close/Open indication | 0-2 V DC close contact >6 V DC open contact |

Binary outputs

| | |
|---------------------|--|
| Low current | 4, non-isolated max 0.5 A switching to positive supply voltage, BATT+ |
| High current | 2, non-isolated max 5 A (60 °C), max 4 A (70 °C) switching to positive supply voltage, BATT+ |

Analog inputs

| | |
|------------------------|--|
| Number | 3 resistive, non-isolated |
| Resolution | 0.1 Ω |
| Range | 0-2500 Ω |
| Input impedance | 800 Ω |
| Accuracy | ±2 % from value in range above ±1.5 kΩ in range 2.5-15 kΩ |

Magnetic pickup

| | |
|--|--|
| Voltage input range | 4 Vpk-pk to 50 Vpk-pk in range 4 Hz to 1 kHz |
| | 6 Vpk-pk to 50 Vpk-pk in range 1 to 5 kHz |
| | 10 Vpk-pk to 50 Vpk-pk in range 5 to 10 kHz |
| Frequency input range | 4 Hz to 10 kHz |
| Frequency measurement tolerance | 0.2 % from range 10 kHz |

[▲ back to Table of contents](#)

8 Appendix

| | |
|------------------------------|-----|
| 8.1 Controller objects | 158 |
| 8.2 Alarms | 372 |
| 8.3 Modules | 403 |

[🔍 back to Table of contents](#)

8.1 Controller objects

8.1.1 List of controller objects types

| | |
|------------------------------------|-----|
| 8.1.2 Setpoints | 158 |
| 8.1.3 Values | 271 |
| 8.1.4 Logical binary inputs | 307 |
| 8.1.5 Logical binary outputs | 329 |
| 8.1.6 Logical analog inputs | 365 |

8.1.2 Setpoints

What setpoints are:

Setpoints are analog, binary or special data objects which are used for adjusting the controller to the specific environment. Setpoints are organized into groups according to their meaning. Setpoints can be adjusted from the controller front panel, PC, MODBUS, etc.

All setpoints can be protected by a password against unauthorized changes. Password protection can be assigned to the setpoints during the configuration procedure. See the chapter **Password (page 76)** in Operator guide for instructions on how to enter and modify a password.

IMPORTANT: Do not write setpoints repeatedly (e.g. power control from a PLC by repeated writing of baseload setpoint via Modbus). The setpoints are stored in EEPROM memory, which can be overwritten up to 10^5 times without risk of damage or data loss, but it may become damaged, when the allowed number of writing cycles is exceeded.

For full list of setpoints go to the chapter **List of setpoints (page 159)**.

List of setpoints

| | | | | | |
|----------------------------|-----|---------------------------|-----|------------------------|-----|
| Group: Basic settings | 162 | Main Screen Line 2 | 175 | After Cooling Time | 192 |
| Subgroup: Name | 162 | Group: Engine settings | 176 | Subgroup: Engine | |
| Gen-set Name | 162 | Subgroup: Starting | 176 | Protections | 192 |
| Subgroup: Power settings | 162 | Cranking Attempts | 176 | Overspeed Sd | 192 |
| Nominal Power Split | | Cranking Fail Pause | 176 | Underspeed Sd | 192 |
| Phase | 162 | Maximum Cranking | | Overspeed Overshot | 193 |
| Nominal Power | 163 | Time | 176 | Overspeed Overshot | |
| Subgroup: Current settings | 163 | Prestart Time | 177 | Period | 193 |
| Nominal Current | 163 | Starting RPM | 177 | Oil Pressure Wrn | 193 |
| CT Ratio | 164 | Starting Oil Pressure | 178 | Oil Pressure Sd | 194 |
| CT Location | 164 | Glow Plugs Time | 178 | Oil Pressure Delay | 194 |
| Subgroup: Voltage settings | 165 | Idle RPM | 178 | ECU Oil Pressure Wrn | 194 |
| Connection type | 165 | Subgroup: Choke | 179 | ECU Oil Pressure Sd | 195 |
| Nominal Voltage Ph-N | 166 | Choke Function | 179 | ECU Oil Pressure Delay | 195 |
| Nominal Voltage Ph-Ph | 167 | Choke Time | 179 | Coolant Temperature | |
| PT Ratio | 167 | Choke Start Temp | 180 | Wrn | 195 |
| Vm PT Ratio | 167 | Choke Increment | 181 | Coolant Temperature | |
| Subgroup: Frequency | | Choke Voltage | 182 | BOC | 196 |
| settings | 168 | Choke Lead | 183 | Coolant Temperature | |
| Nominal Frequency | 168 | Subgroup: D+ Function | 183 | Delay | 196 |
| Gear Teeth | 168 | D+ Function | 183 | ECU Coolant | |
| Nominal RPM | 169 | D+ Threshold | 184 | Temperature Wrn | 196 |
| Subgroup: Controller | | D+ Delay | 185 | ECU Coolant | |
| settings | 169 | D+ Alarm Type | 185 | Temperature BOC | 197 |
| Controller Mode | 169 | Subgroup: Starting Timers | 186 | ECU Coolant | |
| Power On Mode | 170 | Fuel Solenoid Lead | 186 | Temperature Delay | 197 |
| Operation Mode | 170 | Idle Time | 186 | Coolant Temperature | |
| Controller Address | 171 | Minimal Stabilization | | Low Wrn | 197 |
| Reset To Manual | 171 | Time | 188 | Coolant Temperature | |
| Backlight Timeout | 172 | Maximal Stabilization | | Low Delay | 198 |
| Horn Timeout | 172 | Time | 189 | Fuel Level Wrn | 198 |
| Zero Power Mode | 173 | Protection Hold Off | 189 | Fuel Level Sd | 198 |
| RunHoursSource | 173 | Subgroup: Stopping | 190 | Fuel Level Delay | 199 |
| GCB Mode | 174 | Cooling Speed | 190 | ECU Fuel Level Wrn | 199 |
| Screen Filter | 174 | Subgroup: Stopping | | ECU Fuel Level BOC | 199 |
| Subgroup: HMI Settings | 175 | Timers | 190 | ECU Fuel Level Delay | 200 |
| Main Screen Line 1 | 175 | Cooling Time | 190 | Transfer Wrn Delay | 200 |
| | | Stop Time | 190 | Fuel Pump On | 201 |

| | | | | | |
|------------------------------|-----|---------------------------|-----|---------------------------|-----|
| Fuel Pump Off | 202 | Generator | | Mains Overfrequency .. | 219 |
| Subgroup: Maintenance .. | 203 | Overfrequency BOC | 211 | Mains Underfrequency .. | 220 |
| Maintenance Timer 1 .. | 203 | Generator | | Mains <> Frequency | |
| Maintenance Timer 2 .. | 203 | Overfrequency Wrn | 211 | Delay | 220 |
| Maintenance Timer 3 .. | 204 | Generator | | Subgroup: AMF Settings .. | 221 |
| Subgroup: Battery | | Underfrequency BOC .. | 212 | Return From Island | 221 |
| Protections | 204 | Generator | | MCB Logic | 221 |
| Battery Undervoltage .. | 204 | Underfrequency Wrn .. | 212 | MCB Opens On | 223 |
| Battery Overvoltage | 204 | Generator <> Frequency | | Group: General Analog | |
| Battery <> Voltage | | Delay | 212 | Inputs | 223 |
| Delay | 205 | Group: Protections | 213 | Subgroup: General Analog | |
| Low Battery Charging | | Subgroup: Overload | | Inputs 1 | 223 |
| Cycle | 205 | Protection | 213 | Analog Protection 1 Wrn | 223 |
| Subgroup: ECU Settings .. | 206 | Overload Protection | 213 | Analog Protection 1 Sd | 224 |
| ECU Speed Adjustment | 206 | Subgroup: Current | | Analog Protection 1 | |
| Subgroup: Ventilation | 206 | Protection | 213 | Delay | 224 |
| Ventilation Pulse Time .. | 206 | Short Circuit Protection | 213 | Subgroup: General Analog | |
| Group: Generator settings .. | 207 | Subgroup: Voltage | | Inputs 2 | 225 |
| Subgroup: Overload | | Protection | 214 | Analog Protection 2 Wrn | 225 |
| Protection | 207 | Generator <> Voltage | | Analog Protection 2 Sd | 225 |
| Overload BOC | 207 | Protection | 214 | Analog Protection 2 | |
| Overload Wrn | 207 | Subgroup: Frequency | | Delay | 226 |
| Overload Delay | 207 | Protection | 214 | Subgroup: General Analog | |
| Subgroup: Current | | Generator Frequency | | Inputs 3 | 226 |
| Protection | 208 | Protection | 214 | Analog Protection 3 Wrn | 226 |
| Short Circuit BOC | 208 | Subgroup: Speed | | Analog Protection 3 Sd | 227 |
| Short Circuit BOC Delay | 208 | Protection | 215 | Analog Protection 3 | |
| Subgroup: Voltage | | Underspeed Protection | 215 | Delay | 227 |
| Protection | 209 | Overspeed Protection .. | 215 | Group: Scheduler | 228 |
| Generator Overvoltage | | Group: AMF settings | 216 | Subgroup: Time & Date .. | 228 |
| Sd | 209 | Subgroup: AMF Timers .. | 216 | Time | 228 |
| Generator Overvoltage | | Emergency Start Delay | 216 | Date | 228 |
| Wrn | 209 | Mains Return Delay | 216 | Time Stamp Period | 229 |
| Generator Undervoltage | | Transfer Delay | 217 | Summer Time Mode | 229 |
| BOC | 210 | MCB Close Delay | 218 | Subgroup: Timer 1 | 230 |
| Generator Undervoltage | | Subgroup: AMF Voltage | | Timer 1 Function | 230 |
| Wrn | 210 | Conditions | 218 | Timer 1 Setup | 231 |
| Generator <> Voltage | | Mains Overvoltage | 218 | Timer 1 Repetition | 231 |
| Delay | 211 | Mains Undervoltage | 219 | Timer 1 Repetition | 231 |
| Subgroup: Frequency | | Mains <> Voltage Delay | 219 | Timer 1 First Occur. | |
| Protection | 211 | Subgroup: AMF Frequency | | Date | 232 |
| | | Conditions | 219 | Timer 1 First Occur. | 232 |

| | | |
|-------------------------------|------------------------------|-----------------------------|
| Time | Sd Messages | Nominal Power Split |
| Timer 1 Duration 232 | Telephone Number 1 247 | Phase 2 |
| Timer 1 Repeated 233 | Group: CM-Ethernet 248 | Nominal Current 2 263 |
| Timer 1 Refresh Period 234 | Email Address 1 | Connection type 2 |
| Timer 1 Weekends 235 | E-mail/SMS Language 248 | Nominal RPM 3 |
| Timer 1 Day | Time Zone | Nominal Frequency 3 ... |
| Timer 1 Repeat Day | Event Message | Nominal Voltage Ph-N 3 |
| Timer 1 Repeated Day | Wrn Message | Nominal Voltage Ph-Ph |
| In Week | BOC Message | 3 |
| Timer 1 Repeat Day In | Sd Messages | Nominal Power 3 |
| Month | SMTP UserName | Nominal Power Split |
| Timer 1 Repeat Week In | SMTP User Password | Phase 3 |
| Month | SMTP Server Address | Nominal Power 3 |
| Group: Plug-In Modules | SMTP Sender Address | Nominal Current 3 |
| Slot A | IP Address Mode | Connection type 3 |
| Group: CM-RS232-485 237 | IP Address | Subgroup: Engine settings |
| COM1 Mode | Subnet Mask | ECU Speed Adjustment |
| COM1 Communication | Gateway IP | 1 |
| Speed | DNS Mode | ECU Speed Adjustment |
| COM1 MODBUS | DNS Mode | 2 |
| Communication Speed | MODBUS Server | ECU Speed Adjustment |
| COM2 Mode | Web Interface | 3 |
| COM2 Communication | Group: Alternate Config | back to Controller |
| Speed | Subgroup: Basic settings . | objects |
| COM2 MODBUS | Nominal RPM 1 | |
| Communication Speed | Nominal Frequency 1 ... | |
| Group: CM-GPRS 240 | Nominal Voltage Ph-N 1 | |
| Message Language | Nominal Voltage Ph-Ph | |
| Time Zone | 1 | |
| Event Message | Nominal Power 1 | |
| Wrn Message | Nominal Power Split | |
| BOC Message | Phase 1 | |
| Sd Messages | Nominal Current 1 | |
| Telephone Number 1 243 | Connection Type 1 | |
| Group: CM-4G-GPS 244 | Nominal RPM 2 | |
| Required Connection Type | Nominal Frequency 2 ... | |
| Message Language | Nominal Voltage Ph-N 2 | |
| Time Zone | Nominal Voltage Ph-Ph | |
| Event Message | 2 | |
| Wrn Message | Nominal Power 2 | |
| BOC Message | | |

Group: Basic settings

Subgroup: Name

Gen-set Name

| | | | |
|---|------------------------|-----------------------------|----------|
| Setpoint group | Basic settings | Related FW | 1.6.0 |
| Range [units] | 0 .. 15 characters [-] | | |
| Default value | InteliLite | Alternative config | NO |
| Step | [-] | | |
| Comm object | 8637 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |
| Description | | | |
| User defined name, used for the controller identification at remote phone or mobile connection. Gen-set Name is maximally 15 characters long and can be entered using InteliConfig or from controller's configuration menu. | | | |
| <i>Note: If the Gen-set Name is "TurboRunHours", the running hours will be counted faster – 1 minute in real will represent 1 hour.</i> | | | |

🔍 back to List of setpoints

Subgroup: Power settings

Nominal Power Split Phase

| | | | |
|---|---|-----------------------------|----------|
| Setpoint group | Basic settings | Related FW | 1.6.0 |
| Range [units] | 1 .. 5 000 [kW] | | |
| Default value | 200 kW | Alternative config | YES |
| Step | 1 kW | | |
| Comm object | 9977 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Conditioned by the setpoint Connection type (page 165) | | |
| Description | | | |
| Nominal power of the Gen-set for detected split-phase or mono phase connection. Generator Overload BOC (page 207) protection is based on this setpoint. | | | |
| <i>Note: This setpoint is used when setpoint Connection type (page 165) is adjusted to Autodetect and Autodetect detects connection type as Monophase or Splitphase.</i> | | | |
| <i>Note: To lock this setpoint against editing you also have to lock setpoint Nominal Power Split Phase 1 (page 258), Nominal Power Split Phase 2 (page 262) and Nominal Power Split Phase 3 (page 266).</i> | | | |

🔍 back to List of setpoints

Nominal Power

| | | | |
|---|-----------------|-----------------------------|----------|
| Setpoint group | Basic settings | Related FW | 1.6.0 |
| Range [units] | 1 .. 5 000 [kW] | | |
| Default value | 200 kW | Alternative config | YES |
| Step | 1 kW | | |
| Comm object | 8276 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |
| Description | | | |
| Nominal power of the Gen-set. Generator Overload BOC (page 207) protection is based on this setpoint. | | | |
| <p>Note: This setpoint is used when setpoint Connection type (page 165) is adjusted to <i>Monophase or Splitphase or 3Ph3Wire or High Leg D or 3Ph4Wire</i> or when <i>Autodetect</i> detects connection type as <i>3Ph3Wire or High Leg D or 3Ph4Wire</i>.</p> | | | |
| <p>Note: To lock this setpoint against editing you also have to lock setpoint Nominal Power 1 (page 258), Nominal Power 2 (page 262) and Nominal Power 3 (page 267).</p> | | | |
| <p>Note: This value can be also switch into one decimal power format (via <i>InteliConfig PC tool</i>). In this case the range of value is decrease 10 times.</p> | | | |

⬅ back to List of setpoints

Subgroup: Current settings

Nominal Current

| | | | |
|--|---|-----------------------------|----------|
| Setpoint group | Basic settings | Related FW | 1.6.0 |
| Range [units] | 1 .. 10 000 [A] | | |
| Default value | 350 A | Alternative config | YES |
| Step | 1 A | | |
| Comm object | 8275 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Conditioned by the setpoint Connection type (page 165) . | | |
| Description | | | |
| It is current limit for mains current protections and means maximal continuous mains current. Nominal Current can be different from mains rated current value. | | | |
| <p>Note: To lock this setpoint against editing you also have to lock setpoint Nominal Current 1 (page 259), Nominal Current 2 (page 263) and Nominal Current 3 (page 267).</p> | | | |

⬅ back to List of setpoints

CT Ratio

| | | | |
|---|------------------|-----------------------------|----------|
| Setpoint group | Basic settings | Related FW | 1.6.0 |
| Range [units] | 1 .. 5000 [A/5A] | | |
| Default value | 2000 A/5A | Alternative config | NO |
| Step | 1 A/5A | | |
| Comm object | 8274 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |
| Description | | | |
| Current transformers ratio of Gen-set . | | | |
| <i>Note: Generator currents and power measurement is suppressed if current level is below 1% of CT range.</i> | | | |

🔍 back to List of setpoints

CT Location

| | | | | | | | | | |
|--|---|-----------------------------|-------|-------------|---|----------------|---|-------------|----------------------------|
| Setpoint group | Basic settings | Related FW | 1.6.0 | | | | | | |
| Range [units] | Load / Gen-set / None [-] | | | | | | | | |
| Default value | Gen-set | Alternative config | NO | | | | | | |
| Step | [-] | | | | | | | | |
| Comm object | 11625 | Related applications | AMF | | | | | | |
| Config level | Advanced | | | | | | | | |
| Setpoint visibility | Always | | | | | | | | |
| Description | | | | | | | | | |
| This setpoint adjusts position of current measurement. | | | | | | | | | |
| <table border="1"> <tr> <td>Load</td> <td>Current CT's are physically placed on Load (typically between GCB and MCB).</td> </tr> <tr> <td>Gen-set</td> <td>Current CT's are physically placed on Gen-set (typically before GCB).</td> </tr> <tr> <td>None</td> <td>There are no current CT's.</td> </tr> </table> | | | | Load | Current CT's are physically placed on Load (typically between GCB and MCB). | Gen-set | Current CT's are physically placed on Gen-set (typically before GCB). | None | There are no current CT's. |
| Load | Current CT's are physically placed on Load (typically between GCB and MCB). | | | | | | | | |
| Gen-set | Current CT's are physically placed on Gen-set (typically before GCB). | | | | | | | | |
| None | There are no current CT's. | | | | | | | | |
| When option None is selected, following objects are hidden/changed: | | | | | | | | | |
| <ul style="list-style-type: none"> > Current screen is hidden > Generator Power screen is hidden > Statistics screens – values Gen-set kWh, Gen-set kVArh, Mains kWh and Mains kVArh are hidden > Mains screen – kW meter is replaced by generator voltage meter <ul style="list-style-type: none"> >> Generator L1-N voltage is displayed for Monopahse, Splitphase and High Leg delta connection types >> Generator L1-L2 voltage is displayed for 3ph3w and 3ph4w connection types > Group Load is hidden > Group Statistics – values Gen-set kWh, Gen-set kVArh, Mains kWh and Mains kVArh are hidden | | | | | | | | | |

🔍 back to List of setpoints

Subgroup: Voltage settings

Connection type

| | | | |
|----------------------------|--|-----------------------------|----------|
| Setpoint group | Basic settings | Related FW | 1.6.0 |
| Range [units] | Mono Phase / SplPhL1L2 / SplPhL1L3 / 3Ph3Wire / 3Ph4Wire / High Leg D / Autodetect [-] | | |
| Default value | 3Ph4Wire | Alternative config | YES |
| Step | [-] | | |
| Comm object | 11628 | Related applications | AMF, MRS |
| Setpoint visibility | Always | | |

Description

Connection type:

| | |
|------------|--|
| Mono Phase | Single phase voltage measurement L1-N 1x CT (Current Transformer) |
| SplPhL1L2 | Double Delta connection Split Phase Two phase voltage measurement L1,L2 with 180° phase shift 2x CT (Current Transformer) |
| SplPhL1L3 | Double Delta connection Split Phase Two phase voltage measurement L1,L3 with 180° phase shift 2x CT (Current Transformer) |
| 3Ph3Wire | Ungrounded Delta connection Open Delta Ungrounded Wye Corner-Grounded Delta Split Phase Delta Three phase voltage measurement L1,L2,L3 with 120° phase shift No neutral is available 3x CT (Current Transformer) |
| 3Ph4Wire | Grounded Star (Grounded Wye) connection – 3PY Three phase voltage measurement L1,L2,L3 with 120° phase shift 3x CT (Current Transformer) |
| High Leg D | High Leg Delta connection Three phase voltage measurement L1,L2,L3 3x CT (Current Transformer) |

| | | |
|------------|------------------------------------|--|
| Autodetect | High Leg Delta | L1 >=100 V; L1 <=140 V L2 >=140 V L3 >=100 V; L3 <=140 V |
| | 3Ph3Wire or 3Ph4Wire | L1 >=100 V L2 >=100 V L3 >=100 V |
| | SpIPhL1L3 | L1 >=100 V L2 <= 20 V L3 >=100 V |
| | SpIPhL1L2 | L1 >=100 V L2 >= 100 V L3 <= 20 V |
| | Mono Phase | L1 >=100 V L2 <= 20 V L3 <= 20 V |
| | Voltage Autodetect shutdown | |

Note: To lock this setpoint against editing you also have to lock setpoint **Connection Type 1** (page 259), **Connection type 2** (page 263) and **Connection type 3** (page 267).

🔍 back to List of setpoints

Nominal Voltage Ph-N

| | | | |
|--|--|-----------------------------|----------|
| Setpoint group | Basic settings | Related FW | 1.6.0 |
| Range [units] | 80 .. 20 000 [V] | | |
| Default value | 231 V | Alternative config | YES |
| Step | 1 V | | |
| Comm object | 8277 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Conditioned by the setpoint Connection type (page 165). | | |
| Description | | | |
| Nominal voltage (phase to neutral). | | | |
| Note: To lock this setpoint against editing you also have to lock setpoint Nominal Voltage Ph-N 1 (page 257), Nominal Voltage Ph-N 2 (page 261) and Nominal Voltage Ph-N 3 (page 265). | | | |

🔍 back to List of setpoints

Nominal Voltage Ph-Ph

| | | | |
|--|---|-----------------------------|----------|
| Setpoint group | Basic settings | Related FW | 1.6.0 |
| Range [units] | 80 .. 40 000 [V] | | |
| Default value | 400 V | Alternative config | YES |
| Step | 1 V | | |
| Comm object | 11657 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Conditioned by the setpoint Connection type (page 165) . | | |
| Description | | | |
| Nominal system voltage (phase to phase). | | | |
| <p>Note: To lock this setpoint against editing you also have to lock setpoint Nominal Voltage Ph-Ph 1 (page 257), Nominal Voltage Ph-Ph 2 (page 261) and Nominal Voltage Ph-Ph 3 (page 265).</p> | | | |

⬅ back to List of setpoints

PT Ratio

| | | | |
|--|--------------------|-----------------------------|----------|
| Setpoint group | Basic settings | Related FW | 1.6.0 |
| Range [units] | 0.1 .. 500.0 [V/V] | | |
| Default value | 1.0 V/V | Alternative config | NO |
| Step | 0.1 V/V | | |
| Comm object | 9579 | Related applications | AMF, MRS |
| Config level | Advanced | | |
| Setpoint visibility | Always | | |
| Description | | | |
| Generator voltage potential transformers ratio. If no PTs are used, adjust this setpoint to 1. | | | |

⬅ back to List of setpoints

Vm PT Ratio

| | | | |
|---|--|-----------------------------|----------|
| Setpoint group | Basic settings | Related FW | 1.6.0 |
| Range [units] | 0.1 .. 500.0 [V/V] | | |
| Default value | 1.0 V/V | Alternative config | NO |
| Step | 0.1 V/V | | |
| Comm object | 9580 | Related applications | AMF, MRS |
| Config level | Advanced | | |
| Setpoint visibility | Conditioned by the setpoint Operation Mode (page 170) | | |
| Description | | | |
| Mains voltage potential transformers ratio. If no PTs are used, adjust the setpoint to 1. | | | |

⬅ back to List of setpoints

Subgroup: Frequency settings

Nominal Frequency

| | | | |
|---|----------------|-----------------------------|----------|
| Setpoint group | Basic settings | Related FW | 1.6.0 |
| Range [units] | 45 .. 65 [Hz] | | |
| Default value | 50 Hz | Alternative config | YES |
| Step | 1 Hz | | |
| Comm object | 8278 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |
| Description | | | |
| Nominal system frequency (usually 50 or 60 Hz). | | | |
| Note: To lock this setpoint against editing you also have to lock setpoint Nominal Frequency 1 (page 257), Nominal Frequency 2 (page 261) and Nominal Frequency 3 (page 265). | | | |

🔍 back to List of setpoints

Gear Teeth

| | | | |
|--|--------------------------|-----------------------------|----------|
| Setpoint group | Basic settings | Related FW | 1.6.0 |
| Range [units] | FGen->RPM / 1 .. 500 [-] | | |
| Default value | FGen->RPM | Alternative config | NO |
| Step | 1 | | |
| Comm object | 8252 | Related applications | AMF, MRS |
| Config level | Advanced | | |
| Setpoint visibility | Always | | |
| Description | | | |
| Number of teeth on the engine flywheel where the pick-up is installed. Set to zero if no pick-up is used and the Engine speed will be counted from the generator frequency. | | | |
| Note: If no pickup is used, the D+ or W terminal should be used to prevent possible overcranking, which can occur if at least 25% of nominal generator voltage is not present immediately after exceeding firing speed. | | | |

🔍 back to List of setpoints

Nominal RPM

| | | | |
|--|--------------------|-----------------------------|----------|
| Setpoint group | Basic settings | Related FW | 1.6.0 |
| Range [units] | 100 .. 4 000 [RPM] | | |
| Default value | 1 500 RPM | Alternative config | YES |
| Step | 1 RPM | | |
| Comm object | 8253 | Related applications | AMF, MRS |
| Config level | Advanced | | |
| Setpoint visibility | Always | | |
| Description | | | |
| Nominal engine speed (RPM – revolutions per minute). | | | |
| <p>Note: To lock this setpoint against editing you also have to lock setpoint Nominal RPM 1 (page 256), Nominal RPM 2 (page 260) and Nominal RPM 3 (page 264).</p> | | | |

⬅ back to List of setpoints

Subgroup: Controller settings

Controller Mode

| | | | |
|--|-----------------------------|-----------------------------|----------|
| Setpoint group | Basic settings | Related FW | 1.6.0 |
| Range [units] | OFF / MAN / AUTO / TEST [-] | | |
| Default value | OFF | Alternative config | NO |
| Step | [-] | | |
| Comm object | 8315 | Related applications | AMF, MRS |
| Config level | Advanced | | |
| Description | | | |
| This setpoint can be used for changing the Controller mode remotely, e.g. via Modbus. Use the mode selector on the main screen for changing the mode from the front panel. Use mode selector in the control window for changing the mode from IntelliConfig. | | | |

⬅ back to List of setpoints

Power On Mode

| | | | |
|--|--|-----------------------------|----------|
| Setpoint group | Basic settings | Related FW | 1.6.0 |
| Range [units] | Previous / OFF [-] | | |
| Default value | Previous | Alternative config | NO |
| Step | [-] | | |
| Comm object | 13000 | Related applications | AMF, MRS |
| Config level | Advanced | | |
| Setpoint visibility | Always | | |
| Description | | | |
| This setpoint adjusts controller mode after power on of controller. | | | |
| Previous | When controller is power on, controller is switched to last mode before power off. | | |
| OFF | When controller is power on, controller is switched to OFF Mode. | | |
| <p><i>Note: Remote modes – In case that some LBI remote mode is activated during power on of controller than this LBI has higher priority than this setpoint – controller mode is forced into mode selected via LBI. After deactivation of LBI, controller is switched into value selected via setpoint Power On Mode</i></p> | | | |

⬅ back to List of setpoints

Operation Mode

| | | | |
|---|---|-----------------------------|----------|
| Setpoint group | Basic settings | Related FW | 1.6.0 |
| Range [units] | AMF / MRS [-] | | |
| Default value | AMF | Alternative config | NO |
| Step | [-] | | |
| Comm object | 12157 | Related applications | AMF, MRS |
| Config level | Advanced | | |
| Setpoint visibility | Always | | |
| Description | | | |
| This setpoint defines the controller application. | | | |
| AMF | Normal AMF operation | | |
| MRS | When MRS mode is selected the controller will not perform AMF functions anymore. MCB button <input type="checkbox"/> will be inactive and also mains measurement and protections will be disabled. The controller will keep TEST mode and the Gen-set in AUTO mode will be able to start by REMOTE START/STOP (PAGE 326) binary input. | | |

⬅ back to List of setpoints

Controller Address

| | | | |
|---|----------------|-----------------------------|----------|
| Setpoint group | Basic settings | Related FW | 1.6.0 |
| Range [units] | 1 .. 32 [-] | | |
| Default value | 1 | Alternative config | NO |
| Step | 1 | | |
| Comm object | 24537 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |
| Description | | | |
| Controller identification number. It is possible to set controller address different from the default value (1) so that more IL controllers can be interconnected (via RS485) and accessed e.g. from MODBUS terminal. | | | |
| <i>Note: When opening connection to the controller it's address has to correspond with the setting in PC tool.</i> | | | |
| <i>Note: This setpoint is common for CM-Ethernet, CM-GPRS and CM-4G-GPS modules.</i> | | | |

[⬅ back to List of setpoints](#)

Reset To Manual

| | | | |
|---|------------------------|-----------------------------|----------|
| Setpoint group | Basic settings | Related FW | 1.6.0 |
| Range [units] | Disabled / Enabled [-] | | |
| Default value | Disabled | Alternative config | NO |
| Step | [-] | | |
| Comm object | 9983 | Related applications | AMF, MRS |
| Config level | Advanced | | |
| Setpoint visibility | Always | | |
| Description | | | |
| If this function is enabled, the controller will switch automatically to MAN mode when there is a red alarm in the alarm list and fault reset button is pressed. This is a safety function that prevents the gen-set starting again automatically in specific cases when fault reset button is pressed. | | | |
| Example: Controller is in AUTO mode and there is red inactive unconfirmed alarm and fault reset button is pressed, controller will start automatically. | | | |

[⬅ back to List of setpoints](#)

Backlight Timeout

| | | | |
|--|---------------------------|-----------------------------|----------|
| Setpoint group | Basic settings | Related FW | 1.6.0 |
| Range [units] | Disabled / 1 .. 255 [min] | | |
| Default value | Disabled | Alternative config | NO |
| Step | 1 min | | |
| Comm object | 10121 | Related applications | AMF, MRS |
| Config level | Advanced | | |
| Setpoint visibility | Always | | |
| Description | | | |
| The display backlight is switched off when this timer exceed. When setpoint is adjusted to disabled then the display will be backlighted all the time. | | | |

🔍 back to List of setpoints

Horn Timeout

| | | | | | | | | | |
|--|--|-----------------------------|----------|----------|--------------------------------------|--------------|--|------------|--|
| Setpoint group | Basic settings | Related FW | 1.6.0 | | | | | | |
| Range [units] | Disabled / 1 .. 599 s / Horn Reset [-] | | | | | | | | |
| Default value | 10 s | Alternative config | NO | | | | | | |
| Step | 1 s | | | | | | | | |
| Comm object | 8264 | Related applications | AMF, MRS | | | | | | |
| Config level | Advanced | | | | | | | | |
| Setpoint visibility | Always | | | | | | | | |
| Description | | | | | | | | | |
| Setting of horn behavior. | | | | | | | | | |
| <table border="1"> <tr> <td>Disabled</td> <td>Disabling the Horn sounding function</td> </tr> <tr> <td>1 .. 599 [s]</td> <td>Timeout for HORN (PAGE 350) binary output. The HORN (PAGE 350) output is active when this timeout elapsed.</td> </tr> <tr> <td>Horn reset</td> <td>LBO HORN (PAGE 350) is deactivated by Fault reset button or by Horn reset button.</td> </tr> </table> | | | | Disabled | Disabling the Horn sounding function | 1 .. 599 [s] | Timeout for HORN (PAGE 350) binary output. The HORN (PAGE 350) output is active when this timeout elapsed. | Horn reset | LBO HORN (PAGE 350) is deactivated by Fault reset button or by Horn reset button. |
| Disabled | Disabling the Horn sounding function | | | | | | | | |
| 1 .. 599 [s] | Timeout for HORN (PAGE 350) binary output. The HORN (PAGE 350) output is active when this timeout elapsed. | | | | | | | | |
| Horn reset | LBO HORN (PAGE 350) is deactivated by Fault reset button or by Horn reset button. | | | | | | | | |
| <p>Note: Horn timeout starts again from the beginning if a new alarm appears before previous Horn timeout has elapsed.</p> | | | | | | | | | |

🔍 back to List of setpoints

Zero Power Mode

| | | | |
|--|--|-----------------------------|----------|
| Setpoint group | Basic settings | Related FW | 1.6.0 |
| Range [units] | Disabled / 1 .. 360 [min] | | |
| Default value | Disabled | Alternative config | NO |
| Step | 1 min | | |
| Comm object | 8548 | Related applications | AMF, MRS |
| Config level | Advanced | | |
| Setpoint visibility | Conditioned by the setpoint Operation Mode (page 170) | | |
| Description | | | |
| <p>The controller is switched to Zero Power Mode when there is no user interaction with the controller for the preset time period. For the controller wake up press button Start or activate Binary Input 1. The controller will not switch to Zero Power Mode if generator is running. In Zero Power Mode binary outputs go to high impedance.</p> <p>IMPORTANT: This only works if Operation Mode is set to MRS.</p> <p><i>Note: Power consumption of controller in Zero Power Mode is 0 mA. Controller is internally disconnected from power supply.</i></p> <p><i>Note: While there is USB power present (USB cable plugged) the controller is able to turn off when there is no user interaction but wake up is not possible. USB power has to be cut off (USB cable unplugged).</i></p> | | | |

🔍 back to List of setpoints

RunHoursSource

| | | | | | | | | | |
|--|--|-----------------------------|----------|------|--|-----|--|----------|--|
| Setpoint group | Basic settings | Related FW | 1.6.0 | | | | | | |
| Range [units] | AUTO / ECU / INTERNAL [-] | | | | | | | | |
| Default value | AUTO | Alternative config | NO | | | | | | |
| Step | [-] | | | | | | | | |
| Comm object | 13345 | Related applications | AMF, MRS | | | | | | |
| Config level | Advanced | | | | | | | | |
| Setpoint visibility | Always | | | | | | | | |
| Description | | | | | | | | | |
| <p>This setpoint selects source of running hours.</p> <table border="1"> <tr> <td>AUTO</td> <td>If there is some ECU which send valid running hours, then this value is used. Otherwise value from internal counter is used.</td> </tr> <tr> <td>ECU</td> <td>Running hours are taken from ECU if ECU send valid data. It is not possible to set and reset this value in statistics.</td> </tr> <tr> <td>INTERNAL</td> <td>Running hours are taken from internal counter. It is possible to set and reset this value in statistics.</td> </tr> </table> <p><i>Note: It is not necessary to restart controller when this setpoint is changed. Change of this setpoint is applied immediately.</i></p> | | | | AUTO | If there is some ECU which send valid running hours, then this value is used. Otherwise value from internal counter is used. | ECU | Running hours are taken from ECU if ECU send valid data. It is not possible to set and reset this value in statistics. | INTERNAL | Running hours are taken from internal counter. It is possible to set and reset this value in statistics. |
| AUTO | If there is some ECU which send valid running hours, then this value is used. Otherwise value from internal counter is used. | | | | | | | | |
| ECU | Running hours are taken from ECU if ECU send valid data. It is not possible to set and reset this value in statistics. | | | | | | | | |
| INTERNAL | Running hours are taken from internal counter. It is possible to set and reset this value in statistics. | | | | | | | | |

🔍 back to List of setpoints

GCB Mode

| | | | |
|---|---|-----------------------------|-------|
| Setpoint group | Basic settings | Related FW | 1.6.0 |
| Range [units] | Normal / Manual / No Button [-] | | |
| Default value | Normal | Alternative config | YES |
| Step | [-] | | |
| Comm object | 11771 | Related applications | MRS |
| Config level | Advanced | | |
| Description | | | |
| Mode of Generator Circuit Breaker behavior. | | | |
| Normal | In this mode GCB is always controlled by Gen-set controller using relevant GCB control binary outputs (GCB CLOSE/OPEN (PAGE 343)), GCB OFF COIL (PAGE 345) , GCB ON COIL (PAGE 346) or GCB UV COIL (PAGE 346)). GCB alarms are issued as usual. In MAN mode GCB is controlled manually by GCB button. In AUT mode GCB is controlled automatically. | | |
| Manual | In this mode, the GCB is always manually operated (by operator not by controller). GCB feedback signal can be wired up to the controller. (However this isn't mandatory.) The GCB button on the controller is inactive. | | |
| No Button | In this mode GCB button is inactive. In MAN mode GCB is operated automatically. It is closed and opened .at the same time and under same conditions as in AUT mode. GCB FEEDBACK (PAGE 321) is evaluated if configured. There is no change in AUT mode compared to Normal GCB mode. | | |

🔍 back to List of setpoints

Screen Filter

| | | | |
|--|-----------------------|-----------------------------|----------|
| Setpoint group | Basic settings | Related FW | 1.6.0 |
| Range [units] | Enable / Disabled [-] | | |
| Default value | Disabled | Alternative config | NO |
| Step | [-] | | |
| Comm object | 15889 | Related applications | AMF, MRS |
| Config level | Advanced | | |
| Setpoint visibility | Always | | |
| Description | | | |
| Every analog value showed on CU screen is filtered when setpoint is enabled. List of values which are filtered when filter is ON. | | | |
| <ul style="list-style-type: none"> ➤ Generator Voltage L1-L2 ➤ Generator Voltage L2-L3 ➤ Generator Voltage L3-L1 ➤ Generator Voltage L1-N ➤ Generator Voltage L2-N ➤ Generator Voltage L3-N ➤ Generator Frequency | | | |

- > Load kVA
- > Load kVA L1
- > Load kVA L2
- > Load kVA L3
- > Load kVAr
- > Load kVAr L1
- > Load kVAr L2
- > Load kVAr L3
- > Load kW
- > Load kW L1
- > Load kW L2
- > Load kW L3

[back to List of setpoints](#)

Subgroup: HMI Settings

Main Screen Line 1

| | | | |
|--|---------------------------------------|-----------------------------|----------|
| Setpoint group | Basic settings | Related FW | 1.6.0 |
| Range [units] | RPM / PF / Run Hours / ATT / AIN1 [-] | | |
| Default value | PF | Alternative config | NO |
| Step | [-] | | |
| Comm object | 13346 | Related applications | AMF, MRS |
| Config level | Advanced | | |
| Setpoint visibility | Always | | |
| Description | | | |
| This setpoint adjusts line 1 on Main screen. | | | |

[back to List of setpoints](#)

Main Screen Line 2

| | | | |
|--|---------------------------------------|-----------------------------|----------|
| Setpoint group | Basic settings | Related FW | 1.6.0 |
| Range [units] | RPM / PF / Run Hours / ATT / AIN1 [-] | | |
| Default value | RPM | Alternative config | NO |
| Step | [-] | | |
| Comm object | 14628 | Related applications | AMF, MRS |
| Config level | Advanced | | |
| Setpoint visibility | Always | | |
| Description | | | |
| This setpoint adjusts line 2 on Main screen. | | | |

[back to List of setpoints](#)

Group: Engine settings

Subgroup: Starting

Cranking Attempts

| | | | |
|--------------------------------------|-----------------|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | 1 .. 10 [-] | | |
| Default value | 3 | Alternative config | NO |
| Step | 1 | | |
| Comm object | 8255 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |
| Description | | | |
| Maximal number of cranking attempts. | | | |

🔍 back to List of setpoints

Cranking Fail Pause

| | | | |
|--|-----------------|-------------------|-------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Fix value | 8 s | | |
| Description | | | |
| Pause between Cranking Attempts (page 176) . PRESTART (PAGE 357) output is active in this pause until Cranking Fail Pause elapses. | | | |
| IMPORTANT: This is a fixed parameter, it isn't possible to adjust it in any manner. This parameter isn't visible either in controller or in PC tools. | | | |

🔍 back to List of setpoints

Maximum Cranking Time

| | | | |
|---|-----------------|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | 1 .. 255 [s] | | |
| Default value | 5 s | Alternative config | NO |
| Step | 1 s | | |
| Comm object | 8256 | Related applications | AMF, MRS |
| Config level | Advanced | | |
| Setpoint visibility | Always | | |
| Description | | | |
| Maximum time limit of cranking time. | | | |
| IMPORTANT: There is a protection against broken pinion on starter. In case that there are no RPM after 5 seconds of starting, cranking is interrupted and cranking fail pause follows. | | | |

🔍 back to List of setpoints

Prestart Time

| | | | |
|----------------------------|-----------------|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | 0 .. 600 [s] | | |
| Default value | 2 s | Alternative config | NO |
| Step | 1 s | | |
| Comm object | 8394 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |

Description

Time of closing of the **PRESTART (PAGE 357)** output prior to the engine start. Set to zero if you want to leave the output **PRESTART (PAGE 357)** open.




Image 8.1 Prestart Time

🔍 back to List of setpoints

Starting RPM

| | | | |
|----------------------------|-------------------------------|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | 5 .. 50 [%] | | |
| Default value | 25% | Alternative config | NO |
| Step | 1 % of Nominal RPM (page 169) | | |
| Comm object | 8254 | Related applications | AMF, MRS |
| Config level | Advanced | | |
| Setpoint visibility | Always | | |

Description

This setpoint defines the "firing" speed level as percent value of the **Nominal RPM (page 169)**. If this level is exceeded the engine is considered as started.

🔍 back to List of setpoints

Starting Oil Pressure

| | | | |
|---|------------------------------|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | Disabled / 0.1 .. 10.0 [bar] | | |
| Default value | 4.5 bar | Alternative config | NO |
| Step | 0.1 bar | | |
| Comm object | 9681 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |
| Description | | | |
| Oil pressure limit for starting. The controller will stop cranking (STARTER (PAGE 361) goes OFF) if the oil pressure rises above this limit. | | | |
| Option Disabled – when this option is selected, Oil Pressure value (value from CU analog Oil Pressure, value from ECU analog Oil pressure and state of binary input Oil Pressure) is not used for disengagement of starter and for engine running evaluation. | | | |
| IMPORTANT: Value from analog input has higher priority than value from ECU. | | | |

◀ back to List of setpoints

Glow Plugs Time

| | | | |
|--|--|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | 0.0 .. Prestart Time (page 177) [s] | | |
| Default value | 0.1 s | Alternative config | NO |
| Step | 1.0 s | | |
| Comm object | 14412 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |
| Description | | | |
| This setpoint defines the time before starting when logical binary output GLOW PLUGS (PAGE 348) will be active. | | | |

◀ back to List of setpoints

Idle RPM

| | | | |
|---|-------------------|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | 100 .. 4000 [RPM] | | |
| Default value | 900 RPM | Alternative config | NO |
| Step | 1 RPM | | |
| Comm object | 9946 | Related applications | AMF, MRS |
| Config level | Advanced | | |
| Setpoint visibility | Always | | |
| Description | | | |
| This setpoint adjusts idle speed of engine. | | | |

◀ back to List of setpoints

Subgroup: Choke

Choke Function

| | | | | | | | | | |
|---|--|-----------------------------|----------|----------|---|------------|---|------------|--|
| Setpoint group | Engine settings | Related FW | 1.6.0 | | | | | | |
| Range [units] | Disabled /Fixed Time / Temp Based [-] | | | | | | | | |
| Default value | Disabled | Alternative config | NO | | | | | | |
| Step | [-] | | | | | | | | |
| Comm object | 15717 | Related applications | AMF, MRS | | | | | | |
| Config level | Advanced | | | | | | | | |
| Setpoint visibility | Only when LBO CHOKE (PAGE 338) is configured. | | | | | | | | |
| Description | | | | | | | | | |
| This setpoint defines choke function behavior. | | | | | | | | | |
| <table border="1"><tr><td>Disabled</td><td>Choke function is disabled and logical binary output CHOKE (PAGE 338) is activated under no circumstances.</td></tr><tr><td>Fixed Time</td><td>Choke time is fixedly defined by Choke Time (page 179) setpoint.</td></tr><tr><td>Temp Based</td><td>Choke time is calculated using actual engine (coolant) temperature. Setpoints Choke Start Temp (page 180) and Choke Increment (page 181) are taken into consideration.</td></tr></table> | | | | Disabled | Choke function is disabled and logical binary output CHOKE (PAGE 338) is activated under no circumstances. | Fixed Time | Choke time is fixedly defined by Choke Time (page 179) setpoint. | Temp Based | Choke time is calculated using actual engine (coolant) temperature. Setpoints Choke Start Temp (page 180) and Choke Increment (page 181) are taken into consideration. |
| Disabled | Choke function is disabled and logical binary output CHOKE (PAGE 338) is activated under no circumstances. | | | | | | | | |
| Fixed Time | Choke time is fixedly defined by Choke Time (page 179) setpoint. | | | | | | | | |
| Temp Based | Choke time is calculated using actual engine (coolant) temperature. Setpoints Choke Start Temp (page 180) and Choke Increment (page 181) are taken into consideration. | | | | | | | | |

🔍 back to List of setpoints

Choke Time

| | | | |
|--|--|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | 0 .. 3600 [s] | | |
| Default value | 0 s | Alternative config | NO |
| Step | 1 s | | |
| Comm object | 13011 | Related applications | AMF, MRS |
| Config level | Advanced | | |
| Setpoint visibility | Only when LBO CHOKE (PAGE 338) is configured and setpoint Choke Function (page 179) = Fixed Time. | | |
| Description | | | |
| Defines time logical binary output CHOKE (PAGE 338) is activated for when fixed time is used. When setpoint Choke Function (page 179) is set to <i>Temp Based</i> value, <i>Choke Time</i> value have no effect. | | | |
| Note: <i>If setpoint Choke Lead (page 183) is set to nonzero value, total time the CHOKE output is activated still matches value set by Choke Time setpoint. This mean Choke Time should be longer than Choke Lead to ensure expected Choke behavior.</i> | | | |


🔍 back to List of setpoints

Choke Start Temp

| | | | |
|----------------------------|--|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | -20.0 .. 80.0 [°C] | | |
| Default value | 0.0 °C | Alternative config | NO |
| Step | 0.1 °C | | |
| Comm object | 15716 | Related applications | AMF, MRS |
| Config level | Advanced | | |
| Setpoint visibility | Only when LBO CHOKE (PAGE 338) is configured and setpoint Choke Function (page 179) = Temp Based. | | |

Description

This setpoint adjust the base temperature for Choke function. When temperature will be higher than this setpoint, Choke Time will be always 0. When temperature will be lower than this setpoint, Choke Time will be calculated by curve adjusted via setpoint **Choke Increment** (page 181). When setpoint **Choke Function** (page 179) is set to *Fixed Time* value, setpoint *Choke Start Temp* has no effect.




[back to List of setpoints](#)

Choke Increment

| | | | |
|----------------------------|---|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | 0.00 .. 20.00 [s/°C] | | |
| Default value | 0.00 s/°C | Alternative config | NO |
| Step | 0.01 s/°C | | |
| Comm object | 15715 | Related applications | AMF, MRS |
| Config level | Advanced | | |
| Setpoint visibility | Only when LBO CHOKE (PAGE 338) is configured and setpoint Choke Function (page 179) = Temp Based. | | |

Description

This setpoint adjust the maximal time of activation of binary output **CHOKE** (PAGE 338). Calculated time depends on engine (coolant) temperature. Setpoint adjust curve which is used for calculating actual Choke Time. When setpoint **Choke Function** (page 179) is set to *Fixed Time* value, setpoint *Choke Increment* has no effect.



Note: If setpoint **Choke Lead** (page 183) is set to nonzero value, total time the **CHOKE** output is activated still matches calculated value (based on actual temperature and setpoints **Choke Increment** and **Choke Start Temp** (page 180)) This mean that adjusted parameters should ensure that calculated **Choke Time** will be longer than **Choke Lead** to ensure expected **Choke** behavior.


🔍 back to List of setpoints

Choke Voltage

| | | | |
|----------------------------|---|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | Disabled / 1 .. 100 [%] | | |
| Default value | Disabled | Alternative config | NO |
| Step | 1 % | | |
| Comm object | 15718 | Related applications | AMF, MRS |
| Config level | Advanced | | |
| Setpoint visibility | Only when LBO CHOKE (PAGE 338) is configured. | | |

Description

This setpoint adjust threshold level for deactivation of **CHOKE (PAGE 338)** binary output. When generator voltage is higher than this level, then logical binary output CHOKE is deactivated. In multiphase system it is sufficient to deactivate CHOKE LBO when at least one voltage crosses this threshold. In case setpoint *Choke Voltage* is set to *Disabled* value, no voltage is taken into account and CHOKE LBO isn't deactivated on the voltage basis.



[back to List of setpoints](#)

Choke Lead

| | | | |
|--|---|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | 0 .. Prestart Time [s] | | |
| Default value | 0 s | Alternative config | NO |
| Step | 1 s | | |
| Comm object | 15774 | Related applications | AMF, MRS |
| Config level | Advanced | | |
| Setpoint visibility | Only when LBO CHOKE (PAGE 338) is configured. | | |
| Description | | | |
| This setpoint adjust the lead of logical binary output CHOKE. CHOKE (PAGE 338) is activated before logical binary output STARTER (PAGE 361). | | | |
| <i>Note: In case Choke Lead is longer than 8 s (cranking fail pause), Choke Lead will be limited to 8 s (cranking fail pause time). This limitation is applied only for cranking fail pause, Choke Lead in Prestart stays unchanged.</i> | | | |

🔍 back to List of setpoints

Subgroup: D+ Function

D+ Function

| | | | |
|----------------------------|--|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | Enabled / ChargeFail / Disabled [-] | | |
| Default value | Disabled | Alternative config | NO |
| Step | [-] | | |
| Comm object | 9683 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |
| Description | | | |
| Behavior of D+ terminal. | | | |
| Enabled | The D+ terminal is used for both functions – "running engine" detection and charge fail detection. | | |
| ChargeFail | The D+ terminal is used for charge fail detection only | | |
| Disabled | The D+ terminal is not used. | | |




Image 8.2 D+ Function 1




Image 8.3 D+ Function 2

Note: Delay of this function is adjusted via *D+ Delay* (page 185) setpoint, threshold of this function is adjusted via *D+ Level setpoint*.

🔍 back to List of setpoints

D+ Threshold

| | | | |
|--|---|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | 0 .. 100 [%] | | |
| Default value | 80 % | Alternative config | NO |
| Step | 1 % | | |
| Comm object | 14959 | Related applications | AMF, MRS |
| Config level | Advanced | | |
| Setpoint visibility | Only if setpoint D+ Function (page 183) is not set to <i>Disabled</i> value. | | |
| Description | | | |
| This setpoint adjusts threshold level for D+ Function (page 183). | | | |

🔍 back to List of setpoints

D+ Delay

| | | | |
|--|---|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | 1 .. 255 [s] | | |
| Default value | 1 s | Alternative config | NO |
| Step | 1 s | | |
| Comm object | 14960 | Related applications | AMF, MRS |
| Config level | Advanced | | |
| Setpoint visibility | Only if setpoint D+ Function (page 183) is not set to <i>Disabled</i> value. | | |
| Description | | | |
| This setpoint adjusts delay for D+ Function (page 183) . This delay is used for: <ul style="list-style-type: none"> ➤ Alarm Wrn Charging Alternator Fail (page 387). ➤ For engine running condition – disengagement of starter | | | |

🔍 back to List of setpoints

D+ Alarm Type

| | | | |
|--|---|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | No Protec / Wrn / Sd [-] | | |
| Default value | Wrn | Alternative config | NO |
| Step | [-] | | |
| Comm object | 15751 | Related applications | AMF, MRS |
| Config level | Advanced | | |
| Setpoint visibility | Only if setpoint D+ Function (page 183) is not set to <i>Disabled</i> value. | | |
| Description | | | |
| This setpoint adjusts type of alarm Wrn Charging Alternator Fail (page 387) . | | | |

🔍 back to List of setpoints

Subgroup: Starting Timers

Fuel Solenoid Lead

| | | | |
|----------------------------|-----------------|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | 0.0 .. 25.0 [s] | | |
| Default value | 0.5 s | Alternative config | NO |
| Step | 0.1 s | | |
| Comm object | 10525 | Related applications | AMF, MRS |
| Config level | Advanced | | |
| Setpoint visibility | Always | | |

Description

Delay between **FUEL SOLENOID (PAGE 342)** and **STARTER (PAGE 361)** logical binary outputs. **FUEL SOLENOID (PAGE 342)** is active before **STARTER (PAGE 361)**. Lead time is adjusted via this setpoint.




Image 8.4 Fuel Solenoid Lead

Note: LBO PRESTART (PAGE 357) goes to logical zero when Fuel Solenoid Lead goes to logical one.

🔍 back to List of setpoints

Idle Time

| | | | |
|----------------------------|-----------------|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | 0 .. 600 [s] | | |
| Default value | 12 s | Alternative config | NO |
| Step | 1 s | | |
| Comm object | 9097 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |

Description

Idle Time delay starts when RPM exceeds **Starting RPM (page 177)**. Start fail is detected when during Idle state RPM decreases below 2 RPM.

The output **IDLE/NOMINAL (PAGE 351)** remains inactive during the idle period. Binary output Idle/Nominal opens during Cooling period again. This output can be used for switching the governor between idle and nominal speed.

Note: When controller is in the MAN mode, it is possible to finish the Idle Time count down by pushing the Start button.




Image 8.5 Idle Time 1




Image 8.6 Idle Time 2

[back to List of setpoints](#)

Minimal Stabilization Time

| | | | |
|----------------------------|--|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | 1 .. Maximal Stabilization Time (page 189) [s] | | |
| Default value | 2 s | Alternative config | NO |
| Step | 1 s | | |
| Comm object | 8259 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |

Description

When the Gen-set has been started and the idle timer has elapsed, the controller will wait for a period adjusted by this setpoint before closing GCB, even if the generator voltage and frequency are already in limits.




Image 8.7 Minimal Stabilization Time

[back to List of setpoints](#)

Maximal Stabilization Time

| | | | |
|----------------------------|---|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | Minimal Stabilization Time (page 188) .. 300 [s] | | |
| Default value | 10 s | Alternative config | NO |
| Step | 1 s | | |
| Comm object | 8313 | Related applications | AMF, MRS |
| Config level | Advanced | | |
| Setpoint visibility | Always | | |

Description

When the Gen-set has been started and the idle timer has elapsed, the generator voltage and frequency must get within limits within this period of time, otherwise an appropriate shutdown alarm (generator voltage and/or frequency) is issued.




Image 8.8 Maximal Stabilization Time

[back to List of setpoints](#)

Protection Hold Off

| | | | |
|----------------------------|------------------|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | 0.0 .. 300.0 [s] | | |
| Default value | 5.0 s | Alternative config | YES |
| Step | 0.1 s | | |
| Comm object | 10023 | Related applications | AMF, MRS |
| Config level | Advanced | | |
| Setpoint visibility | Always | | |

Description

During the start of the Gen-set, some engine protections have to be blocked (e.g. Oil pressure). The protections are unblocked after the Protect Hold Off. The time starts after reaching Starting RPM.

[back to List of setpoints](#)

Subgroup: Stopping

Cooling Speed

| | | | |
|---|---|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | Idle / Nominal [-] | | |
| Default value | Nominal | Alternative config | NO |
| Step | [-] | | |
| Comm object | 10046 | Related applications | AMF, MRS |
| Config level | Advanced | | |
| Setpoint visibility | Always | | |
| Description | | | |
| Selects the function of the binary output IDLE/NOMINAL (PAGE 351) during engine cooling state. | | | |
| Idle | Cooling is executed at Idle speed and generator protections are switched off. | | |
| Nominal | Cooling is executed at Nominal speed and generator protections are active. | | |
| Note: When ECU is connected the predefined value 900 RPM for Idle speed is requested. | | | |
| Note: Binary output IDLE/NOMINAL (PAGE 351) must be configured and connected to speed governor. Engine Idle speed must be adjusted on speed governor. | | | |

⬅ back to List of setpoints

Subgroup: Stopping Timers

Cooling Time

| | | | |
|---|-----------------|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | 0 .. 3 600 [s] | | |
| Default value | 30 s | Alternative config | NO |
| Step | 1 s | | |
| Comm object | 8258 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |
| Description | | | |
| Runtime of the unloaded Gen-set to cool the engine before stop. | | | |

⬅ back to List of setpoints

Stop Time

| | | | |
|----------------------------|-----------------|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | 0 .. 600 [s] | | |
| Default value | 60 s | Alternative config | NO |
| Step | 1 s | | |
| Comm object | 9815 | Related applications | AMF, MRS |
| Config level | Advanced | | |
| Setpoint visibility | Always | | |

Description

Under normal conditions the engine must certainly stop within this period after the **FUEL SOLENOID (PAGE 342)** has been de-energized and the **STOP SOLENOID (PAGE 362)** energized. The Stop Solenoid output is deactivated 12 s after last running engine indication went off.




Image 8.9 Stop Time 1




Image 8.10 Stop Time 2

[back to List of setpoints](#)

After Cooling Time

| | | | |
|---|-----------------|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | 0 .. 3 600 [s] | | |
| Default value | 180 s | Alternative config | NO |
| Step | 1 s | | |
| Comm object | 8662 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |
| Description | | | |
| Runtime of engine after cooling pump. Binary output COOLING PUMP (PAGE 339) is active when the engine starts deactivates after timer set in this setpoint elapses (timer starts counting down as soon as engine switches to stop phase). | | | |

[back to List of setpoints](#)

Subgroup: Engine Protections

Overspeed Sd

| | | | |
|---|--|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | Underspeed Sd (page 192) .. 200 [%] | | |
| Default value | 115% | Alternative config | NO |
| Step | 1 % of Nominal RPM (page 169) | | |
| Comm object | 8263 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |
| Description | | | |
| Threshold for over speed protection. Relative to the nominal speed. | | | |

[back to List of setpoints](#)

Underspeed Sd

| | | | |
|---|---|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | 0 .. Overspeed Sd (page 192) [%] | | |
| Default value | 25% | Alternative config | NO |
| Step | 1 % of Nominal RPM (page 169) | | |
| Comm object | 8260 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |
| Description | | | |
| Threshold for underspeed protection. Relative to the nominal speed. | | | |

[back to List of setpoints](#)

Overspeed Overshot

| | | | |
|---|-------------------------------|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | 0 .. 50 [%] | | |
| Default value | 20% | Alternative config | NO |
| Step | 1 % of Nominal RPM (page 169) | | |
| Comm object | 14107 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |
| Description | | | |
| This setpoint rise the upper limit of overspeed protection for the time which is defined in setpoint Overspeed Overshot Period (page 193) . In this time the upper limit of protection is Overspeed Sd (page 192) + Overspeed Overshoot . | | | |

🔍 back to List of setpoints

Overspeed Overshot Period

| | | | |
|---|--|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | 0 .. 255 [s] | | |
| Default value | 5 s | Alternative config | NO |
| Step | 1 s | | |
| Comm object | 14108 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Conditioned by the setpoint Overspeed Overshot (page 193) | | |
| Description | | | |
| Time for which is Overspeed Overshot (page 193) active. The timer starts in the same time when starter starts. | | | |
| <i>Note: The setpoint is visible only, if Overspeed Overshot (page 193) is greater than 0.</i> | | | |

🔍 back to List of setpoints

Oil Pressure Wrn

| | | | |
|---|---|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | the range is defined by an analog sensor curve | | |
| Default value | the value is defined by an analog sensor curve | Alternative config | NO |
| Step | the step is defined by an analog sensor curve | | |
| Comm object | 12895 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Visible only if the logical analog input OIL PRESSURE (PAGE 371) is configured | | |
| Description | | | |
| Warning or history threshold level for OIL PRESSURE (PAGE 371) . | | | |

🔍 back to List of setpoints

Oil Pressure Sd

| | | | |
|---|---|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | the range is defined by an analog sensor curve | | |
| Default value | the value is defined by an analog sensor curve | Alternative config | NO |
| Step | the step is defined by an analog sensor curve | | |
| Comm object | 12779 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Visible only if the logical analog input OIL PRESSURE (PAGE 371) is configured | | |
| Description | | | |
| Shutdown threshold level for OIL PRESSURE (PAGE 371) . | | | |

[back to List of setpoints](#)

Oil Pressure Delay

| | | | |
|--|---|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | 0 .. 900 [s] | | |
| Default value | 3 s | Alternative config | NO |
| Step | 1 s | | |
| Comm object | 14341 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Visible only if the logical analog input OIL PRESSURE (PAGE 371) is configured | | |
| Description | | | |
| Delay for OIL PRESSURE (PAGE 371) . | | | |

[back to List of setpoints](#)

ECU Oil Pressure Wrn

| | | | |
|--|--|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | the range is defined by an ECU sensor curve | | |
| Default value | the value is defined by an an ECU sensor curve | Alternative config | YES |
| Step | the step is defined by an ECU sensor curve | | |
| Comm object | 14426 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Visible only if ECU is configured | | |
| Description | | | |
| Warning threshold level for Oil pressure which is send from ECU. | | | |

[back to List of setpoints](#)

ECU Oil Pressure Sd

| | | | |
|---|--|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | the range is defined by an ECU sensor curve | | |
| Default value | the value is defined by an an ECU sensor curve | Alternative config | NO |
| Step | the step is defined by an ECU sensor curve | | |
| Comm object | 14425 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Visible only if ECU is configured | | |
| Description | | | |
| Shutdown threshold level for Oil pressure which is send from ECU. | | | |

[back to List of setpoints](#)

ECU Oil Pressure Delay

| | | | |
|--|-----------------------------------|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | 0 .. 900 [s] | | |
| Default value | 3 s | Alternative config | NO |
| Step | 1 s | | |
| Comm object | 14427 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Visible only if ECU is configured | | |
| Description | | | |
| Delay for Oil pressure which is send from ECU. | | | |

[back to List of setpoints](#)

Coolant Temperature Wrn

| | | | |
|---|---|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | the range is defined by an analog sensor curve | | |
| Default value | the value is defined by an analog sensor curve | Alternative config | NO |
| Step | the step is defined by an analog sensor curve | | |
| Comm object | 12896 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Visible only if the logical analog input COOLANT TEMP (PAGE 369) is configured | | |
| Description | | | |
| Warning or history threshold level for COOLANT TEMP (PAGE 369) . | | | |

[back to List of setpoints](#)

Coolant Temperature BOC

| | | | |
|--|---|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | the range is defined by an analog sensor curve | | |
| Default value | the value is defined by an analog sensor curve | Alternative config | NO |
| Step | the step is defined by an analog sensor curve | | |
| Comm object | 12780 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Visible only if the logical analog input COOLANT TEMP (PAGE 369) is configured | | |
| Description | | | |
| Shutdown or BOC threshold level for COOLANT TEMP (PAGE 369) . | | | |

[back to List of setpoints](#)

Coolant Temperature Delay

| | | | |
|--|---|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | 0 .. 900 [s] | | |
| Default value | 5 s | Alternative config | NO |
| Step | 1 s | | |
| Comm object | 14342 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Visible only if the logical analog input COOLANT TEMP (PAGE 369) is configured | | |
| Description | | | |
| Delay for COOLANT TEMP (PAGE 369) . | | | |

[back to List of setpoints](#)

ECU Coolant Temperature Wrn

| | | | |
|---|--|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | the range is defined by an ECU sensor curve | | |
| Default value | the value is defined by an an ECU sensor curve | Alternative config | NO |
| Step | the step is defined by an ECU sensor curve | | |
| Comm object | 14429 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Visible only if ECU is configured | | |
| Description | | | |
| Warning threshold level for Coolant temperature which is send from ECU. | | | |

[back to List of setpoints](#)

ECU Coolant Temperature BOC

| | | | |
|---|--|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | the range is defined by an ECU sensor curve | | |
| Default value | the value is defined by an an ECU sensor curve | Alternative config | NO |
| Step | the step is defined by an ECU sensor curve | | |
| Comm object | 14428 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Visible only if ECU is configured | | |
| Description | | | |
| Shutdown or BOC threshold level for Coolant temperature which is send from ECU. | | | |

[back to List of setpoints](#)

ECU Coolant Temperature Delay

| | | | |
|---|-----------------------------------|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | 0 .. 900 [s] | | |
| Default value | 5 s | Alternative config | NO |
| Step | 1 s | | |
| Comm object | 14430 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Visible only if ECU is configured | | |
| Description | | | |
| Delay for Coolant temperature which is send from ECU. | | | |

[back to List of setpoints](#)

Coolant Temperature Low Wrn

| | | | |
|---|---|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | the range is defined by an analog sensor curve | | |
| Default value | the value is defined by an analog sensor curve | Alternative config | YES |
| Step | the step is defined by an analog sensor curve | | |
| Comm object | 9684 | Related applications | AMF, MRS |
| Config level | Advanced | | |
| Setpoint visibility | Visible only if the logical analog input COOLANT TEMP (PAGE 369) is configured | | |
| Description | | | |
| Threshold level for lower limit of COOLANT TEMP (PAGE 369) . | | | |

[back to List of setpoints](#)

Coolant Temperature Low Delay

| | | | |
|---|---|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | 0 .. 900 [s] | | |
| Default value | 5 s | Alternative config | YES |
| Step | 1 s | | |
| Comm object | 10270 | Related applications | AMF, MRS |
| Config level | Advanced | | |
| Setpoint visibility | Visible only if the logical analog input COOLANT TEMP (PAGE 369) is configured | | |
| Description | | | |
| Delay for Coolant Temperature Low Wrn (page 197). | | | |

[back to List of setpoints](#)

Fuel Level Wrn

| | | | |
|---|---|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | the range is defined by an analog sensor curve | | |
| Default value | the value is defined by an analog sensor curve | Alternative config | NO |
| Step | the step is defined by an analog sensor curve | | |
| Comm object | 12897 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Visible only if the logical analog input FUEL LEVEL (PAGE 369) is configured | | |
| Description | | | |
| Warning or history threshold level for FUEL LEVEL (PAGE 369) . | | | |

[back to List of setpoints](#)

Fuel Level Sd

| | | | |
|--|---|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | the range is defined by an analog sensor curve | | |
| Default value | the value is defined by an analog sensor curve | Alternative config | NO |
| Step | the step is defined by an analog sensor curve | | |
| Comm object | 12898 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Visible only if the logical analog input FUEL LEVEL (PAGE 369) is configured | | |
| Description | | | |
| Shutdown or BOC threshold level for FUEL LEVEL (PAGE 369) . | | | |

[back to List of setpoints](#)

Fuel Level Delay

| | | | |
|--|---|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | 0 .. 900 [s] | | |
| Default value | 10 s | Alternative config | NO |
| Step | 1 s | | |
| Comm object | 14343 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Visible only if the logical analog input FUEL LEVEL (PAGE 369) is configured | | |
| Description | | | |
| Delay for FUEL LEVEL (PAGE 369) . | | | |

🔍 back to List of setpoints

ECU Fuel Level Wrn

| | | | |
|--|--|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | the range is defined by an ECU sensor curve | | |
| Default value | the value is defined by an an ECU sensor curve | Alternative config | NO |
| Step | the step is defined by an ECU sensor curve | | |
| Comm object | 14432 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Visible only if ECU is configured | | |
| Description | | | |
| Warning threshold level for Fuel level which is send from ECU. | | | |

🔍 back to List of setpoints

ECU Fuel Level BOC

| | | | |
|--|--|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | the range is defined by an ECU sensor curve | | |
| Default value | the value is defined by an an ECU sensor curve | Alternative config | NO |
| Step | the step is defined by an ECU sensor curve | | |
| Comm object | 14431 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Visible only if ECU is configured | | |
| Description | | | |
| Shutdown or BOC threshold level for Fuel level which is send from ECU. | | | |

🔍 back to List of setpoints

ECU Fuel Level Delay

| | | | |
|--|------------------------------------|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | 0 .. 900 [s] | | |
| Default value | 10 s | Alternative config | NO |
| Step | 1 s | | |
| Comm object | 14433 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Visible only if ECU is configuredd | | |
| Description | | | |
| Delay for Fuel level which is send from ECU. | | | |

🔍 back to List of setpoints

Transfer Wrn Delay

| | | | |
|--|---|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | Disabled / 1 .. 60 [s] | | |
| Default value | 30 s | Alternative config | YES |
| Step | 1 s | | |
| Comm object | 10685 | Related applications | AMF, MRS |
| Config level | Advanced | | |
| Setpoint visibility | Visible only if the logical binary output FUEL PUMP (PAGE 342) is configured | | |
| Description | | | |
| <p>If the controller does not see the fuel increase during fuel transfer within this time alarm Wrn Fuel Transfer Failed (page 381) will be displayed and the FUEL PUMP (PAGE 342) will be turned off. Alarm Wrn Fuel Transfer Failed (page 381) will be displayed but this alarm becomes immediately inactive and it will be possible to delete this message by the Fault reset button. If the fault is deleted the controller will initiate the transfer again.</p> | | | |

🔍 back to List of setpoints

Fuel Pump On

| | | | |
|----------------------------|--|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | 0 .. Fuel Pump Off (page 202) [%] | | |
| Default value | 20 % | Alternative config | YES |
| Step | 1 % | | |
| Comm object | 10100 | Related applications | AMF, MRS |
| Config level | Advanced | | |
| Setpoint visibility | Visible only if the logical binary output FUEL PUMP (PAGE 342) is configured and logical binary input FUEL PUMP ON/OFF (PAGE 320) isn't configured | | |

Description

Threshold level for switching the binary output **FUEL PUMP (PAGE 342)** on.




Image 8.11 Fuel Pump On

IMPORTANT: When binary input FUEL PUMP ON/OFF (PAGE 320) is configured then binary output FUEL PUMP (PAGE 342) is control by this binary input. Setpoints Fuel Pump On and Fuel Pump Off (page 202) are not evaluated!

Note: Value from analog input has higher priority than ECU.

Note: This setpoint is visible only if the logical binary output **FUEL PUMP (PAGE 342)** is configured.

🔍 back to List of setpoints

Fuel Pump Off

| | | | |
|----------------------------|--|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | Fuel Pump On (page 201) .. 100 [%] | | |
| Default value | 90 % | Alternative config | YES |
| Step | 1 % | | |
| Comm object | 10101 | Related applications | AMF, MRS |
| Config level | Advanced | | |
| Setpoint visibility | Visible only if the logical binary output FUEL PUMP (PAGE 342) is configured and logical binary input FUEL PUMP ON/OFF (PAGE 320) isn't configured | | |

Description

Threshold level for switching the binary output **FUEL PUMP (PAGE 342)** off.




Image 8.12 Fuel Pump Off

IMPORTANT: When binary input FUEL PUMP ON/OFF (PAGE 320) is configured then binary output FUEL PUMP (PAGE 342) is control by this binary input. Setpoints Fuel Pump On (page 201) and Fuel Pump Off are not evaluated!

Note: Value from analog input has higher priority than ECU.

Note: This setpoint is visible only if the logical binary output **FUEL PUMP (PAGE 342)** is configured.

[back to List of setpoints](#)

Subgroup: Maintenance

Maintenance Timer 1

| | | | |
|--|---------------------------------|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | -10 000 .. 9 999 [h] / Disabled | | |
| Default value | 1 000 h | Alternative config | NO |
| Step | 1 h | | |
| Comm object | 11616 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |
| Description | | | |
| Maintenance timer 1 counts down when engine is running. If reaches zero, an alarm appears, but the timer still counting down into negative values. When the value 10000 is set, than the Maintenance function is disabled and counter does not count. Counter value disappear from controllers statistics. | | | |

[◀ back to List of setpoints](#)

Maintenance Timer 2

| | | | |
|--|---------------------------------|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | -10 000 .. 9 999 [h] / Disabled | | |
| Default value | 1 000 h | Alternative config | NO |
| Step | 1 h | | |
| Comm object | 11617 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |
| Description | | | |
| Maintenance timer 2 counts down when engine is running. If reaches zero, an alarm appears, but the timer still counting down into negative values. When the value 10000 is set, than the Maintenance function is disabled and counter does not count. Counter value disappear from controllers statistics. | | | |

[◀ back to List of setpoints](#)

Maintenance Timer 3

| | | | |
|--|---------------------------------|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | -10 000 .. 9 999 [h] / Disabled | | |
| Default value | 1 000 h | Alternative config | NO |
| Step | 1 h | | |
| Comm object | 11618 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |
| Description | | | |
| Maintenance timer 3 counts down when engine is running. If reaches zero, an alarm appears, but the timer still counting down into negative values. When the value 10000 is set, than the Maintenance function is disabled and counter does not count. Counter value disappear from controllers statistics. | | | |

[⬅ back to List of setpoints](#)

Subgroup: Battery Protections

Battery Undervoltage

| | | | |
|--|--|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | 8.0 V .. Battery Overvoltage (page 204) [V] | | |
| Default value | 18.0 V | Alternative config | NO |
| Step | 0.1 V | | |
| Comm object | 8387 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |
| Description | | | |
| Warning threshold for low battery voltage. | | | |

[⬅ back to List of setpoints](#)

Battery Overvoltage

| | | | |
|---|--|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | Battery Undervoltage (page 204) .. 40.0 [V] | | |
| Default value | 36.0 V | Alternative config | NO |
| Step | 0.1 V | | |
| Comm object | 9587 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |
| Description | | | |
| Warning threshold for high battery voltage. | | | |

[⬅ back to List of setpoints](#)

Battery <> Voltage Delay

| | | | |
|---|-----------------|-------------------|-------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Fix value | 5 s | | |
| Description | | | |
| Delay for Battery Undervoltage (page 204) and Battery Overvoltage (page 204) protection. | | | |
| <p>IMPORTANT: This is a fixed parameter, it isn't possible to adjust it in any manner. This parameter isn't visible either in controller or in PC tools.</p> | | | |

⬅ back to List of setpoints

Low Battery Charging Cycle

| | | | |
|--|------------------------|-----------------------------|-------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | Disabled / 1–240 [min] | | |
| Default value | Disabled | Alternative config | NO |
| Step | 1 min | | |
| Comm object | 15766 | Related applications | MRS |
| Config level | Advanced | | |
| Setpoint visibility | Always | | |
| Description | | | |
| <p>This setpoint enables battery charging and defines the time Gen-set is running for to recharge battery. If battery charging is enabled and battery undervoltage is detected for more than 5 minutes, Gen-set is started and will run for time defined in setpoint <i>Low Battery Charging Cycle</i>.</p> <p>Battery charging is only initiated in AUTO mode when no Shutdown alarm and Fuel Level alarm is active. If there is battery undervoltage detected again after previous Charging Cycle is finished (and undervoltage lasts more than 5 minutes) next Charging Cycle is initiated.</p> <p>If controller is switched to MAN mode during battery charging, Gen-set stay running regardless timer (<i>Low Battery Charging Cycle</i> setpoint) elapsing. Gen-set is stopped by STOP button or by any SD alarm event only in this case.</p> <p>If there is <i>Charging Alternator Fail</i> alarm occurred during battery recharging period, current battery recharging continues until time is elapsed. Next Gen-set start due to battery undervoltage is blocked until controller is restarted.</p> <p>IMPORTANT: If controller is in MAN mode and the battery voltage is under the limit more than 5 minutes engine is started immediately when controller is switched to AUTO mode.</p> <p><i>Note: Low Battery Charging function is available only when separate MRS archive is used.</i></p> | | | |

⬅ back to List of setpoints

Subgroup: ECU Settings

ECU Speed Adjustment

| | | | |
|---|-----------------------------------|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | 0 .. 100 [%] | | |
| Default value | 50 % | Alternative config | NO |
| Step | 1 % | | |
| Comm object | 9948 | Related applications | AMF, MRS |
| Config level | Advanced | | |
| Setpoint visibility | Visible only if ECU is configured | | |
| Description | | | |
| Enables to adjust engine speed in ECU via CAN bus. Nominal speed corresponds to 50 %. This setpoint should be used only for Volvo Penta and Scania engines. It has no effect on other engine brands. | | | |
| <i>Note: To lock this setpoint against editing you also have to lock setpoint ECU Speed Adjustment 1 (page 269), ECU Speed Adjustment 2 (page 269) and ECU Speed Adjustment 3 (page 270).</i> | | | |

🔍 back to List of setpoints

Subgroup: Ventilation

Ventilation Pulse Time

| | | | |
|--|--|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | 0 .. 3600 [s] | | |
| Default value | 30 s | Alternative config | NO |
| Step | 1 s | | |
| Comm object | 15767 | Related applications | AMF, MRS |
| Config level | Advanced | | |
| Setpoint visibility | Only when logical binary output VENTILATION ON PULSE (PAGE 363) or VENTILATION OFF PULSE (PAGE 364) is configured. | | |
| Description | | | |
| This setpoint defines duration of pulse generated on logical binary outputs VENTILATION ON PULSE (PAGE 363) or VENTILATION OFF PULSE (PAGE 364) at the moment when logical binary output VENTILATION (PAGE 363) is activated or deactivated respectively. | | | |

🔍 back to List of setpoints

Group: Generator settings

Subgroup: Overload Protection

Overload BOC

| | | | |
|--|------------------------------------|-----------------------------|----------|
| Setpoint group | Generator settings | Related FW | 1.6.0 |
| Range [units] | Overload Wrn (page 207) .. 200 [%] | | |
| Default value | 120 % | Alternative config | NO |
| Step | 1 % of Nominal Power (page 163) | | |
| Comm object | 8280 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |
| Description | | | |
| Threshold level for overload of generator (in % of Nominal power) protection. Protection is BOC (Breaker Open and Gen-set Cooldown). | | | |
| <i>Note: When there is no control of breakers, the type of protection is Sd not BOC.</i> | | | |

⬅ back to List of setpoints

Overload Wrn

| | | | |
|--|----------------------------------|-----------------------------|----------|
| Setpoint group | Generator settings | Related FW | 1.6.0 |
| Range [units] | 0 .. Overload BOC (page 207) [%] | | |
| Default value | 120 % | Alternative config | NO |
| Step | 1 % of Nominal Power (page 163) | | |
| Comm object | 9685 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |
| Description | | | |
| Threshold level for overload of generator (in % of Nominal Power (page 163)) protection. This is only warning. | | | |

⬅ back to List of setpoints

Overload Delay

| | | | |
|---|--------------------|-----------------------------|----------|
| Setpoint group | Generator settings | Related FW | 1.6.0 |
| Range [units] | 0.0 .. 600.0 [s] | | |
| Default value | 5.0 s | Alternative config | NO |
| Step | 0.1 s | | |
| Comm object | 8281 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |
| Description | | | |
| Delay for protections Overload BOC (page 207) and Overload Wrn (page 207) . | | | |

⬅ back to List of setpoints

Subgroup: Current Protection

Short Circuit BOC

| | | | |
|--|--|-----------------------------|----------|
| Setpoint group | Generator settings | Related FW | 1.6.0 |
| Range [units] | 100 .. 500 [%] | | |
| Default value | 250 % | Alternative config | NO |
| Step | 1 % of Nominal Current (page 163) | | |
| Comm object | 8282 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |
| Description | | | |
| Protection occurs when generator current reaches this preset threshold. Type of the protection is BOC. | | | |
| <i>Note: When there is no control of breakers, the type of protection is Sd not BOC.</i> | | | |

[◀ back to List of setpoints](#)

Short Circuit BOC Delay

| | | | |
|---|--------------------|-----------------------------|----------|
| Setpoint group | Generator settings | Related FW | 1.6.0 |
| Range [units] | 0.00 .. 10.00 [s] | | |
| Default value | 0.04 s | Alternative config | YES |
| Step | 0.01 s | | |
| Comm object | 9991 | Related applications | AMF, MRS |
| Config level | Advanced | | |
| Setpoint visibility | Always | | |
| Description | | | |
| Delay for Short Circuit BOC (page 208) protection. | | | |

[◀ back to List of setpoints](#)

Subgroup: Voltage Protection

Generator Overvoltage Sd

| | | | |
|---|--|-----------------------------|----------|
| Setpoint group | Generator settings | Related FW | 1.6.0 |
| Range [units] | Generator Overvoltage Wrn (page 209) .. 200 [%] | | |
| Default value | 110 % | Alternative config | NO |
| Step | 1 % of Nominal Voltage Ph-N (page 166) or Nominal Voltage Ph-Ph (page 167) | | |
| Comm object | 8291 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |
| Description | | | |
| Threshold for generator overvoltage protection. All three phases are checked. Maximum out of three is used. | | | |
| <i>Note: Phase to phase and phase to neutral voltages are used for this protection.</i> | | | |

[back to List of setpoints](#)

Generator Overvoltage Wrn

| | | | |
|---|--|-----------------------------|----------|
| Setpoint group | Generator settings | Related FW | 1.6.0 |
| Range [units] | Generator Undervoltage Wrn (page 210) .. Generator Overvoltage Sd (page 209) [%] | | |
| Default value | 110 % | Alternative config | NO |
| Step | 1 % of Nominal Voltage Ph-N (page 166) or Nominal Voltage Ph-Ph (page 167) | | |
| Comm object | 9686 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |
| Description | | | |
| Threshold for generator overvoltage protection. All three phases are checked. Maximum out of three is used. | | | |
| <i>Note: Phase to phase and phase to neutral voltages are used for this protection.</i> | | | |

[back to List of setpoints](#)

Generator Undervoltage BOC

| | | | |
|--|--|-----------------------------|----------|
| Setpoint group | Generator settings | Related FW | 1.6.0 |
| Range [units] | 0 .. Generator Undervoltage Wrn (page 210) [%] | | |
| Default value | 70 % | Alternative config | NO |
| Step | 1 % of Nominal Voltage Ph-N (page 166) or Nominal Voltage Ph-Ph (page 167) | | |
| Comm object | 8293 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |
| Description | | | |
| Threshold for generator undervoltage protection. All three phases are checked. Minimum out of three is used. | | | |
| <i>Note: Phase to phase and phase to neutral voltages are used for this protection.</i> | | | |
| <i>Note: When there is no control of breakers, the type of protection is Sd not BOC.</i> | | | |

[back to List of setpoints](#)

Generator Undervoltage Wrn

| | | | |
|--|---|-----------------------------|----------|
| Setpoint group | Generator settings | Related FW | 1.6.0 |
| Range [units] | Generator Undervoltage BOC (page 210) .. Generator Overvoltage Wrn (page 209) [%] | | |
| Default value | 70 % | Alternative config | NO |
| Step | 1 % of Nominal Voltage Ph-N (page 166) or Nominal Voltage Ph-Ph (page 167) | | |
| Comm object | 9687 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |
| Description | | | |
| Threshold for generator undervoltage protection. All three phases are checked. Minimum out of three is used. | | | |
| <i>Note: Phase to phase and phase to neutral voltages are used for this protection.</i> | | | |

[back to List of setpoints](#)

Generator <> Voltage Delay

| | | | |
|--|--------------------|-----------------------------|----------|
| Setpoint group | Generator settings | Related FW | 1.6.0 |
| Range [units] | 0.0 .. 600.0 [s] | | |
| Default value | 3.0 s | Alternative config | NO |
| Step | 0.1 s | | |
| Comm object | 9103 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |
| Description | | | |
| Delay for Generator Overvoltage Sd (page 209) , Generator Overvoltage Wrn (page 209) , Generator Undervoltage BOC (page 210) and Generator Undervoltage Wrn (page 210) protection. | | | |

[back to List of setpoints](#)

Subgroup: Frequency Protection

Generator Overfrequency BOC

| | | | |
|--|--|-----------------------------|----------|
| Setpoint group | Generator settings | Related FW | 1.6.0 |
| Range [units] | Generator Overfrequency Wrn (page 211) .. 200.0 [%] | | |
| Default value | 110.0 % | Alternative config | NO |
| Step | 0.1 % of Nominal Frequency (page 168) | | |
| Comm object | 8296 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |
| Description | | | |
| Threshold for generator phase L1 overfrequency. | | | |
| <i>Note: When there is no control of breakers, the type of protection is Sd not BOC.</i> | | | |

[back to List of setpoints](#)

Generator Overfrequency Wrn

| | | | |
|---|--|-----------------------------|----------|
| Setpoint group | Generator settings | Related FW | 1.6.0 |
| Range [units] | Generator Underfrequency Wrn (page 212) .. Generator Overfrequency BOC (page 211) [%] | | |
| Default value | 110.0 % | Alternative config | NO |
| Step | 0.1 % of Nominal Frequency (page 168) | | |
| Comm object | 9688 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |
| Description | | | |
| Threshold for generator phase L1 overfrequency. | | | |

[back to List of setpoints](#)

Generator Underfrequency BOC

| | | | |
|--|---|-----------------------------|----------|
| Setpoint group | Generator settings | Related FW | 1.6.0 |
| Range [units] | 0.0 .. Generator Underfrequency Wrn (page 212) [%] | | |
| Default value | 85.0 % | Alternative config | NO |
| Step | 0.1 % of Nominal Frequency (page 168) | | |
| Comm object | 8298 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |
| Description | | | |
| Threshold for generator phase L1 underfrequency. | | | |
| <i>Note: When there is no control of breakers, the type of protection is Sd not BOC.</i> | | | |

⬅ back to List of setpoints

Generator Underfrequency Wrn

| | | | |
|--|--|-----------------------------|----------|
| Setpoint group | Generator settings | Related FW | 1.6.0 |
| Range [units] | Generator Underfrequency BOC (page 212) .. Generator Overfrequency Wrn (page 211) [%] | | |
| Default value | 85.0 % | Alternative config | NO |
| Step | 0.1 % of Nominal Frequency (page 168) | | |
| Comm object | 9689 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |
| Description | | | |
| Threshold for generator phase L1 underfrequency. | | | |

⬅ back to List of setpoints

Generator <> Frequency Delay

| | | | |
|---|--------------------|-----------------------------|----------|
| Setpoint group | Generator settings | Related FW | 1.6.0 |
| Range [units] | 0.0 .. 600.0 [s] | | |
| Default value | 3.0 s | Alternative config | NO |
| Step | 0.1 s | | |
| Comm object | 8297 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |
| Description | | | |
| Delay for Generator Overfrequency BOC (page 211) , Generator Overfrequency Wrn (page 211) , Generator Underfrequency Wrn (page 212) and Generator Underfrequency BOC (page 212) protection. | | | |

⬅ back to List of setpoints

Group: Protections

Subgroup: Overload Protection

Overload Protection

| | | | |
|--|--|-----------------------------|----------|
| Setpoint group | Protections | Related FW | 1.6.0 |
| Range [units] | Enabled / Disabled / By LBI [-] | | |
| Default value | Enabled | Alternative config | NO |
| Step | [-] | | |
| Comm object | 15664 | Related applications | AMF, MRS |
| Config level | Advanced | | |
| Setpoint visibility | Always | | |
| Description | | | |
| This setpoint adjusts the behavior of generator Overload protection. | | | |
| Enabled: | Protection is enabled. Behavior of protection is adjusted via setpoints Overload BOC (page 207) , Overload Wrn (page 207) and Overload Delay (page 207) . | | |
| Disabled: | Protection is disabled. | | |
| By LBI: | Protection is enabled or disabled by the state of LBI PROTECTION ENABLE (PAGE 324) . | | |

[back to List of setpoints](#)

Subgroup: Current Protection

Short Circuit Protection

| | | | |
|---|---|-----------------------------|----------|
| Setpoint group | Protections | Related FW | 1.6.0 |
| Range [units] | Enabled / Disabled / By LBI [-] | | |
| Default value | Enabled | Alternative config | NO |
| Step | [-] | | |
| Comm object | 15665 | Related applications | AMF, MRS |
| Config level | Advanced | | |
| Setpoint visibility | Always | | |
| Description | | | |
| This setpoint adjusts the behavior of generator Short Circuit protection. | | | |
| Enabled: | Protection is enabled. Behavior of protection is adjusted via setpoints Short Circuit BOC (page 208) and Short Circuit BOC Delay (page 208) . | | |
| Disabled: | Protection is disabled. | | |
| By LBI: | Protection is enabled or disabled by the state of LBI PROTECTION ENABLE (PAGE 324) . | | |

[back to List of setpoints](#)

Subgroup: Voltage Protection

Generator <> Voltage Protection

| | | | |
|---|---|-----------------------------|----------|
| Setpoint group | Protections | Related FW | 1.6.0 |
| Range [units] | Enabled / Disabled / By LBI [-] | | |
| Default value | Enabled | Alternative config | NO |
| Step | [-] | | |
| Comm object | 15668 | Related applications | AMF, MRS |
| Config level | Advanced | | |
| Setpoint visibility | Always | | |
| Description | | | |
| This setpoint adjusts the behavior of generator Generator <> Voltage protection. GCB closing is blocked, if the protection is disabled! | | | |
| Enabled: | Protection is enabled. Behavior of protection is adjusted via setpoints Generator Overvoltage Sd (page 209) , Generator Overvoltage Wrn (page 209) , Generator Undervoltage BOC (page 210) , Generator Undervoltage Wrn (page 210) and Generator <> Voltage Delay (page 211) . | | |
| Disabled: | Protection is disabled. | | |
| By LBI: | Protection is enabled or disabled by the state of LBI PROTECTION ENABLE (PAGE 324) . | | |

[back to List of setpoints](#)

Subgroup: Frequency Protection

Generator Frequency Protection

| | | | |
|---|--|-----------------------------|----------|
| Setpoint group | Protections | Related FW | 1.6.0 |
| Range [units] | Enabled / Disabled / By LBI [-] | | |
| Default value | Enabled | Alternative config | NO |
| Step | [-] | | |
| Comm object | 15670 | Related applications | AMF, MRS |
| Config level | Advanced | | |
| Setpoint visibility | Always | | |
| Description | | | |
| This setpoint adjusts the behavior of Generator Frequency protection. GCB closing is blocked, if the protection is disabled!. | | | |
| Enabled: | Protection is enabled. Behavior of protection is adjusted via setpoints Generator Overfrequency BOC (page 211) , Generator Overfrequency Wrn (page 211) , Generator Underfrequency BOC (page 212) , Generator Underfrequency Wrn (page 212) , and Generator <> Frequency Delay (page 212) . | | |
| Disabled: | Protection is disabled. | | |
| By LBI: | Protection is enabled or disabled by the state of LBI PROTECTION ENABLE (PAGE 324) . | | |

[back to List of setpoints](#)

Subgroup: Speed Protection

Underspeed Protection

| | | | |
|--|--|-----------------------------|----------|
| Setpoint group | Protections | Related FW | 1.6.0 |
| Range [units] | Enabled / Disabled / By LBI [-] | | |
| Default value | Enabled | Alternative config | NO |
| Step | [-] | | |
| Comm object | 15671 | Related applications | AMF, MRS |
| Config level | Advanced | | |
| Setpoint visibility | Always | | |
| Description | | | |
| This setpoint adjusts the behavior of generator Underspeed protection. | | | |
| Enabled: | Protection is enabled. Behavior of protection is adjusted via setpoint Underspeed Sd (page 192) . | | |
| Disabled: | Protection is disabled. | | |
| By LBI: | Protection is enabled or disabled by the state of LBI PROTECTION ENABLE (PAGE 324) . | | |

[▲ back to List of setpoints](#)

Overspeed Protection

| | | | |
|---|---|-----------------------------|----------|
| Setpoint group | Protections | Related FW | 1.6.0 |
| Range [units] | Enabled / Disabled / By LBI [-] | | |
| Default value | Enabled | Alternative config | NO |
| Step | [-] | | |
| Comm object | 15672 | Related applications | AMF, MRS |
| Config level | Advanced | | |
| Setpoint visibility | Always | | |
| Description | | | |
| This setpoint adjusts the behavior of generator Overspeed protection. | | | |
| Enabled: | Protection is enabled. Behavior of protection is adjusted via setpoint Overspeed Sd (page 192) . | | |
| Disabled: | Protection is disabled. | | |
| By LBI: | Protection is enabled or disabled by the state of LBI PROTECTION ENABLE (PAGE 324) . | | |

[▲ back to List of setpoints](#)

Group: AMF settings

Subgroup: AMF Timers

Emergency Start Delay

| | | | |
|----------------------------|--|-----------------------------|-------|
| Setpoint group | AMF settings | Related FW | 1.6.0 |
| Range [units] | 0 .. 6 000 [s] | | |
| Default value | 5 s | Alternative config | NO |
| Step | 1 s | | |
| Comm object | 8301 | Related applications | AMF |
| Config level | Standard | | |
| Setpoint visibility | Conditioned by the setpoint Operation Mode (page 170) | | |

Description

Delay after the mains failure to the start command of the Gen-set.




Image 8.13 Emergency Start Delay

[back to List of setpoints](#)

Mains Return Delay

| | | | |
|----------------------------|--|-----------------------------|-------|
| Setpoint group | AMF settings | Related FW | 1.6.0 |
| Range [units] | 1 .. 3 600 [s] | | |
| Default value | 20 s | Alternative config | NO |
| Step | 1 s | | |
| Comm object | 8302 | Related applications | AMF |
| Config level | Standard | | |
| Setpoint visibility | Conditioned by the setpoint Operation Mode (page 170) | | |

Description

This setpoint adjust the delay, how long mains has to be returned after mains fail to start load transfer to mains.

[back to List of setpoints](#)

Transfer Delay

| | | | |
|----------------------------|--|-----------------------------|-------|
| Setpoint group | AMF settings | Related FW | 1.6.0 |
| Range [units] | 0.0 .. 600.0 [s] | | |
| Default value | 1.0 s | Alternative config | NO |
| Step | 0.1 s | | |
| Comm object | 8303 | Related applications | AMF |
| Config level | Standard | | |
| Setpoint visibility | Conditioned by the setpoint Operation Mode (page 170) | | |

Description

Transition Delay between power sources.

Delay after GCB opening to MCB closing during the return procedure. Delay after MCB opening to GCB closing if the setpoint **MCB Opens On (page 223)** is set to GENRUN.

The time charts bellow show recommended setting of Transfer Delay setpoint.

If the Transfer Delay setpoint is set shorter than the time required for opening of the circuit breaker, the controller closes **GCB CLOSE/OPEN (PAGE 343)** output straight away (100 ms) after the **MCB FEEDBACK (PAGE 323)** input deactivates.




Image 8.14 Transfer Delay 1

If some delay between **MCB FEEDBACK (PAGE 323)** deactivation and closing of **GCB CLOSE/OPEN (PAGE 343)** output is required, then the Transfer Delay must be set to sum of "MCB opening" + "Delay" time.




Image 8.15 Transfer Delay 2

⬅ back to List of setpoints

MCB Close Delay

| | | | |
|--|--------------|-------------------|-------|
| Setpoint group | AMF settings | Related FW | 1.6.0 |
| Fix value | 1.0 s | | |
| Description | | | |
| Delay after mains returns to MCB closing, if the Gen-set is not running (e.g. is in start-up procedure). | | | |
| IMPORTANT: This is a fixed parameter, it isn't possible to adjust it in any manner. This parameter isn't visible either in controller or in PC tools. | | | |

⬅ back to List of setpoints

Subgroup: AMF Voltage Conditions

Mains Overvoltage

| | | | |
|--|---|-----------------------------|-------|
| Setpoint group | AMF settings | Related FW | 1.6.0 |
| Range [units] | Mains Undervoltage (page 219) .. 150 [%] | | |
| Default value | 110 % | Alternative config | NO |
| Step | 1 % of Nominal Voltage Ph-Ph (page 167) | | |
| Comm object | 8305 | Related applications | AMF |
| Config level | Standard | | |
| Setpoint visibility | Conditioned by the setpoint Operation Mode (page 170) | | |
| Description | | | |
| Threshold for Mains overvoltage. All three phases are checked. Maximum out of three is used. | | | |

⬅ back to List of setpoints

Mains Undervoltage

| | | | |
|--|---|-----------------------------|-------|
| Setpoint group | AMF settings | Related FW | 1.6.0 |
| Range [units] | 50 .. Mains Overvoltage (page 218) [%] | | |
| Default value | 60 % | Alternative config | YES |
| Step | 1 % of Nominal Voltage Ph-Ph (page 167) | | |
| Comm object | 8307 | Related applications | AMF |
| Config level | Standard | | |
| Setpoint visibility | Conditioned by the setpoint Operation Mode (page 170) | | |
| Description | | | |
| Threshold for Mains undervoltage. All three phases are checked. Minimum voltage out of three phases is used. | | | |

⬅ back to List of setpoints

Mains <> Voltage Delay

| | | | |
|--|---|-----------------------------|-------|
| Setpoint group | AMF settings | Related FW | 1.6.0 |
| Range [units] | 0.0 .. 600.0 [s] | | |
| Default value | 2.0 s | Alternative config | YES |
| Step | 0.1 s | | |
| Comm object | 8306 | Related applications | AMF |
| Config level | Standard | | |
| Setpoint visibility | Conditioned by the setpoint Operation Mode (page 170) | | |
| Description | | | |
| Delay for Mains Undervoltage (page 219) and Mains Overvoltage (page 218) protection. | | | |

⬅ back to List of setpoints

Subgroup: AMF Frequency Conditions

Mains Overfrequency

| | | | |
|------------------------------------|---|-----------------------------|-------|
| Setpoint group | AMF settings | Related FW | 1.6.0 |
| Range [units] | Mains Underfrequency (page 220) .. 150 [%] | | |
| Default value | 102.0 % | Alternative config | NO |
| Step | 1.0 % of Nominal Frequency (page 168) | | |
| Comm object | 8310 | Related applications | AMF |
| Config level | Standard | | |
| Setpoint visibility | Conditioned by the setpoint Operation Mode (page 170) | | |
| Description | | | |
| Threshold for Mains overfrequency. | | | |

⬅ back to List of setpoints

Mains Underfrequency

| | | | |
|-------------------------------------|---|-----------------------------|-------|
| Setpoint group | AMF settings | Related FW | 1.6.0 |
| Range [units] | 50 .. Mains Overfrequency (page 219) [%] | | |
| Default value | 98.0 % | Alternative config | NO |
| Step | 1.0 % of Nominal Frequency (page 168) | | |
| Comm object | 8312 | Related applications | AMF |
| Config level | Standard | | |
| Setpoint visibility | Conditioned by the setpoint Operation Mode (page 170) | | |
| Description | | | |
| Threshold for Mains underfrequency. | | | |

🔍 back to List of setpoints

Mains < > Frequency Delay

| | | | |
|--|---|-----------------------------|-------|
| Setpoint group | AMF settings | Related FW | 1.6.0 |
| Range [units] | 0.0 .. 600.0 [s] | | |
| Default value | 0.5 s | Alternative config | NO |
| Step | 0.1 s | | |
| Comm object | 8311 | Related applications | AMF |
| Config level | Standard | | |
| Setpoint visibility | Conditioned by the setpoint Operation Mode (page 170) | | |
| Description | | | |
| Delay for Mains Underfrequency (page 220) and Mains Overfrequency (page 219) protection. | | | |

🔍 back to List of setpoints

Subgroup: AMF Settings

Return From Island

| | | | |
|---|---|-----------------------------|-------|
| Setpoint group | AMF settings | Related FW | 1.6.0 |
| Fix value | Auto | Alternative config | NO |
| Comm object | 9590 | Related applications | AMF |
| Config level | Advanced | | |
| Setpoint visibility | Conditioned by the setpoint Operation Mode (page 170) | | |
| Description | | | |
| Setpoint adjust the behavior of closing MCB when the mains returns. | | | |
| Manual | <p>Controller remains in AUT mode and the manual return to Mains is done via MCB button. Manual Restore (page 391) message is displayed in alarmlist to notify operator – it will disappear automatically after MCB close button is pushed.</p> <p>Note: Select MANUAL in case you need to manually control the moment when the load is transferred back to the mains.</p> | | |
| Auto | <p>MCB is closed automatically after the timer Mains Return Delay (page 216) elapses.</p> | | |

🔍 back to List of setpoints

MCB Logic

| | | | |
|--|--|-----------------------------|-------|
| Setpoint group | AMF settings | Related FW | 1.6.0 |
| Range [units] | Close On / Close Off [-] | | |
| Default value | Close Off | Alternative config | NO |
| Step | [-] | | |
| Comm object | 8444 | Related applications | AMF |
| Config level | Advanced | | |
| Setpoint visibility | Conditioned by the setpoint Operation Mode (page 170) | | |
| Description | | | |
| <p>The setpoint influences the behavior of the output MCB CLOSE/OPEN (PAGE 351).</p> <p>Close On When the output MCB CLOSE/OPEN (PAGE 351) is active – MCB should be closed.</p> <p>Close Off When the output MCB CLOSE/OPEN (PAGE 351) is active – MCB should be opened.</p> | | | |




Image 8.16 MCB Logic 1




Image 8.17 MCB Logic 2

[back to List of setpoints](#)

MCB Opens On

| | | | |
|--|---|-----------------------------|-------|
| Setpoint group | AMF settings | Related FW | 1.6.0 |
| Range [units] | Mains Fail / Gen Run [-] | | |
| Default value | Gen Run | Alternative config | NO |
| Step | [-] | | |
| Comm object | 9850 | Related applications | AMF |
| Config level | Advanced | | |
| Setpoint visibility | Conditioned by the setpoint Operation Mode (page 170) | | |
| Description | | | |
| Setpoint adjust the behavior of opening MCB in AUTO mode when there is mains fail. | | | |
| Mains Fail | <p>The command to open the MCB is given immediately after mains fail condition is evaluated.</p> <p>If the mains will return into parameters after MCB was opened and before GCB is closed, timer MCB Close Delay (page 218) is applied before MCB closing.</p> | | |
| Gen Run | <p>MCB will be opened when engine will be running and it will be possible to transfer load from Mains to Gen-set (after stabilization phase).</p> <p>Note: This option should be used for MCBs using 230V control and not equipped with the undervoltage coil.</p> | | |

⬅ back to List of setpoints

Group: General Analog Inputs

Subgroup: General Analog Inputs 1

Analog Protection 1 Wrn

| | | | |
|---|---|-----------------------------|----------|
| Setpoint group | General Analog Inputs | Related FW | 1.6.0 |
| Range [units] | the range is defined by an analog sensor curve | | |
| Default value | the value is defined by an analog sensor curve | Alternative config | NO |
| Step | the step is defined by an analog sensor curve | | |
| Comm object | 9259 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Visible only if the logical analog input AIN PROT01 (PAGE 366) is configured | | |
| Description | | | |
| Warning or history threshold level for AIN PROT01 (PAGE 366) . | | | |
| <p>Note: These setpoints are used only if LAI AIN PROT01 (PAGE 366) is adjusted to required protection type. Otherwise these setpoints are useless.</p> | | | |

⬅ back to List of setpoints

Analog Protection 1 Sd

| | | | |
|---|---|-----------------------------|----------|
| Setpoint group | General Analog Inputs | Related FW | 1.6.0 |
| Range [units] | the range is defined by an analog sensor curve | | |
| Default value | the value is defined by an analog sensor curve | Alternative config | NO |
| Step | the step is defined by an analog sensor curve | | |
| Comm object | 9260 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Visible only if the logical analog input AIN PROT01 (PAGE 366) is configured | | |
| Description | | | |
| Shutdown or BOC threshold level for AIN PROT01 (PAGE 366) . | | | |
| <i>Note: These setpoints are used only if LAI AIN PROT01 (PAGE 366) is adjusted to required protection type. Otherwise these setpoints are useless.</i> | | | |

[back to List of setpoints](#)

Analog Protection 1 Delay

| | | | |
|---|---|-----------------------------|----------|
| Setpoint group | General Analog Inputs | Related FW | 1.6.0 |
| Range [units] | 0 .. 900 [s] | | |
| Default value | 0 s | Alternative config | NO |
| Step | 1 s | | |
| Comm object | 9261 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Visible only if the logical analog input AIN PROT01 (PAGE 366) is configured | | |
| Description | | | |
| Delay for AIN PROT01 (PAGE 366) . | | | |
| <i>Note: These setpoints are used only if LAI AIN PROT01 (PAGE 366) is adjusted to required protection type. Otherwise these setpoints are useless.</i> | | | |

[back to List of setpoints](#)

Subgroup: General Analog Inputs 2

Analog Protection 2 Wrn

| | | | |
|---|---|-----------------------------|----------|
| Setpoint group | General Analog Inputs | Related FW | 1.6.0 |
| Range [units] | the range is defined by an analog sensor curve | | |
| Default value | the value is defined by an analog sensor curve | Alternative config | NO |
| Step | the step is defined by an analog sensor curve | | |
| Comm object | 9262 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Visible only if the logical analog input AIN PROT02 (PAGE 367) is configured | | |
| Description | | | |
| Warning or history threshold level for AIN PROT02 (PAGE 367) . | | | |
| These setpoints are used only if LAI AIN PROT02 (PAGE 367) is adjusted to required protection type. Otherwise these setpoints are useless. | | | |

[back to List of setpoints](#)

Analog Protection 2 Sd

| | | | |
|---|---|-----------------------------|----------|
| Setpoint group | General Analog Inputs | Related FW | 1.6.0 |
| Range [units] | the range is defined by an analog sensor curve | | |
| Default value | the value is defined by an analog sensor curve | Alternative config | NO |
| Step | the step is defined by an analog sensor curve | | |
| Comm object | 9263 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Visible only if the logical analog input AIN PROT02 (PAGE 367) is configured | | |
| Description | | | |
| Shutdown or BOC threshold level for AIN PROT02 (PAGE 367) . | | | |
| <i>Note: These setpoints are used only if LAI AIN PROT02 (PAGE 367) is adjusted to required protection type. Otherwise these setpoints are useless.</i> | | | |

[back to List of setpoints](#)

Analog Protection 2 Delay

| | | | |
|--|---|-----------------------------|----------|
| Setpoint group | General Analog Inputs | Related FW | 1.6.0 |
| Range [units] | 0 .. 900 [s] | | |
| Default value | 0 s | Alternative config | NO |
| Step | 1 s | | |
| Comm object | 9264 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Visible only if the logical analog input AIN PROT02 (PAGE 367) is configured | | |
| Description | | | |
| Delay for AIN PROT02 (PAGE 367) . | | | |
| <i>Note: These setpoints are used only if LAI AIN PROT02 (PAGE 367) is adjusted to required protection type. Otherwise these setpoints are useless.</i> | | | |

⬅ back to List of setpoints

Subgroup: General Analog Inputs 3

Analog Protection 3 Wrn

| | | | |
|--|---|-----------------------------|----------|
| Setpoint group | General Analog Inputs | Related FW | 1.6.0 |
| Range [units] | the range is defined by an analog sensor curve | | |
| Default value | the value is defined by an analog sensor curve | Alternative config | NO |
| Step | the step is defined by an analog sensor curve | | |
| Comm object | 9265 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Visible only if the logical analog input AIN PROT03 (PAGE 368) is configured | | |
| Description | | | |
| Warning or history threshold level for AIN PROT03 (PAGE 368) . | | | |
| <i>Note: These setpoints are used only if LAI AIN PROT03 (PAGE 368) is adjusted to required protection type. Otherwise these setpoints are useless.</i> | | | |

⬅ back to List of setpoints

Analog Protection 3 Sd

| | | | |
|---|---|-----------------------------|----------|
| Setpoint group | General Analog Inputs | Related FW | 1.6.0 |
| Range [units] | the range is defined by an analog sensor curve | | |
| Default value | the value is defined by an analog sensor curve | Alternative config | NO |
| Step | the step is defined by an analog sensor curve | | |
| Comm object | 9266 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Visible only if the logical analog input AIN PROT03 (PAGE 368) is configured | | |
| Description | | | |
| Shutdown or BOC threshold level for AIN PROT03 (PAGE 368) . | | | |
| <i>Note: These setpoints are used only if LAI AIN PROT03 (PAGE 368) is adjusted to required protection type. Otherwise these setpoints are useless.</i> | | | |

[back to List of setpoints](#)

Analog Protection 3 Delay

| | | | |
|---|---|-----------------------------|----------|
| Setpoint group | General Analog Inputs | Related FW | 1.6.0 |
| Range [units] | 0 .. 900 [s] | | |
| Default value | 0 s | Alternative config | NO |
| Step | 1 s | | |
| Comm object | 9267 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Visible only if the logical analog input AIN PROT03 (PAGE 368) is configured | | |
| Description | | | |
| Delay for AIN PROT03 (PAGE 368) . | | | |
| <i>Note: These setpoints are used only if LAI AIN PROT03 (PAGE 368) is adjusted to required protection type. Otherwise these setpoints are useless.</i> | | | |

[back to List of setpoints](#)

Group: Scheduler

Subgroup: Time & Date

Time

| | | | |
|--|--------------|-----------------------------|----------|
| Setpoint group | Scheduler | Related FW | 1.6.0 |
| Range [units] | HH:MM:SS [-] | | |
| Default value | 00:00:00 | Alternative config | NO |
| Step | [-] | | |
| Comm object | 24554 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |
| Description | | | |
| Real time clock adjustment. | | | |
| <i>Note: RTC has no backup battery. This setpoint needs to be set-up after connection of +/- terminal.</i> | | | |

[◀ back to List of setpoints](#)

Date

| | | | |
|--|----------------|-----------------------------|----------|
| Setpoint group | Scheduler | Related FW | 1.6.0 |
| Range [units] | DD/MM/YYYY [-] | | |
| Default value | 1.1.2015 | Alternative config | NO |
| Step | [-] | | |
| Comm object | 24553 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |
| Description | | | |
| Actual date adjustment. | | | |
| <i>Note: RTC has no backup battery. This setpoint needs to be set-up after connection of +/- terminal.</i> | | | |

[◀ back to List of setpoints](#)

Time Stamp Period

| | | | |
|--|----------------|-----------------------------|----------|
| Setpoint group | Scheduler | Related FW | 1.6.0 |
| Range [units] | 0 .. 240 [min] | | |
| Default value | 60 min | Alternative config | NO |
| Step | 1 min | | |
| Comm object | 8979 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |
| Description | | | |
| Time interval for periodic history records. | | | |
| <i>Note: History record is made only when engine is running.</i> | | | |

⬅ back to List of setpoints

Summer Time Mode

| | | | | | | | | | |
|---|---|-----------------------------|----------|---------|--|-----------------|---|-------------------------|---------------------------------------|
| Setpoint group | Scheduler | Related FW | 1.6.0 | | | | | | |
| Range [units] | Disabled / Winter / Summer / Winter - S / Summer - S [-] | | | | | | | | |
| Default value | Disabled | Alternative config | NO | | | | | | |
| Step | [-] | | | | | | | | |
| Comm object | 8727 | Related applications | AMF, MRS | | | | | | |
| Config level | Advanced | | | | | | | | |
| Setpoint visibility | Always | | | | | | | | |
| Description | | | | | | | | | |
| Behavior of switching between winter and summer time. | | | | | | | | | |
| <table border="1"> <tr> <td>Disable</td> <td>Automatic switching between summer and wintertime is disabled.</td> </tr> <tr> <td>Winter (Summer)</td> <td>Automatic switching between summer and wintertime is enabled and it is set to winter (summer) season.</td> </tr> <tr> <td>Winter - S (Summer - S)</td> <td>Modification for southern hemisphere.</td> </tr> </table> | | | | Disable | Automatic switching between summer and wintertime is disabled. | Winter (Summer) | Automatic switching between summer and wintertime is enabled and it is set to winter (summer) season. | Winter - S (Summer - S) | Modification for southern hemisphere. |
| Disable | Automatic switching between summer and wintertime is disabled. | | | | | | | | |
| Winter (Summer) | Automatic switching between summer and wintertime is enabled and it is set to winter (summer) season. | | | | | | | | |
| Winter - S (Summer - S) | Modification for southern hemisphere. | | | | | | | | |

⬅ back to List of setpoints

Subgroup: Timer 1

Timer 1 Function

| | | | |
|----------------------------|---|-----------------------------|----------|
| Setpoint group | Scheduler | Related FW | 1.6.0 |
| Range [units] | Disable / No Func / TEST / MFail Blk / Test OnLd / Mode OFF [-] | | |
| Default value | Disable | Alternative config | NO |
| Step | [-] | | |
| Comm object | 15358 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |

Description

It is possible to choose from following timer functions. Binary output **EXERCISE TIMER 1 (PAGE 341)** is always activated when Timer is active regardless of chosen timer function. Timer functions require controller running in AUTO mode.

Controller activates timer whenever it is powered up even in period, where timer should be already running.

| | |
|-----------|---|
| Disable | The Timer is disabled. |
| No Func | There is no any other function, only binary output of timer is activated. |
| Mode OFF | When this option is chosen then the binary output of timer is internally connected to the Remote OFF binary input. |
| TEST | When this option is chosen then the binary output of timer is internally connected to the binary input Remote TEST. |
| MFail Blk | When this option is chosen then the binary output of timer is internally connected to the Mains Fail Block binary input. |
| TEST OnLd | When this option is chosen then the binary output of timer is internally connected to the Remote TEST On Load binary input. |

[🔍 back to List of setpoints](#)

Timer 1 Setup

| | | | |
|--|-----------|--|----------|
| Setpoint group | Scheduler | Related FW | 1.6.0 |
| Range [units] | [-] | | |
| Default value | [-] | Alternative config | NO |
| Step | [-] | | |
| Comm object | 10969 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |
| Description | | | |
| Related setpoints for timer 1 are: | | | |
| <ul style="list-style-type: none"> > Timer 1 Function (page 230) > Timer 1 Repetition (page 231) > Timer 1 First Occur. Date (page 232) > Timer 1 First Occur. Time (page 232) > Timer 1 Duration (page 232) > Timer 1 Repeated (page 233) > Timer 1 Repeat Day (page 236) | | <ul style="list-style-type: none"> > Timer 1 Day (page 235) > Timer 1 Repeated Day In Week (page 236) > Timer 1 Repeat Day In Month (page 236) > Timer 1 Repeat Week In Month (page 237) > Timer 1 Refresh Period (page 234) > Timer 1 Weekends (page 235) | |

[back to List of setpoints](#)

Timer 1 Repetition

| | | | |
|--|--|-----------------------------|----------|
| Setpoint group | Scheduler | Related FW | 1.6.0 |
| Range [units] | Off / Once / Repeated [-] | | |
| Default value | Off | Alternative config | NO |
| Step | [-] | | |
| Comm object | 0 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Conditioned by the setpoint Timer 1 Function (page 230) | | |
| Description | | | |
| Defines repetition of Timer 1 Function (page 230) . | | | |
| Off | Timer 1 Function (page 230) will not be activated. | | |
| Once | Timer 1 Function (page 230) will be activated only one time. | | |
| Repeated | Timer 1 Function (page 230) will be repeatedly activated. | | |

[back to List of setpoints](#)

Timer 1 First Occur. Date

| | | | |
|--|--|-----------------------------|----------|
| Setpoint group | Scheduler | Related FW | 1.6.0 |
| Range [units] | [DD/MM/YYYY] | | |
| Default value | 01/01/2000 | Alternative config | NO |
| Step | [-] | | |
| Comm object | 0 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Conditioned by the setpoint Timer 1 Function (page 230) | | |
| Description | | | |
| Date of first occurrence of Timer 1 Function (page 230) . | | | |

[back to List of setpoints](#)

Timer 1 First Occur. Time

| | | | |
|--|--|-----------------------------|----------|
| Setpoint group | Scheduler | Related FW | 1.6.0 |
| Range [units] | [HH:MM] | | |
| Default value | 00:00 | Alternative config | NO |
| Step | [-] | | |
| Comm object | 0 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Conditioned by the setpoint Timer 1 Function (page 230) | | |
| Description | | | |
| Time of first occurrence of Timer 1 Function (page 230) . | | | |

[back to List of setpoints](#)

Timer 1 Duration

| | | | |
|---|--|-----------------------------|----------|
| Setpoint group | Scheduler | Related FW | 1.6.0 |
| Range [units] | [HH:MM] | | |
| Default value | 00:00 | Alternative config | NO |
| Step | [-] | | |
| Comm object | 0 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Conditioned by the setpoint Timer 1 Function (page 230) | | |
| Description | | | |
| Timer 1 Function (page 230) duration time. | | | |

[back to List of setpoints](#)

Timer 1 Repeated

| | | | |
|---|--|-----------------------------|----------|
| Setpoint group | Scheduler | Related FW | 1.6.0 |
| Range [units] | Daily / Weekly / Monthly / Short Period [-] | | |
| Default value | Daily | Alternative config | NO |
| Step | [-] | | |
| Comm object | 0 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Conditioned by the setpoint Timer 1 Function (page 230) | | |
| Description | | | |
| Repeated interval of Timer 1 Function (page 230) . | | | |
| Daily | Timer 1 Function (page 230) is repeated every day. | | |
| Weekly | Timer 1 Function (page 230) is repeated every week in chosen days. | | |
| Monthly | Timer 1 Function (page 230) is repeated in chosen day every month or in chosen days of chosen week of month | | |
| Short Period | Timer 1 Function (page 230) is repeated in adjusted period. | | |

[⬅ back to List of setpoints](#)

Timer 1 Refresh Period

| | | | |
|----------------------------|--|-----------------------------|----------|
| Setpoint group | Scheduler | Related FW | 1.6.0 |
| Range [units] | [-] | | |
| Default value | [-] | Alternative config | NO |
| Step | [-] | | |
| Comm object | 0 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Conditioned by the setpoint Timer 1 Function (page 230) | | |

Description

Refresh period of **Timer 1 Function (page 230)**. Meaning of this setpoint depends on type of repetition adjusted in **Timer 1 Repeated (page 233)**.

| | |
|--------------|---|
| Daily | <p>Range [units]: 1 .. 1000 [day]. This setpoint adjust that every X day the timer will be activated.</p> <p>Example: If you have daily repetition and you set this setpoint to 2, then every second day from first occurrence of Timer 1 Function (page 230), the Timer 1 Function (page 230) will be activated.</p> |
| Weekly | <p>Range [units]: 1 .. 60 [week]. This setpoint adjust that every X week the timer will be activated.</p> <p>Example: If you have weekly repetition and you set this setpoint to 2, then every second week from first occurrence of Timer 1 Function (page 230), the Timer 1 Function (page 230) will be activated in selected days adjusted by Timer 1 Day (page 235).</p> |
| Monthly | <p>Range [units]: 1 .. 12 [month]. This setpoint adjust that every X month the timer will be activated.</p> <p>Example: If you have monthly repetition and you set this setpoint to 2, then every second month from first occurrence of Timer 1 Function (page 230), the Timer 1 Function (page 230) will be activated in selected day of month adjusted by Timer 1 Repeat Day In Month (page 236) or in selected days of week of month adjusted by Timer 1 Day (page 235) and Timer 1 Repeat Week In Month (page 237).</p> |
| Short Period | <p>Range [units]: [HH:MM]. This setpoint adjust that every X short period the timer will be activated.</p> <p>Example: If you have short period repetition and you set this setpoint to 2, then every second minute from first occurrence of Timer 1 Function (page 230), the Timer 1 Function (page 230) will be activated.</p> |

 [back to List of setpoints](#)

Timer 1 Weekends

| | | | |
|---|---|-----------------------------|----------|
| Setpoint group | Scheduler | Related FW | 1.6.0 |
| Range [units] | Including / Skip / Postpone [-] | | |
| Default value | Including | Alternative config | NO |
| Step | [-] | | |
| Comm object | 0 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Conditioned by the setpoint Timer 1 Function (page 230) | | |
| Description | | | |
| Behavior of Timer 1 Function (page 230) on weekends. | | | |
| Including | Timer 1 Function (page 230) counter is running on the weekends and Timer 1 Function (page 230) can be active. | | |
| Skip | Timer 1 Function (page 230) counter is running on the weekends but Timer 1 Function (page 230) isn't active. | | |
| Postpone | Timer 1 Function (page 230) counter isn't running on the weekends and Timer 1 Function (page 230) isn't active. If the activation of timer is counted on the weekend, than timer will be activated after weekend. Another activation of timer is counted from original date of first occurrence date. | | |

🔍 back to List of setpoints

Timer 1 Day

| | | | |
|--|--|-----------------------------|----------|
| Setpoint group | Scheduler | Related FW | 1.6.0 |
| Range [units] | Monday / Tuesday / Wednesday / Thursday / Friday / Saturday/ Sunday[-] | | |
| Default value | All OFF | Alternative config | NO |
| Step | [-] | | |
| Comm object | 0 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Conditioned by the setpoint Timer 1 Function (page 230) | | |
| Description | | | |
| Use this setpoint to include or exclude individual days of week. To select the day use Up and Down buttons. To change the value of day use Enter button. | | | |

🔍 back to List of setpoints

Timer 1 Repeat Day

| | | | |
|--|--|---|----------|
| Setpoint group | Scheduler | Related FW | 1.6.0 |
| Range [units] | Repeated Day / Repeated Day In Week [-] | | |
| Default value | Repeated Day | Alternative config | NO |
| Step | [-] | | |
| Comm object | 0 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Conditioned by the setpoint Timer 1 Function (page 230) | | |
| Description | | | |
| Use this setpoint to adjust behavior of monthly repetition of the Timer 1 Function (page 230) . | | | |
| Repeated Day | | Chose one day in month when Timer 1 Function (page 230) will be activated. | |
| Repeated Day In Week | | Chose days in one week when Timer 1 Function (page 230) will be activated. | |

[back to List of setpoints](#)

Timer 1 Repeated Day In Week

| | | | |
|--|--|-----------------------------|----------|
| Setpoint group | Scheduler | Related FW | 1.6.0 |
| Range [units] | Monday / Tuesday / Wednesday / Thursday / Friday / Saturday/ Sunday[-] | | |
| Default value | All OFF | Alternative config | NO |
| Step | [-] | | |
| Comm object | 0 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Conditioned by the setpoint Timer 1 Function (page 230) | | |
| Description | | | |
| Use this setpoint to select the day of week when timer will be activated. | | | |
| <i>Note: More day can be selected. Timer will be activated on the day which happened like the first.</i> | | | |

[back to List of setpoints](#)

Timer 1 Repeat Day In Month

| | | | |
|--|--|-----------------------------|----------|
| Setpoint group | Scheduler | Related FW | 1.6.0 |
| Range [units] | 1 .. 31 [day] | | |
| Default value | 0 | Alternative config | NO |
| Step | [-] | | |
| Comm object | 0 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Conditioned by the setpoint Timer 1 Function (page 230) | | |
| Description | | | |
| Use this setpoint to chose the day in month when the Timer 1 Function (page 230) will be activated. | | | |

[back to List of setpoints](#)

Timer 1 Repeat Week In Month

| | | | |
|---|--|-----------------------------|----------|
| Setpoint group | Scheduler | Related FW | 1.6.0 |
| Range [units] | 1 .. 5 [week] | | |
| Default value | 1 week | Alternative config | NO |
| Step | 1 week | | |
| Comm object | 0 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Conditioned by the setpoint Timer 1 Function (page 230) | | |
| Description | | | |
| This setpoint adjust the week of month in which the Timer 1 Function (page 230) will be activated. | | | |

[back to List of setpoints](#)

Group: Plug-In Modules

Slot A

| | | | |
|---|------------------------|-----------------------------|----------|
| Setpoint group | Plug-In Modules | Related FW | 1.6.0 |
| Range [units] | ENABLED / DISABLED [-] | | |
| Default value | ENABLED | Alternative config | NO |
| Step | [-] | | |
| Comm object | 24280 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |
| Description | | | |
| This setpoint enable or disable module in slot A. | | | |

[back to List of setpoints](#)

Group: CM-RS232-485

COM1 Mode

| | | | |
|---|--------------------------------------|---|----------|
| Setpoint group | CM-RS232-485 | Related FW | 1.6.0 |
| Range [units] | Direct / MODBUS [-] | | |
| Default value | Direct | Alternative config | NO |
| Step | [-] | | |
| Comm object | 24522 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Only if relevant module is installed | | |
| Description | | | |
| Communication protocol switch for the COM1 channel. | | | |
| | Direct | InteliConfig communication protocol via serial cable. | |
| | MODBUS | MODBUS protocol. | |

[back to List of setpoints](#)

COM1 Communication Speed

| | | | |
|--|--|-----------------------------|----------|
| Setpoint group | CM-RS232-485 | Related FW | 1.6.0 |
| Range [units] | 9600 / 19200 / 38400 / 57600 / 115200[bps] | | |
| Default value | 57600 bps | Alternative config | NO |
| Step | [-] | | |
| Comm object | 24341 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Only if relevant module is installed + conditioned by the setpoint COM1 Mode (page 237) | | |
| Description | | | |
| If the direct mode is selected on COM1 channel, the direct communication speed of controller part of line can be adjusted here. Speed of second part of line has to be adjusted to the same value. | | | |
| <i>Note: WinScope supports only 19200, 38400, 57600 speeds.</i> | | | |

[back to List of setpoints](#)

COM1 MODBUS Communication Speed

| | | | |
|--|--|-----------------------------|----------|
| Setpoint group | CM-RS232-485 | Related FW | 1.6.0 |
| Range [units] | 9600 / 19200 / 38400 / 57600 / 115200 [bps] | | |
| Default value | 9600 bps | Alternative config | NO |
| Step | [-] | | |
| Comm object | 24477 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Only if relevant module is installed + conditioned by the setpoint COM1 Mode (page 237) | | |
| Description | | | |
| If the MODBUS mode is selected on COM1 channel, the MODBUS communication speed can be adjusted here. | | | |

[back to List of setpoints](#)

COM2 Mode

| | | | | | | | |
|---|--|-----------------------------|----------|--------|---|--------|------------------|
| Setpoint group | CM-RS232-485 | Related FW | 1.6.0 | | | | |
| Range [units] | Direct / MODBUS [-] | | | | | | |
| Default value | Direct | Alternative config | NO | | | | |
| Step | [-] | | | | | | |
| Comm object | 24451 | Related applications | AMF, MRS | | | | |
| Config level | Standard | | | | | | |
| Setpoint visibility | Only if relevant module is installed | | | | | | |
| Description | | | | | | | |
| Communication protocol switch for the COM2 channel. | | | | | | | |
| | <table border="1"> <tr> <td>Direct</td> <td>InteliConfig communication protocol via serial cable.</td> </tr> <tr> <td>MODBUS</td> <td>MODBUS protocol.</td> </tr> </table> | | | Direct | InteliConfig communication protocol via serial cable. | MODBUS | MODBUS protocol. |
| Direct | InteliConfig communication protocol via serial cable. | | | | | | |
| MODBUS | MODBUS protocol. | | | | | | |

⬆️ [back to List of setpoints](#)

COM2 Communication Speed

| | | | |
|--|--|-----------------------------|----------|
| Setpoint group | CM-RS232-485 | Related FW | 1.6.0 |
| Range [units] | 9600 / 19200 / 38400 / 57600 / 115200[bps] | | |
| Default value | 57600 bps | Alternative config | NO |
| Step | [-] | | |
| Comm object | 24340 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Only if relevant module is installed + conditioned by the setpoint COM2 Mode (page 239) | | |
| Description | | | |
| If the direct mode is selected on COM2 channel, the direct communication speed of controller part of line can be adjusted here. Speed of second part of line has to be adjusted to the same value. | | | |
| Note: WinScope supports only 19200, 38400, 57600 speeds. | | | |

⬆️ [back to List of setpoints](#)

COM2 MODBUS Communication Speed

| | | | |
|--|--|-----------------------------|----------|
| Setpoint group | CM-RS232-485 | Related FW | 1.6.0 |
| Range [units] | 9600 / 19200 / 38400 / 57600 / 115200 [bps] | | |
| Default value | 9600 bps | Alternative config | NO |
| Step | [-] | | |
| Comm object | 24420 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Only if relevant module is installed + conditioned by the setpoint COM2 Mode (page 239) | | |
| Description | | | |
| If the MODBUS mode is selected on COM2 channel, the MODBUS communication speed can be adjusted here. | | | |

⬅ back to List of setpoints

Group: CM-GPRS

Message Language

| | | | |
|---|--------------------------------------|-----------------------------|----------|
| Setpoint group | CM-GPRS CM-4G-GPS CM-Ethernet | Related FW | 1.6.0 |
| Range [units] | Depends on CU languages [-] | | |
| Default value | English | Alternative config | NO |
| Step | [-] | | |
| Comm object | 24299 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Only if relevant module is installed | | |
| Description | | | |
| Use this setpoint to set the language of SMS and e-mail. | | | |
| <p>Note: Numbers correspond with languages in language list. See the chapter Language selection (page 83) for more information.</p> | | | |
| This setpoint is common for CM-Ethernet, CM-GPRS and CM-4G-GPS modules. | | | |

⬅ back to List of setpoints

Time Zone

| | | | |
|---|--------------------------------------|-----------------------------|----------|
| Setpoint group | CM-GPRS CM-4G-GPS CM-Ethernet | Related FW | 1.6.0 |
| Range [units] | GMT-12:00 .. GMT+13:00 [hours] | | |
| Default value | GMT+1:00 hour | Alternative config | NO |
| Step | [-] | | |
| Comm object | 24366 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Only if relevant module is installed | | |
| Description | | | |
| <p>This setpoint is used to select the time zone where the controller is located. See your computer time zone setting (click on the time indicator located in the rightmost position of the Windows task bar) if you are not sure about your time zone.</p> <p>Note: <i>If the time zone is not selected properly the active e-mails may contain incorrect information about sending time, which may result in confusion when the respective problem actually occurred.</i></p> <p>Note: <i>This setpoint is common for CM-Ethernet, CM-GPRS and CM-4G-GPS modules.</i></p> | | | |

[◀ back to List of setpoints](#)

Event Message

| | | | |
|---|--------------------------------------|-----------------------------|----------|
| Setpoint group | CM-GPRS CM-4G-GPS CM-Ethernet | Related FW | 1.6.0 |
| Range [units] | ON / OFF [-] | | |
| Default value | ON | Alternative config | NO |
| Step | [-] | | |
| Comm object | 10926 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Only if relevant module is installed | | |
| Description | | | |
| <p>This setpoint enables or disables Event Messages.</p> <p>This setpoint is common for CM-Ethernet, CM-GPRS and CM-4G-GPS modules.</p> | | | |

[◀ back to List of setpoints](#)

Wrn Message

| | | | |
|---|--------------------------------------|-----------------------------|----------|
| Setpoint group | CM-GPRS CM-4G-GPS CM-Ethernet | Related FW | 1.6.0 |
| Range [units] | ON / OFF [-] | | |
| Default value | ON | Alternative config | NO |
| Step | [-] | | |
| Comm object | 8482 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Only if relevant module is installed | | |
| Description | | | |
| This setpoint enables or disables Wrn Messages. | | | |
| This setpoint is common for CM-Ethernet, CM-GPRS and CM-4G-GPS modules. | | | |

[◀ back to List of setpoints](#)

BOC Message

| | | | |
|---|--------------------------------------|-----------------------------|----------|
| Setpoint group | CM-GPRS CM-4G-GPS CM-Ethernet | Related FW | 1.6.0 |
| Range [units] | ON / OFF [-] | | |
| Default value | ON | Alternative config | NO |
| Step | [-] | | |
| Comm object | 10566 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Only if relevant module is installed | | |
| Description | | | |
| This setpoint enables or disables BOC Messages. | | | |
| This setpoint is common for CM-Ethernet, CM-GPRS and CM-4G-GPS modules. | | | |

[◀ back to List of setpoints](#)

Sd Messages

| | | | |
|---|--------------------------------------|-----------------------------|----------|
| Setpoint group | CM-GPRS CM-4G-GPS CM-Ethernet | Related FW | 1.6.0 |
| Range [units] | ON / OFF [-] | | |
| Default value | ON | Alternative config | NO |
| Step | [-] | | |
| Comm object | 8484 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Only if relevant module is installed | | |
| Description | | | |
| This setpoint enables or disables Sd Messages. | | | |
| This setpoint is common for CM-Ethernet, CM-GPRS and CM-4G-GPS modules. | | | |

[back to List of setpoints](#)

Telephone Number 1

| | | | |
|---|--------------------------------------|-----------------------------|----------|
| Setpoint group | CM-GPRS; CM-4G-GPS | Related FW | 1.6.0 |
| Range [units] | 0 .. 31 characters [-] | | |
| Default value | [-] | Alternative config | NO |
| Step | [-] | | |
| Comm object | 24296 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Only if relevant module is installed | | |
| Description | | | |
| Enter in this setpoint either a valid GSM phone number where the alarm messages shall be sent. For GSM numbers use either the national format (i.e. the number you would dial if you wanted to make a local call) or the full international format beginning with a "+" character followed by the country prefix. | | | |
| IMPORTANT: Telephone number has to be entered without spaces. | | | |

[back to List of setpoints](#)

Group: CM-4G-GPS

Required Connection Type

| | | | |
|--|--------------------------------------|-----------------------------|----------|
| Setpoint group | CM-4G-GPS | Related FW | 1.6.0 |
| Range [units] | 2G / 3G / 4G / Automatic [-] | | |
| Default value | Automatic | Alternative config | NO |
| Step | [-] | | |
| Comm object | 24132 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Only if relevant module is installed | | |
| Description | | | |
| This setpoint adjusts preferred connection type of CM-4G-GPS module. | | | |

🔍 back to List of setpoints

Message Language

| | | | |
|--|--------------------------------------|-----------------------------|----------|
| Setpoint group | CM-GPRS CM-4G-GPS CM-Ethernet | Related FW | 1.6.0 |
| Range [units] | Depends on CU languages [-] | | |
| Default value | English | Alternative config | NO |
| Step | [-] | | |
| Comm object | 24299 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Only if relevant module is installed | | |
| Description | | | |
| Use this setpoint to set the language of SMS and e-mail. | | | |
| Note: Numbers correspond with languages in language list. See the chapter Language selection (page 83) for more information. | | | |
| This setpoint is common for CM-Ethernet, CM-GPRS and CM-4G-GPS modules. | | | |

🔍 back to List of setpoints

Time Zone

| | | | |
|---|--------------------------------------|-----------------------------|----------|
| Setpoint group | CM-GPRS CM-4G-GPS CM-Ethernet | Related FW | 1.6.0 |
| Range [units] | GMT-12:00 .. GMT+13:00 [hours] | | |
| Default value | GMT+1:00 hour | Alternative config | NO |
| Step | [-] | | |
| Comm object | 24366 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Only if relevant module is installed | | |
| Description | | | |
| <p>This setpoint is used to select the time zone where the controller is located. See your computer time zone setting (click on the time indicator located in the rightmost position of the Windows task bar) if you are not sure about your time zone.</p> <p>Note: <i>If the time zone is not selected properly the active e-mails may contain incorrect information about sending time, which may result in confusion when the respective problem actually occurred.</i></p> <p>Note: <i>This setpoint is common for CM-Ethernet, CM-GPRS and CM-4G-GPS modules.</i></p> | | | |

[back to List of setpoints](#)

Event Message

| | | | |
|---|--------------------------------------|-----------------------------|----------|
| Setpoint group | CM-GPRS CM-4G-GPS CM-Ethernet | Related FW | 1.6.0 |
| Range [units] | ON / OFF [-] | | |
| Default value | ON | Alternative config | NO |
| Step | [-] | | |
| Comm object | 10926 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Only if relevant module is installed | | |
| Description | | | |
| <p>This setpoint enables or disables Event Messages.</p> <p>This setpoint is common for CM-Ethernet, CM-GPRS and CM-4G-GPS modules.</p> | | | |

[back to List of setpoints](#)

Wrn Message

| | | | |
|---|--------------------------------------|-----------------------------|----------|
| Setpoint group | CM-GPRS CM-4G-GPS CM-Ethernet | Related FW | 1.6.0 |
| Range [units] | ON / OFF [-] | | |
| Default value | ON | Alternative config | NO |
| Step | [-] | | |
| Comm object | 8482 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Only if relevant module is installed | | |
| Description | | | |
| This setpoint enables or disables Wrn Messages. | | | |
| This setpoint is common for CM-Ethernet, CM-GPRS and CM-4G-GPS modules. | | | |

[◀ back to List of setpoints](#)

BOC Message

| | | | |
|---|--------------------------------------|-----------------------------|----------|
| Setpoint group | CM-GPRS CM-4G-GPS CM-Ethernet | Related FW | 1.6.0 |
| Range [units] | ON / OFF [-] | | |
| Default value | ON | Alternative config | NO |
| Step | [-] | | |
| Comm object | 10566 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Only if relevant module is installed | | |
| Description | | | |
| This setpoint enables or disables BOC Messages. | | | |
| This setpoint is common for CM-Ethernet, CM-GPRS and CM-4G-GPS modules. | | | |

[◀ back to List of setpoints](#)

Sd Messages

| | | | |
|---|--------------------------------------|-----------------------------|----------|
| Setpoint group | CM-GPRS CM-4G-GPS CM-Ethernet | Related FW | 1.6.0 |
| Range [units] | ON / OFF [-] | | |
| Default value | ON | Alternative config | NO |
| Step | [-] | | |
| Comm object | 8484 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Only if relevant module is installed | | |
| Description | | | |
| This setpoint enables or disables Sd Messages. | | | |
| This setpoint is common for CM-Ethernet, CM-GPRS and CM-4G-GPS modules. | | | |

[back to List of setpoints](#)

Telephone Number 1

| | | | |
|---|--------------------------------------|-----------------------------|----------|
| Setpoint group | CM-GPRS; CM-4G-GPS | Related FW | 1.6.0 |
| Range [units] | 0 .. 31 characters [-] | | |
| Default value | [-] | Alternative config | NO |
| Step | [-] | | |
| Comm object | 24296 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Only if relevant module is installed | | |
| Description | | | |
| Enter in this setpoint either a valid GSM phone number where the alarm messages shall be sent. For GSM numbers use either the national format (i.e. the number you would dial if you wanted to make a local call) or the full international format beginning with a "+" character followed by the country prefix. | | | |
| IMPORTANT: Telephone number has to be entered without spaces. | | | |

[back to List of setpoints](#)

Group: CM-Ethernet

Email Address 1

| | | | |
|---|--------------------------------------|-----------------------------|----------|
| Setpoint group | CM-GPRS CM-4G-GPS CM-Ethernet | Related FW | 1.6.0 |
| Range [units] | 0 .. 63 characters [-] | | |
| Default value | [-] | Alternative config | NO |
| Step | [-] | | |
| Comm object | 24298 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Only if relevant module is installed | | |
| Description | | | |
| Enter in this setpoint a valid e-mail address where the alarm and event e-mails shall be sent. Leave this setpoint blank if alarm and event email should not be send. | | | |

 [back to List of setpoints](#)

E-mail/SMS Language

| | | | |
|--|--------------------------------------|-----------------------------|----------|
| Setpoint group | CM-GPRS; CM-4G-GPS; CM-Ethernet | Related FW | 1.6.0 |
| Range [units] | [-] | | |
| Default value | English | Alternative config | NO |
| Step | [-] | | |
| Comm object | 24299 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Only if relevant module is installed | | |
| Description | | | |
| Use this setpoint to set the language of SMS and e-mail. | | | |
| Note: Numbers correspond with languages in language list. See the chapter for Language selection (page 83) more information. | | | |
| Note: This setpoint is common for CM-Ethernet, CM-GPRS and CM-4G-GPS modules. | | | |

 [back to List of setpoints](#)

Time Zone

| | | | |
|---|--------------------------------------|-----------------------------|----------|
| Setpoint group | CM-GPRS CM-4G-GPS CM-Ethernet | Related FW | 1.6.0 |
| Range [units] | GMT-12:00 .. GMT+13:00 [hours] | | |
| Default value | GMT+1:00 hour | Alternative config | NO |
| Step | [-] | | |
| Comm object | 24366 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Only if relevant module is installed | | |
| Description | | | |
| <p>This setpoint is used to select the time zone where the controller is located. See your computer time zone setting (click on the time indicator located in the rightmost position of the Windows task bar) if you are not sure about your time zone.</p> <p>Note: <i>If the time zone is not selected properly the active e-mails may contain incorrect information about sending time, which may result in confusion when the respective problem actually occurred.</i></p> <p>Note: <i>This setpoint is common for CM-Ethernet, CM-GPRS and CM-4G-GPS modules.</i></p> | | | |

[◀ back to List of setpoints](#)

Event Message

| | | | |
|---|--------------------------------------|-----------------------------|----------|
| Setpoint group | CM-GPRS CM-4G-GPS CM-Ethernet | Related FW | 1.6.0 |
| Range [units] | ON / OFF [-] | | |
| Default value | ON | Alternative config | NO |
| Step | [-] | | |
| Comm object | 10926 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Only if relevant module is installed | | |
| Description | | | |
| <p>This setpoint enables or disables Event Messages.</p> <p>This setpoint is common for CM-Ethernet, CM-GPRS and CM-4G-GPS modules.</p> | | | |

[◀ back to List of setpoints](#)

Wrn Message

| | | | |
|---|--------------------------------------|-----------------------------|----------|
| Setpoint group | CM-GPRS CM-4G-GPS CM-Ethernet | Related FW | 1.6.0 |
| Range [units] | ON / OFF [-] | | |
| Default value | ON | Alternative config | NO |
| Step | [-] | | |
| Comm object | 8482 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Only if relevant module is installed | | |
| Description | | | |
| This setpoint enables or disables Wrn Messages. | | | |
| This setpoint is common for CM-Ethernet, CM-GPRS and CM-4G-GPS modules. | | | |

[◀ back to List of setpoints](#)

BOC Message

| | | | |
|---|--------------------------------------|-----------------------------|----------|
| Setpoint group | CM-GPRS CM-4G-GPS CM-Ethernet | Related FW | 1.6.0 |
| Range [units] | ON / OFF [-] | | |
| Default value | ON | Alternative config | NO |
| Step | [-] | | |
| Comm object | 10566 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Only if relevant module is installed | | |
| Description | | | |
| This setpoint enables or disables BOC Messages. | | | |
| This setpoint is common for CM-Ethernet, CM-GPRS and CM-4G-GPS modules. | | | |

[◀ back to List of setpoints](#)

Sd Messages

| | | | |
|---|--------------------------------------|-----------------------------|----------|
| Setpoint group | CM-GPRS CM-4G-GPS CM-Ethernet | Related FW | 1.6.0 |
| Range [units] | ON / OFF [-] | | |
| Default value | ON | Alternative config | NO |
| Step | [-] | | |
| Comm object | 8484 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Only if relevant module is installed | | |
| Description | | | |
| This setpoint enables or disables Sd Messages. | | | |
| This setpoint is common for CM-Ethernet, CM-GPRS and CM-4G-GPS modules. | | | |

[back to List of setpoints](#)

SMTP UserName

| | | | |
|---|--------------------------------------|-----------------------------|----------|
| Setpoint group | CM-Ethernet | Related FW | 1.6.0 |
| Range [units] | 0 .. 31 characters [-] | | |
| Default value | [-] | Alternative config | NO |
| Step | [-] | | |
| Comm object | 24370 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Only if relevant module is installed | | |
| Description | | | |
| Use this setpoint to enter the username for the SMTP server. Leave the setpoint blank if the SMTP server does not require authentication. | | | |

[back to List of setpoints](#)

SMTP User Password

| | | | |
|---|--------------------------------------|-----------------------------|----------|
| Setpoint group | CM-Ethernet | Related FW | 1.6.0 |
| Range [units] | 0 .. 15 characters [-] | | |
| Default value | [-] | Alternative config | NO |
| Step | [-] | | |
| Comm object | 24369 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Only if relevant module is installed | | |
| Description | | | |
| Use this setpoint to enter the password for the SMTP server. Leave the setpoint blank if the SMTP server does not require authentication. | | | |

[back to List of setpoints](#)

SMTP Server Address

| | | | |
|--|--------------------------------------|-----------------------------|----------|
| Setpoint group | CM-Ethernet | Related FW | 1.6.0 |
| Range [units] | 0 .. 31 characters [-] | | |
| Default value | airgate.comap.cz:9925 | Alternative config | NO |
| Step | [-] | | |
| Comm object | 24537 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Only if relevant module is installed | | |
| Description | | | |
| This setpoint is used for entering the domain name (e.g. smtp.yourprovider.com) or IP address (e.g. 74.125.39.109) or number of port (with colon like a first mark) of the SMTP server. Ask your internet provider or IT manager for this information. | | | |

[◀ back to List of setpoints](#)

SMTP Sender Address

| | | | |
|--|--------------------------------------|-----------------------------|----------|
| Setpoint group | CM-Ethernet | Related FW | 1.6.0 |
| Range [units] | 0 .. 31 characters [-] | | |
| Default value | [-] | Alternative config | NO |
| Step | [-] | | |
| Comm object | 24367 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Only if relevant module is installed | | |
| Description | | | |
| Enter an existing email address into this setpoint. This address will be used as sender address in active e-mails that will be sent from the controller. | | | |
| Note: <i>It is not needed to enter an existing email address, nevertheless valid email format needs to be followed.</i> | | | |
| IMPORTANT: This item is obligatory when emails are configured. | | | |

[◀ back to List of setpoints](#)

IP Address Mode

| | | | |
|--|---|-----------------------------|----------|
| Setpoint group | CM-Ethernet | Related FW | 1.6.0 |
| Range [units] | FIXED / AUTOMATIC [-] | | |
| Default value | AUTOMATIC | Alternative config | NO |
| Step | [-] | | |
| Comm object | 24259 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Only if relevant module is installed | | |
| Description | | | |
| The setpoint is used to select the method how the ethernet connection is adjusted. | | | |
| FIXED | <p>The Ethernet connection is fixed by means of the setpoints <u>IP Addr</u>, <u>NetMask</u>, <u>GateIP</u>, <u>DNS IP Address</u>.</p> <p>This method should be used for a classic Ethernet or internet connection. When this type of connection opens, the controller is specified by its IP address. This means that it would be inconvenient if the IP address were not fixed (static).</p> | | |
| AUTOMATIC | <p>The Ethernet connection setting is obtained automatically from the DHCP server. The obtained settings are then copied to the related setpoints. If the process of obtaining the settings from the DHCP server is not successful, the value <i>000.000.000.000</i> is copied to the setpoint IP address and the module continues to try to obtain the settings.</p> | | |

[back to List of setpoints](#)

IP Address

| | | | |
|--|--|-----------------------------|----------|
| Setpoint group | CM-Ethernet | Related FW | 1.6.0 |
| Range [units] | Valid IP address [-] | | |
| Default value | 192.168.1.254 | Alternative config | NO |
| Step | [-] | | |
| Comm object | 24376 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Only if relevant module is installed + conditioned by the setpoint IP Address Mode (page 253) | | |
| Description | | | |
| The setpoint is used to set the address when you are in static mode. | | | |
| If IP Address Mode (page 253) is FIXED this setpoint is used to adjust the IP address of the ethernet interface of the controller. Ask your IT specialist for help with this setting. | | | |
| If IP Address Mode (page 253) is AUTOMATIC this setpoint is inactive. The IP address is assigned by the DHCP server. | | | |

[back to List of setpoints](#)

Subnet Mask

| | | | |
|--|--|-----------------------------|----------|
| Setpoint group | CM-Ethernet | Related FW | 1.6.0 |
| Range [units] | Valid IP address [-] | | |
| Default value | 255.255.255.0 | Alternative config | NO |
| Step | [-] | | |
| Comm object | 24375 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Only if relevant module is installed + conditioned by the setpoint IP Address Mode (page 253) | | |
| Description | | | |
| <p>The setpoint is used to select the method how the Subnet Mask is adjusted.</p> <p>If IP Address Mode (page 253) is FIXED this setpoint is used to adjust the Subnet Mask. Ask your IT specialist for help with this setting.</p> <p>If IP Address Mode (page 253) is AUTOMATIC this setpoint is inactive. The Subnet Mask is assigned by the DHCP server.</p> | | | |

[back to List of setpoints](#)

Gateway IP

| | | | |
|--|--|-----------------------------|----------|
| Setpoint group | CM-Ethernet | Related FW | 1.6.0 |
| Range [units] | Valid IP address [-] | | |
| Default value | 192.168.1.1 | Alternative config | NO |
| Step | [-] | | |
| Comm object | 24373 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Only if relevant module is installed + conditioned by the setpoint IP Address Mode (page 253) | | |
| Description | | | |
| <p>The setpoint is used to select the method how the Gateway IP is adjusted.</p> <p>If IP Address Mode (page 253) is DISABLE this setpoint is used to adjust the IP address of the gateway of the network segment where the controller is connected.</p> <p>If IP Address Mode (page 253) is ENABLED this setpoint is used to display the gateway IP address which has been assigned by the DHCP server.</p> <p>A gateway is a device which connects the respective segment with the other segments and/or Internet.</p> | | | |

[back to List of setpoints](#)

DNS Mode

| | | | |
|---|--------------------------------------|-----------------------------|----------|
| Setpoint group | CM-Ethernet | Related FW | 1.6.0 |
| Range [units] | Valid IP address [-] | | |
| Default value | 8.8.8.8 | Alternative config | NO |
| Step | [-] | | |
| Comm object | 24362 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Only if relevant module is installed | | |
| Description | | | |
| <p>The setpoint is used to select the method how the DNS Address 1 is adjusted.</p> <p>If IP Address Mode (page 253) is FIXED this setpoint is used to adjust the domain name server (DNS), which is needed to translate domain names in email addresses and server names into correct IP addresses.</p> <p>If IP Address Mode (page 253) is AUTOMATIC this setpoint is inactive. The DNS server IP address is assigned by the DHCP server.</p> | | | |

[◀ back to List of setpoints](#)

DNS Mode

| | | | |
|---|--------------------------------------|-----------------------------|----------|
| Setpoint group | CM-Ethernet | Related FW | 1.6.0 |
| Range [units] | Valid IP address [-] | | |
| Default value | 8.8.8.8 | Alternative config | NO |
| Step | [-] | | |
| Comm object | 24331 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Only if relevant module is installed | | |
| Description | | | |
| <p>The setpoint is used to select the method how the DNS Address 2 is adjusted.</p> <p>If IP Address Mode (page 253) is FIXED this setpoint is used to adjust the domain name server (DNS), which is needed to translate domain names in email addresses and server names into correct IP addresses.</p> <p>If IP Address Mode (page 253) is AUTOMATIC this setpoint is inactive. The DNS server IP address is assigned by the DHCP server.</p> | | | |

[◀ back to List of setpoints](#)

MODBUS Server

| | | | |
|--|--------------------------------------|-----------------------------|----------|
| Setpoint group | CM-Ethernet | Related FW | 1.6.0 |
| Range [units] | DISABLED / ENABLED [-] | | |
| Default value | Disabled | Alternative config | NO |
| Step | [-] | | |
| Comm object | 24337 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Only if relevant module is installed | | |
| Description | | | |
| Enable or disable Modbus communication via ethernet interface. | | | |

[back to List of setpoints](#)

Web Interface

| | | | |
|--|--|-----------------------------|----------|
| Setpoint group | CM-Ethernet | Related FW | 1.6.0 |
| Range [units] | Disabled / Enabled [-] | | |
| Default value | Disabled | Alternative config | NO |
| Step | [-] | | |
| Comm object | 24110 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Only if relevant module is installed + conditioned by the setpoint IP Address Mode (page 253) | | |
| Description | | | |
| The setpoint is used to enable/disable WebServer function. | | | |

[back to List of setpoints](#)

Group: Alternate Config

Subgroup: Basic settings

Nominal RPM 1

| | | | |
|---|-------------------|-----------------------------|----------|
| Setpoint group | Basic settings | Related FW | 1.6.0 |
| Range [units] | 100 .. 4000 [RPM] | | |
| Default value | 1 500 RPM | Alternative config | YES |
| Step | 1 RPM | | |
| Comm object | 9915 | Related applications | AMF, MRS |
| Config level | Advanced | | |
| Setpoint visibility | Always | | |
| Description | | | |
| Nominal engine speed (RPM revolutions per minute). | | | |
| Note: This value is used when any other alternate configuration is not active. | | | |

[back to List of setpoints](#)

Nominal Frequency 1

| | | | |
|---|----------------|-----------------------------|----------|
| Setpoint group | Basic settings | Related FW | 1.6.0 |
| Range [units] | 45 .. 65 [Hz] | | |
| Default value | 50 Hz | Alternative config | YES |
| Step | 1 Hz | | |
| Comm object | 9913 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |
| Description | | | |
| Nominal system frequency (usually 50 or 60 Hz). | | | |
| <i>Note: This value is used when any other alternate configuration is not active.</i> | | | |

⬅ back to List of setpoints

Nominal Voltage Ph-N 1

| | | | |
|---|---|-----------------------------|----------|
| Setpoint group | Basic settings | Related FW | 1.6.0 |
| Range [units] | 80 .. 20000 [V] | | |
| Default value | 231 V | Alternative config | YES |
| Step | 1 V | | |
| Comm object | 12052 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Conditioned by the setpoint Connection type (page 165) . | | |
| Description | | | |
| Nominal system voltage (phase to neutral). | | | |
| <i>Note: This value is used when any other alternate configuration is not active.</i> | | | |

⬅ back to List of setpoints

Nominal Voltage Ph-Ph 1

| | | | |
|---|---|-----------------------------|----------|
| Setpoint group | Basic settings | Related FW | 1.6.0 |
| Range [units] | 80 .. 40000 [V] | | |
| Default value | 400 V | Alternative config | YES |
| Step | 1 V | | |
| Comm object | 12055 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Conditioned by the setpoint Connection Type 1 (page 259) . | | |
| Description | | | |
| Nominal system voltage (phase to phase). | | | |
| <i>Note: This value is used when any other alternate configuration is not active.</i> | | | |

⬅ back to List of setpoints

Nominal Power 1

| | | | |
|--|-----------------|-----------------------------|----------|
| Setpoint group | Basic settings | Related FW | 1.6.0 |
| Range [units] | 1 .. 5 000 [kW] | | |
| Default value | 200 kW | Alternative config | YES |
| Step | 1 kW | | |
| Comm object | 12046 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |
| Description | | | |
| Nominal power of the Gen-set. Generator Overload BOC (page 207) protection is based on this setpoint. | | | |
| <i>Note: This setpoint is used when setpoint Connection type (page 165) is adjusted to Monophase or Splitphase or 3Ph3Wire or High Leg D or 3Ph4Wire or when Autodetect detects connection type as 3Ph3Wire or High Leg D or 3Ph4Wire.</i> | | | |
| <i>Note: This value is used when any other alternate configuration is not active.</i> | | | |
| <i>Note: This value can be also switch into one decimal power format (via IntelliConfig PC tool). In this case the range of value is decrease 10 times.</i> | | | |

⬅ back to List of setpoints

Nominal Power Split Phase 1

| | | | |
|--|---|-----------------------------|----------|
| Setpoint group | Basic settings | Related FW | 1.6.0 |
| Range [units] | 1 .. 5 000 [kW] | | |
| Default value | 200 kW | Alternative config | YES |
| Step | 1 kW | | |
| Comm object | 15771 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Conditioned by the setpoint Connection type (page 165) | | |
| Description | | | |
| Nominal power of the Gen-set for detected split-phase or mono phase connection. Generator Overload BOC (page 207) protection is based on this setpoint. | | | |
| <i>Note: This setpoint is used when setpoint Connection type (page 165) is adjusted to Autodetect and Autodetect detects connection type as Monophase or Splitphase.</i> | | | |
| <i>Note: This value is used when any other alternate configuration is not active.</i> | | | |

⬅ back to List of setpoints

Nominal Current 1

| | | | |
|--|-----------------|-----------------------------|----------|
| Setpoint group | Basic settings | Related FW | 1.6.0 |
| Range [units] | 1 .. 10 000 [A] | | |
| Default value | 350 A | Alternative config | YES |
| Step | 1 A | | |
| Comm object | 12049 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |
| Description | | | |
| It is current limit for generator current protections and means maximal continuous generator current. Nominal Current can be different from generator rated current value. | | | |
| <i>Note: This value is used when any other alternate configuration is not active.</i> | | | |

🔍 back to List of setpoints

Connection Type 1

| | | | |
|----------------------------|---|-----------------------------|----------|
| Setpoint group | Basic settings | Related FW | 1.6.0 |
| Range [units] | Mono Phase / SplPh / 3Ph3Wire / 3Ph4Wire / High Leg D / Autodetect [-] | | |
| Default value | 3Ph4Wire | Alternative config | YES |
| Step | [-] | | |
| Comm object | 12058 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |
| Description | | | |
| Connection type: | | | |
| Mono Phase | Single phase voltage measurement L1-N 1x CT (Current Transformer) | | |
| SplitPhase | Double Delta connection Split Phase Two phase voltage measurement L1,L2 with 180° phase shift 2x CT (Current Transformer) | | |
| 3Ph4Wire | Grounded Star (Grounded Wye) connection – 3PY Three phase voltage measurement L1,L2,L3 with 120° phase shift 3x CT (Current Transformer) | | |
| 3Ph3Wire | Ungrounded Delta connection Open Delta Ungrounded Wye Corner-Grounded Delta Split Phase Delta Three phase voltage measurement L1,L2,L3 with 120° phase shift | | |

| | | |
|------------------------------------|--|---|
| | No neutral is available 3x CT (Current Transformer) | |
| High Leg D | High Leg Delta connection Three phase voltage measurement L1,L2,L3 3x CT (Current Transformer) | |
| Autodetect | High Leg Delta | L1 >=100V; L1 <=140V L2 >=140V L3 >=100V; L3 <=140V |
| | or | |
| | 3PH3Wire or 3Ph4Wire | L1 >=100V L2 >=100V L3 >=100V |
| | or | |
| | SpIPhL1L2 | L1 >=100V L2 >=100V L3 <= 20V |
| | or | |
| | SpIPhL1L3 | L1 >=100V L2 <= 20V L3 >=100V |
| | or | |
| | Mono Phase | L1 >=100V L2 <= 20V L3 <= 20V |
| | or | |
| Voltage Autodetect shutdown | | |

Note: This value is used when binary input CONFIGURATION 2 (PAGE 317) is active.

[back to List of setpoints](#)

Nominal RPM 2

| | | | |
|---|-------------------|-----------------------------|----------|
| Setpoint group | Basic settings | Related FW | 1.6.0 |
| Range [units] | 100 .. 4000 [RPM] | | |
| Default value | 1 500 RPM | Alternative config | YES |
| Step | 1 RPM | | |
| Comm object | 9916 | Related applications | AMF, MRS |
| Config level | Advanced | | |
| Setpoint visibility | Always | | |
| Description | | | |
| Nominal engine speed (RPM – revolutions per minute). | | | |
| Note: This value is used when binary input CONFIGURATION 2 (PAGE 317) is active. | | | |

[back to List of setpoints](#)

Nominal Frequency 2

| | | | |
|---|----------------|-----------------------------|----------|
| Setpoint group | Basic settings | Related FW | 1.6.0 |
| Range [units] | 45 .. 65 [Hz] | | |
| Default value | 50 Hz | Alternative config | YES |
| Step | 1 Hz | | |
| Comm object | 9914 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |
| Description | | | |
| Nominal system frequency (usually 50 or 60 Hz). | | | |
| <i>Note: This value is used when binary input CONFIGURATION 2 (PAGE 317) is active.</i> | | | |

⬅ back to List of setpoints

Nominal Voltage Ph-N 2

| | | | |
|---|---|-----------------------------|----------|
| Setpoint group | Basic settings | Related FW | 1.6.0 |
| Range [units] | 80 .. 20000 [V] | | |
| Default value | 231 V | Alternative config | YES |
| Step | 1 V | | |
| Comm object | 12053 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Conditioned by the setpoint Connection type 2 (page 263). | | |
| Description | | | |
| Nominal system voltage (phase to neutral). | | | |
| <i>Note: This value is used when binary input CONFIGURATION 2 (PAGE 317) is active.</i> | | | |

⬅ back to List of setpoints

Nominal Voltage Ph-Ph 2

| | | | |
|---|---|-----------------------------|----------|
| Setpoint group | Basic settings | Related FW | 1.6.0 |
| Range [units] | 80 .. 40000 [V] | | |
| Default value | 400 V | Alternative config | YES |
| Step | 1 V | | |
| Comm object | 12056 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Conditioned by the setpoint Connection type 2 (page 263). | | |
| Description | | | |
| Nominal system voltage (phase to phase). | | | |
| <i>Note: This value is used when binary input CONFIGURATION 2 (PAGE 317) is active.</i> | | | |

⬅ back to List of setpoints

Nominal Power 2

| | | | |
|--|-----------------|-----------------------------|----------|
| Setpoint group | Basic settings | Related FW | 1.6.0 |
| Range [units] | 1 .. 5 000 [kW] | | |
| Default value | 200 kW | Alternative config | YES |
| Step | 1 kW | | |
| Comm object | 12047 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |
| Description | | | |
| Nominal power of the Gen-set. Generator Overload BOC (page 207) protection is based on this setpoint. | | | |
| <i>Note: This setpoint is used when setpoint Connection type 2 (page 263) is adjusted to Monophase or Splitphase or 3Ph3Wire or High Leg D or 3Ph4Wire or when Autodetect detects connection type as 3Ph3Wire or High Leg D or 3Ph4Wire.</i> | | | |
| <i>Note: This value is used when binary input CONFIGURATION 2 (PAGE 317) is active.</i> | | | |
| <i>Note: This value can be also switch into one decimal power format (via InteliConfig PC tool). In this case the range of value is decrease 10 times.</i> | | | |

[back to List of setpoints](#)

Nominal Power Split Phase 2

| | | | |
|--|---|-----------------------------|----------|
| Setpoint group | Basic settings | Related FW | 1.6.0 |
| Range [units] | 1 .. 5 000 [kW] | | |
| Default value | 200 kW | Alternative config | YES |
| Step | 1 kW | | |
| Comm object | 15772 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Conditioned by the setpoint Connection type 2 (page 263) | | |
| Description | | | |
| Nominal power of the Gen-set for detected split-phase or mono phase connection. Generator Overload BOC (page 207) protection is based on this setpoint. | | | |
| <i>Note: This setpoint is used when setpoint Connection type 2 (page 263) is adjusted to Autodetect and Autodetect detects connection type as Monophase or Splitphase.</i> | | | |
| <i>Note: This value is used when binary input CONFIGURATION 2 (PAGE 317) is active.</i> | | | |

[back to List of setpoints](#)

Nominal Current 2

| | | | |
|--|----------------|-----------------------------|----------|
| Setpoint group | Basic settings | Related FW | 1.6.0 |
| Range [units] | 1 .. 10000 [A] | | |
| Default value | 350 A | Alternative config | YES |
| Step | 1 A | | |
| Comm object | 12050 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |
| Description | | | |
| It is current limit for generator current protections and means maximal continuous generator current. Nominal Current can be different from generator rated current value. | | | |
| <i>Note: This value is used when binary input CONFIGURATION 2 (PAGE 317) is active.</i> | | | |

🔍 back to List of setpoints

Connection type 2

| | | | |
|----------------------------|---|-----------------------------|----------|
| Setpoint group | Basic settings | Related FW | 1.6.0 |
| Range [units] | Mono Phase / SplPh / 3Ph3Wire / 3Ph4Wire / High Leg D / Autodetect [-] | | |
| Default value | 3Ph4Wire | Alternative config | YES |
| Step | [-] | | |
| Comm object | 12059 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |
| Description | | | |
| Connection type: | | | |
| Mono Phase | Single phase voltage measurement L1-N 1x CT (Current Transformer) | | |
| SplitPhase | Double Delta connection Split Phase Two phase voltage measurement L1,L2 with 180° phase shift 2x CT (Current Transformer) | | |
| 3Ph4Wire | Grounded Star (Grounded Wye) connection – 3PY Three phase voltage measurement L1,L2,L3 with 120° phase shift 3x CT (Current Transformer) | | |
| 3Ph3Wire | Ungrounded Delta connection Open Delta Ungrounded Wye Corner-Grounded Delta Split Phase Delta Three phase voltage measurement L1,L2,L3 with 120° phase shift | | |

| | | |
|---|--|---|
| | No neutral is available 3x CT (Current Transformer) | |
| High Leg D | High Leg Delta connection Three phase voltage measurement L1,L2,L3 3x CT (Current Transformer) | |
| Autodetect | High Leg Delta or | L1 >=100V; L1 <=140V L2 >=140V L3 >=100V; L3 <=140V |
| | 3PH3Wire or 3Ph4Wire or | L1 >=100V L2 >=100V L3 >=100V |
| | SpIPhL1L2 or | L1 >=100V L2 >=100V L3 <= 20V |
| | SpIPhL1L3 or | L1 >=100V L2 <= 20V L3 >=100V |
| | Mono Phase or | L1 >=100V L2 <= 20V L3 <= 20V |
| | Voltage Autodetect shutdown | |
| Note: This value is used when binary input CONFIGURATION 2 (PAGE 317) is active. | | |

⬅ back to List of setpoints

Nominal RPM 3

| | | | |
|---|--------------------|-----------------------------|----------|
| Setpoint group | Basic settings | Related FW | 1.6.0 |
| Range [units] | 100 .. 4 000 [RPM] | | |
| Default value | 1 500 RPM | Alternative config | YES |
| Step | 1 RPM | | |
| Comm object | 15196 | Related applications | AMF, MRS |
| Config level | Advanced | | |
| Setpoint visibility | Always | | |
| Description | | | |
| Nominal engine speed (RPM – revolutions per minute). | | | |
| Note: This value is used when binary input CONFIGURATION 3 (PAGE 317) is active. | | | |

⬅ back to List of setpoints

Nominal Frequency 3

| | | | |
|---|----------------|-----------------------------|----------|
| Setpoint group | Basic settings | Related FW | 1.6.0 |
| Range [units] | 45 .. 65 [Hz] | | |
| Default value | 50 Hz | Alternative config | YES |
| Step | 1 Hz | | |
| Comm object | 15197 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |
| Description | | | |
| Nominal system frequency (usually 50 or 60 Hz). | | | |
| <i>Note: This value is used when binary input CONFIGURATION 3 (PAGE 317) is active.</i> | | | |

⬅ back to List of setpoints

Nominal Voltage Ph-N 3

| | | | |
|---|---|-----------------------------|----------|
| Setpoint group | Basic settings | Related FW | 1.6.0 |
| Range [units] | 80 .. 20 000 [V] | | |
| Default value | 231 V | Alternative config | YES |
| Step | 1 V | | |
| Comm object | 12054 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Conditioned by the setpoint Connection type 3 (page 267). | | |
| Description | | | |
| Nominal system voltage (phase to neutral). | | | |
| <i>Note: This value is used when binary input CONFIGURATION 3 (PAGE 317) is active.</i> | | | |

⬅ back to List of setpoints

Nominal Voltage Ph-Ph 3

| | | | |
|---|---|-----------------------------|----------|
| Setpoint group | Basic settings | Related FW | 1.6.0 |
| Range [units] | 80 .. 40 000 [V] | | |
| Default value | 400 V | Alternative config | YES |
| Step | 1 V | | |
| Comm object | 12057 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Conditioned by the setpoint Connection type 3 (page 267). | | |
| Description | | | |
| Nominal system voltage (phase to phase). | | | |
| <i>Note: This value is used when binary input CONFIGURATION 3 (PAGE 317) is active.</i> | | | |

⬅ back to List of setpoints

Nominal Power 3

| | | | |
|--|-----------------|-----------------------------|----------|
| Setpoint group | Basic settings | Related FW | 1.6.0 |
| Range [units] | 1 .. 5 000 [kW] | | |
| Default value | 200 kW | Alternative config | YES |
| Step | 1 kW | | |
| Comm object | 12048 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |
| Description | | | |
| Nominal power of the Gen-set. Generator Overload BOC (page 207) protection is based on this setpoint. | | | |
| <i>Note: This setpoint is used when setpoint Connection type 3 (page 267) is adjusted to Monophase or Splitphase or 3Ph3Wire or High Leg D or 3Ph4Wire or when Autodetect detects connection type as 3Ph3Wire or High Leg D or 3Ph4Wire.</i> | | | |
| <i>Note: This value is used when binary input CONFIGURATION 3 (PAGE 317) is active.</i> | | | |
| <i>Note: This value can be also switch into one decimal power format (via InteliConfig PC tool). In this case the range of value is decrease 10 times.</i> | | | |

⬅ back to List of setpoints

Nominal Power Split Phase 3

| | | | |
|--|---|-----------------------------|----------|
| Setpoint group | Basic settings | Related FW | 1.6.0 |
| Range [units] | 1 .. 5 000 [kW] | | |
| Default value | 200 kW | Alternative config | YES |
| Step | 1 kW | | |
| Comm object | 15773 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Conditioned by the setpoint Connection type 3 (page 267) | | |
| Description | | | |
| Nominal power of the Gen-set for detected split-phase or mono phase connection. Generator Overload BOC (page 207) protection is based on this setpoint. | | | |
| <i>Note: This setpoint is used when setpoint Connection type 3 (page 267) is adjusted to Autodetect and Autodetect detects connection type as Monophase or Splitphase.</i> | | | |
| <i>Note: This value is used when binary input CONFIGURATION 3 (PAGE 317) is active.</i> | | | |

⬅ back to List of setpoints

Nominal Power 3

| | | | |
|---|-----------------|-----------------------------|----------|
| Setpoint group | Basic settings | Related FW | 1.6.0 |
| Range [units] | 1 .. 5 000 [kW] | | |
| Default value | 200 kW | Alternative config | YES |
| Step | 1 kW | | |
| Comm object | 12048 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |
| Description | | | |
| Nominal power of the Gen-set. Generator Overload BOC (page 207) protection is based on this setpoint. | | | |
| <i>Note: This setpoint is used when setpoint Connection type 3 (page 267) is adjusted to Monophase or Splitphase or 3Ph3Wire or High Leg D or 3Ph4Wire or when Autodetect detects connection type as 3Ph3Wire or High Leg D or 3Ph4Wire.</i> | | | |
| <i>Note: This value is used when binary input CONFIGURATION 3 (PAGE 317) is active.</i> | | | |
| <i>Note: This value can be also switch into one decimal power format (via InteliConfig PC tool). In this case the range of value is decrease 10 times.</i> | | | |

⬅ back to List of setpoints

Nominal Current 3

| | | | |
|--|-----------------|-----------------------------|----------|
| Setpoint group | Basic settings | Related FW | 1.6.0 |
| Range [units] | 1 .. 10 000 [A] | | |
| Default value | 350 A | Alternative config | YES |
| Step | 1 A | | |
| Comm object | 12051 | Related applications | AMF, MRS |
| Config level | Standard | | |
| Setpoint visibility | Always | | |
| Description | | | |
| It is current limit for generator current protections and means maximal continuous generator current. Nominal Current can be different from generator rated current value. | | | |
| <i>Note: This value is used when binary input CONFIGURATION 3 (PAGE 317) is active.</i> | | | |

⬅ back to List of setpoints

Connection type 3

| | | | |
|-----------------------|--|-----------------------------|----------|
| Setpoint group | Basic settings | Related FW | 1.6.0 |
| Range [units] | Mono Phase / SplPh / 3Ph3Wire / 3Ph4Wire / High Leg D / Autodetect [-] | | |
| Default value | 3Ph4Wire | Alternative config | YES |
| Step | [-] | | |
| Comm object | 12060 | Related applications | AMF, MRS |
| Config level | Standard | | |

| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|----------------------------|--|----------------|----------------------|--|-----------|----|----------------------|----------------------|-----------|--|-----------|----|-----------|-----------|-----------|--|-----------|----|-----------|-----------|-----------|--|-----------|----|-----------|------------|-----------|--|-----------|----|-----------|
| Setpoint visibility | Always | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Description | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Connection type: | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Mono Phase | Single phase voltage measurement L1-N 1x CT (Current Transformer) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SplitPhase | Double Delta connection Split Phase Two phase voltage measurement L1,L2 with 180° phase shift 2x CT (Current Transformer) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3Ph4Wire | Grounded Star (Grounded Wye) connection – 3PY Three phase voltage measurement L1,L2,L3 with 120° phase shift 3x CT (Current Transformer) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3Ph3Wire | Ungrounded Delta connection Open Delta Ungrounded Wye Corner-Grounded Delta Split Phase Delta Three phase voltage measurement L1,L2,L3 with 120° phase shift No neutral is available 3x CT (Current Transformer) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| High Leg D | High Leg Delta connection Three phase voltage measurement L1,L2,L3 3x CT (Current Transformer) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Autodetect | <table border="0"> <tr> <td>High Leg Delta</td> <td>L1 >=100V; L1 <=140V</td> </tr> <tr> <td></td> <td>L2 >=140V</td> </tr> <tr> <td>or</td> <td>L3 >=100V; L3 <=140V</td> </tr> <tr> <td>3PH3Wire or 3Ph4Wire</td> <td>L1 >=100V</td> </tr> <tr> <td></td> <td>L2 >=100V</td> </tr> <tr> <td>or</td> <td>L3 >=100V</td> </tr> <tr> <td>SpIPhL1L2</td> <td>L1 >=100V</td> </tr> <tr> <td></td> <td>L2 >=100V</td> </tr> <tr> <td>or</td> <td>L3 <= 20V</td> </tr> <tr> <td>SpIPhL1L3</td> <td>L1 >=100V</td> </tr> <tr> <td></td> <td>L2 <= 20V</td> </tr> <tr> <td>or</td> <td>L3 >=100V</td> </tr> <tr> <td>Mono Phase</td> <td>L1 >=100V</td> </tr> <tr> <td></td> <td>L2 <= 20V</td> </tr> <tr> <td>or</td> <td>L3 <= 20V</td> </tr> </table> | High Leg Delta | L1 >=100V; L1 <=140V | | L2 >=140V | or | L3 >=100V; L3 <=140V | 3PH3Wire or 3Ph4Wire | L1 >=100V | | L2 >=100V | or | L3 >=100V | SpIPhL1L2 | L1 >=100V | | L2 >=100V | or | L3 <= 20V | SpIPhL1L3 | L1 >=100V | | L2 <= 20V | or | L3 >=100V | Mono Phase | L1 >=100V | | L2 <= 20V | or | L3 <= 20V |
| High Leg Delta | L1 >=100V; L1 <=140V | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | L2 >=140V | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| or | L3 >=100V; L3 <=140V | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3PH3Wire or 3Ph4Wire | L1 >=100V | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | L2 >=100V | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| or | L3 >=100V | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SpIPhL1L2 | L1 >=100V | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | L2 >=100V | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| or | L3 <= 20V | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SpIPhL1L3 | L1 >=100V | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | L2 <= 20V | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| or | L3 >=100V | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Mono Phase | L1 >=100V | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | L2 <= 20V | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| or | L3 <= 20V | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

Voltage Autodetect shutdown

Note: This value is used when binary input **CONFIGURATION 3 (PAGE 317)** is active.

▲ back to List of setpoints

Subgroup: Engine settings

ECU Speed Adjustment 1

| | | | |
|---|-----------------------------------|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | 0 .. 100 [%] | | |
| Default value | 50 % | Alternative config | NO |
| Step | 1 % | | |
| Comm object | 14337 | Related applications | AMF, MRS |
| Config level | Advanced | | |
| Setpoint visibility | Visible only if ECU is configured | | |
| Description | | | |
| Enables to adjust engine speed in ECU via CAN bus. Nominal speed corresponds to 50%. This setpoint should be used only for Volvo Penta and Scania engines. It has no effect on other engine brands. | | | |
| Note: This value is used when any other alternate configuration is not active. | | | |

▲ back to List of setpoints

ECU Speed Adjustment 2

| | | | |
|---|-----------------------------------|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | 0 .. 100 [%] | | |
| Default value | 50 % | Alternative config | NO |
| Step | 1 % | | |
| Comm object | 14338 | Related applications | AMF, MRS |
| Config level | Advanced | | |
| Setpoint visibility | Visible only if ECU is configured | | |
| Description | | | |
| Enables to adjust engine speed in ECU via CAN bus. Nominal speed corresponds to 50%. This setpoint should be used only for Volvo Penta and Scania engines. It has no effect on other engine brands. | | | |
| Note: This value is used when binary input CONFIGURATION 2 (PAGE 317) is active. | | | |

▲ back to List of setpoints

ECU Speed Adjustment 3

| | | | |
|--|-----------------------------------|-----------------------------|----------|
| Setpoint group | Engine settings | Related FW | 1.6.0 |
| Range [units] | 0 .. 100 [%] | | |
| Default value | 50 % | Alternative config | NO |
| Step | 1 % | | |
| Comm object | 15199 | Related applications | AMF, MRS |
| Config level | Advanced | | |
| Setpoint visibility | Visible only if ECU is configured | | |
| Description | | | |
| <p>Enables to adjust engine speed in ECU via CAN bus. Nominal speed corresponds to 50%. This setpoint should be used only for Volvo Penta and Scania engines. It has no effect on other engine brands.</p> <p>Note: This value is used when binary input <i>CONFIGURATION 3</i> (PAGE 317) is active.</p> | | | |

 [back to List of setpoints](#)

8.1.3 Values

What values are:

Values (or quantities) are analog or binary data objects, measured or computed by the controller, that are intended for reading from the controller screen, PC, MODBUS, etc. Values are organized into groups according to their meaning.

For full list of values go to the chapter **List of values (page 272)**.

Invalid flag

If valid data is not available for a particular value, the invalid flag is set to it. This situation may be due to the following:

- The value is not being evaluated in the scope of the current application and configuration.
- Sensor fail has been detected on an analog input.
- The configured ECU or extension module does not provide the particular value.
- The communication with the ECU or extension module is interrupted.

A value containing the invalid flag is displayed as "####" in IntelliConfig and on the controller screen. If such a value is read out via MODBUS, it will contain the data 32768 in the case of signed values and 65535 in the case of unsigned values.

List of values

| | | | | | |
|-------------------------|-----|------------------------|-----|-----------------|-----|
| Group: Engine | 274 | Load Characteristic L3 | 282 | Mains kVArh | 290 |
| DEF Level | 274 | Load kVA | 282 | Mains kWh | 290 |
| DPF Ash Load | 274 | Load kVA L1 | 283 | Maintenance 1 | 290 |
| DPF Soot Load | 274 | Load kVA L2 | 283 | Maintenance 2 | 291 |
| ECU AIN 1 | 274 | Load kVA L3 | 283 | Maintenance 3 | 291 |
| ECU AIN 2 | 275 | Load kVAr | 283 | Num E-Stops | 291 |
| ECU AIN 3 | 275 | Load kVAr L1 | 284 | Num Starts | 291 |
| ECU AIN 4 | 275 | Load kVAr L2 | 284 | Running Hours | 291 |
| ECU AIN 5 | 275 | Load kVAr L3 | 284 | Shutdowns | 292 |
| ECU AIN 6 | 276 | Load kW | 284 | Group: IL Info | 292 |
| ECU AIN 7 | 276 | Load kW L1 | 285 | Application | 292 |
| ECU AIN 8 | 276 | Load kW L2 | 285 | Breaker State | 292 |
| ECU AIN 9 | 276 | Load kW L3 | 285 | Connection Type | 292 |
| ECU-AIN-EXT-1 | 277 | Load Power Factor | 285 | Engine State | 293 |
| ECU Frequency Select | 277 | Load Power Factor L1 | 286 | FW Branch | 293 |
| ECU State | 277 | Load Power Factor L2 | 286 | FW Version | 293 |
| RPM | 278 | Load Power Factor L3 | 286 | ID String | 293 |
| Speed Request | 278 | Group: Mains | 286 | SPI Module A | 293 |
| Speed Required RPM | 278 | Mains Frequency | 286 | Timer Text | 294 |
| Group: Generator | 279 | Mains Voltage L1-L2 | 286 | Timer Value | 294 |
| Generator Frequency | 279 | Mains Voltage L1-N | 287 | Group: Log Bout | 294 |
| Generator Voltage L1-L2 | 279 | Mains Voltage L2-L3 | 287 | Log Bout 1 | 294 |
| Generator Voltage L1-N | 279 | Mains Voltage L2-N | 287 | Log Bout 2 | 294 |
| Generator Voltage L2-L3 | 279 | Mains Voltage L3-L1 | 287 | Log Bout 3 | 295 |
| Generator Voltage L2-N | 279 | Mains Voltage L3-N | 287 | Log Bout 4 | 295 |
| Generator Voltage L3-L1 | 280 | Group: Controller I/O | 288 | Log Bout 5 | 295 |
| Generator Voltage L3-N | 280 | Analog Input 1 | 288 | Log Bout 6 | 295 |
| Nominal Current | 280 | Analog Input 2 | 288 | Log Bout 7 | 295 |
| Nominal Power | 280 | Analog Input 3 | 288 | Log Bout 8 | 296 |
| Nominal Voltage | 280 | Battery Volts | 288 | Log Bout 9 | 296 |
| Group: Load | 281 | Binary Inputs | 288 | Log Bout 10 | 296 |
| Load A L1 | 281 | Binary Outputs | 289 | Log Bout 11 | 296 |
| Load A L2 | 281 | D+ | 289 | Group: CM-GPRS | 297 |
| Load A L3 | 281 | E-Stop | 289 | Connection Type | 297 |
| Load Characteristic | 281 | Group: Statistics | 289 | Cell Error Rate | 297 |
| Load Characteristic L1 | 282 | Genset kWh | 289 | Cell Diag Codes | 298 |
| Load Characteristic L2 | 282 | Genset kWh | 290 | Cell Signal Lev | 299 |

| | |
|----------------------------|-----|
| Cell Status | 299 |
| Operator | 300 |
| Group: CM-4G-GPS | 300 |
| Connection Type | 300 |
| Cell Diag Codes | 301 |
| Cell Error Rate | 302 |
| Cell Signal Lev | 302 |
| Cell Status | 303 |
| Operator | 303 |
| Group: CM-Ethernet | 303 |
| Current DNS | 303 |
| ETH Interface Status | 303 |
| Current Gateway | 304 |
| Current IP Address | 304 |
| Last Email Results | 305 |
| MAC Address | 305 |
| Current Subnet Mask | 306 |
| Group: Date/Time | 306 |
| Time | 306 |
| Date | 306 |
| Group: Plug-In I/O | 306 |
| EM BIO A | 306 |

**⬅ back to Controller
objects**

Group: Engine

DEF Level

| | | | |
|---|--------|-----------------------------|----------|
| Value group | Engine | Related FW | 1.6.0 |
| Units | % | | |
| Comm object | 14522 | Related applications | AMF, MRS |
| Description | | | |
| The level of diesel exhaust fluid tank. | | | |

🔍 back to List of values

DPF Ash Load

| | | | |
|---|--------|-----------------------------|----------|
| Value group | Engine | Related FW | 1.6.0 |
| Units | % | | |
| Comm object | 12483 | Related applications | AMF, MRS |
| Description | | | |
| Indicates the ash load percentage of diesel particulate filter (DPF). | | | |

🔍 back to List of values

DPF Soot Load

| | | | |
|--|--------|-----------------------------|----------|
| Value group | Engine | Related FW | 1.6.0 |
| Units | % | | |
| Comm object | 12484 | Related applications | AMF, MRS |
| Description | | | |
| Indicates the soot load percentage of diesel particulate filter (DPF). | | | |

🔍 back to List of values

ECU AIN 1

| | | | |
|--|----------------------|-----------------------------|----------|
| Value group | Engine | Related FW | 1.6.0 |
| Units | Depends on ECU value | | |
| Comm object | 10153 | Related applications | AMF, MRS |
| Description | | | |
| This is one of the inputs, which are defined by ECU. Order of values depends on type of ECU. | | | |
| <i>Note: Usually there are engine speed [RPM], fuel rate [L/h], coolant temperature [°C], intake temperature [°C], oil pressure [bar], boost pressure [bar], load [%], oil temperature [°C] etc.</i> | | | |

🔍 back to List of values

ECU AIN 2

| | | | |
|--|----------------------|-----------------------------|----------|
| Value group | Engine | Related FW | 1.6.0 |
| Units | Depends on ECU value | | |
| Comm object | 10154 | Related applications | AMF, MRS |
| Description | | | |
| This is one of the inputs, which are defined by ECU. Order of values depends on type of ECU. <i>Note: Usually there are engine speed [RPM], fuel rate [L/h], coolant temperature [°C], intake temperature [°C], oil pressure [bar], boost pressure [bar], load [%], oil temperature [°C] etc.</i> | | | |

🔍 back to List of values

ECU AIN 3

| | | | |
|--|----------------------|-----------------------------|----------|
| Value group | Engine | Related FW | 1.6.0 |
| Units | Depends on ECU value | | |
| Comm object | 10155 | Related applications | AMF, MRS |
| Description | | | |
| This is one of the inputs, which are defined by ECU. Order of values depends on type of ECU. <i>Note: Usually there are engine speed [RPM], fuel rate [L/h], coolant temperature [°C], intake temperature [°C], oil pressure [bar], boost pressure [bar], load [%], oil temperature [°C] etc.</i> | | | |

🔍 back to List of values

ECU AIN 4

| | | | |
|--|----------------------|-----------------------------|----------|
| Value group | Engine | Related FW | 1.6.0 |
| Units | Depends on ECU value | | |
| Comm object | 10156 | Related applications | AMF, MRS |
| Description | | | |
| This is one of the inputs, which are defined by ECU. Order of values depends on type of ECU. <i>Note: Usually there are engine speed [RPM], fuel rate [L/h], coolant temperature [°C], intake temperature [°C], oil pressure [bar], boost pressure [bar], load [%], oil temperature [°C] etc.</i> | | | |

🔍 back to List of values

ECU AIN 5

| | | | |
|--|----------------------|-----------------------------|----------|
| Value group | Engine | Related FW | 1.6.0 |
| Units | Depends on ECU value | | |
| Comm object | 10157 | Related applications | AMF, MRS |
| Description | | | |
| This is one of the inputs, which are defined by ECU. Order of values depends on type of ECU. <i>Note: Usually there are engine speed [RPM], fuel rate [L/h], coolant temperature [°C], intake temperature [°C], oil pressure [bar], boost pressure [bar], load [%], oil temperature [°C] etc.</i> | | | |

🔍 back to List of values

ECU AIN 6

| | | | |
|--|----------------------|-----------------------------|----------|
| Value group | Engine | Related FW | 1.6.0 |
| Units | Depends on ECU value | | |
| Comm object | 10158 | Related applications | AMF, MRS |
| Description | | | |
| This is one of the inputs, which are defined by ECU. Order of values depends on type of ECU. <i>Note: Usually there are engine speed [RPM], fuel rate [L/h], coolant temperature [°C], intake temperature [°C], oil pressure [bar], boost pressure [bar], load [%], oil temperature [°C] etc.</i> | | | |

🔍 back to List of values

ECU AIN 7

| | | | |
|--|----------------------|-----------------------------|----------|
| Value group | Engine | Related FW | 1.6.0 |
| Units | Depends on ECU value | | |
| Comm object | 10159 | Related applications | AMF, MRS |
| Description | | | |
| This is one of the inputs, which are defined by ECU. Order of values depends on type of ECU. <i>Note: Usually there are engine speed [RPM], fuel rate [L/h], coolant temperature [°C], intake temperature [°C], oil pressure [bar], boost pressure [bar], load [%], oil temperature [°C] etc.</i> | | | |

🔍 back to List of values

ECU AIN 8

| | | | |
|--|----------------------|-----------------------------|----------|
| Value group | Engine | Related FW | 1.6.0 |
| Units | Depends on ECU value | | |
| Comm object | 10160 | Related applications | AMF, MRS |
| Description | | | |
| This is one of the inputs, which are defined by ECU. Order of values depends on type of ECU. <i>Note: Usually there are engine speed [RPM], fuel rate [L/h], coolant temperature [°C], intake temperature [°C], oil pressure [bar], boost pressure [bar], load [%], oil temperature [°C] etc.</i> | | | |

🔍 back to List of values

ECU AIN 9

| | | | |
|--|----------------------|-----------------------------|----------|
| Value group | Engine | Related FW | 1.6.0 |
| Units | Depends on ECU value | | |
| Comm object | 10161 | Related applications | AMF, MRS |
| Description | | | |
| This is one of the inputs, which are defined by ECU. Order of values depends on type of ECU. <i>Note: Usually there are engine speed [RPM], fuel rate [L/h], coolant temperature [°C], intake temperature [°C], oil pressure [bar], boost pressure [bar], load [%], oil temperature [°C] etc.</i> | | | |

🔍 back to List of values

ECU-AIN-EXT-1

| | | | |
|--|----------------------|-----------------------------|----------|
| Value group | Engine | Related FW | 1.6.0 |
| Units | Depends on ECU value | | |
| Comm object | 10173 | Related applications | AMF, MRS |
| Description | | | |
| This is one of the inputs, which are defined by ECU. Order of values depends on type of ECU. | | | |
| <i>Note: Usually there are engine speed [RPM], fuel rate [L/h], coolant temperature [°C], intake temperature [°C], oil pressure [bar], boost pressure [bar], load [%], oil temperature [°C] etc.</i> | | | |

🔍 back to List of values

ECU Frequency Select

| | | | |
|---|--------|-----------------------------|----------|
| Value group | Engine | Related FW | 1.6.0 |
| Units | - | | |
| Comm object | 12926 | Related applications | AMF, MRS |
| Description | | | |
| Shows selected frequency of ECU. The value is calculated from setpoint Nominal Frequency (page 168) . | | | |
| <ul style="list-style-type: none">➤ If is Nominal Frequency (page 168) in range from 45 Hz to 54 Hz, is considered as 50 Hz application. The value is set to 0.➤ If is Nominal Frequency (page 168) in range from 55 Hz to 65 Hz, is considered as 60 Hz application. The value is set to 1. | | | |

🔍 back to List of values

ECU State

| | | | |
|--|--------|-----------------------------|----------|
| Value group | Engine | Related FW | 1.6.0 |
| Units | - | | |
| Comm object | 10034 | Related applications | AMF, MRS |
| Description | | | |
| Shows binary status (0 or 1) of ECU: | | | |
| <ul style="list-style-type: none">➤ ECU Yellow Lamp➤ ECU Red Lamp➤ Wait To Start | | | |

🔍 back to List of values

RPM

| | | | |
|---|--------|-----------------------------|----------|
| Value group | Engine | Related FW | 1.6.0 |
| Units | RPM | | |
| Comm object | 10123 | Related applications | AMF, MRS |
| Description | | | |
| This value contains the current engine speed. The value is obtained from one of the following sources: <ul style="list-style-type: none">> ECU, if an ECU is configured> Pickup input> Generator frequency | | | |

⬅ back to List of values

Speed Request

| Value group | Engine | Related FW | 1.6.0 | | | | | | | | | | | | |
|--|-----------------|-----------------------------|-------|---------------|-----------------|----------------------------|----|----------|----|-----|----------|-----|------|----------|------|
| Units | % | | | | | | | | | | | | | | |
| Comm object | 10137 | Related applications | AMF | | | | | | | | | | | | |
| Description | | | | | | | | | | | | | | | |
| This value contains the speed control signal expressed in %. | | | | | | | | | | | | | | | |
| <table border="1"><thead><tr><th>Speed request</th><th>Requested speed</th><th>Accelerator pedal position</th></tr></thead><tbody><tr><td>0%</td><td>1350 RPM</td><td>0%</td></tr><tr><td>50%</td><td>1500 RPM</td><td>50%</td></tr><tr><td>100%</td><td>1650 RPM</td><td>100%</td></tr></tbody></table> | | | | Speed request | Requested speed | Accelerator pedal position | 0% | 1350 RPM | 0% | 50% | 1500 RPM | 50% | 100% | 1650 RPM | 100% |
| Speed request | Requested speed | Accelerator pedal position | | | | | | | | | | | | | |
| 0% | 1350 RPM | 0% | | | | | | | | | | | | | |
| 50% | 1500 RPM | 50% | | | | | | | | | | | | | |
| 100% | 1650 RPM | 100% | | | | | | | | | | | | | |
| Note: Accelerator pedal position will be 0 if the engine is not running or loaded. | | | | | | | | | | | | | | | |

⬅ back to List of values

Speed Required RPM

| | | | |
|---|--------|-----------------------------|----------|
| Value group | Engine | Related FW | 1.6.0 |
| Units | RPM | | |
| Comm object | 10006 | Related applications | AMF, MRS |
| Description | | | |
| This value contains the speed which is currently requested by the controller from the attached ECU. This value is used for digital interfacing (via a communication bus) with ECUs that require the requested speed directly in RPM. | | | |

⬅ back to List of values

Group: Generator

Generator Frequency

| | | | |
|-------------------------|-----------|-----------------------------|----------|
| Value group | Generator | Related FW | 1.6.0 |
| Units | Hz | | |
| Comm object | 8210 | Related applications | AMF, MRS |
| Description | | | |
| Frequency of generator. | | | |

[back to List of values](#)

Generator Voltage L1-L2

| | | | |
|--|-----------|-----------------------------|----------|
| Value group | Generator | Related FW | 1.6.0 |
| Units | V | | |
| Comm object | 9628 | Related applications | AMF, MRS |
| Description | | | |
| Generator phase to phase voltage between L1 and L2 phases. | | | |

[back to List of values](#)

Generator Voltage L1-N

| | | | |
|-------------------------------|-----------|-----------------------------|----------|
| Value group | Generator | Related FW | 1.6.0 |
| Units | V | | |
| Comm object | 8192 | Related applications | AMF, MRS |
| Description | | | |
| Generator voltage on phase 1. | | | |

[back to List of values](#)

Generator Voltage L2-L3

| | | | |
|--|-----------|-----------------------------|----------|
| Value group | Generator | Related FW | 1.6.0 |
| Units | V | | |
| Comm object | 9629 | Related applications | AMF, MRS |
| Description | | | |
| Generator phase to phase voltage between L2 and L3 phases. | | | |

[back to List of values](#)

Generator Voltage L2-N

| | | | |
|-------------------------------|-----------|-----------------------------|----------|
| Value group | Generator | Related FW | 1.6.0 |
| Units | V | | |
| Comm object | 8193 | Related applications | AMF, MRS |
| Description | | | |
| Generator voltage on phase 2. | | | |

[back to List of values](#)

Generator Voltage L3-L1

| | | | |
|--|-----------|-----------------------------|----------|
| Value group | Generator | Related FW | 1.6.0 |
| Units | V | | |
| Comm object | 9630 | Related applications | AMF, MRS |
| Description | | | |
| Generator phase to phase voltage between L3 and L1 phases. | | | |

[back to List of values](#)

Generator Voltage L3-N

| | | | |
|-------------------------------|-----------|-----------------------------|----------|
| Value group | Generator | Related FW | 1.6.0 |
| Units | V | | |
| Comm object | 8194 | Related applications | AMF, MRS |
| Description | | | |
| Generator voltage on phase 3. | | | |

[back to List of values](#)

Nominal Current

| | | | |
|----------------------------|-----------|-----------------------------|----------|
| Value group | Generator | Related FW | 1.6.0 |
| Units | A | | |
| Comm object | 9978 | Related applications | AMF, MRS |
| Description | | | |
| Generator nominal current. | | | |

[back to List of values](#)

Nominal Power

| | | | |
|--------------------------|-----------|-----------------------------|----------|
| Value group | Generator | Related FW | 1.6.0 |
| Units | V | | |
| Comm object | 9018 | Related applications | AMF, MRS |
| Description | | | |
| Generator nominal power. | | | |

[back to List of values](#)

Nominal Voltage

| | | | |
|----------------------------|-----------|-----------------------------|----------|
| Value group | Generator | Related FW | 1.6.0 |
| Units | V | | |
| Comm object | 9917 | Related applications | AMF, MRS |
| Description | | | |
| Generator nominal voltage. | | | |

[back to List of values](#)

Group: Load

Load A L1

| | | | |
|--|------|-----------------------------|----------|
| Value group | Load | Related FW | 1.6.0 |
| Units | A | | |
| Comm object | 8198 | Related applications | AMF, MRS |
| Description | | | |
| Load current phase L1. | | | |
| <i>Note: This value can be also switch into one decimal power format (via InteliConfig PC tool). In this case the range of value is decrease 10 times.</i> | | | |

⬅ back to List of values

Load A L2

| | | | |
|--|------|-----------------------------|----------|
| Value group | Load | Related FW | 1.6.0 |
| Units | A | | |
| Comm object | 8199 | Related applications | AMF, MRS |
| Description | | | |
| Load current phase L2. | | | |
| <i>Note: This value can be also switch into one decimal power format (via InteliConfig PC tool). In this case the range of value is decrease 10 times.</i> | | | |

⬅ back to List of values

Load A L3

| | | | |
|--|------|-----------------------------|----------|
| Value group | Load | Related FW | 1.6.0 |
| Units | A | | |
| Comm object | 8200 | Related applications | AMF, MRS |
| Description | | | |
| Load current phase L3. | | | |
| <i>Note: This value can be also switch into one decimal power format (via InteliConfig PC tool). In this case the range of value is decrease 10 times.</i> | | | |

⬅ back to List of values

Load Characteristic

| | | | |
|--|------|-----------------------------|----------|
| Value group | Load | Related FW | 1.6.0 |
| Units | [-] | | |
| Comm object | 8395 | Related applications | AMF, MRS |
| Description | | | |
| Character of the load. "L" means inductive load, "C" is capacitive and "R" is resistive load (power factor = 1). | | | |

⬅ back to List of values

Load Characteristic L1

| | | | |
|--|------|-----------------------------|----------|
| Value group | Load | Related FW | 1.6.0 |
| Units | [-] | | |
| Comm object | 8626 | Related applications | AMF, MRS |
| Description | | | |
| Character of the generator load in the L1 phase. "L" means inductive load, "C" is capacitive and "R" is resistive load (power factor = 1). | | | |

⬅ back to List of values

Load Characteristic L2

| | | | |
|--|------|-----------------------------|----------|
| Value group | Load | Related FW | 1.6.0 |
| Units | [-] | | |
| Comm object | 8627 | Related applications | AMF, MRS |
| Description | | | |
| Character of the generator load in the L2 phase. "L" means inductive load, "C" is capacitive and "R" is resistive load (power factor = 1). | | | |

⬅ back to List of values

Load Characteristic L3

| | | | |
|--|------|-----------------------------|----------|
| Value group | Load | Related FW | 1.6.0 |
| Units | [-] | | |
| Comm object | 8628 | Related applications | AMF, MRS |
| Description | | | |
| Character of the generator load in the L3 phase. "L" means inductive load, "C" is capacitive and "R" is resistive load (power factor = 1). | | | |

⬅ back to List of values

Load kVA

| | | | |
|---|------|-----------------------------|----------|
| Value group | Load | Related FW | 1.6.0 |
| Units | kVA | | |
| Comm object | 8565 | Related applications | AMF, MRS |
| Description | | | |
| Load apparent power. | | | |
| <i>Note: This value can be also switch into one decimal power format (via IntelConfig PC tool). In this case the range of value is decrease 10 times.</i> | | | |

⬅ back to List of values

Load kVA L1

| | | | |
|--|------|----------------------|----------|
| Value group | Load | Related FW | 1.6.0 |
| Units | kVA | | |
| Comm object | 8530 | Related applications | AMF, MRS |
| Description | | | |
| Load apparent power L1. | | | |
| <i>Note: This value can be also switch into one decimal power format (via InteliConfig PC tool). In this case the range of value is decrease 10 times.</i> | | | |

⬅ back to List of values

Load kVA L2

| | | | |
|--|------|----------------------|----------|
| Value group | Load | Related FW | 1.6.0 |
| Units | kVA | | |
| Comm object | 8531 | Related applications | AMF, MRS |
| Description | | | |
| Load apparent power L2. | | | |
| <i>Note: This value can be also switch into one decimal power format (via InteliConfig PC tool). In this case the range of value is decrease 10 times.</i> | | | |

⬅ back to List of values

Load kVA L3

| | | | |
|--|------|----------------------|----------|
| Value group | Load | Related FW | 1.6.0 |
| Units | kVA | | |
| Comm object | 8532 | Related applications | AMF, MRS |
| Description | | | |
| Load apparent power L3. | | | |
| <i>Note: This value can be also switch into one decimal power format (via InteliConfig PC tool). In this case the range of value is decrease 10 times.</i> | | | |

⬅ back to List of values

Load kVAr

| | | | |
|--|------|----------------------|----------|
| Value group | Load | Related FW | 1.6.0 |
| Units | kVAr | | |
| Comm object | 8203 | Related applications | AMF, MRS |
| Description | | | |
| Load reactive power. | | | |
| <i>Note: This value can be also switch into one decimal power format (via InteliConfig PC tool). In this case the range of value is decrease 10 times.</i> | | | |

⬅ back to List of values

Load kVAr L1

| | | | |
|--|------|-----------------------------|----------|
| Value group | Load | Related FW | 1.6.0 |
| Units | kVAr | | |
| Comm object | 8527 | Related applications | AMF, MRS |
| Description | | | |
| Load reactive power in phase L1. | | | |
| <i>Note: This value can be also switch into one decimal power format (via InteliConfig PC tool). In this case the range of value is decrease 10 times.</i> | | | |

[back to List of values](#)

Load kVAr L2

| | | | |
|--|------|-----------------------------|----------|
| Value group | Load | Related FW | 1.6.0 |
| Units | kVAr | | |
| Comm object | 8528 | Related applications | AMF, MRS |
| Description | | | |
| Load reactive power in phase L2. | | | |
| <i>Note: This value can be also switch into one decimal power format (via InteliConfig PC tool). In this case the range of value is decrease 10 times.</i> | | | |

[back to List of values](#)

Load kVAr L3

| | | | |
|--|------|-----------------------------|----------|
| Value group | Load | Related FW | 1.6.0 |
| Units | kVAr | | |
| Comm object | 8529 | Related applications | AMF, MRS |
| Description | | | |
| Load reactive power in phase L3. | | | |
| <i>Note: This value can be also switch into one decimal power format (via InteliConfig PC tool). In this case the range of value is decrease 10 times.</i> | | | |

[back to List of values](#)

Load kW

| | | | |
|--|------|-----------------------------|----------|
| Value group | Load | Related FW | 1.6.0 |
| Units | kW | | |
| Comm object | 8202 | Related applications | AMF, MRS |
| Description | | | |
| Load active power. | | | |
| <i>Note: This value can be also switch into one decimal power format (via InteliConfig PC tool). In this case the range of value is decrease 10 times.</i> | | | |

[back to List of values](#)

Load kW L1

| | | | |
|--|------|-----------------------------|----------|
| Value group | Load | Related FW | 1.6.0 |
| Units | kW | | |
| Comm object | 8524 | Related applications | AMF, MRS |
| Description | | | |
| Load active power in phase L1. | | | |
| <i>Note: This value can be also switch into one decimal power format (via InteliConfig PC tool). In this case the range of value is decrease 10 times.</i> | | | |

⬅ back to List of values

Load kW L2

| | | | |
|--|------|-----------------------------|----------|
| Value group | Load | Related FW | 1.6.0 |
| Units | kW | | |
| Comm object | 8525 | Related applications | AMF, MRS |
| Description | | | |
| Load active power in phase L2. | | | |
| <i>Note: This value can be also switch into one decimal power format (via InteliConfig PC tool). In this case the range of value is decrease 10 times.</i> | | | |

⬅ back to List of values

Load kW L3

| | | | |
|--|------|-----------------------------|----------|
| Value group | Load | Related FW | 1.6.0 |
| Units | kW | | |
| Comm object | 8526 | Related applications | AMF, MRS |
| Description | | | |
| Load active power in phase L3. | | | |
| <i>Note: This value can be also switch into one decimal power format (via InteliConfig PC tool). In this case the range of value is decrease 10 times.</i> | | | |

⬅ back to List of values

Load Power Factor

| | | | |
|-------------------------|------|-----------------------------|----------|
| Load | Load | Related FW | 1.6.0 |
| Units | [-] | | |
| Comm object | 8204 | Related applications | AMF, MRS |
| Description | | | |
| Generator power factor. | | | |

⬅ back to List of values

Load Power Factor L1

| | | | |
|-------------------------------------|------|-----------------------------|----------|
| Load | Load | Related FW | 1.6.0 |
| Units | [-] | | |
| Comm object | 8533 | Related applications | AMF, MRS |
| Description | | | |
| Generator power factor in phase L1. | | | |

[back to List of values](#)

Load Power Factor L2

| | | | |
|-------------------------------------|------|-----------------------------|----------|
| Load | Load | Related FW | 1.6.0 |
| Units | [-] | | |
| Comm object | 8534 | Related applications | AMF, MRS |
| Description | | | |
| Generator power factor in phase L2. | | | |

[back to List of values](#)

Load Power Factor L3

| | | | |
|-------------------------------------|------|-----------------------------|----------|
| Load | Load | Related FW | 1.6.0 |
| Units | [-] | | |
| Comm object | 8535 | Related applications | AMF, MRS |
| Description | | | |
| Generator power factor in phase L3. | | | |

[back to List of values](#)

Group: Mains

Mains Frequency

| | | | |
|---------------------|-------|-----------------------------|-------|
| Value group | Mains | Related FW | 1.6.0 |
| Units | Hz | | |
| Comm object | 8211 | Related applications | AMF |
| Description | | | |
| Frequency of Mains. | | | |

[back to List of values](#)

Mains Voltage L1-L2

| | | | |
|--|-------|-----------------------------|-------|
| Value group | Mains | Related FW | 1.6.0 |
| Units | V | | |
| Comm object | 9631 | Related applications | AMF |
| Description | | | |
| Mains phase to phase voltage between L1 and L2 phases. | | | |

[back to List of values](#)

Mains Voltage L1-N

| | | | |
|---------------------------|-------|-----------------------------|-------|
| Value group | Mains | Related FW | 1.6.0 |
| Units | V | | |
| Comm object | 8195 | Related applications | AMF |
| Description | | | |
| Mains voltage on phase 1. | | | |

[back to List of values](#)

Mains Voltage L2-L3

| | | | |
|--|-------|-----------------------------|-------|
| Value group | Mains | Related FW | 1.6.0 |
| Units | V | | |
| Comm object | 9632 | Related applications | AMF |
| Description | | | |
| Mains phase to phase voltage between L2 and L3 phases. | | | |

[back to List of values](#)

Mains Voltage L2-N

| | | | |
|---------------------------|-------|-----------------------------|-------|
| Value group | Mains | Related FW | 1.6.0 |
| Units | V | | |
| Comm object | 8196 | Related applications | AMF |
| Description | | | |
| Mains voltage on phase 2. | | | |

[back to List of values](#)

Mains Voltage L3-L1

| | | | |
|--|-------|-----------------------------|-------|
| Value group | Mains | Related FW | 1.6.0 |
| Units | V | | |
| Comm object | 9633 | Related applications | AMF |
| Description | | | |
| Mains phase to phase voltage between L3 and L1 phases. | | | |

[back to List of values](#)

Mains Voltage L3-N

| | | | |
|---------------------------|-------|-----------------------------|-------|
| Value group | Mains | Related FW | 1.6.0 |
| Units | V | | |
| Comm object | 8197 | Related applications | AMF |
| Description | | | |
| Mains voltage on phase 3. | | | |

[back to List of values](#)

Group: Controller I/O

Analog Input 1

| | | | |
|--|----------------|-----------------------------|----------|
| Value group | Controller I/O | Related FW | 1.6.0 |
| Units | Configurable | | |
| Comm object | 9151 | Related applications | AMF, MRS |
| Description | | | |
| This is the value of the analog input 1 of the controller. | | | |

[back to List of values](#)

Analog Input 2

| | | | |
|--|----------------|-----------------------------|----------|
| Value group | Controller I/O | Related FW | 1.6.0 |
| Units | Configurable | | |
| Comm object | 9152 | Related applications | AMF, MRS |
| Description | | | |
| This is the value of the analog input 2 of the controller. | | | |

[back to List of values](#)

Analog Input 3

| | | | |
|--|----------------|-----------------------------|----------|
| Value group | Controller I/O | Related FW | 1.6.0 |
| Units | Configurable | | |
| Comm object | 9153 | Related applications | AMF, MRS |
| Description | | | |
| This is the value of the analog input 3 of the controller. | | | |

[back to List of values](#)

Battery Volts

| | | | |
|----------------------------|----------------|-----------------------------|----------|
| Value group | Controller I/O | Related FW | 1.6.0 |
| Units | V | | |
| Comm object | 8213 | Related applications | AMF, MRS |
| Description | | | |
| Controller supply voltage. | | | |

[back to List of values](#)

Binary Inputs

| | | | |
|---|----------------|-----------------------------|----------|
| Value group | Controller I/O | Related FW | 1.6.0 |
| Units | [-] | | |
| Comm object | 8235 | Related applications | AMF, MRS |
| Description | | | |
| State of the binary inputs of the controller. | | | |

[back to List of values](#)

Binary Outputs

| | | | |
|--|---------------|-----------------------------|----------|
| Value group | Controler I/O | Related FW | 1.6.0 |
| Units | [-] | | |
| Comm object | 8239 | Related applications | AMF, MRS |
| Description | | | |
| State of the binary outputs of the controller. | | | |

🔍 back to List of values

D+

| | | | |
|----------------------|---------------|-----------------------------|----------|
| Value group | Controler I/O | Related FW | 1.6.0 |
| Units | V | | |
| Comm object | 10603 | Related applications | AMF, MRS |
| Description | | | |
| D+ terminal voltage. | | | |

🔍 back to List of values

E-Stop

| | | | |
|--|---------------|-----------------------------|----------|
| Value group | Controler I/O | Related FW | 1.6.0 |
| Units | % | | |
| Comm object | 15780 | Related applications | AMF, MRS |
| Description | | | |
| Shows number of E-STOP input – the same principle of visualization like binary inputs. Principle of value (principle of normally close binary input): | | | |
| <ul style="list-style-type: none">> 1 – E-STOP has voltage – state is OK> 0 – E-STOP has no voltage – protection is active | | | |

🔍 back to List of values

Group: Statistics

Genset kWh

| | | | |
|---|------------|-----------------------------|----------|
| Value group | Statistics | Related FW | 1.6.0 |
| Units | kWh | | |
| Comm object | 8539 | Related applications | AMF, MRS |
| Description | | | |
| Counter of Gen-set reactive power. | | | |
| Note: This value can be also switch into one decimal power format (via IntelliConfig PC tool). In this case the range of value is decrease 10 times. | | | |

🔍 back to List of values

Genset kWh

| | | | |
|--|------------|-----------------------------|----------|
| Value group | Statistics | Related FW | 1.6.0 |
| Units | kWh | | |
| Comm object | 8205 | Related applications | AMF, MRS |
| Description | | | |
| Counter of Gen-set active power. | | | |
| <i>Note: This value can be also switch into one decimal power format (via InteliConfig PC tool). In this case the range of value is decrease 10 times.</i> | | | |

⬅ back to List of values

Mains kVArh

| | | | |
|--|------------|-----------------------------|-------|
| Value group | Statistics | Related FW | 1.6.0 |
| Units | kVArh | | |
| Comm object | 11026 | Related applications | AMF |
| Description | | | |
| Counter of mains reactive power. | | | |
| <i>Note: This value can be also switch into one decimal power format (via InteliConfig PC tool). In this case the range of value is decrease 10 times.</i> | | | |

⬅ back to List of values

Mains kWh

| | | | |
|--|------------|-----------------------------|-------|
| Value group | Statistics | Related FW | 1.6.0 |
| Units | kWh | | |
| Comm object | 11025 | Related applications | AMF |
| Description | | | |
| Counter of mains active power. | | | |
| <i>Note: This value can be also switch into one decimal power format (via InteliConfig PC tool). In this case the range of value is decrease 10 times.</i> | | | |

⬅ back to List of values

Maintenance 1

| | | | |
|---|------------|-----------------------------|----------|
| Value group | Statistics | Related FW | 1.6.0 |
| Units | hours | | |
| Comm object | 11616 | Related applications | AMF, MRS |
| Description | | | |
| Countdown until next maintenance 1. Initial value can be set in Maintenance Timer 1 (page 203) . | | | |

⬅ back to List of values

Maintenance 2

| | | | |
|---|------------|-----------------------------|----------|
| Value group | Statistics | Related FW | 1.6.0 |
| Units | hours | | |
| Comm object | 11617 | Related applications | AMF, MRS |
| Description | | | |
| Countdown until next maintenance 2. Initial value can be set in Maintenance Timer 2 (page 203) . | | | |

[back to List of values](#)

Maintenance 3

| | | | |
|---|------------|-----------------------------|----------|
| Value group | Statistics | Related FW | 1.6.0 |
| Units | hours | | |
| Comm object | 11618 | Related applications | AMF, MRS |
| Description | | | |
| Countdown until next maintenance 3. Initial value can be set in Maintenance Timer 3 (page 204) . | | | |

[back to List of values](#)

Num E-Stops

| | | | |
|--------------------------------|------------|-----------------------------|----------|
| Value group | Statistics | Related FW | 1.6.0 |
| Units | [-] | | |
| Comm object | 11195 | Related applications | AMF, MRS |
| Description | | | |
| Emergency stop alarms counter. | | | |

[back to List of values](#)

Num Starts

| | | | |
|--|------------|-----------------------------|----------|
| Value group | Statistics | Related FW | 1.6.0 |
| Units | [-] | | |
| Comm object | 8207 | Related applications | AMF, MRS |
| Description | | | |
| Engine start commands counter. The counter is increased by 1 even if the particular start command will take more than one attempt. | | | |

[back to List of values](#)

Running Hours

| | | | |
|---|------------|-----------------------------|----------|
| Value group | Statistics | Related FW | 1.6.0 |
| Units | hours | | |
| Comm object | 8206 | Related applications | AMF, MRS |
| Description | | | |
| Engine operation hours counter. The engine hours are incremented in the controller while the engine is running. | | | |

[back to List of values](#)

Shutdowns

| | | | |
|--|------------|-----------------------------|----------|
| Value group | Statistics | Related FW | 1.6.0 |
| Units | [-] | | |
| Comm object | 11196 | Related applications | AMF, MRS |
| Description | | | |
| Shutdown alarms counter. This counter counts all occurrences of a shutdown alarm, not only real shutdowns of the Gen-set, i.e. the counter is increased by 2 if two shutdown alarms appear simultaneously. | | | |

[▲ back to List of values](#)

Group: IL Info

Application

| | | | |
|--|---------|-----------------------------|----------|
| Value group | IL Info | Related FW | 1.6.0 |
| Units | [-] | | |
| Comm object | 8480 | Related applications | AMF, MRS |
| Description | | | |
| The value contains actual application in controller. | | | |

[▲ back to List of values](#)

Breaker State

| | | | |
|--|---------|-----------------------------|----------|
| Value group | IL Info | Related FW | 1.6.0 |
| Units | [-] | | |
| Comm object | 9245 | Related applications | AMF, MRS |
| Description | | | |
| The value contains actual "breaker state" message which is shown on the main screen of the controller. | | | |

[▲ back to List of values](#)

Connection Type

| | | | |
|---|---------|-----------------------------|----------|
| Value group | IL Info | Related FW | 1.6.0 |
| Units | [-] | | |
| Comm object | 12944 | Related applications | AMF, MRS |
| Description | | | |
| The text of this value represents the connection type which is adjusted in setpoint Connection type (page 165) . | | | |

[▲ back to List of values](#)

Engine State

| | | | |
|---|---------|-----------------------------|----------|
| Value group | IL Info | Related FW | 1.6.0 |
| Units | [-] | | |
| Comm object | 9244 | Related applications | AMF, MRS |
| Description | | | |
| The value contains actual "engine state" message which is shown on the main screen of the controller. | | | |

[back to List of values](#)

FW Branch

| | | | |
|---|---------|-----------------------------|----------|
| Value group | IL Info | Related FW | 1.6.0 |
| Units | [-] | | |
| Comm object | 8707 | Related applications | AMF, MRS |
| Description | | | |
| The value contains actual branch of firmware in controller. | | | |

[back to List of values](#)

FW Version

| | | | |
|--|---------|-----------------------------|----------|
| Value group | IL Info | Related FW | 1.6.0 |
| Units | [-] | | |
| Comm object | 24339 | Related applications | AMF, MRS |
| Description | | | |
| Major and minor firmware version number. | | | |

[back to List of values](#)

ID String

| | | | |
|---|---------|-----------------------------|----------|
| Value group | IL Info | Related FW | 1.6.0 |
| Units | [-] | | |
| Comm object | 24501 | Related applications | AMF, MRS |
| Description | | | |
| Name of controller which is used in IntelliConfig in command bar. | | | |

[back to List of values](#)

SPI Module A

| | | | |
|---|---------|-----------------------------|----------|
| Value group | IL Info | Related FW | 1.6.0 |
| Units | [-] | | |
| Comm object | 14447 | Related applications | AMF, MRS |
| Description | | | |
| The name of plug-in module which is inserted in slot A. | | | |

[back to List of values](#)

Timer Text

| | | | |
|--|---------|-----------------------------|----------|
| Value group | IL Info | Related FW | 1.6.0 |
| Units | [-] | | |
| Comm object | 10040 | Related applications | AMF, MRS |
| Description | | | |
| The value contains the numeric code of the "Current process timer" text which is shown on the main screen of the controller. | | | |
| The assignment of texts to the codes can be obtained using IntelliConfig. Open any connection (also offline with a previously saved archive) and go to the Tools ribbon -> Generate CFG image (all). The resulting file will contain the assignment of texts to the codes. | | | |

[◀ back to List of values](#)

Timer Value

| | | | |
|---|------------|-----------------------------|----------|
| Value group | IL Info | Related FW | 1.6.0 |
| Units | [HH:MM:SS] | | |
| Comm object | 14147 | Related applications | AMF, MRS |
| Description | | | |
| The value contains the "Current process timer" value which is shown on the main screen of the controller. | | | |

[◀ back to List of values](#)

Group: Log Bout

Log Bout 1

| | | | |
|--------------------------|----------|-----------------------------|----------|
| Value group | Log Bout | Related FW | 1.6.0 |
| Units | [-] | | |
| Comm object | 9143 | Related applications | AMF, MRS |
| Description | | | |
| State of binary outputs. | | | |

[◀ back to List of values](#)

Log Bout 2

| | | | |
|--------------------------|----------|-----------------------------|----------|
| Value group | Log Bout | Related FW | 1.6.0 |
| Units | [-] | | |
| Comm object | 9144 | Related applications | AMF, MRS |
| Description | | | |
| State of binary outputs. | | | |

[◀ back to List of values](#)

Log Bout 3

| | | | |
|--------------------------|----------|-----------------------------|----------|
| Value group | Log Bout | Related FW | 1.6.0 |
| Units | [-] | | |
| Comm object | 9145 | Related applications | AMF, MRS |
| Description | | | |
| State of binary outputs. | | | |

[back to List of values](#)

Log Bout 4

| | | | |
|--------------------------|----------|-----------------------------|----------|
| Value group | Log Bout | Related FW | 1.6.0 |
| Units | [-] | | |
| Comm object | 9146 | Related applications | AMF, MRS |
| Description | | | |
| State of binary outputs. | | | |

[back to List of values](#)

Log Bout 5

| | | | |
|--------------------------|----------|-----------------------------|----------|
| Value group | Log Bout | Related FW | 1.6.0 |
| Units | [-] | | |
| Comm object | 9147 | Related applications | AMF, MRS |
| Description | | | |
| State of binary outputs. | | | |

[back to List of values](#)

Log Bout 6

| | | | |
|--------------------------|----------|-----------------------------|----------|
| Value group | Log Bout | Related FW | 1.6.0 |
| Units | [-] | | |
| Comm object | 9148 | Related applications | AMF, MRS |
| Description | | | |
| State of binary outputs. | | | |

[back to List of values](#)

Log Bout 7

| | | | |
|--------------------------|----------|-----------------------------|----------|
| Value group | Log Bout | Related FW | 1.6.0 |
| Units | [-] | | |
| Comm object | 9149 | Related applications | AMF, MRS |
| Description | | | |
| State of binary outputs. | | | |

[back to List of values](#)

Log Bout 8

| | | | |
|--------------------------|----------|-----------------------------|----------|
| Value group | Log Bout | Related FW | 1.6.0 |
| Units | [-] | | |
| Comm object | 9150 | Related applications | AMF, MRS |
| Description | | | |
| State of binary outputs. | | | |

[back to List of values](#)

Log Bout 9

| | | | |
|--------------------------|----------|-----------------------------|----------|
| Value group | Log Bout | Related FW | 1.6.0 |
| Units | [-] | | |
| Comm object | 11896 | Related applications | AMF, MRS |
| Description | | | |
| State of binary outputs. | | | |

[back to List of values](#)

Log Bout 10

| | | | |
|--------------------------|----------|-----------------------------|----------|
| Value group | Log Bout | Related FW | 1.6.0 |
| Units | [-] | | |
| Comm object | 11897 | Related applications | AMF, MRS |
| Description | | | |
| State of binary outputs. | | | |

[back to List of values](#)

Log Bout 11

| | | | |
|--------------------------|----------|-----------------------------|----------|
| Value group | Log Bout | Related FW | 1.6.0 |
| Units | [-] | | |
| Comm object | 11898 | Related applications | AMF, MRS |
| Description | | | |
| State of binary outputs. | | | |

[back to List of values](#)

Group: CM-GPRS

Connection Type

| | | | |
|------------------------------|--------------------|-----------------------------|----------|
| Value group | CM-GPRS; CM-4G-GPS | Related FW | 1.6.0 |
| Units | [-] | | |
| Comm object | 24146 | Related applications | AMF, MRS |
| Description | | | |
| The type of data connection. | | | |

[▲ back to List of values](#)

Cell Error Rate

| | | | |
|--|------------------------------|-----------------------------|----------|
| Value group | CM-GPRS; CM-4G-GPS (4G part) | Related FW | 1.6.0 |
| Units | % | | |
| Comm object | 24300 | Related applications | AMF, MRS |
| Description | | | |
| This value contains information about relative quality of the cellular signal received by the CM-GPRS module or by CM-4G-GPS module. The lower value means higher quality of signal. | | | |

[▲ back to List of values](#)

Cell Diag Codes

| | | | |
|--------------------|------------------------------|-----------------------------|----------|
| Value group | CM-GPRS; CM-4G-GPS (4G part) | Related FW | 1.6.0 |
| Units | [-] | | |
| Comm object | 24288 | Related applications | AMF, MRS |

Description

Diagnostic code for the CM-GPRS or CM-4G-GPS module.

GSM Diag Code – Common list of diagnostic codes for cellular modules

| Code | Description |
|------|---|
| 0 | OK. No error. |
| 1 | Not possible to hang up. |
| 2 | Modul is switched off |
| 3 | Module is switched on |
| 4 | Module – error in initialization |
| 5 | Module – not possible to set the APN |
| 6 | Module – not possible to connect to GPRS network |
| 7 | Module – not possible to retrieve IP address |
| 8 | Module – not accepted DNS IP address |
| 9 | Error in modem detection |
| 10 | Error in initialization of analog modem |
| 11 | SIM card is locked (Possibly PIN code required, PIN needs to be deactivated) or unknown status of SIM locking |
| 12 | No GSM signal |
| 13 | Not possible to read the SIM card parameters |
| 14 | GSM modem did not accepted particular initialization command, possibly caused by locked SIM card |
| 15 | Unknown modem |
| 16 | Bad answer to complement initialization string |
| 17 | Not possible to read GSM signal strength |
| 18 | CDMA modem not detected |
| 19 | No CDMA network |
| 20 | Unsuccessful registration to CDMA network |
| 21 | SIMCom/ME909s: can't read FW version |
| 22 | SIMCom: GSM signal not found |
| 23 | SIMCom: can't detect module speed |
| 24 | SIMCom: HW reset issued |
| 25 | PUK is required |
| 26 | Error of SIM card detected |

| | |
|-----|--|
| 27 | ME909s: can't set module bps |
| 28 | ME909s: can't set link configuration |
| 29 | ME909s: can't do power-off |
| 30 | ME909s: can't do power-on |
| 31 | ME909s: can't do hardware reset |
| 32 | ME909s: ME909s not started |
| 33 | ME909s: switch off issued |
| 34 | ME909s: switch on issued |
| 35 | ME909s: HW reset issued |
| 36 | ME909s: can't switch echo off |
| 37 | ME909s: can't find out state of registration |
| 38 | ME909s: GSM signal not found |
| 39 | ME909s: no SIM memory for SMS |
| 40 | ME909s: waiting for registration |
| 41 | Can't read operator name |
| 42 | ME909s: can't set flow control |
| 43 | APN not typed |
| 255 | Only running communication is needed to indicate |

[back to List of values](#)

Cell Signal Lev

| | | | |
|---|--------------------|-----------------------------|----------|
| Value group | CM-GPRS; CM-4G-GPS | Related FW | 1.6.0 |
| Units | % | | |
| Comm object | 24302 | Related applications | AMF, MRS |
| Description | | | |
| This value contains information about relative strength of the cellular signal received by the CM-GPRS module or by CM-4G-GPS module. It is a relative value helping to find the best signal and for troubleshooting cases. | | | |

[back to List of values](#)

Cell Status

| | | | |
|--|--------------------|-----------------------------|----------|
| Value group | CM-GPRS; CM-4G-GPS | Related FW | 1.6.0 |
| Units | [-] | | |
| Comm object | 24290 | Related applications | AMF, MRS |
| Description | | | |
| The text of this value represents the status of the GSM modem. | | | |

[back to List of values](#)

Operator

| | | | |
|--|--------------------|-----------------------------|----------|
| Value group | CM-GPRS; CM-4G-GPS | Related FW | 1.6.0 |
| Units | [-] | | |
| Comm object | 24147 | Related applications | AMF, MRS |
| Description | | | |
| The name of operator which to SIM card is connected. | | | |
| Note: <i>If roaming service is used then prefix "R" is added before the name of operator.</i> | | | |

[▲ back to List of values](#)

Group: CM-4G-GPS

Connection Type

| | | | |
|------------------------------|--------------------|-----------------------------|----------|
| Value group | CM-GPRS; CM-4G-GPS | Related FW | 1.6.0 |
| Units | [-] | | |
| Comm object | 24146 | Related applications | AMF, MRS |
| Description | | | |
| The type of data connection. | | | |

[▲ back to List of values](#)

Cell Diag Codes

| | | | |
|--------------------|------------------------------|-----------------------------|----------|
| Value group | CM-GPRS; CM-4G-GPS (4G part) | Related FW | 1.6.0 |
| Units | [-] | | |
| Comm object | 24288 | Related applications | AMF, MRS |

Description

Diagnostic code for the CM-GPRS or CM-4G-GPS module.

GSM Diag Code – Common list of diagnostic codes for cellular modules

| Code | Description |
|------|---|
| 0 | OK. No error. |
| 1 | Not possible to hang up. |
| 2 | Modul is switched off |
| 3 | Module is switched on |
| 4 | Module – error in initialization |
| 5 | Module – not possible to set the APN |
| 6 | Module – not possible to connect to GPRS network |
| 7 | Module – not possible to retrieve IP address |
| 8 | Module – not accepted DNS IP address |
| 9 | Error in modem detection |
| 10 | Error in initialization of analog modem |
| 11 | SIM card is locked (Possibly PIN code required, PIN needs to be deactivated) or unknown status of SIM locking |
| 12 | No GSM signal |
| 13 | Not possible to read the SIM card parameters |
| 14 | GSM modem did not accepted particular initialization command, possibly caused by locked SIM card |
| 15 | Unknown modem |
| 16 | Bad answer to complement initialization string |
| 17 | Not possible to read GSM signal strength |
| 18 | CDMA modem not detected |
| 19 | No CDMA network |
| 20 | Unsuccessful registration to CDMA network |
| 21 | SIMCom/ME909s: can't read FW version |
| 22 | SIMCom: GSM signal not found |
| 23 | SIMCom: can't detect module speed |
| 24 | SIMCom: HW reset issued |
| 25 | PUK is required |
| 26 | Error of SIM card detected |

| | |
|-----|--|
| 27 | ME909s: can't set module bps |
| 28 | ME909s: can't set link configuration |
| 29 | ME909s: can't do power-off |
| 30 | ME909s: can't do power-on |
| 31 | ME909s: can't do hardware reset |
| 32 | ME909s: ME909s not started |
| 33 | ME909s: switch off issued |
| 34 | ME909s: switch on issued |
| 35 | ME909s: HW reset issued |
| 36 | ME909s: can't switch echo off |
| 37 | ME909s: can't find out state of registration |
| 38 | ME909s: GSM signal not found |
| 39 | ME909s: no SIM memory for SMS |
| 40 | ME909s: waiting for registration |
| 41 | Can't read operator name |
| 42 | ME909s: can't set flow control |
| 43 | APN not typed |
| 255 | Only running communication is needed to indicate |

[back to List of values](#)

Cell Error Rate

| | | | |
|--|------------------------------|-----------------------------|----------|
| Value group | CM-GPRS; CM-4G-GPS (4G part) | Related FW | 1.6.0 |
| Units | % | | |
| Comm object | 24300 | Related applications | AMF, MRS |
| Description | | | |
| This value contains information about relative quality of the cellular signal received by the CM-GPRS module or by CM-4G-GPS module. The lower value means higher quality of signal. | | | |

[back to List of values](#)

Cell Signal Lev

| | | | |
|---|--------------------|-----------------------------|----------|
| Value group | CM-GPRS; CM-4G-GPS | Related FW | 1.6.0 |
| Units | % | | |
| Comm object | 24302 | Related applications | AMF, MRS |
| Description | | | |
| This value contains information about relative strength of the cellular signal received by the CM-GPRS module or by CM-4G-GPS module. It is a relative value helping to find the best signal and for troubleshooting cases. | | | |

[back to List of values](#)

Cell Status

| | | | |
|--|--------------------|-----------------------------|----------|
| Value group | CM-GPRS; CM-4G-GPS | Related FW | 1.6.0 |
| Units | [-] | | |
| Comm object | 24290 | Related applications | AMF, MRS |
| Description | | | |
| The text of this value represents the status of the GSM modem. | | | |

[◀ back to List of values](#)

Operator

| | | | |
|--|--------------------|-----------------------------|----------|
| Value group | CM-GPRS; CM-4G-GPS | Related FW | 1.6.0 |
| Units | [-] | | |
| Comm object | 24147 | Related applications | AMF, MRS |
| Description | | | |
| The name of operator which to SIM card is connected. | | | |
| <i>Note: If roaming service is used then prefix "R" is added before the name of operator.</i> | | | |

[◀ back to List of values](#)

Group: CM-Ethernet

Current DNS

| | | | |
|-----------------------------|-------------|-----------------------------|----------|
| Value group | CM-Ethernet | Related FW | 1.6.0 |
| Units | [-] | | |
| Comm object | 24181 | Related applications | AMF, MRS |
| Description | | | |
| Current domain name server. | | | |

[◀ back to List of values](#)

ETH Interface Status

| | | | |
|---|-------------|-----------------------------|----------|
| Value group | CM-Ethernet | Related FW | 1.6.0 |
| Units | [-] | | |
| Comm object | 24180 | Related applications | AMF, MRS |
| Description | | | |
| Current status of ethernet communication. | | | |

[◀ back to List of values](#)

Current Gateway

| | | | |
|--------------------------|-------------|-----------------------------|----------|
| Value group | CM-Ethernet | Related FW | 1.6.0 |
| Units | [-] | | |
| Comm object | 24182 | Related applications | AMF, MRS |
| Description | | | |
| Current gateway address. | | | |

[↶ back to List of values](#)

Current IP Address

| | | | |
|---------------------------------------|-------------|-----------------------------|----------|
| Value group | CM-Ethernet | Related FW | 1.6.0 |
| Units | [-] | | |
| Comm object | 24184 | Related applications | AMF, MRS |
| Description | | | |
| Current IP address of the controller. | | | |

[↶ back to List of values](#)

Last Email Results

| Value group | CM-Ethernet | Related FW | 1.6.0 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|--|--|-----------------------------|----------|------|-------------|---|------------------------------|---|--|---|---|---|---------------------------|---|---------------------------|----|---------------------------------|----|------------------|----|-----------------|----|--------------------------------|----|------------------------------|----|---------------------------|----|--------------------------|----|---------------------------|----|---|----|---|----|------------------------------|----|--|----|---|
| Units | [-] | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Comm object | 24332 | Related applications | AMF, MRS | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Description | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Result of last email, which was sent by controller. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <table border="1"> <thead> <tr> <th>Code</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Email was successfully sent.</td> </tr> <tr> <td>2</td> <td>It is not possible to establish connection with SMTP server.</td> </tr> <tr> <td>3</td> <td>SMTP server is not ready for communication.</td> </tr> <tr> <td>8</td> <td>HELO command was refused.</td> </tr> <tr> <td>9</td> <td>EHLO command was refused.</td> </tr> <tr> <td>11</td> <td>AUTH LOGIN command was refused.</td> </tr> <tr> <td>12</td> <td>Wrong user name.</td> </tr> <tr> <td>13</td> <td>Wrong password.</td> </tr> <tr> <td>14</td> <td>MAIL FROM command was refused.</td> </tr> <tr> <td>15</td> <td>RCPT TO command was refused.</td> </tr> <tr> <td>16</td> <td>DATA command was refused.</td> </tr> <tr> <td>17</td> <td>Sending of email failed.</td> </tr> <tr> <td>20</td> <td>QUIT command was refused.</td> </tr> <tr> <td>25</td> <td>It is impossible to create data for command DATA.</td> </tr> <tr> <td>26</td> <td>It is impossible to read data for command DATA.</td> </tr> <tr> <td>27</td> <td>Email address can't be read.</td> </tr> <tr> <td>30</td> <td>SMTP server address translation error (from DNS server).</td> </tr> <tr> <td>31</td> <td>Error reading email content data (24327).</td> </tr> </tbody> </table> | | | | Code | Description | 0 | Email was successfully sent. | 2 | It is not possible to establish connection with SMTP server. | 3 | SMTP server is not ready for communication. | 8 | HELO command was refused. | 9 | EHLO command was refused. | 11 | AUTH LOGIN command was refused. | 12 | Wrong user name. | 13 | Wrong password. | 14 | MAIL FROM command was refused. | 15 | RCPT TO command was refused. | 16 | DATA command was refused. | 17 | Sending of email failed. | 20 | QUIT command was refused. | 25 | It is impossible to create data for command DATA. | 26 | It is impossible to read data for command DATA. | 27 | Email address can't be read. | 30 | SMTP server address translation error (from DNS server). | 31 | Error reading email content data (24327). |
| Code | Description | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | Email was successfully sent. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | It is not possible to establish connection with SMTP server. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | SMTP server is not ready for communication. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 8 | HELO command was refused. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 9 | EHLO command was refused. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 11 | AUTH LOGIN command was refused. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 12 | Wrong user name. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 13 | Wrong password. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 14 | MAIL FROM command was refused. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 15 | RCPT TO command was refused. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 16 | DATA command was refused. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 17 | Sending of email failed. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 20 | QUIT command was refused. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 25 | It is impossible to create data for command DATA. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 26 | It is impossible to read data for command DATA. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 27 | Email address can't be read. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 30 | SMTP server address translation error (from DNS server). | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 31 | Error reading email content data (24327). | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

[⬅ back to List of values](#)

MAC Address

| | | | |
|---|-------------|-----------------------------|----------|
| Value group | CM-Ethernet | Related FW | 1.6.0 |
| Units | [-] | | |
| Comm object | 24333 | Related applications | AMF, MRS |
| Description | | | |
| Current MAC address of the controller ethernet interface. | | | |

[⬅ back to List of values](#)

Current Subnet Mask

| | | | |
|----------------------|-------------|-----------------------------|----------|
| Value group | CM-Ethernet | Related FW | 1.6.0 |
| Units | [-] | | |
| Comm object | 24183 | Related applications | AMF, MRS |
| Description | | | |
| Current subnet mask. | | | |

[◀ back to List of values](#)

Group: Date/Time

Time

| | | | |
|--------------------|-----------|-----------------------------|----------|
| Value group | Date/Time | Related FW | 1.6.0 |
| Units | HH:MM:SS | | |
| Comm object | 24554 | Related applications | AMF, MRS |
| Description | | | |
| Shows setup time. | | | |

[◀ back to List of values](#)

Date

| | | | |
|--------------------|------------|-----------------------------|----------|
| Value group | Date/Time | Related FW | 1.6.0 |
| Units | DD.MM.YYYY | | |
| Comm object | 24553 | Related applications | AMF, MRS |
| Description | | | |
| Shows setup date. | | | |

[◀ back to List of values](#)

Group: Plug-In I/O

EM BIO A

| | | | |
|--|-------------|-----------------------------|----------|
| Value group | Plug-In I/O | Related FW | 1.6.0 |
| Units | [-] | | |
| Comm object | 14291 | Related applications | AMF, MRS |
| Description | | | |
| Binary inputs from extension module in slot A. | | | |

[◀ back to List of values](#)

8.1.4 Logical binary inputs

What Logical binary inputs are:

Logical binary inputs are inputs for binary values and functions.

Alphabetical groups of Logical binary inputs

| | |
|--------------|-----|
| LBI: A | 309 |
| LBI: B | 309 |
| LBI: C | 317 |
| LBI: D | 319 |
| LBI: E | 319 |
| LBI: F | 320 |
| LBI: G | 321 |
| LBI: H | 321 |
| LBI: M | 322 |
| LBI: N | 323 |
| LBI: O | 324 |
| LBI: P | 324 |
| LBI: R | 324 |
| LBI: S | 328 |

For full list of Logical binary inputs go to the chapter **Logical binary inputs alphabetically (page 308)**.

Logical binary inputs alphabetically

| | | | |
|--------------------------|-----|---|-----|
| AMF Function | 309 | Remote OFF | 325 |
| AMF Start Block | 309 | Remote Start/Stop | 326 |
| BIN Protection 1 | 309 | Rem TEST On Load | 326 |
| BIN Protection 02 | 310 | Remote TEST | 327 |
| BIN Protection 03 | 310 | Sd Override | 328 |
| BIN Protection 04 | 311 | | |
| BIN Protection 05 | 311 | ▲ back to Controller objects | |
| BIN Protection 06 | 312 | | |
| BIN Protection 07 | 312 | | |
| BIN Protection 08 | 313 | | |
| BIN Protection 09 | 313 | | |
| BIN Protection 10 | 314 | | |
| BIN Protection 11 | 314 | | |
| BIN Protection 12 | 315 | | |
| BIN Protection 13 | 315 | | |
| BIN Protection 14 | 316 | | |
| BIN Protection 15 | 316 | | |
| BIN Protection 16 | 317 | | |
| Configuration 2 | 317 | | |
| Configuration 3 | 317 | | |
| Choke Inhibit | 318 | | |
| Dark Mode | 319 | | |
| ECU Key Switch | 319 | | |
| Emergency Stop | 319 | | |
| Fault Reset Button | 320 | | |
| Force Regeneration | 320 | | |
| Fuel Pump On/Off | 320 | | |
| GCB Feedback | 321 | | |
| Horn Reset Button | 321 | | |
| Mains Fail Block | 322 | | |
| MCB Feedback | 323 | | |
| Not Used | 323 | | |
| Oil Pressure | 324 | | |
| Protection Enable | 324 | | |
| Regeneration Inhib | 324 | | |
| Remote AUTO | 325 | | |
| Remote MAN | 325 | | |

LBI: A

AMF Function

| | | | |
|---|-------|-----------------------------|-----|
| Related FW | 1.6.0 | Related applications | AMF |
| Comm object | 692 | | |
| Description | | | |
| This binary input can switch controller function between AMF and MRS. | | | |
| <i>Note: Binary input "AMF function" has higher priority than the setpoint Operation Mode (page 170) in Basic settings.</i> | | | |

◀ back to Logical binary inputs alphabetically

AMF Start Block

| | | | |
|--|-------|-----------------------------|-----|
| Related FW | 1.6.0 | Related applications | AMF |
| Comm object | 211 | | |
| Description | | | |
| This binary input can allow or block the AMF start. In case of running Gen-set in AUTO mode Gen-set goes to cooling procedure and stops. | | | |

◀ back to Logical binary inputs alphabetically

LBI: B

BIN Protection 1

| | | | |
|--|---|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 9999 | | |
| Description | | | |
| This binary input is for general input function used as alarm. | | | |
| Protection types | | | |
| Monitoring | Binary input is not used for protection or any other function. Signal is only monitored. | | |
| HistRecOnl | Binary input is not used for protection. Only history record is made if binary input is active. | | |
| AL Indic | Binary input is not used for protection. Only alarmlist record is made if binary input is active. | | |
| Wrn | Binary input is used for warning protection only. | | |
| BOC | Binary input is used for BOC (Breaker Open and Cooling) protection. | | |
| Sd | Binary input is used for shutdown protection. | | |

◀ back to Logical binary inputs alphabetically

BIN Protection 02

| | | | |
|--|---|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 9998 | | |
| Description | | | |
| This binary input is for general input function used as alarm. | | | |
| Protection types | | | |
| Monitoring | Binary input is not used for protection or any other function. Signal is only monitored. | | |
| HistRecOnl | Binary input is not used for protection. Only history record is made if binary input is active. | | |
| AL Indic | Binary input is not used for protection. Only alarmlist record is made if binary input is active. | | |
| Wrn | Binary input is used for warning protection only. | | |
| BOC | Binary input is used for BOC (Breaker Open and Cooling) protection. | | |
| Sd | Binary input is used for shutdown protection. | | |

[◀ back to Logical binary inputs alphabetically](#)

BIN Protection 03

| | | | |
|--|---|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 9997 | | |
| Description | | | |
| This binary input is for general input function used as alarm. | | | |
| Protection types | | | |
| Monitoring | Binary input is not used for protection or any other function. Signal is only monitored. | | |
| HistRecOnl | Binary input is not used for protection. Only history record is made if binary input is active. | | |
| AL Indic | Binary input is not used for protection. Only alarmlist record is made if binary input is active. | | |
| Wrn | Binary input is used for warning protection only. | | |
| BOC | Binary input is used for BOC (Breaker Open and Cooling) protection. | | |
| Sd | Binary input is used for shutdown protection. | | |

[◀ back to Logical binary inputs alphabetically](#)

BIN Protection 04

| | | | |
|--|---|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 9996 | | |
| Description | | | |
| This binary input is for general input function used as alarm. | | | |
| Protection types | | | |
| Monitoring | Binary input is not used for protection or any other function. Signal is only monitored. | | |
| HistRecOnl | Binary input is not used for protection. Only history record is made if binary input is active. | | |
| AL Indic | Binary input is not used for protection. Only alarmlist record is made if binary input is active. | | |
| Wrn | Binary input is used for warning protection only. | | |
| BOC | Binary input is used for BOC (Breaker Open and Cooling) protection. | | |
| Sd | Binary input is used for shutdown protection. | | |

[◀ back to Logical binary inputs alphabetically](#)

BIN Protection 05

| | | | |
|--|---|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 9995 | | |
| Description | | | |
| This binary input is for general input function used as alarm. | | | |
| Protection types | | | |
| Monitoring | Binary input is not used for protection or any other function. Signal is only monitored. | | |
| HistRecOnl | Binary input is not used for protection. Only history record is made if binary input is active. | | |
| AL Indic | Binary input is not used for protection. Only alarmlist record is made if binary input is active. | | |
| Wrn | Binary input is used for warning protection only. | | |
| BOC | Binary input is used for BOC (Breaker Open and Cooling) protection. | | |
| Sd | Binary input is used for shutdown protection. | | |

[◀ back to Logical binary inputs alphabetically](#)

BIN Protection 06

| | | | |
|--|---|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 9994 | | |
| Description | | | |
| This binary input is for general input function used as alarm. | | | |
| Protection types | | | |
| Monitoring | Binary input is not used for protection or any other function. Signal is only monitored. | | |
| HistRecOnl | Binary input is not used for protection. Only history record is made if binary input is active. | | |
| AL Indic | Binary input is not used for protection. Only alarmlist record is made if binary input is active. | | |
| Wrn | Binary input is used for warning protection only. | | |
| BOC | Binary input is used for BOC (Breaker Open and Cooling) protection. | | |
| Sd | Binary input is used for shutdown protection. | | |

[◀ back to Logical binary inputs alphabetically](#)

BIN Protection 07

| | | | |
|--|---|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 9993 | | |
| Description | | | |
| This binary input is for general input function used as alarm. | | | |
| Protection types | | | |
| Monitoring | Binary input is not used for protection or any other function. Signal is only monitored. | | |
| HistRecOnl | Binary input is not used for protection. Only history record is made if binary input is active. | | |
| AL Indic | Binary input is not used for protection. Only alarmlist record is made if binary input is active. | | |
| Wrn | Binary input is used for warning protection only. | | |
| BOC | Binary input is used for BOC (Breaker Open and Cooling) protection. | | |
| Sd | Binary input is used for shutdown protection. | | |

[◀ back to Logical binary inputs alphabetically](#)

BIN Protection 08

| | | | |
|--|---|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 9992 | | |
| Description | | | |
| This binary input is for general input function used as alarm. | | | |
| Protection types | | | |
| Monitoring | Binary input is not used for protection or any other function. Signal is only monitored. | | |
| HistRecOnl | Binary input is not used for protection. Only history record is made if binary input is active. | | |
| AL Indic | Binary input is not used for protection. Only alarmlist record is made if binary input is active. | | |
| Wrn | Binary input is used for warning protection only. | | |
| BOC | Binary input is used for BOC (Breaker Open and Cooling) protection. | | |
| Sd | Binary input is used for shutdown protection. | | |

[◀ back to Logical binary inputs alphabetically](#)

BIN Protection 09

| | | | |
|--|---|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 9991 | | |
| Description | | | |
| This binary input is for general input function used as alarm. | | | |
| Protection types | | | |
| Monitoring | Binary input is not used for protection or any other function. Signal is only monitored. | | |
| HistRecOnl | Binary input is not used for protection. Only history record is made if binary input is active. | | |
| AL Indic | Binary input is not used for protection. Only alarmlist record is made if binary input is active. | | |
| Wrn | Binary input is used for warning protection only. | | |
| BOC | Binary input is used for BOC (Breaker Open and Cooling) protection. | | |
| Sd | Binary input is used for shutdown protection. | | |

[◀ back to Logical binary inputs alphabetically](#)

BIN Protection 10

| | | | |
|--|---|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 9990 | | |
| Description | | | |
| This binary input is for general input function used as alarm. | | | |
| Protection types | | | |
| Monitoring | Binary input is not used for protection or any other function. Signal is only monitored. | | |
| HistRecOnl | Binary input is not used for protection. Only history record is made if binary input is active. | | |
| AL Indic | Binary input is not used for protection. Only alarmlist record is made if binary input is active. | | |
| Wrn | Binary input is used for warning protection only. | | |
| BOC | Binary input is used for BOC (Breaker Open and Cooling) protection. | | |
| Sd | Binary input is used for shutdown protection. | | |

[◀ back to Logical binary inputs alphabetically](#)

BIN Protection 11

| | | | |
|--|---|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 9989 | | |
| Description | | | |
| This binary input is for general input function used as alarm. | | | |
| Protection types | | | |
| Monitoring | Binary input is not used for protection or any other function. Signal is only monitored. | | |
| HistRecOnl | Binary input is not used for protection. Only history record is made if binary input is active. | | |
| AL Indic | Binary input is not used for protection. Only alarmlist record is made if binary input is active. | | |
| Wrn | Binary input is used for warning protection only. | | |
| BOC | Binary input is used for BOC (Breaker Open and Cooling) protection. | | |
| Sd | Binary input is used for shutdown protection. | | |

[◀ back to Logical binary inputs alphabetically](#)

BIN Protection 12

| | | | |
|--|---|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 9988 | | |
| Description | | | |
| This binary input is for general input function used as alarm. | | | |
| Protection types | | | |
| Monitoring | Binary input is not used for protection or any other function. Signal is only monitored. | | |
| HistRecOnl | Binary input is not used for protection. Only history record is made if binary input is active. | | |
| AL Indic | Binary input is not used for protection. Only alarmlist record is made if binary input is active. | | |
| Wrn | Binary input is used for warning protection only. | | |
| BOC | Binary input is used for BOC (Breaker Open and Cooling) protection. | | |
| Sd | Binary input is used for shutdown protection. | | |

[◀ back to Logical binary inputs alphabetically](#)

BIN Protection 13

| | | | |
|--|---|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 9987 | | |
| Description | | | |
| This binary input is for general input function used as alarm. | | | |
| Protection types | | | |
| Monitoring | Binary input is not used for protection or any other function. Signal is only monitored. | | |
| HistRecOnl | Binary input is not used for protection. Only history record is made if binary input is active. | | |
| AL Indic | Binary input is not used for protection. Only alarmlist record is made if binary input is active. | | |
| Wrn | Binary input is used for warning protection only. | | |
| BOC | Binary input is used for BOC (Breaker Open and Cooling) protection. | | |
| Sd | Binary input is used for shutdown protection. | | |

[◀ back to Logical binary inputs alphabetically](#)

BIN Protection 14

| | | | |
|--|---|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 9986 | | |
| Description | | | |
| This binary input is for general input function used as alarm. | | | |
| Protection types | | | |
| Monitoring | Binary input is not used for protection or any other function. Signal is only monitored. | | |
| HistRecOnl | Binary input is not used for protection. Only history record is made if binary input is active. | | |
| AL Indic | Binary input is not used for protection. Only alarmlist record is made if binary input is active. | | |
| Wrn | Binary input is used for warning protection only. | | |
| BOC | Binary input is used for BOC (Breaker Open and Cooling) protection. | | |
| Sd | Binary input is used for shutdown protection. | | |

[◀ back to Logical binary inputs alphabetically](#)

BIN Protection 15

| | | | |
|--|---|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 9985 | | |
| Description | | | |
| This binary input is for general input function used as alarm. | | | |
| Protection types | | | |
| Monitoring | Binary input is not used for protection or any other function. Signal is only monitored. | | |
| HistRecOnl | Binary input is not used for protection. Only history record is made if binary input is active. | | |
| AL Indic | Binary input is not used for protection. Only alarmlist record is made if binary input is active. | | |
| Wrn | Binary input is used for warning protection only. | | |
| BOC | Binary input is used for BOC (Breaker Open and Cooling) protection. | | |
| Sd | Binary input is used for shutdown protection. | | |

[◀ back to Logical binary inputs alphabetically](#)

BIN Protection 16

| | | | |
|--|---|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 9984 | | |
| Description | | | |
| This binary input is for general input function used as alarm. | | | |
| Protection types | | | |
| Monitoring | Binary input is not used for protection or any other function. Signal is only monitored. | | |
| HistRecOnl | Binary input is not used for protection. Only history record is made if binary input is active. | | |
| AL Indic | Binary input is not used for protection. Only alarmlist record is made if binary input is active. | | |
| Wrn | Binary input is used for warning protection only. | | |
| BOC | Binary input is used for BOC (Breaker Open and Cooling) protection. | | |
| Sd | Binary input is used for shutdown protection. | | |

🔍 back to Logical binary inputs alphabetically

LBI: C

Configuration 2

| | | | |
|--|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 859 | | |
| Description | | | |
| This binary input can switch between configuration sets. When this binary input is active, setpoints in Alternate Config group are switched to the second set (setpoints with number 2). | | | |
| IMPORTANT: If LBO ECU POWER RELAY (PAGE 340) is used, change of alternate configuration can be made only in prestart phase. So prestart has to be set up for enough long time. | | | |

🔍 back to Logical binary inputs alphabetically

Configuration 3

| | | | |
|---|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 860 | | |
| Description | | | |
| This binary input can switch between configuration sets. When this binary input is active, setpoints in Alternate Config group are switched to the third set (setpoints with number 3). | | | |
| IMPORTANT: If LBO ECU POWER RELAY (PAGE 340) is used, change of alternate configuration can be made only in prestart phase. So prestart has to be set up for enough long time. | | | |


🔍 back to Logical binary inputs alphabetically

Choke Inhibit

| | | | |
|--------------------|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 946 | | |

Description

Logical binary input CHOKE INHIBIT prevent Choke functionality when logical binary output **CHOKE (PAGE 338)** is activated. If CHOKE INHIBIT is activated when CHOKE LBO is active, CHOKE LBO is deactivated immediately and vice versa if LBI CHOKE INHIBIT is deactivated and LBO CHOKE should be active then is activated.



⬅ back to Logical binary inputs alphabetically

LBI: D

Dark Mode

| | | | |
|--|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 930 | | |
| Description | | | |
| This binary input activates function of dark mode. It means that backlight of display is turn off (information on controller screens are not affected) and LEDs (Mains, Generator, Load, Breakers, etc.) are turn off (LEDs don't react on normal condition of their activation and deactivation). | | | |
| <i>Note: After deactivation of dark mode, backlight of display is turned on and then behaves normally.</i> | | | |
| <i>Note: After deactivation of dark mode, Front Face status LEDs are turned on due to current situation of gen-set.</i> | | | |

🔍 back to Logical binary inputs alphabetically

LBI: E

ECU Key Switch

| | | | |
|---|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 951 | | |
| Description | | | |
| This binary input is used to switch on ECU POWER RELAY (PAGE 340) , when engine start is not requested. It is intended to enable engine values reading, when engine doesn't run. | | | |
| When this binary input is active, binary output ECU POWER RELAY (PAGE 340) is active too. | | | |
| When this binary input is inactive, function of ECU POWER RELAY (PAGE 340) is not affected. | | | |

🔍 back to Logical binary inputs alphabetically


Emergency Stop

| | | | |
|---|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 40 | | |
| Description | | | |
| The shutdown procedure will start immediately when this input is activated. Input is inverted (NC = normally closed) in default configuration. | | | |
| <i>Note: In case of controller hardware or software fail, safe stop of the engine doesn't have to be ensured. To back-up the Emergency Stop function it is recommended to connect separate circuit for disconnection of Fuel Solenoid and Starter signals.</i> | | | |
| For more detail see chapter Recommended wiring. | | | |

🔍 back to Logical binary inputs alphabetically

LBI: F

Fault Reset Button

| | | | |
|--|-------|----------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 191 | | |
| Description | | | |
| Binary input has the same function as Fault Reset button  on the IntelliLite 9 front panel. | | | |

◀ back to Logical binary inputs alphabetically

Force Regeneration

| | | | |
|--|-------|----------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 680 | | |
| Description | | | |
| When this binary input is activated, the controller send request for force regeneration of DPF (diesel particulate filter) to ECU. | | | |
| <i>Note: ECU with Tier IV support is required for proper functionality.</i> | | | |

◀ back to Logical binary inputs alphabetically

Fuel Pump On/Off

| | | | |
|--|-------|----------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 694 | | |
| Description | | | |
| This binary input is used for manual control of binary output FUEL PUMP (PAGE 342) . The output is deactivated automatically as soon as fuel level reaches 100 %. | | | |
| <i>Note: This binary input is basically designed for ON and OFF switch (switch with arrestment in these positions) because controller reacts to rising and falling edge of signal in this input.</i> | | | |
| IMPORTANT: When binary input FUEL PUMP ON/OFF (PAGE 320) is configured then binary output FUEL PUMP (PAGE 342) is control by this binary input. | | | |
| IMPORTANT: It is necessary to configure analog input FUEL LEVEL (PAGE 369) for proper function of this binary input. | | | |

◀ back to Logical binary inputs alphabetically

LBI: G

GCB Feedback

| | | | |
|--------------------|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 63 | | |

Description

Use this input for indication whether the generator circuit breaker is open or closed.




Image 8.18 GCB Feedback 1




Image 8.19 GCB Feedback 2

Note: IntelliLite 9 controller can work even without breaker feedbacks, in this case do not configure the feedback to binary inputs.


🔍 back to Logical binary inputs alphabetically

LBI: H

Horn Reset Button

| | | | |
|--------------------|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 192 | | |

Description

Binary input has the same function as Horn reset  button on the IntelliLite 9 front panel.

🔍 back to Logical binary inputs alphabetically

LBI: M

Mains Fail Block

| | | | |
|---|-------|-----------------------------|-----|
| Related FW | 1.6.0 | Related applications | AMF |
| Comm object | 622 | | |
| Description | | | |
| If the input is active, the automatic start of the Gen-set at Mains failure is blocked. In case of running Gen-set in AUTO mode, timer Mains Return Delay (page 216) is started and when it elapses GCB is opened, Gen-set goes to cooling procedure and stops. When GCB is opened after Transfer Delay (page 217) the MCB is closed. | | | |
| Note: <i>This input simulates healthy Mains.</i> | | | |

🔍 back to Logical binary inputs alphabetically

MCB Feedback

| | | | |
|--------------------|-------|-----------------------------|-----|
| Related FW | 1.6.0 | Related applications | AMF |
| Comm object | 65 | | |

Description

Use this input for indication whether the mains circuit breaker is open or closed.




Image 8.20 MCB Feedback 1




Image 8.21 MCB Feedback 2

Note: IntelliLite 9 controller can work even without breaker feedbacks, in this case do not configure the feedback to binary inputs.

🔍 back to Logical binary inputs alphabetically

LBI: N

Not Used

| | | | |
|--------------------|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 184 | | |

Description

Binary input has no function. Use this configuration when binary input is not used.

🔍 back to Logical binary inputs alphabetically

LBI: O

Oil Pressure

| | | | |
|---|---|----------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 43 | | |
| Description | | | |
| Binary input for OIL PRESSURE (PAGE 371) protection. | | | |
| Protection types | | | |
| Monitoring | Binary input is not used for protection or any other function. Signal is only monitored. | | |
| HistRecOnI | Binary input is not used for protection. Only history record is made if binary input is active. | | |
| Wrn | Binary input is used for warning protection only. | | |
| Sd | Binary input is used for shutdown protection. | | |
| IMPORTANT: This binary input is also used for evaluating engine running condition. | | | |
| Example: Normally close connection – when LBI is active then oil pressure is OK and is higher than starting oil pressure. | | | |
| Note: In case that you want to use this binary input of oil pressure sensor just for protection please use one of the BIN PROTECTION 1 (PAGE 309) . | | | |

🔍 back to Logical binary inputs alphabetically

LBI: P

Protection Enable

| | | | |
|---|-------|----------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 920 | | |
| Description | | | |
| This logic binary input enables or disables protections adjusted as LBI Enable. | | | |

🔍 back to Logical binary inputs alphabetically

LBI: R

Regeneration Inhib

| | | | |
|--|-------|----------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 679 | | |
| Description | | | |
| When this binary input is activated, the controller sends request to inhibit regeneration of DPF (diesel particulate filter) to ECU. | | | |
| Note: ECU with Tier IV support is required for proper functionality. | | | |

🔍 back to Logical binary inputs alphabetically

Remote AUTO

| | | | |
|--|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 620 | | |
| Description | | | |
| The controller is switched to the AUTO mode (there are fourthree modes OFF / MAN / AUTO / TEST) when this binary input is active. When opens controller is switched back to previous mode. | | | |
| This binary input has the lowest priority from Remote OFF / MAN / AUTO / TEST binary inputs | | | |
| Remote control priority: | | | |
| > Remote OFF (Highest priority) | | | |
| > Remote TEST | | | |
| > Remote MAN | | | |
| > Remote AUTO (Lowest Priority) | | | |

[◀ back to Logical binary inputs alphabetically](#)

Remote MAN

| | | | |
|---|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 618 | | |
| Description | | | |
| The controller is switched to the MAN mode (there are fourthree modes OFF / MAN / AUTO / TEST) when this binary input is active. When opens controller is switched back to previous mode. | | | |
| Remote control priority: | | | |
| > Remote OFF (Highest priority) | | | |
| > Remote TEST | | | |
| > Remote MAN | | | |
| > Remote AUTO (Lowest Priority) | | | |

[◀ back to Logical binary inputs alphabetically](#)

Remote OFF

| | | | |
|---|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 617 | | |
| Description | | | |
| The controller is switched to the OFF mode (there are fourthree modes OFF / MAN / AUTO / TEST) when this binary input is active. When opens controller is switched back to previous mode. | | | |
| Remote control priority: | | | |
| > Remote OFF (Highest priority) | | | |
| > Remote TEST | | | |
| > Remote MAN | | | |
| > Remote AUTO (Lowest Priority) | | | |

[◀ back to Logical binary inputs alphabetically](#)

Remote Start/Stop

| | | | |
|--------------------|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 38 | | |

Description

Use this input to start and stop the Gen-set in AUTO mode.

Note: If the binary input Remote Start/Stop is active and engine is running and mains failure occurs, the MCB breaker opens, after Transfer Delay (page 217) the GCB breaker is closed. Once the mains is OK, the Mains Return Delay (page 216) elapses and the GCB breaker is opened. Then after Transfer Delay (page 217) is MCB breaker closed. Gen-set remains running as long as binary input Rem Start/Stop is active. For more details see timing diagram below.




Image 8.22 Remote Start/Stop

Taken action in AMF application (AUTO Mode)

| | |
|----------|--|
| Active | <ul style="list-style-type: none"> > Start the Gen-set and stay running with opened GCB if Mains OK. > Go to Island if Mains fails (due to AMF function). > If Mains is not OK the AMF function starts the Gen-set to Island anyway. |
| Inactive | <ul style="list-style-type: none"> > Stop the Gen-set if Mains is OK > If Mains not OK the Gen-set stays running due to AMF function anyway. |

Taken action in MRS application (AUTO Mode)

| | |
|----------|--|
| Active | <ul style="list-style-type: none"> > Starts the Gen-set – No delay > Close GCB |
| Inactive | <ul style="list-style-type: none"> > Open GCB > Stop the Gen-set – No delay |

🔍 back to Logical binary inputs alphabetically

Rem TEST On Load

| | | | |
|-------------------|-------|-----------------------------|-----|
| Related FW | 1.6.0 | Related applications | AMF |
|-------------------|-------|-----------------------------|-----|

| | | |
|---|--|--|
| Comm object | 61 | |
| Description | | |
| Closing of the GCB in MRS or transferring of the load from the mains to Gen-set in AMF. | | |
| Application | TEST | Remote TEST On Load |
| MRS | Gen-set started and running until the TEST mode deactivated. | Active: Gen-set is put to TEST mode. On the top of it the GCB is closed. The same behavior like the REMOTE START/STOP (PAGE 326) . Inactive: Gen-set comes back to the original mode and behaves accordingly to this mode and other conditions. |
| AMF | Gen-set started and running until the TEST mode deactivated. | Active: Gen-set is put to TEST mode. On the top of it the load is transferred to the Gen-set. The open load transfer is performed. Inactive: Gen-set comes back to the original mode and behaves accordingly to this mode and other conditions. (the load can be transferred back to the mains (OFF, AUTO) or stay on the Gen-set (MAN)). |

🔍 back to Logical binary inputs alphabetically

Remote TEST

| | | | |
|---|-------|-----------------------------|-----|
| Related FW | 1.6.0 | Related applications | AMF |
| Comm object | 621 | | |
| Description | | | |
| The controller is switched to the TEST mode (there are four modes OFF / MAN / AUTO / TEST) when this binary input is active. When opens controller is switched back to previous mode. | | | |
| Remote control priority: | | | |
| <ul style="list-style-type: none"> > Remote OFF (Highest priority) > Remote TEST > Remote MAN > Remote AUTO (Lowest Priority) | | | |

🔍 back to Logical binary inputs alphabetically

LBI: S

Sd Override

| | | | |
|---|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 44 | | |
| Description | | | |
| If this input is active, all alarms except Emergency Stop and Overspeed are suppressed. The suppressed alarms will be displayed in the alarm list, but they will not take effect regarding the Gen-set control. | | | |
| Note: <i>Sd Override (page 328)</i> is indicated in the alarm list if Sd Override mode is active to inform the operator that the engine is not protected. | | | |
| IMPORTANT: MISUSE OF THIS INPUT CAN CAUSE DAMAGE TO THE GEN-SET! | | | |
| Note: <i>User protection Sd Override is not blocked</i> | | | |

[⬅ back to Logical binary inputs alphabetically](#)

8.1.5 Logical binary outputs

What Logical binary outputs are:

Logical binary outputs are outputs for binary values and functions.

Alphabetical groups of Logical binary outputs

| | |
|--------------|-----|
| LBO: A | 331 |
| LBO: C | 338 |
| LBO: E | 339 |
| LBO: F | 342 |
| LBO: G | 343 |
| LBO: H | 350 |
| LBO: I | 351 |
| LBO: M | 351 |
| LBO: N | 357 |
| LBO: P | 357 |
| LBO: R | 359 |
| LBO: S | 361 |
| LBO: V | 363 |

For full list of Logical binary inputs go to the chapter **Logical binary outputs alphabetically (page 330)**.

Logical binary outputs alphabetically

| | | | | | |
|-------------------------|-----|--------------------|-----|-----------------------|-----|
| AL AIN 1 Sd+BOC | 331 | Choke | 338 | Running | 360 |
| AL AIN 1 Wrn | 331 | Cooling Pump | 339 | Starter | 361 |
| AL AIN 2 Sd+BOC | 331 | ECU Communic Error | 339 | Stop Pulse | 362 |
| AL AIN 2 Wrn | 331 | ECU Communic OK | 339 | Stop Solenoid | 362 |
| AL AIN 3 Sd+BOC | 331 | ECU Power Relay | 340 | Ventilation | 363 |
| AL AIN 3 Wrn | 332 | ECU Red Lamp | 340 | Ventilation On Pulse | 363 |
| AL Battery Flat | 332 | ECU Run Stop | 341 | Ventilation Off Pulse | 364 |
| AL Battery Overvoltage | 332 | ECU Wait To Start | 341 | | |
| AL Battery Undervoltage | 332 | ECU Yellow Lamp | 341 | | |
| AL Battery Voltage | 332 | Exercise Timer 1 | 341 | | |
| AL Common BOC | 333 | Fault Reset | 342 | | |
| AL Common Fls | 333 | Frequency Select | 342 | | |
| AL Common Sd | 333 | Fuel Pump | 342 | | |
| AL Common Wrn | 333 | Fuel Solenoid | 342 | | |
| AL CoolantTemp Low | 334 | GCB Close/Open | 343 | | |
| AL CoolantTemp Sd | 334 | GCB OFF Coil | 345 | | |
| AL CoolantTemp Wrn | 334 | GCB ON Coil | 346 | | |
| AL D+ Fail | 334 | GCB UV Coil | 346 | | |
| AL Fuel Level Sd | 334 | Generator Healthy | 348 | | |
| AL Fuel Level Wrn | 335 | Glow Plugs | 348 | | |
| AL Mains Fail | 335 | Horn | 350 | | |
| AL Maintenance 1 | 335 | Idle/Nominal | 351 | | |
| AL Maintenance 2 | 335 | Mains Healthy | 351 | | |
| AL Maintenance 3 | 335 | MCB Close/Open | 351 | | |
| AL Oil Press Sd | 336 | MCB OFF Coil | 353 | | |
| AL Oil Press Wrn | 336 | MCB ON Coil | 354 | | |
| AL Overcurrent | 336 | MCB UV Coil | 355 | | |
| AL Overload BOC | 336 | Mode AUTO | 356 | | |
| AL Overload Wrn | 336 | Mode MAN | 357 | | |
| AL Overspeed | 337 | Mode OFF | 357 | | |
| AL Underspeed | 337 | Mode TEST | 357 | | |
| Alarm | 337 | Not In AUTO | 357 | | |
| ATT DEF Level Lamp | 337 | Not Used | 357 | | |
| ATT Filter Lamp | 337 | Prestart | 357 | | |
| ATT HEST Lamp | 338 | Ready To AMF | 359 | | |
| ATT Inhibited Lamp | 338 | Ready To Load | 359 | | |
| ATT SCR Error Lamp | 338 | Ready | 360 | | |

🔍 back to Controller objects

LBO: A

AL AIN 1 Sd+BOC

| | | | |
|---|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 1386 | | |
| Description | | | |
| The output is active when there is the shutdown or BOC alarm from the analog input 1 of the controller present in the alarmlist or isn't confirmed. | | | |

[◀ back to Logical binary outputs alphabetically](#)

AL AIN 1 Wrn

| | | | |
|---|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 1382 | | |
| Description | | | |
| the output is active when there is the warning alarm from the analog input 1 of the controller present in the alarmlist or isn't confirmed. | | | |

[◀ back to Logical binary outputs alphabetically](#)

AL AIN 2 Sd+BOC

| | | | |
|---|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 1387 | | |
| Description | | | |
| the output is active when there is the shutdown or BOC alarm from the analog input 2 of the controller present in the alarmlist or isn't confirmed. | | | |

[◀ back to Logical binary outputs alphabetically](#)

AL AIN 2 Wrn

| | | | |
|---|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 1383 | | |
| Description | | | |
| the output is active when there is the warning alarm from the analog input 2 of the controller present in the alarmlist or isn't confirmed. | | | |

[◀ back to Logical binary outputs alphabetically](#)

AL AIN 3 Sd+BOC

| | | | |
|---|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 1388 | | |
| Description | | | |
| the output is active when there is the shutdown or BOC alarm from the analog input 3 of the controller present in the alarmlist or isn't confirmed. | | | |

[◀ back to Logical binary outputs alphabetically](#)

AL AIN 3 Wrn

| | | | |
|---|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 1384 | | |
| Description | | | |
| the output is active when there is the warning alarm from the analog input 3 of the controller present in the alarmlist or isn't confirmed. | | | |

🔍 back to Logical binary outputs alphabetically

AL Battery Flat

| | | | |
|--|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 1292 | | |
| Description | | | |
| This output is active when the Sd Battery Flat (page 398) or Wrn Battery Undervoltage (page 391) alarm is present in the alarmlist or isn't confirm. | | | |

🔍 back to Logical binary outputs alphabetically

AL Battery Overvoltage

| | | | |
|--|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 1995 | | |
| Description | | | |
| This output is active when the Wrn Battery Overvoltage (page 391) alarm is present in the alarmlist or isn't confirm. | | | |

🔍 back to Logical binary outputs alphabetically

AL Battery Undervoltage

| | | | |
|---|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 1994 | | |
| Description | | | |
| This output is active when the Wrn Battery Undervoltage (page 391) alarm is present in the alarmlist or isn't confirm. | | | |


🔍 back to Logical binary outputs alphabetically

AL Battery Voltage

| | | | |
|--|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 1293 | | |
| Description | | | |
| This output is active when the Wrn Battery Overvoltage (page 391) or Wrn Battery Undervoltage (page 391) alarm is present in the alarmlist or isn't confirm. | | | |


🔍 back to Logical binary outputs alphabetically

AL Common BOC

| | | | |
|---|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 9 | | |
| Description | | | |
| Output is activated when any BOC alarm appears. | | | |
| The output opens, if: | | | |
| > No BOC alarm is active and | | | |
| > Fault reset  button is pressed | | | |


 [back to Logical binary outputs alphabetically](#)

AL Common FIs

| | | | |
|--|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 6 | | |
| Description | | | |
| Output is activated when any sensor fail alarm appears. | | | |
| The output opens, if: | | | |
| > No sensor fail alarm is active and | | | |
| > Fault reset  button is pressed | | | |


 [back to Logical binary outputs alphabetically](#)

AL Common Sd

| | | | |
|---|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 4 | | |
| Description | | | |
| Output is activated when any shutdown alarm appears. | | | |
| The output opens, if: | | | |
| > No shutdown alarm is active and | | | |
| > Fault reset  button is pressed | | | |

 [back to Logical binary outputs alphabetically](#)

AL Common Wrn

| | | | |
|---|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 3 | | |
| Description | | | |
| Output is activated when any warning alarm appears. | | | |
| The output opens, if: | | | |
| > No warning alarm is active and | | | |
| > Fault reset  button is pressed | | | |

 [back to Logical binary outputs alphabetically](#)

AL CoolantTemp Low

| | | | |
|--|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 1295 | | |
| Description | | | |
| the output is active when there is the Wrn Coolant Temperature Low (page 387) alarm from the COOLANT TEMP (PAGE 369) in the alarmlist or isn't confirmed. | | | |

🔍 back to Logical binary outputs alphabetically

AL CoolantTemp Sd

| | | | |
|--|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 1421 | | |
| Description | | | |
| the output is active when there is the shutdown or BOC alarm from the COOLANT TEMP (PAGE 369) in the alarmlist or isn't confirmed. | | | |

Logical binary outputs alphabetically (page 330)

AL CoolantTemp Wrn

| | | | |
|--|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 1420 | | |
| Description | | | |
| the output is active when there is the warning alarm from the COOLANT TEMP (PAGE 369) in the alarmlist or isn't confirmed. | | | |
| <i>Note: Binary output is also active if protection type is set to HistRecOnl and threshold level for history record is reach.</i> | | | |

🔍 back to Logical binary outputs alphabetically

AL D+ Fail

| | | | |
|---|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 1260 | | |
| Description | | | |
| This output is active when the Wrn Charging Alternator Fail (page 387) alarm is present in the alarmlist or isn't confirm. | | | |

🔍 back to Logical binary outputs alphabetically

AL Fuel Level Sd

| | | | |
|--|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 1423 | | |
| Description | | | |
| the output is active when there is the shutdown or BOC alarm from the FUEL LEVEL (PAGE 369) in the alarmlist or isn't confirmed. | | | |

🔍 back to Logical binary outputs alphabetically

AL Fuel Level Wrn

| | | | |
|--|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 1422 | | |
| Description | | | |
| The output is active when there is the warning alarm from the FUEL LEVEL (PAGE 369) in the alarmlist or isn't confirmed. | | | |
| <i>Note: Binary output is also active if protection type is set to HistRecOnl and threshold level for history record is reach.</i> | | | |

🔍 back to Logical binary outputs alphabetically

AL Mains Fail

| | | | |
|---|-------|-----------------------------|-----|
| Related FW | 1.6.0 | Related applications | AMF |
| Comm object | 197 | | |
| Description | | | |
| Output for signaling Mains Failure. This output is active when at least one mains frequency BOC or Sd alarm or at least one mains voltage BOC or Sd alarm is present in alarmlist or isn't confirmed. | | | |

🔍 back to Logical binary outputs alphabetically

AL Maintenance 1

| | | | |
|---|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 1254 | | |
| Description | | | |
| This output is active when the Alarm Maintenance 1 is present in the alarmlist. It means that counter of maintenance is on zero or the Alarm Maintenance 1 isn't confirm. | | | |

🔍 back to Logical binary outputs alphabetically

AL Maintenance 2

| | | | |
|---|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 1255 | | |
| Description | | | |
| This output is active when the Alarm Maintenance 2 is present in the alarmlist. It means that counter of maintenance is on zero or the Alarm Maintenance 2 isn't confirm. | | | |

🔍 back to Logical binary outputs alphabetically

AL Maintenance 3

| | | | |
|---|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 1256 | | |
| Description | | | |
| This output is active when the Alarm Maintenance 3 is present in the alarmlist. It means that counter of maintenance is on zero or the Alarm Maintenance 3 isn't confirm. | | | |

🔍 back to Logical binary outputs alphabetically

AL Oil Press Sd

| | | | |
|--|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 1419 | | |
| Description | | | |
| the output is active when there is the shutdown alarm from the OIL PRESSURE (PAGE 371) in the alarmlist or isn't confirmed. | | | |

🔍 back to Logical binary outputs alphabetically

AL Oil Press Wrn

| | | | |
|--|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 1418 | | |
| Description | | | |
| the output is active when there is the warning alarm from the OIL PRESSURE (PAGE 371) in the alarmlist or isn't confirmed. | | | |
| <i>Note: Binary output is also active if protection type is set to HistRecOnl and threshold level for history record is reach.</i> | | | |

🔍 back to Logical binary outputs alphabetically

AL Overcurrent

| | | | |
|--|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 109 | | |
| Description | | | |
| This output is active when the BOC Short Circuit (page 394) alarm is present in alarmlist or isn't confirm. | | | |

🔍 back to Logical binary outputs alphabetically

AL Overload BOC

| | | | |
|--|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 1268 | | |
| Description | | | |
| This output is active when the Sd Overload (page 398) alarm is present in the alarmlist or isn't confirm. | | | |

🔍 back to Logical binary outputs alphabetically

AL Overload Wrn

| | | | |
|---|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 1269 | | |
| Description | | | |
| This output is active when the Wrn Overload (page 387) alarm is present in alarmlist or isn't confirm. | | | |

🔍 back to Logical binary outputs alphabetically

AL Overspeed

| | | | |
|---|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 779 | | |
| Description | | | |
| This output is active when the Sd Overspeed (page 399) alarm is present in the alarmlist or isn't confirm. | | | |

◀ back to Logical binary outputs alphabetically

AL Underspeed

| | | | |
|--|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 1296 | | |
| Description | | | |
| This output is active when the Sd Underspeed (page 400) alarm is present in the alarmlist or isn't confirm. | | | |

◀ back to Logical binary outputs alphabetically

Alarm

| | | | |
|---|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 2 | | |
| Description | | | |
| The output is designed to be used as external alarm indication such as a red bulb in the control room etc. The output is active when at least one unconfirmed alarm is present in the alarmlist and remains active until confirmation of alarm. | | | |

◀ back to Logical binary outputs alphabetically

ATT DEF Level Lamp

| | | | |
|--|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 2154 | | |
| Description | | | |
| This output is active when ATT DEF Level Lamp is active. | | | |

◀ back to Logical binary outputs alphabetically

ATT Filter Lamp

| | | | |
|---|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 2152 | | |
| Description | | | |
| This output is active when ATT Filter Lamp is active. | | | |

◀ back to Logical binary outputs alphabetically

ATT HEST Lamp

| | | | |
|--|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 1373 | | |
| Description | | | |
| This output is closed if ECU send signal HEST Lamp. If ECU stop send HEST LAMP signal binary input will be opened without no matter if alarms in alarmlist are confirmed or not. | | | |

⬅ back to Logical binary outputs alphabetically

ATT Inhibited Lamp

| | | | |
|--|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 2155 | | |
| Description | | | |
| This output is active when ATT Inhibited Lamp is active. | | | |

⬅ back to Logical binary outputs alphabetically

ATT SCR Error Lamp

| | | | |
|--|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 2153 | | |
| Description | | | |
| This output is active when ATT SCR Error Lamp is active. | | | |

⬅ back to Logical binary outputs alphabetically

LBO: C

Choke

| | | | |
|---|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 2091 | | |
| Description | | | |
| Logical binary output for choke valve control. Output CHOKE is activated every time when logical binary output STARTER (PAGE 361) is activated. Output is deactivated when one of these conditions is fulfilled: | | | |
| <ul style="list-style-type: none">> Choke Time is elapsed> Generator voltage is higher than Choke Voltage> Logical binary input Choke Inhibit is activated | | | |
| Or when some of these situations during start occurs: | | | |
| <ul style="list-style-type: none">> Any second level alarm> Emergency stop> Stop command> Cranking pause | | | |

⬅ back to Logical binary outputs alphabetically

Cooling Pump

| | | | |
|---|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 40 | | |
| Description | | | |
| <p>This output is dedicated for coolant pump control. It is activated in the moment the Gen-set is started and remains active until the Gen-set is stopped and After Cooling Time (page 192) elapses or the cranking pause or the Emergency Stop occurs or the controller is switched to OFF mode.</p> | | | |
| | | | |
| Image 8.23 Cooling Pump | | | |

⬅ back to Logical binary outputs alphabetically

LBO: E

ECU Communic Error

| | | | |
|--|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 114 | | |
| Description | | | |
| <p>This output is active when an ECU is configured, but the communication with the ECU is not established or has dropped out.</p> | | | |
| <p>Note: When ECU POWER RELAY (PAGE 340) is not configured, output is evaluated all the time. If ECU POWER RELAY (PAGE 340) is configured, output is evaluated only when engine is not stop (ECU POWER RELAY (PAGE 340) is active).</p> | | | |

⬅ back to Logical binary outputs alphabetically

ECU Communic OK

| | | | |
|--|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 347 | | |
| Description | | | |
| <p>This output is active when an ECU is configured, connected and the communication with the ECU is established.</p> | | | |
| <p>Note: When ECU POWER RELAY (PAGE 340) is not configured, output is evaluated all the time. If ECU POWER RELAY (PAGE 340) is configured, output is evaluated only when engine is not stop (ECU POWER RELAY (PAGE 340) is active).</p> | | | |

⬅ back to Logical binary outputs alphabetically

ECU Power Relay

| | | | |
|--------------------|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 116 | | |

Description

This output is to be used for control of "keyswitch" input of an ECU. If the particular ECU does not have keyswitch or a similar input, it can be used for control of DC power for the ECU.

The output is activated together with **PRESTART (PAGE 357)** and remains active for the entire duration that the engine is running. It is deactivated at the moment that the engine comes to a stop (i.e. together with the **FUEL SOLENOID (PAGE 342)**).




Image 8.24 ECU Power Relay

IMPORTANT: This LBO also affects evaluation of **Sd ECU Communication Fail (page 394)** or **Wrn ECU Communication Fail (page 381)** alarms. With configured LBO ECU Power Relay, these alarms are evaluated only when this LBO is active. Without configured LBO ECU Power Relay, these alarm are evaluated all the time.

⬆️ back to Logical binary outputs alphabetically

ECU Red Lamp

| | | | |
|--------------------|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 350 | | |

Description

This output is active when the ECU sends an active "red lamp" flag, i.e. it has detected a critical malfunction and the engine should not be operated until a service check is performed. This flag is taken from the DM1 frame on standard J1939 ECUs. Some ECUs provide this flag in their own proprietary frames and some do not provide the flag at all.

⬆️ back to Logical binary outputs alphabetically

ECU Run Stop

| | | | |
|--|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 958 | | |
| Description | | | |
| Signal for starting and stopping of ECU. | | | |

🔍 back to Logical binary outputs alphabetically

ECU Wait To Start

| | | | |
|--|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 959 | | |
| Description | | | |
| This output is active when ECU Wait To Start Lamp is active. | | | |

🔍 back to Logical binary outputs alphabetically

ECU Yellow Lamp

| | | | |
|--|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 349 | | |
| Description | | | |
| This output is active when the ECU sends an active “yellow lamp” flag, i.e. it has detected a non-critical malfunction. This flag is taken from the DM1 frame on standard J1939 ECUs. Some ECUs provide this flag in their own proprietary frames and some do not provide the flag at all. | | | |

🔍 back to Logical binary outputs alphabetically

Exercise Timer 1

| | | | |
|---|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 1250 | | |
| Description | | | |
| This is an output from the Exercise timer 1. This output makes it easy to make periodic tests of the Gen-set and its activation depends on the setpoints in the Subgroup: Timer 1 (page 230) subgroup. This output is active when Timer 1 is active. | | | |

🔍 back to Logical binary outputs alphabetically

LBO: F

Fault Reset

| | | | |
|--|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 592 | | |
| Description | | | |
| This output provides 1s pulse when: | | | |
| <ul style="list-style-type: none">> Fault Reset button is pressed on the controller front facia or> Fault Reset button is pressed on any of external local/remote terminals or> Fault Reset command is received via communication line or> The input FAULT RESET BUTTON (PAGE 320) is activated. | | | |

⬅ back to Logical binary outputs alphabetically

Frequency Select

| | | | |
|---|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 1815 | | |
| Description | | | |
| The Frequency select output is active when Nominal Frequency (Frequency Settings) is equal to 50 Hz and is deactivated when Nominal Frequency (Frequency Settings) is equal to 60 Hz. | | | |

⬅ back to Logical binary outputs alphabetically

Fuel Pump

| | | | |
|--|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 1253 | | |
| Description | | | |
| Output is activated when the value of Fuel Level lies under the value of setpoint Fuel Pump On (page 201) and is deactivated when value of Fuel Pump Off (page 202) is reached. | | | |
| This output also can be activated by binary input FUEL PUMP ON/OFF (PAGE 320) . In this case the binary output is active until the binary input FUEL PUMP ON/OFF (PAGE 320) is active or until the value of Fuel Level reaches 100 % or the time set by setpoint Transfer Wrn Delay (page 200) elapsed. | | | |

⬅ back to Logical binary outputs alphabetically

Fuel Solenoid

| | | | |
|---|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 22 | | |
| Description | | | |
| This output controls the fuel solenoid valve. | | | |

The output is activated before binary output **STARTER (PAGE 361)**. The lead time is adjusted by setpoint **Fuel Solenoid Lead (page 186)**.




Image 8.25 Fuel Solenoid 1




Image 8.26 Fuel Solenoid 2

The output is deactivated when:

- > Emergency Stop comes
- > Cooled Gen-set is stopped
- > In pause between repeated starts

🔍 back to Logical binary outputs alphabetically

LBO: G

GCB Close/Open

| | | | |
|---|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 41 | | |
| Description | | | |
| The output controls the generator circuit breaker. Its state represents the breaker position requested by the controller. The breaker must react within 5 seconds to a close or open command, otherwise an alarm is issued. | | | |
| <i>Note: IntelliLite 9 controllers can work even without breaker feedbacks, in this case do not configure the feedback to binary inputs.</i> | | | |




Image 8.27 GCB Close command




Image 8.28 Repeated GCB Close command




Image 8.29 GCB Open command

🔍 back to Logical binary outputs alphabetically

GCB OFF Coil

| | | | |
|--------------------|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 43 | | |

Description

The output is intended for control of open coil of generator circuit breaker. The output gives a pulse in the moment the breaker has to be opened. The pulse lasts until the feedback deactivates, but at least for 5 seconds.

Image 8.30 GCB OFF Coil command

[back to Logical binary outputs alphabetically](#)

GCB ON Coil

| | | | |
|--------------------|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 42 | | |

Description

The output is intended for control of close coil of generator circuit breaker. The output gives at least 5 second pulse in the moment the breaker has to be closed.




Image 8.31 GCB ON Coil close command




Image 8.32 Repeated GCB ON coil close command

[back to Logical binary outputs alphabetically](#)

GCB UV Coil

| | | | |
|--------------------|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 44 | | |

Description

The output is intended for control of undervoltage coil of generator circuit breaker. The output is active the whole time when the generator is running. The output is deactivated for at least 5 seconds in the moment

the breaker has to be switched off.




Image 8.33 GCB UV Coil close command




Image 8.34 GCB UV Coil open command

🔍 back to Logical binary outputs alphabetically

Generator Healthy

| | | | |
|---|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 77 | | |
| Description | | | |
| <p>This output is active when the generator voltage and frequency is within limits. It is deactivated:</p> <ul style="list-style-type: none"> > immediately when the voltage/frequency gets out of limits (when GCB is not closed) or > with an appropriate delay after the voltage/frequency has got out of limits (when GCB is closed) | | | |

🔍 back to Logical binary outputs alphabetically

Glow Plugs

| | | | |
|--|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 1252 | | |
| Description | | | |
| <p>This output is dedicated for diesel engine only. This output will be active for exact time pre-set by setpoint Glow Plugs Time (page 178) before every starting attempt. The output is deactivated at the same time as the STARTER (PAGE 361) output is activated (100 ms after PRESTART (PAGE 357) output is deactivated).</p> | | | |
| <p>The diagram shows the timing of binary outputs and engine RPM during a starting attempt. The vertical axis represents Binary Outputs, and the horizontal axis represents Time. The outputs shown are Glow Plugs On/Off, Starter On/Off, and Prestart On/Off. A shaded area represents Engine RPM, which begins to rise after a 100 ms delay following the Prestart Off signal. Key timing intervals include Prestart Time, a 100 ms delay, Glow Plugs Time, and another 100 ms delay. The engine is running after the Starter On signal is activated.</p> | | | |
| Image 8.35 Glow Plugs | | | |

When the **Glow Plugs Time** (page 178) is longer than **Cranking Fail Pause** (page 176) then the **Glow Plugs Time** (page 178) in **Cranking Fail Pause** (page 176) is long as **Cranking Fail Pause** (page 176).




Image 8.36 Glow Plugs in Cranking Fail Pause 1

When the **Glow Plugs Time** (page 178) is shorter than **Cranking Fail Pause** (page 176) then the **Glow Plugs Time** (page 178) in **Cranking Fail Pause** (page 176) is long as normal **Glow Plugs Time** (page 178).






Image 8.37 Glow Plugs in Cranking Fail Pause 2

[back to Logical binary outputs alphabetically](#)

LBO: H


Horn

| | | | |
|--|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 1 | | |
| Description | | | |
| <p>The output designed to be used for acoustic indication of a newly appeared alarm. The output is activated each time a new alarm has appeared and remains active until one of the following events occurs:</p> <ul style="list-style-type: none">> Fault reset  is pressed> Horn reset  is pressed> Horn Timeout (page 172) has elapsed | | | |

 [back to Logical binary outputs alphabetically](#)

LBO: I

Idle/Nominal

| | | | |
|--|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 39 | | |
| Description | | | |
| <p>This output is used for switching between idle speed and nominal speed of the engine during the startup phase, if this feature (input) is available on the particular engine. In the case of some EFI engines, the idle/nominal switching is performed over the communication bus.</p> <p>The output Idle/Nominal is activated after the timer Idle Time (page 186) elapses. The Idle Time (page 186) starts to countdown when Starting RPM (page 177) reached. The underspeed protection is not evaluated during fixed 5 seconds period after reaching Starting RPM (page 177). A Start Fail protection occurs if the RPM drop below 2RPM during idle.</p> | | | |
|  <p>The diagram illustrates the engine's operational phases and the corresponding binary outputs. The 'Starting' phase begins with 'Starter On' and ends at 'Starting RPM'. The 'Idle' phase follows, with 'Idle Time' measured from 'Starting RPM' to 'Idle RPM'. The 'Idle Speed' phase is between 'Idle RPM' and 'Nominal RPM'. The 'Nominal Speed' phase begins at 'Nominal RPM'. The 'Idle/Nominal On' output is active during the 'Idle' and 'Idle Speed' phases, while 'Idle/Nominal Off' is active during the 'Starting' and 'Nominal Speed' phases. The 'Engine RPM' curve shows a ramp up during starting, a steady state during idle, and a further increase during nominal speed.</p> | | | |
| Image 8.38 Idle/Nominal | | | |
| <p>Note: Connect binary output Idle/Nominal to speed governor to switch the speed: opened = Idle closed = Nominal (for normally open contact type)</p> | | | |

⬅ back to Logical binary outputs alphabetically

LBO: M

Mains Healthy

| | | | |
|---|-------|-----------------------------|-----|
| Related FW | 1.6.0 | Related applications | AMF |
| Comm object | 78 | | |
| Description | | | |
| This output is active while Mains failure is not detected and Mains voltage and frequency is within limits. | | | |

⬅ back to Logical binary outputs alphabetically

MCB Close/Open

| | | | |
|-------------------|-------|-----------------------------|-----|
| Related FW | 1.6.0 | Related applications | AMF |
|-------------------|-------|-----------------------------|-----|

Description

The output controls the mains circuit breaker. Its state represents the breaker position requested by the controller. The breaker must react within 5 seconds to a close or open command, otherwise an alarm is issued.

Note: IntelliLite 9 controllers can work even without breaker feedbacks, in this case do not configure the feedback to binary inputs.




Image 8.39 MCB Close command




Image 8.40 Repeated MCB Close command




Image 8.41 MCB Open command

🔍 back to Logical binary outputs alphabetically

MCB OFF Coil

| | | | |
|--------------------|-------|-----------------------------|-----|
| Related FW | 1.6.0 | Related applications | AMF |
| Comm object | 47 | | |

Description

The output is intended for control of open coil of mains circuit breaker. The output gives a pulse in the moment the breaker has to be opened. The pulse lasts until the feedback deactivates, but at least for 5 seconds.




Image 8.42 MCB OFF Coil command

[back to Logical binary outputs alphabetically](#)

MCB ON Coil

| | | | |
|--------------------|-------|-----------------------------|-----|
| Related FW | 1.6.0 | Related applications | AMF |
| Comm object | 46 | | |

Description

The output is intended for control of close coil of mains circuit breaker. The output gives at least 5 second pulse in the moment the breaker has to be closed.




Image 8.43 MCB ON Coil close command




Image 8.44 Repeated MCB ON coil close command

[back to Logical binary outputs alphabetically](#)

MCB UV Coil

| | | | |
|--------------------|-------|-----------------------------|-----|
| Related FW | 1.6.0 | Related applications | AMF |
| Comm object | 48 | | |

Description

The output is intended for control of undervoltage coil of mains circuit breaker. The output is active the whole time when the controller is switched on. The output is deactivated for at least 5 seconds in the moment the breaker has to be switched off.




Image 8.45 MCB UV Coil close command




Image 8.46 MCB UV Coil open command




Image 8.47 MCB UV Coil close command




Image 8.48 MCB UV Coil close command

🔍 back to Logical binary outputs alphabetically

Mode AUTO

| | | | |
|--|-------|----------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 19 | | |
| Description | | | |
| This output is active whenever the controller is in AUTO mode. | | | |

🔍 back to Logical binary outputs alphabetically

Mode MAN

| | | | |
|---|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 18 | | |
| Description | | | |
| This output is active whenever the controller is in MAN mode. | | | |

[◀ back to Logical binary outputs alphabetically](#)

Mode OFF

| | | | |
|---|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 17 | | |
| Description | | | |
| This output is active whenever the controller is in OFF mode. | | | |

[◀ back to Logical binary outputs alphabetically](#)

Mode TEST

| | | | |
|--|-------|-----------------------------|-----|
| Related FW | 1.6.0 | Related applications | AMF |
| Comm object | 20 | | |
| Description | | | |
| This output is active whenever the controller is in TEST mode. | | | |

[◀ back to Logical binary outputs alphabetically](#)

LBO: N

Not In AUTO

| | | | |
|---|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 1248 | | |
| Description | | | |
| This output is active when controller isn't in AUTO mode. | | | |

[◀ back to Logical binary outputs alphabetically](#)

Not Used

| | | | |
|-------------------------|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 286 | | |
| Description | | | |
| Output has no function. | | | |

[◀ back to Logical binary outputs alphabetically](#)

LBO: P

Prestart

| | | | |
|--------------------|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 36 | | |
| Description | | | |

This output can be used for control of any device, which has to be activated just before start. the output is active for time period of **Prestart Time** (page 177). The output is deactivated 100 ms before the **STARTER** (PAGE 361) output is activated.




Image 8.49 Engine start

When the **Prestart Time** (page 177) is longer than **Cranking Fail Pause** (page 176) then the **Prestart Time** (page 177) in **Cranking Fail Pause** (page 176) is long as **Cranking Fail Pause** (page 176) minus 100 ms.




Image 8.50 Prestart in Cranking Fail Pause 1

When the **Prestart Time** (page 177) is shorter than **Cranking Fail Pause** (page 176) then the **Prestart Time** (page 177) in **Cranking Fail Pause** (page 176) is long as normal **Prestart Time** (page 177).




Image 8.51 Prestart in Cranking Fail Pause 2

🔍 back to Logical binary outputs alphabetically

LBO: R

Ready To AMF

| | | | |
|---|-------|-----------------------------|-----|
| Related FW | 1.6.0 | Related applications | AMF |
| Comm object | 324 | | |
| Description | | | |
| the output is active if the Gen-set is ready to start automatically and take the load if the mains fails, i.e.: | | | |
| <ul style="list-style-type: none"> ➤ the controller is in AMF operating mode ➤ the controller is in AUTO controller mode and ➤ no red alarm is present in the alarmlist ➤ when the red alarm is confirmed during Stop Valve and other requirements are fulfilled then the LBO is still inactive until the state ready | | | |

🔍 back to Logical binary outputs alphabetically

Ready To Load

| | | | |
|---|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 58 | | |
| Description | | | |
| the output is active whenever the GCB is closed or can be closed i.e. the stabilization phase is finished, the Gen-set is running and the Minimal Stabilization Time (page 188) timer has elapsed and the Gen-set voltage and frequency are within limits. | | | |
| If GCB is open then Gen-set voltage and frequency must be in limits. | | | |
| If GCB is close then Gen-set voltage and frequency can be out of limits, but protection delay can't be count down. If Gen-set voltage and frequency will return into limits until delay is count down then output is still active. | | | |

🔍 back to Logical binary outputs alphabetically

Ready

| | | | |
|--|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 62 | | |
| Description | | | |
| The binary output is active when the engine is stopped and it is possible to start it i.e. no red alarm is activated or SD OVERRIDE (PAGE 328) is active. | | | |
| The binary output is switch on when the Ready state occurs. | | | |
| The binary output is switch off when the Prestart or the Not Ready or the Stop state occurs i.e. always except Ready state. | | | |

◀ back to Logical binary outputs alphabetically

| | | | |
|---|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 1372 | | |
| Description | | | |
| This output is active when DPF lamp from ECU is active. | | | |

◀ back to Logical binary outputs alphabetically

Running

| | | | |
|---|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 67 | | |
| Description | | | |
| The output is designed to be used as an indication that the Gen-set is running. The output is activated if FUEL SOLENOID (PAGE 342) is active and STARTER (PAGE 361) and PRESTART (PAGE 357) are deactivated. The out remains active until engine stop and cooling period elapses. | | | |
| | | | |
| Image 8.52 Running | | | |

◀ back to Logical binary outputs alphabetically

LBO: S

Starter

| | | | |
|--------------------|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 24 | | |

Description

This output is dedicated for starter motor control. The number of cranking attempts is adjusted by setpoint **Cranking Attempts** (page 176) in Engine Settings group. Cranking fail pause is adjusted by setpoint **Cranking Fail Pause** (page 176).




Image 8.53 Starter

The starter output opens when:

- > the "firing" speed is reached (gas engines only)
- > maximum time of cranking is exceeded
- > request to stop comes up
- > D+ value is higher than **D+ Threshold** (page 184)
- > Oil pressure value is higher than **Starting Oil Pressure** (page 178)
- > Generator voltage >25 % of **Nominal Voltage Ph-N** (page 166) or **Nominal Voltage Ph-Ph** (page 167) (any phase)

🔍 back to Logical binary outputs alphabetically

Stop Pulse

| | | | |
|---|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 25 | | |
| Description | | | |
| Output is active for 1 second after STOP SOLENOID (PAGE 362) output activation. This signal is sent to ECU in case of engine stop request. | | | |

Image 8.54 Stop Pulse

🔍 back to Logical binary outputs alphabetically

Stop Solenoid

| | | | |
|---|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 23 | | |
| Description | | | |
| This output is dedicated to control the stop solenoid (valve). The output is activated when an engine stop command is received and is deactivated 12 s after last running engine indication went off, i.e. engine is stopped. | | | |

Image 8.55 Stop Solenoid 1




Image 8.56 Stop Solenoid 2

Note: If Additional running engine indications (page 117) went off during 5 s pause than Stop Solenoid is not activated again otherwise stop solenoid is activated again.

⬅ back to Logical binary outputs alphabetically

LBO: V

Ventilation

| | | | |
|---|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 38 | | |
| Description | | | |
| This logical binary output is activated at the beginning of start procedure together with PRESTART (PAGE 357) LBO . Ventilation output is deactivated when engine stops revolving. | | | |
| Ventilation LBO is also deactivated immediately when EMERGENCY STOP (PAGE 319) (or E-Stop) is activated or when controller is switched to OFF mode. | | | |
| Note: The output is intended for control of an engine room ventilation fan, engine container ventilation fan, container louvres or similar running gen-set technology. | | | |

⬅ back to Logical binary outputs alphabetically

Ventilation On Pulse

| | | | |
|---|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 2089 | | |
| Description | | | |
| This logical binary output is activated on rising edge of VENTILATION (PAGE 363) LBO (at the beginning of prestart period). The pulse duration is adjusted by Ventilation Pulse Time (page 206) setpoint. | | | |
| Note: The output is intended for control of an engine room ventilation fan, engine container ventilation fan, container louvres or similar running gen-set technology. | | | |

⬅ back to Logical binary outputs alphabetically

Ventilation Off Pulse

| | | | |
|--|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 2090 | | |
| Description | | | |
| This logical binary output is activated on falling edge of VENTILATION (PAGE 363) LBO (when engine stops). The pulse duration is adjusted by Ventilation Pulse Time (page 206) setpoint. | | | |
| Note: <i>The output is intended for control of an engine room ventilation fan, engine container ventilation fan, container louvres or similar running gen-set technology.</i> | | | |

🔍 [back to Logical binary outputs alphabetically](#)

8.1.6 Logical analog inputs

What Logical analog inputs are:

Logical analog inputs are inputs for analog values.

Alphabetical groups of Logical analog inputs

| | |
|--------------|-----|
| LAI: A | 366 |
| LAI: C | 369 |
| LAI: F | 369 |
| LAI: N | 371 |
| LAI: O | 371 |

For full list of Logical analog inputs go to the chapter **Logical analog inputs alphabetically (page 365)**.

Logical analog inputs alphabetically

| | |
|--------------------|-----|
| AIN Prot01 | 366 |
| AIN Prot02 | 367 |
| AIN Prot03 | 368 |
| Coolant Temp | 369 |
| Fuel Level | 369 |
| Not Used | 371 |
| Oil Pressure | 371 |

 **back to Controller objects**

LAI: A

AIN Prot01

| | | | |
|--------------------|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 9999 | | |

Description

Logical analog input designed for general value received from analog sensor. For more information about wiring of analog inputs **see Analog inputs on page 44**. Limits for this protection are adjusted by setpoints **Analog Protection 1 Wrn (page 223)** and **Analog Protection 1 Sd (page 224)**. Delay is adjusted by setpoint **Analog Protection 1 Delay (page 224)**.

Protection types

| | |
|------------|--|
| Monitoring | Analog value is only measured and displayed on the LCD screen but not used for protection. |
| HistRecOnl | Analog value is only measured and displayed on the LCD screen but not used for protection. History record is made if value is out of the limits. |
| AL Indic | Analog value is not used for protection. Only alarmlist record is made if analog value is out of the limits. |
| Wrn | Analog value is used for warning protection only. |
| Wrn + BOC | Analog value is used for warning and BOC (Breaker Open and Cooling) protection. |
| BOC | Analog value is used for BOC (Breaker Open and Cooling) protection. |
| Wrn + Sd | Analog value is used for warning and shutdown protection. |
| Sd | Analog value is used for shutdown protection. |

Note: This parameter has to be adjusted via *InteliConfig*.

Alarm

| | |
|-------------------|--|
| Under limit | Alarm is activated when value of analog input is under adjusted limits |
| Over limit | Alarm is activated when value of analog input is over adjusted limits |
| Under limit + fls | Alarm is activated when value of analog input is under adjusted limits. If sensor fail is detected then the alarm with higher level is activate as well. |
| Over limit + fls | Alarm is activated when value of analog input is over adjusted limits. If sensor fail is detected then the alarm with higher level is activate as well. |

Example: Protection type is Wrn + Sd. When sensor fail is detected then Sd alarm will be activated + Sensor fail alarm will be activated.

Note: This parameter has to be adjusted via *InteliConfig*.

🔍 back to Logical analog inputs alphabetically

AIN Prot02

| | | | |
|--------------------|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 9998 | | |

Description

Logical analog input designed for general value received from analog sensor. For more information about wiring of analog inputs **see Analog inputs on page 44**. Limits for this protection are adjusted by setpoints **Analog Protection 2 Wrn (page 225)** and **Analog Protection 2 Sd (page 225)**. Delay is adjusted by setpoint **Analog Protection 2 Delay (page 226)**.

Protection types

| | |
|------------|--|
| Monitoring | Analog value is only measured and displayed on the LCD screen but not used for protection. |
| HistRecOnl | Analog value is only measured and displayed on the LCD screen but not used for protection. History record is made if value is out of the limits. |
| AL Indic | Analog value is not used for protection. Only alarmlist record is made if analog value is out of the limits. |
| Wrn | Analog value is used for warning protection only. |
| Wrn + BOC | Analog value is used for warning and BOC (Breaker Open and Cooling) protection. |
| BOC | Analog value is used for BOC (Breaker Open and Cooling) protection. |
| Wrn + Sd | Analog value is used for warning and shutdown protection. |
| Sd | Analog value is used for shutdown protection. |

Note: This parameter has to be adjusted via *InteliConfig*.

Alarm

| | |
|-------------------|--|
| Under limit | Alarm is activated when value of analog input is under adjusted limits |
| Over limit | Alarm is activated when value of analog input is over adjusted limits |
| Under limit + fls | Alarm is activated when value of analog input is under adjusted limits. If sensor fail is detected then the alarm with higher level is activate as well. |
| Over limit + fls | Alarm is activated when value of analog input is over adjusted limits. If sensor fail is detected then the alarm with higher level is activate as well. |

Example: Protection type is Wrn + Sd. When sensor fail is detected then Sd alarm will be activated + Sensor fail alarm will be activated.

Note: This parameter has to be adjusted via *InteliConfig*.

🔍 back to Logical analog inputs alphabetically

AIN Prot03

| | | | |
|--------------------|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 9997 | | |

Description

Logical analog input designed for general value received from analog sensor. For more information about wiring of analog inputs **see Analog inputs on page 44**. Limits for this protection are adjusted by setpoints **Analog Protection 3 Wrn (page 226)** and **Analog Protection 3 Sd (page 227)**. Delay is adjusted by setpoint **Analog Protection 3 Delay (page 227)**.

Protection types

| | |
|------------|--|
| Monitoring | Analog value is only measured and displayed on the LCD screen but not used for protection. |
| HistRecOnl | Analog value is only measured and displayed on the LCD screen but not used for protection. History record is made if value is out of the limits. |
| AL Indic | Analog value is not used for protection. Only alarmlist record is made if analog value is out of the limits. |
| Wrn | Analog value is used for warning protection only. |
| Wrn + BOC | Analog value is used for warning and BOC (Breaker Open and Cooling) protection. |
| BOC | Analog value is used for BOC (Breaker Open and Cooling) protection. |
| Wrn + Sd | Analog value is used for warning and shutdown protection. |
| Sd | Analog value is used for shutdown protection. |

Note: This parameter has to be adjusted via *InteliConfig*.

Alarm

| | |
|-------------------|--|
| Under limit | Alarm is activated when value of analog input is under adjusted limits |
| Over limit | Alarm is activated when value of analog input is over adjusted limits |
| Under limit + fls | Alarm is activated when value of analog input is under adjusted limits. If sensor fail is detected then the alarm with higher level is activate as well. |
| Over limit + fls | Alarm is activated when value of analog input is over adjusted limits. If sensor fail is detected then the alarm with higher level is activate as well. |

Example: Protection type is Wrn + Sd. When sensor fail is detected then Sd alarm will be activated + Sensor fail alarm will be activated.

Note: This parameter has to be adjusted via *InteliConfig*.

🔍 back to Logical analog inputs alphabetically

LAI: C

Coolant Temp

| | | | |
|--------------------|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 67 | | |

Description

Logical analog input designed for coolant temperature value received from analog sensor. For more information about wiring of analog inputs **see Analog inputs on page 44**. Limits for this protection are adjusted by setpoints **Coolant Temperature Wrn (page 195)** and **Coolant Temperature BOC (page 196)**. Delay is adjusted by setpoint **Coolant Temperature Delay (page 196)**.

Protection types

| | |
|------------|--|
| Monitoring | Analog value is only measured and displayed on the LCD screen but not used for protection. |
| HistRecOnI | Analog value is only measured and displayed on the LCD screen but not used for protection. History record is made if value is out of the limits. |
| Wrn | Analog value is used for warning protection only. |
| Wrn + BOC | Analog value is used for warning and BOC (Breaker Open and Cooling) protection. |
| BOC | Analog value is used for BOC (Breaker Open and Cooling) protection. |
| Wrn + Sd | Analog value is used for warning and shutdown protection. |
| Sd | Analog value is used for shutdown protection. |

Note: This parameter has to be adjusted via *InteliConfig*.

Alarm

| | |
|-------------------|--|
| Under limit | Alarm is activated when value of analog input is under adjusted limits |
| Over limit | Alarm is activated when value of analog input is over adjusted limits |
| Under limit + fls | Alarm is activated when value of analog input is under adjusted limits. If sensor fail is detected then the alarm with higher level is activate as well. |
| Over limit + fls | Alarm is activated when value of analog input is over adjusted limits. If sensor fail is detected then the alarm with higher level is activate as well. |

Example: Protection type is Wrn + Sd. When sensor fail is detected then Sd alarm will be activated + Sensor fail alarm will be activated.

Note: This parameter has to be adjusted via *InteliConfig*.

IMPORTANT: Value from analog input has higher priority than value from ECU.

🔍 back to Logical analog inputs alphabetically

LAI: F

Fuel Level

| | | | |
|--------------------|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 78 | | |

Description

Logical analog input designed for fuel level value received from analog sensor. For more information about wiring of analog inputs **see Analog inputs on page 44**. Limits for this protection are adjusted by setpoints **Fuel Level Wrn (page 198)** and **Fuel Level Sd (page 198)**. Delay is adjusted by setpoint **Fuel Level Delay (page 199)**.

Protection types

| | |
|------------|--|
| Monitoring | Analog value is only measured and displayed on the LCD screen but not used for protection. |
| HistRecOnI | Analog value is only measured and displayed on the LCD screen but not used for protection. History record is made if value is out of the limits. |
| Wrn | Analog value is used for warning protection only. |
| Wrn + BOC | Analog value is used for warning and BOC (Breaker Open and Cooling) protection. |
| BOC | Analog value is used for BOC (Breaker Open and Cooling) protection. |
| Wrn + Sd | Analog value is used for warning and shutdown protection. |
| Sd | Analog value is used for shutdown protection. |

Note: This parameter has to be adjusted via *InteliConfig*.

Alarm

| | |
|-------------------|--|
| Under limit | Alarm is activated when value of analog input is under adjusted limits |
| Over limit | Alarm is activated when value of analog input is over adjusted limits |
| Under limit + fls | Alarm is activated when value of analog input is under adjusted limits. If sensor fail is detected then the alarm with higher level is activate as well. |
| Over limit + fls | Alarm is activated when value of analog input is over adjusted limits. If sensor fail is detected then the alarm with higher level is activate as well. |

Example: Protection type is Wrn + Sd. When sensor fail is detected then Sd alarm will be activated + Sensor fail alarm will be activated.

Note: This parameter has to be adjusted via *InteliConfig*.

IMPORTANT: For right behavior of this function, curve for analog input has to be in percentage.

IMPORTANT: Value from analog input has higher priority than value from ECU.

[◀ back to Logical analog inputs alphabetically](#)

LAI: N

Not Used

| | | | |
|------------------------|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 230 | | |
| Description | | | |
| Input has no function. | | | |

🔍 back to Logical analog inputs alphabetically

LAI: O

Oil Pressure

| | | | |
|--------------------|-------|-----------------------------|----------|
| Related FW | 1.6.0 | Related applications | AMF, MRS |
| Comm object | 9 | | |
| Description | | | |

Logical analog input designed for oil pressure value received from analog sensor. Limits for this protection are adjusted by setpoints **Oil Pressure Wrn** (page 193) and **Oil Pressure Sd** (page 194). Delay is adjusted by setpoint **Oil Pressure Delay** (page 194).

Protection types

| | |
|------------|--|
| Monitoring | Analog value is only measured and displayed on the LCD screen but not used for protection. |
| HistRecOnl | Analog value is only measured and displayed on the LCD screen but not used for protection. History record is made if value is out of the limits. |
| Wrn | Analog value is used for warning protection only. |
| Wrn + Sd | Analog value is used for warning and Sd protection. |
| Sd | Analog value is used for Sd protection. |

Note: This parameter has to be adjusted via *InteliConfig*.

Alarm

| | |
|-------------------|--|
| Under limit | Alarm is activated when value of analog input is under adjusted limits |
| Over limit | Alarm is activated when value of analog input is over adjusted limits |
| Under limit + fls | Alarm is activated when value of analog input is under adjusted limits. If sensor fail is detected then the alarm with higher level is activate as well. |
| Over limit + fls | Alarm is activated when value of analog input is over adjusted limits. If sensor fail is detected then the alarm with higher level is activate as well. |

Example: Protection type is Wrn + Sd. When sensor fail is detected then Sd alarm will be activated + Sensor fail alarm will be activated.

Note: This parameter has to be adjusted via *InteliConfig*.

IMPORTANT: Value from analog input has higher priority than value from ECU.

🔍 back to Logical analog inputs alphabetically

8.2 Alarms

What alarms are:

The controller evaluates two levels of alarms. For more information see **Alarm management on page 99**.

8.2.1 Alarm levels in the controller

| | |
|---|-----|
| 8.2.2 Alarms level 1 | 372 |
| 8.2.3 Alarms level 2 | 392 |
| 8.2.4 Fail sensor and other types | 401 |

8.2.2 Alarms level 1

What alarms level 1 are:

The level 1 alarm indicates that a value or parameter is out of normal limits, but has still not reached critical level.

List of alarms level 1

| | | | | | |
|----------------------------|-----|---------------------------|-----|---------------------------|-----|
| After-Treatment | 374 | Wrn ECU Communication | | Module(slotA) - unknown | |
| AI/Hist.msg. 1 | 374 | Fail | 381 | module | 386 |
| AI/Hist.msg. 2 | 374 | Wrn Generator L1 | | Wrn Overload | 387 |
| AI/Hist.msg. 3 | 374 | Overvoltage | 381 | PasswEnterBlock | 387 |
| AI/Hist.msg. 4 | 374 | Wrn Generator L1 | | Transferring Fuel | 387 |
| AI/Hist.msg. 5 | 374 | Undervoltage | 382 | Wrn Charging Alternator | |
| AI/Hist.msg. 6 | 375 | Wrn Generator L1L2 | | Fail | 387 |
| AI/Hist.msg. 7 | 375 | Overvoltage | 382 | Wrn Coolant | |
| AI/Hist.msg. 8 | 375 | Wrn Generator L1L2 | | Temperature Low | 387 |
| AI/Hist.msg. 9 | 375 | Undervoltage | 382 | Wrn Mains Voltage | |
| AI/Hist.msg. 10 | 375 | Wrn Generator L2 | | Detected | 388 |
| AI/Hist.msg. 11 | 376 | Overvoltage | 382 | Wrn Maintenance 1 | 388 |
| AI/Hist.msg. 12 | 376 | Wrn Generator L2 | | Wrn Maintenance 2 | 388 |
| AI/Hist.msg. 13 | 376 | Undervoltage | 383 | Wrn Maintenance 3 | 389 |
| AI/Hist.msg. 14 | 376 | Wrn Generator L2L3 | | Wrn MCB Fail | 389 |
| AI/Hist.msg. 15 | 376 | Overvoltage | 383 | Wrn Oil Pressure | 389 |
| AI/Hist.msg. 16 | 377 | Wrn Generator L2L3 | | Wrn Override All Sd | 390 |
| Alarm Email 1 Fail | 377 | Undervoltage | 383 | Wrn Stop Fail | 390 |
| Alarm SMS 1 Fail | 377 | Wrn Generator L3 | | Wrong Config | 390 |
| ATT DEF Level Lamp | 377 | Overvoltage | 383 | Generator CCW Rotation | 390 |
| ATT Filter Lamp | 377 | Wrn Generator L3 | | Manual Restore | 391 |
| ATT HEST Lamp | 378 | Undervoltage | 384 | Wrn Battery Overvoltage | 391 |
| ATT Inhibited Lamp | 378 | Wrn Generator L3L1 | | Wrn Battery Undervoltage | 391 |
| ATT SCR Error Lamp | 378 | Overvoltage | 384 | Mains CCW Rotation | 391 |
| ECU Red Lamp | 378 | Wrn Generator L3L1 | | | |
| ECU Wait To Start | 378 | Undervoltage | 384 | | |
| ECU Yellow Lamp | 379 | Wrn Generator | | | |
| ECUdiagBlocked | 379 | Overfrequency | 384 | | |
| EM(A) - a message lost .. | 379 | Wrn Generator | | | |
| EM(A) - configuration | | Uderfrequency | 385 | | |
| mistake | 379 | Mains Overfrequency | 385 | | |
| EM(A) - insufficient | 380 | Mains Underfrequency ... | 385 | | |
| EM(A) - missing or | | Module(slotA) - comm. | | | |
| damaged | 380 | outage | 385 | | |
| Event Email 1 Fail | 380 | Module(slotA) - false | | | |
| Event SMS 1 Fail | 380 | module | 386 | | |
| Fuel Transfer Failed | 380 | Module(slotA) - | | | |
| Wrn Default Credentials . | 381 | unattended | 386 | | |
| | | Module(slotA) - | | | |
| | | unexpected | 386 | | |

 [back to Alarms](#)

After-Treatment

| | |
|----------------------|--|
| Alarm Type | ALI |
| Alarmlist message | After-Treatment |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | This alarm occurs when appropriate after-treatment lamp is active. |

[◀ back to List of fail sensor](#)

AI/Hist.msg. 1

| | |
|----------------------|---|
| Alarm Type | WRN |
| Alarmlist message | AI/Hist.msg. 1 |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | This alarm is issued when history event 1 will trigger. |

[◀ back to List of alarms level 1](#)

AI/Hist.msg. 2

| | |
|----------------------|---|
| Alarm Type | WRN |
| Alarmlist message | AI/Hist.msg. 2 |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | This alarm is issued when history event 2 will trigger. |

[◀ back to List of alarms level 1](#)

AI/Hist.msg. 3

| | |
|----------------------|---|
| Alarm Type | WRN |
| Alarmlist message | AI/Hist.msg. 3 |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | This alarm is issued when history event 3 will trigger. |

[◀ back to List of alarms level 1](#)

AI/Hist.msg. 4

| | |
|----------------------|---|
| Alarm Type | WRN |
| Alarmlist message | AI/Hist.msg. 4 |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | This alarm is issued when history event 4 will trigger. |

[◀ back to List of alarms level 1](#)

AI/Hist.msg. 5

| | |
|------------|-----|
| Alarm Type | WRN |
|------------|-----|

| | |
|-----------------------------|---|
| Alarmlist message | AI/Hist.msg. 5 |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | This alarm is issued when history event 5 will trigger. |

🔍 back to List of alarms level 1

AI/Hist.msg. 6

| | |
|-----------------------------|---|
| Alarm Type | WRN |
| Alarmlist message | AI/Hist.msg. 6 |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | This alarm is issued when history event 6 will trigger. |

🔍 back to List of alarms level 1

AI/Hist.msg. 7

| | |
|-----------------------------|---|
| Alarm Type | WRN |
| Alarmlist message | AI/Hist.msg. 7 |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | This alarm is issued when history event 7 will trigger. |

🔍 back to List of alarms level 1

AI/Hist.msg. 8

| | |
|-----------------------------|---|
| Alarm Type | WRN |
| Alarmlist message | AI/Hist.msg. 8 |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | This alarm is issued when history event 8 will trigger. |

🔍 back to List of alarms level 1

AI/Hist.msg. 9

| | |
|-----------------------------|---|
| Alarm Type | WRN |
| Alarmlist message | AI/Hist.msg. 9 |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | This alarm is issued when history event 9 will trigger. |

🔍 back to List of alarms level 1

AI/Hist.msg. 10

| | |
|-----------------------------|-----------------|
| Alarm Type | WRN |
| Alarmlist message | AI/Hist.msg. 10 |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |

| | |
|--------------------|--|
| Description | This alarm is issued when history event 10 will trigger. |
|--------------------|--|

🔍 back to List of alarms level 1

AI/Hist.msg. 11

| | |
|-----------------------------|--|
| Alarm Type | WRN |
| Alarmlist message | AI/Hist.msg. 11 |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | This alarm is issued when history event 11 will trigger. |

🔍 back to List of alarms level 1

AI/Hist.msg. 12

| | |
|-----------------------------|--|
| Alarm Type | WRN |
| Alarmlist message | AI/Hist.msg. 12 |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | This alarm is issued when history event 12 will trigger. |

🔍 back to List of alarms level 1

AI/Hist.msg. 13

| | |
|-----------------------------|--|
| Alarm Type | WRN |
| Alarmlist message | AI/Hist.msg. 13 |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | This alarm is issued when history event 13 will trigger. |

🔍 back to List of alarms level 1

AI/Hist.msg. 14

| | |
|-----------------------------|--|
| Alarm Type | WRN |
| Alarmlist message | AI/Hist.msg. 14 |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | This alarm is issued when history event 14 will trigger. |

🔍 back to List of alarms level 1

AI/Hist.msg. 15

| | |
|-----------------------------|--|
| Alarm Type | WRN |
| Alarmlist message | AI/Hist.msg. 1 |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | This alarm is issued when history event 15 will trigger. |

🔍 back to List of alarms level 1

AI/Hist.msg. 16

| | |
|-----------------------------|--|
| Alarm Type | WRN |
| Alarmlist message | AI/Hist.msg. 16 |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | This alarm is issued when history event 16 will trigger. |

🔍 back to List of alarms level 1

Alarm Email 1 Fail

| | |
|-----------------------------|---|
| Alarm Type | WRN |
| Alarmlist message | Alarm Email 1 Fail |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | The alarm indicates that there was a request to send an alarm email to email address which is adjusted in setpoint Email Address 1 (page 248) and email wasn't send. |

🔍 back to List of alarms level 1

Alarm SMS 1 Fail

| | |
|-----------------------------|---|
| Alarm Type | WRN |
| Alarmlist message | Alarm SMS 1 Fail |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | The alarm indicates that there was a request to send an alarm SMS to telephone number which is adjusted in setpoint Telephone Number 1 (page 247) and SMS wasn't sent. |

🔍 back to List of alarms level 1

ATT DEF Level Lamp

| | |
|-----------------------------|--|
| Alarm Type | AHI |
| Alarmlist message | ATT DEF Level Lamp |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | This alarm is issued to indicate DEF Level lamp. |

🔍 back to List of alarms level 1

ATT Filter Lamp

| | |
|-----------------------------|---|
| Alarm Type | AHI |
| Alarmlist message | ATT Filter Lamp |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | This alarm is issued to indicate the ATT Filter lamp. |

🔍 back to List of alarms level 1

ATT HEST Lamp

| | |
|----------------------|---|
| Alarm Type | AHI |
| Alarmlist message | ATT HEST Lamp |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | This alarm is issued to indicate HEST Lamp. |

🔍 back to List of alarms level 1

ATT Inhibited Lamp

| | |
|----------------------|--|
| Alarm Type | AHI |
| Alarmlist message | ATT Inhibited Lamp |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | This alarm is issued to indicate Inhibited Lamp. |

🔍 back to List of alarms level 1

ATT SCR Error Lamp

| | |
|----------------------|--|
| Alarm Type | AHI |
| Alarmlist message | ATT SCR Error Lamp |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | This alarm is issued to indicate SCR error lamp. |

🔍 back to List of alarms level 1

ECU Red Lamp

| | |
|----------------------|---|
| Alarm Type | AHI |
| Alarmlist message | ECU Red Lamp |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | This alarm occurs when an red ECU alarm is logged in Alarm List. Note: This lamp can be ignored during prestart phase. Use IntelliConfig to enable this function. |

🔍 back to List of alarms level 1

ECU Wait To Start

| | |
|----------------------|--|
| Alarm Type | AHI |
| Alarmlist message | ECU Wait To Start |
| Alarm evaluated | Only when ECU is connected |
| Related applications | AMF, MRS |
| Description | This alarm is activated when ECU send information that ECU Wait To Start lamp is activated. LBO ALARM (PAGE 337) is not activated, after deactivation of lamp, alarm automatically disappears. |

[back to List of alarms level 1](#)

ECU Yellow Lamp

| | |
|----------------------|---|
| Alarm Type | AHI |
| Alarmlist message | ECU Yellow Lamp |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | This alarm is activated when ECU send information that ECU Yellow lamp is activated. LBO ALARM (PAGE 337) is not activated, after deactivation of lamp, alarm automatically disappears. |

[back to List of alarms level 1](#)

ECUdiagBlocked

| | |
|----------------------|--|
| Alarm Type | ALI |
| Alarmlist message | ECUdiagBlocked |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | LBO ALARM (PAGE 337) is not activated, after deactivation of lamp, alarm automatically disappears. |

[back to List of alarms level 1](#)

EM(A) - a message lost

| | |
|----------------------|--|
| Alarm Type | WRN |
| Alarmlist message | EM(A) - a message lost |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | This alarm indicates that there is a problem with communication between controller and module in slot. |

[back to List of alarms level 1](#)

EM(A) - configuration mistake

| | |
|----------------------|--|
| Alarm Type | WRN |
| Alarmlist message | EM(A) - configuration mistake |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | This alarm indicates that there is a problem with configuration of binary input or output of module in slot. |

[back to List of alarms level 1](#)

EM(A) - insufficient

| | |
|----------------------|--|
| Alarm Type | WRN |
| Alarmlist message | EM(A) - insufficient |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | This alarm indicates that module does not support all required features. |

🔍 back to List of alarms level 1

EM(A) - missing or damaged

| | |
|----------------------|--|
| Alarm Type | WRN |
| Alarmlist message | EM(A) - missing or damaged |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | This alarm indicates that there is a problem with communication with module in slot (in first 5 second there was no communication and module is configured in slot). |

🔍 back to List of alarms level 1

Event Email 1 Fail

| | |
|----------------------|---|
| Alarm Type | WRN |
| Alarmlist message | Event Email 1 Fail |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | The alarm indicates that there was a request to send an event email to email address which is adjusted in setpoint Email Address 1 (page 248) and email wasn't send. |

🔍 back to List of alarms level 1

Event SMS 1 Fail

| | |
|----------------------|---|
| Alarm Type | WRN |
| Alarmlist message | Event SMS 1 Fail |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | The alarm indicates that there was a request to send an event SMS to telephone number which is adjusted in setpoint Telephone Number 1 (page 247) and SMS wasn't send. |

🔍 back to List of alarms level 1

Fuel Transfer Failed

| | |
|----------------------|----------------------|
| Alarm Type | ALI |
| Alarmlist message | Fuel Transfer Failed |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |

| | |
|--------------------|--|
| Description | |
|--------------------|--|

🔍 back to List of alarms level 1

Wrn Default Credentials

| | |
|-----------------------------|--|
| Alarm Type | WRN |
| Alarmlist message | Wrn Default Credentials |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | The alarm is issued if the factory default password and/or access code are used. Factory default password and access code are "0". |

🔍 back to List of alarms level 1

Wrn ECU Communication Fail

| | |
|-----------------------------|---|
| Alarm Type | WRN |
| Alarmlist message | Wrn ECU Communication Fail |
| Alarm evaluated | With configured LBO ECU POWER RELAY (PAGE 340) - only when this LBO is active Without configured LBO ECU POWER RELAY (PAGE 340) - all the time |
| Related applications | AMF, MRS |
| Description | This alarm occurs when an ECU is configured, but the communication with the ECU is not established or has dropped out. |

🔍 back to List of alarms level 1

Wrn Fuel Transfer Failed

| | |
|-----------------------------|---|
| Alarm Type | Warning |
| Alarmlist message | Wrn Fuel Transfer Failed |
| Alarm evaluated | When FUEL PUMP (PAGE 342) is active |
| Related applications | AMF, MRS |
| Description | This alarm will occur when there is no increase of fuel level when FUEL PUMP (PAGE 342) is active. |

🔍 back to List of alarms level 1

Wrn Generator L1 Overvoltage

| | |
|-----------------------------|---|
| Alarm Type | WRN |
| Alarmlist message | Generator L1 > Voltage |
| Alarm evaluated | Generator excited only |
| Related applications | AMF, MRS |
| Description | This alarm evaluates the generator phase voltage in phase 1. The following setpoints are related to it: <ul style="list-style-type: none"> ➤ Generator Overvoltage Wrn (page 209) ➤ Generator <> Voltage Delay (page 211) |

🔍 back to List of alarms level 1

Wrn Generator L1 Undervoltage

| | |
|-----------------------------|---|
| Alarm Type | WRN |
| Alarmlist message | Generator L1 < Voltage |
| Alarm evaluated | Generator excited only |
| Related applications | AMF, MRS |
| Description | This alarm evaluates the generator phase voltage in phase 1. The following setpoints are related to it: <ul style="list-style-type: none">> Generator Undervoltage Wrn (page 210)> Generator <> Voltage Delay (page 211) |

⬅ back to List of alarms level 1

Wrn Generator L1L2 Overvoltage

| | |
|-----------------------------|---|
| Alarm Type | WRN |
| Alarmlist message | Generator L1L2 > Voltage |
| Alarm evaluated | Generator excited only |
| Related applications | AMF, MRS |
| Description | This alarm evaluates the generator phase to phase voltage between phases 1 and 2. The following setpoints are related to it: <ul style="list-style-type: none">> Generator Overvoltage Wrn (page 209)> Generator <> Voltage Delay (page 211) |

⬅ back to List of alarms level 1

Wrn Generator L1L2 Undervoltage

| | |
|-----------------------------|--|
| Alarm Type | WRN |
| Alarmlist message | Generator L1L2 < Voltage |
| Alarm evaluated | Generator excited only |
| Related applications | AMF, MRS |
| Description | This alarm evaluates the generator phase to phase voltage between phases 1 and 2. The following setpoints are related to it: <ul style="list-style-type: none">> Generator Undervoltage Wrn (page 210)> Generator <> Voltage Delay (page 211) |

⬅ back to List of alarms level 1

Wrn Generator L2 Overvoltage

| | |
|-----------------------------|--|
| Alarm Type | WRN |
| Alarmlist message | Generator L2 > Voltage |
| Alarm evaluated | Generator excited only |
| Related applications | AMF, MRS |
| Description | This alarm evaluates the generator phase voltage in phase 2. The following setpoints are related to it: <ul style="list-style-type: none">> Generator Overvoltage Wrn (page 209)> Generator <> Voltage Delay (page 211) |

⬅ back to List of alarms level 1

Wrn Generator L2 Undervoltage

| | |
|-----------------------------|---|
| Alarm Type | WRN |
| Alarmlist message | Generator L2 < Voltage |
| Alarm evaluated | Generator excited only |
| Related applications | AMF, MRS |
| Description | This alarm evaluates the generator phase voltage in phase 2. The following setpoints are related to it: <ul style="list-style-type: none">> Generator Undervoltage Wrn (page 210)> Generator <> Voltage Delay (page 211) |

⬅ back to List of alarms level 1

Wrn Generator L2L3 Overvoltage

| | |
|-----------------------------|---|
| Alarm Type | WRN |
| Alarmlist message | Generator L2L3 > Voltage |
| Alarm evaluated | Generator excited only |
| Related applications | AMF, MRS |
| Description | This alarm evaluates the generator phase to phase voltage between phases 2 and 3. The following setpoints are related to it: <ul style="list-style-type: none">> Generator Overvoltage Wrn (page 209)> Generator <> Voltage Delay (page 211) |

⬅ back to List of alarms level 1

Wrn Generator L2L3 Undervoltage

| | |
|-----------------------------|--|
| Alarm Type | WRN |
| Alarmlist message | Generator L2L3 < Voltage |
| Alarm evaluated | Generator excited only |
| Related applications | AMF, MRS |
| Description | This alarm evaluates the generator phase to phase voltage between phases 2 and 3. The following setpoints are related to it: <ul style="list-style-type: none">> Generator Undervoltage Wrn (page 210)> Generator <> Voltage Delay (page 211) |

⬅ back to List of alarms level 1

Wrn Generator L3 Overvoltage

| | |
|-----------------------------|---|
| Alarm Type | WRN |
| Alarmlist message | Generator L3 > Voltage |
| Alarm evaluated | Generator excited only |
| Related applications | AMF, MRS |
| Description | This alarm evaluates the generator phase voltage in phase 3. The following setpoints are related to it: <ul style="list-style-type: none">> Generator Overvoltage Wrn (page 209) |

| | |
|--|--|
| | > Generator <> Voltage Delay (page 211) |
|--|--|

[back to List of alarms level 1](#)

Wrn Generator L3 Undervoltage

| | |
|-----------------------------|---|
| Alarm Type | WRN |
| Alarmlist message | Generator L3 < Voltage |
| Alarm evaluated | Generator excited only |
| Related applications | AMF, MRS |
| Description | <p>This alarm evaluates the generator phase voltage in phase 3. The following setpoints are related to it:</p> <ul style="list-style-type: none"> > Generator Undervoltage Wrn (page 210) > Generator <> Voltage Delay (page 211) |

[back to List of alarms level 1](#)

Wrn Generator L3L1 Overvoltage

| | |
|-----------------------------|---|
| Alarm Type | WRN |
| Alarmlist message | Generator L3L1 > Voltage |
| Alarm evaluated | Generator excited only |
| Related applications | AMF, MRS |
| Description | <p>This alarm evaluates the generator phase to phase voltage between phases 3 and 1. The following setpoints are related to it:</p> <ul style="list-style-type: none"> > Generator Overvoltage Wrn (page 209) > Generator <> Voltage Delay (page 211) |

[back to List of alarms level 1](#)

Wrn Generator L3L1 Undervoltage

| | |
|-----------------------------|--|
| Alarm Type | WRN |
| Alarmlist message | Generator L3L1 < Voltage |
| Alarm evaluated | Generator excited only |
| Related applications | AMF, MRS |
| Description | <p>This alarm evaluates the generator phase to phase voltage between phases 3 and 1. The following setpoints are related to it:</p> <ul style="list-style-type: none"> > Generator Undervoltage Wrn (page 210) > Generator <> Voltage Delay (page 211) |

[back to List of alarms level 1](#)

Wrn Generator Overfrequency

| | |
|-----------------------------|---|
| Alarm Type | WRN |
| Alarmlist message | Generator > Frequency |
| Alarm evaluated | Generator excited only |
| Related applications | AMF, MRS |
| Description | <p>This alarm evaluates the generator overfrequency in the phase L1. The following setpoints are related to it:</p> |

| | |
|--|---|
| | <ul style="list-style-type: none"> > Generator Overfrequency Wrn (page 211) > Generator <> Frequency Delay (page 212) |
|--|---|

⬅ back to List of alarms level 1

Wrn Generator Underfrequency

| | |
|-----------------------------|---|
| Alarm Type | WRN |
| Alarmlist message | Generator < Frequency |
| Alarm evaluated | Generator excited only |
| Related applications | AMF, MRS |
| Description | <p>This alarm evaluates the generator underfrequency in the phase L1. The following setpoints are related to it:</p> <ul style="list-style-type: none"> > Generator Underfrequency Wrn (page 212) > Generator <> Frequency Delay (page 212) |

⬅ back to List of alarms level 1

Mains Overfrequency

| | |
|-----------------------------|--|
| Alarm Type | MP |
| Alarmlist message | Mains Overfrequency |
| Alarm evaluated | All the time |
| Related applications | AMF |
| Description | <p>This alarm is active when Mains frequency is above the setpoint Mains Overfrequency (page 219) for the period longer than Mains < > Frequency Delay (page 220).</p> |

⬅ back to List of alarms level 1

Mains Underfrequency

| | |
|-----------------------------|---|
| Alarm Type | MP |
| Alarmlist message | Mains Underfrequency |
| Alarm evaluated | All the time |
| Related applications | AMF |
| Description | <p>This alarm is active when Mains frequency is below the setpoint Mains Underfrequency (page 220) for the period longer than Mains < > Frequency Delay (page 220).</p> |

⬅ back to List of alarms level 1

Module(slotA) - comm. outage

| | |
|-----------------------------|---|
| Alarm Type | WRN |
| Alarmlist message | Module(slotA) - comm. outage |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | <p>This alarm indicates that there is a problem with communication between controller and module in slot.</p> |

⬅ back to List of alarms level 1

Module(slotA) - false module

| | |
|-----------------------------|---|
| Alarm Type | WRN |
| Alarmlist message | Module(slotA) - fake module |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | This alarm indicates that false module is inserted in slot. |

[◀ back to List of alarms level 1](#)

Module(slotA) - unattended

| | |
|-----------------------------|--|
| Alarm Type | WRN |
| Alarmlist message | Module(slotA) - unattended |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | This alarm indicates that two same communication modules are inserted in slots and one of them will be inactive. |

[◀ back to List of alarms level 1](#)

Module(slotA) - unexpected

| | |
|-----------------------------|---|
| Alarm Type | WRN |
| Alarmlist message | Module(slotA) - unexpected |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | This alarm indicates that in slot is inserted different module than which is configured or the module is unconfigured and has to be configured for proper function. |

[◀ back to List of alarms level 1](#)

Module(slotA) - unknown module

| | |
|-----------------------------|---|
| Alarm Type | WRN |
| Alarmlist message | Module(slotA) - unknown module |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | This alarm indicates that unknown module is inserted in slot. |

[◀ back to List of alarms level 1](#)

Wrn Overload

| | |
|----------------------|---|
| Alarm Type | WRN |
| Alarmlist message | Overload |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | <p>The alarm is issued when the Gen-set power is over the limit for time period longer than the delay. The following setpoints are related to it:</p> <ul style="list-style-type: none">> Overload Wrn (page 207) adjusts the overload limit.> Overload BOC (page 207) Overload Del adjusts the delay. |

🔍 back to List of alarms level 1

PasswEnterBlock

| | |
|----------------------|--|
| Alarm Type | WRN |
| Alarmlist message | PasswEnterBlock |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | <p>This alarm is issued to indicate that user will not be able to type in password for set amount of time.</p> <p>Note: This is cause by too many invalid attempts.</p> |

🔍 back to List of alarms level 1

Transferring Fuel

| | |
|----------------------|--|
| Alarm Type | ALI |
| Alarmlist message | Transferring Fuel |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | This alarm is issued if FUEL PUMP (PAGE 342) is active. |

🔍 back to List of alarms level 1

Wrn Charging Alternator Fail

| | |
|----------------------|--|
| Alarm Type | SD |
| Alarmlist message | Sd Charging Alternator Fail |
| Alarm evaluated | Engine running only |
| Related applications | AMF, MRS |
| Description | <p>This alarm is issued if the engine is running and the voltage on the D+ terminal is lower than D+ Threshold (page 184) of the controller supply voltage. This alarm works similar to the red "battery" alarm indicator on a vehicle dashboard. The setpoint has to be in Charge Fail or Enabled position to enable this alarm.</p> |

🔍 back to List of alarms level 2

Wrn Coolant Temperature Low

| | |
|------------|-----|
| Alarm Type | WRN |
|------------|-----|

| | |
|-----------------------------|--|
| Alarmlist message | Wrn Coolant Temperature Low |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | This alarm indicates that the coolant temperature is lower than the temperature set in Coolant Temperature Low Wrn (page 197) setpoint. |

🔍 back to List of alarms level 1

Wrn Mains Voltage Detected

| | |
|-----------------------------|---|
| Alarm Type | WRN |
| Alarmlist message | Wrn Mains Voltage Detected |
| Alarm evaluated | Gen-set is running |
| Related applications | AMF |
| Description | This alarm occurs when setpoint Operation Mode (page 170) is adjusted to MRS and voltage is detected on mains. |

🔍 back to List of alarms level 1

Wrn Maintenance 1

| | |
|-----------------------------|---|
| Alarm Type | WRN |
| Alarmlist message | Wrn Maintenance 1 |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | Adjust the setpoint Maintenance Timer 1 (page 203) to the interval of the next maintenance check. The value of the setpoint will count down while the engine is running and if reaches zero, this alarm will be issued. The alarm message will remain in the alarm list (even if the controller is switched off and on again) until the setpoint is re-adjusted to a positive value. |

🔍 back to List of alarms level 1

Wrn Maintenance 2

| | |
|-----------------------------|---|
| Alarm Type | WRN |
| Alarmlist message | Wrn Maintenance 2 |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | Adjust the setpoint Maintenance Timer 2 (page 203) to the interval of the next maintenance check. The value of the setpoint will count down while the engine is running and if reaches zero, this alarm will be issued. The alarm message will remain in the alarm list (even if the controller is switched off and on again) until the setpoint is re-adjusted to a positive value. |

🔍 back to List of alarms level 1

Wrn Maintenance 3

| | |
|-----------------------------|---|
| Alarm Type | WRN |
| Alarmlist message | Wrn Maintenance 3 |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | Adjust the setpoint Maintenance Timer 3 (page 204) to the interval of the next maintenance check. The value of the setpoint will count down while the engine is running and if reaches zero, this alarm will be issued. The alarm message will remain in the alarm list (even if the controller is switched off and on again) until the setpoint is re-adjusted to a positive value. |

🔍 back to List of alarms level 1

Wrn MCB Fail

| | |
|-----------------------------|---|
| Alarm Type | WRN |
| Alarmlist message | Wrn MCB Fail |
| Alarm evaluated | All the time |
| Related applications | AMF |
| Description | <p>This alarm will occur when the MCB FEEDBACK (PAGE 323) input does not match the expected position given by the MCB CLOSE/OPEN (PAGE 351) output. It stays active until the mismatch between the output and feedback disappears.</p> <ul style="list-style-type: none"> ➤ If there was no command issued by the controller and the breaker (feedback) changes suddenly the position itself, the alarm will be issued immediately. ➤ Self-opening of the breaker is not considered a fault and if all mains values are within limits, the command to reclose the breaker is issued after delay given by the setpoint Mains Return Delay (page 216) has elapsed. ➤ The alarm will be also issued, if the breaker does not respond to the close command within 2 seconds. After this period has elapsed the output MCB Close/Open is deactivated again and the next attempt to close the breaker will occur first after the alarm is reset. ➤ The alarm will be also issued if the breaker does not respond to the open command within 2 seconds. The output MCB Close/Open will stay deactivated. Closing of GCB is blocked until this alarm becomes inactive. |

🔍 back to List of alarms level 1

Wrn Oil Pressure

| | |
|-----------------------------|---|
| Alarm Type | Warning |
| Alarmlist message | Wrn Oil Pressure |
| Alarm evaluated | Gen-set is running |
| Related applications | AMF, MRS |
| Description | This alarm indicates that the oil pressure is lower than the pressure set in Oil Pressure Wrn (page 193) setpoint. |


🔍 back to List of alarms level 1

Wrn Override All Sd

| | |
|----------------------|---|
| Alarm Type | WRN |
| Alarmlist message | Override All Sd |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | This alarm occurs when binary input SD OVERRIDE (PAGE 328) is activated. |

⬅ back to List of alarms level 1

Wrn Stop Fail

| | |
|----------------------|--|
| Alarm Type | WRN |
| Alarmlist message | Wrn Stop Fail |
| Alarm evaluated | While the engine shall be stopped |
| Related applications | AMF, MRS |
| Description | <p>This alarm occurs if the Gen-set shall be stopped, but some symptom indicates that it is not stopped. The period when the Gen-set shall be stopped begins after the FUEL SOLENOID (PAGE 342) has been switched off and time delay Stop Time (page 190) has elapsed and lasts for the entire time the FUEL SOLENOID (PAGE 342) or STARTER (PAGE 361) are off.</p>  <p style="text-align: center;">Image 8.57 Stop Fail</p> <p>Note: Gen-set cannot be started until this alarm is inactive and reset.</p> |

⬅ back to List of alarms level 1

Wrong Config

| | |
|----------------------|--|
| Alarm Type | ALI |
| Alarmlist message | Wrong Config |
| Alarm evaluated | |
| Related applications | AMF, MRS |
| Description | This alarm is issued to indicate that content of the configuration in controller unit does not match to configuration. |

⬅ back to List of alarms level 1

Generator CCW Rotation

| | |
|------------|-----|
| Alarm Type | WRN |
|------------|-----|

| | |
|-----------------------------|---|
| Alarmlist message | Generator CCW Rotation |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | This alarm is issued if Gen-set phases are connected in a different order. Controller checks this automatically. This protection is important after controller installation to avoid wrong voltage phase connection. This alarm will prevent circuit breaker closing. |

⬅ back to List of alarms level 1

Manual Restore

| | |
|-----------------------------|--|
| Alarm Type | ALI |
| Alarmlist message | Manual Restore |
| Alarm evaluated | All the time |
| Related applications | AMF |
| Description | Alarm is activated when controller is in AUTO mode, Return From Island (page 221) setpoint is set to manual, load is on Gen-set and mains has returned. |

⬅ back to List of alarms level 1

Wrn Battery Overvoltage

| | |
|-----------------------------|--|
| Alarm Type | WRN |
| Alarmlist message | All the time |
| Alarm evaluated | Wrn Battery > Voltage |
| Related applications | AMF, MRS |
| Description | This alarm informs the operator that the controller supply voltage is too high. The following setpoints are related to it: <ul style="list-style-type: none"> > Battery Overvoltage (page 204) > Battery <> Voltage Delay (page 205) |

⬅ back to List of alarms level 1

Wrn Battery Undervoltage

| | |
|-----------------------------|--|
| Alarm Type | WRN |
| Alarmlist message | Wrn Battery < Voltage |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | This alarm informs the operator that the controller supply voltage is too low. The following setpoints are related to it: <ul style="list-style-type: none"> > Battery Undervoltage (page 204) > Battery <> Voltage Delay (page 205) |

⬅ back to List of alarms level 1

Mains CCW Rotation

| | |
|--------------------------|--------------------|
| Alarm Type | WRN |
| Alarmlist message | Mains CCW Rotation |

| | |
|-----------------------------|---|
| Alarm evaluated | All the time |
| Related applications | AMF |
| Description | The controller detects phase sequence on mains voltage terminals. This protection is important after controller installation to avoid wrong voltage phase connection. There is a fixed defined phase sequence in IntelliLite 9 controller: T39 = N, T40 = L1, T41 = L2 and T42 = L3. When the phases are connected in a different order, alarms are detected. This alarm prevent circuit breaker closing. |

[🔍 back to List of alarms level 1](#)

8.2.3 Alarms level 2

What alarms level 2 are:

The level 2 level alarm indicates that a critical level of the respective value or parameter has been reached.

List of alarms level 2

| | | | |
|-------------------------|-----|------------------------|-----|
| BOC Short Circuit | 394 | Sd Short Circuit | 400 |
| Sd Emergency Stop | 394 | Sd Charging Alternator | |
| Sd ECU Communication | | Fail | 400 |
| Fail | 394 | | |
| Sd Generator L1 | | | |
| Overvoltage | 394 | | |
| BOC Generator L1 | | | |
| Undervoltage | 395 | | |
| Sd Generator L1L2 | | | |
| Overvoltage | 395 | | |
| BOC Generator L1L2 | | | |
| Undervoltage | 395 | | |
| Sd Generator L2 | | | |
| Overvoltage | 395 | | |
| BOC Generator L2 | | | |
| Undervoltage | 396 | | |
| Sd Generator L2L3 | | | |
| Overvoltage | 396 | | |
| BOC Generator L2L3 | | | |
| Undervoltage | 396 | | |
| Sd Generator L3 | | | |
| Overvoltage | 397 | | |
| BOC Generator L3 | | | |
| Undervoltage | 397 | | |
| Sd Generator L3L1 | | | |
| Overvoltage | 397 | | |
| BOC Generator L3L1 | | | |
| Undervoltage | 397 | | |
| BOC Generator | | | |
| Overfrequency | 398 | | |
| Generator | | | |
| Underfrequency | 398 | | |
| Sd Overload | 398 | | |
| Sd Battery Flat | 398 | | |
| Sd GCB Fail | 399 | | |
| Sd Overspeed | 399 | | |
| Sd RPM Measurement | | | |
| Fail | 399 | | |
| Sd Start Fail | 400 | | |
| Sd Underspeed | 400 | | |

 **back to Alarms**

BOC Short Circuit

| | |
|----------------------|---|
| Alarm Type | BOC |
| Alarmlist message | BOC Short Circuit |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | <p>This is a fast overcurrent protection. The following setpoints are related to this alarm:</p> <ul style="list-style-type: none"> > Short Circuit BOC (page 208) adjusts the short current limit > Short Circuit BOC Delay (page 208) adjusts the delay in fine steps |

⬅ back to List of alarms level 2

Sd Emergency Stop

| | |
|----------------------|--|
| Alarm Type | SD |
| Alarmlist message | Emergency Stop |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | <p>Alarm is activated when binary input EMERGENCY STOP (PAGE 319) is activated. The Gen-set shuts down in the moment the input is activated and starting is blocked until the input is deactivated and fault reset is pressed.</p> <p>Note: Use red emergency button placed on the switchboard door and connect it to a binary input of the controller. Then configure the function Emergency Stop to this binary input. It is recommended to use NC contact of the button.</p> <p>Note: The MCB control is not affected by this alarm.</p> |

⬅ back to List of alarms level 2

Sd ECU Communication Fail

| | |
|----------------------|--|
| Alarm Type | Shutdown |
| Alarmlist message | Sd ECU Communication Fail |
| Alarm evaluated | <p>With configured LBO ECU POWER RELAY (PAGE 340) – only when this LBO is active</p> <p>Without configured LBO ECU POWER RELAY (PAGE 340) – all the time</p> |
| Related applications | AMF, MRS |
| Description | <p>This alarm occurs when an ECU is configured, but the communication with the ECU is not established or has dropped out.</p> |

⬅ back to List of alarms level 2

Sd Generator L1 Overvoltage

| | |
|----------------------|---------------------------|
| Alarm Type | SD |
| Alarmlist message | Sd Generator L1 > Voltage |
| Alarm evaluated | Generator excited only |
| Related applications | AMF, MRS |

| | |
|--------------------|---|
| Description | <p>This alarm evaluates the generator phase voltage in phase 1. The following setpoints are related to it:</p> <ul style="list-style-type: none"> > Generator Overvoltage Sd (page 209) > Generator <> Voltage Delay (page 211) |
|--------------------|---|

⬅ back to List of alarms level 2

BOC Generator L1 Undervoltage

| | |
|-----------------------------|--|
| Alarm Type | BOC |
| Alarmlist message | Sd Generator L1 < Voltage |
| Alarm evaluated | Generator excited only |
| Related applications | AMF, MRS |
| Description | <p>This alarm evaluates the generator phase voltage in phases 1. The following setpoints are related to it:</p> <ul style="list-style-type: none"> > Generator Undervoltage BOC (page 210) > Generator <> Voltage Delay (page 211) |

⬅ back to List of alarms level 2

Sd Generator L1L2 Overvoltage

| | |
|-----------------------------|--|
| Alarm Type | SD |
| Alarmlist message | Sd Generator L1L2 > Voltage |
| Alarm evaluated | Generator excited only |
| Related applications | AMF, MRS |
| Description | <p>This alarm evaluates the generator phase to phase voltage between phases 1 and 2. The following setpoints are related to it:</p> <ul style="list-style-type: none"> > Generator Overvoltage Sd (page 209) > Generator <> Voltage Delay (page 211) |

⬅ back to List of alarms level 2

BOC Generator L1L2 Undervoltage

| | |
|-----------------------------|--|
| Alarm Type | BOC |
| Alarmlist message | Sd Generator L1L2 < Voltage |
| Alarm evaluated | Generator excited only |
| Related applications | AMF, MRS |
| Description | <p>This alarm evaluates the generator phase to phase voltage between phases 1 and 2. The following setpoints are related to it:</p> <ul style="list-style-type: none"> > Generator Undervoltage BOC (page 210) > Generator <> Voltage Delay (page 211) |

⬅ back to List of alarms level 2

Sd Generator L2 Overvoltage

| | |
|--------------------------|---------------------------|
| Alarm Type | SD |
| Alarmlist message | Sd Generator L2 > Voltage |

| | |
|-----------------------------|---|
| Alarm evaluated | Generator excited only |
| Related applications | AMF, MRS |
| Description | <p>This alarm evaluates the generator phase voltage in phase 2. The following setpoints are related to it:</p> <ul style="list-style-type: none"> > Generator Overvoltage Sd (page 209) > Generator <> Voltage Delay (page 211) |

⬅ back to List of alarms level 2

BOC Generator L2 Undervoltage

| | |
|-----------------------------|--|
| Alarm Type | BOC |
| Alarmlist message | Sd Generator L2 < Voltage |
| Alarm evaluated | Generator excited only |
| Related applications | AMF, MRS |
| Description | <p>This alarm evaluates the generator phase voltage in phases 2. The following setpoints are related to it:</p> <ul style="list-style-type: none"> > Generator Undervoltage BOC (page 210) > Generator <> Voltage Delay (page 211) |

⬅ back to List of alarms level 2

Sd Generator L2L3 Overvoltage

| | |
|-----------------------------|--|
| Alarm Type | SD |
| Alarmlist message | Sd Generator L2L3 > Voltage |
| Alarm evaluated | Generator excited only |
| Related applications | AMF, MRS |
| Description | <p>This alarm evaluates the generator phase to phase voltage between phases 2 and 3. The following setpoints are related to it:</p> <ul style="list-style-type: none"> > Generator Overvoltage Sd (page 209) > Generator <> Voltage Delay (page 211) |

⬅ back to List of alarms level 2

BOC Generator L2L3 Undervoltage

| | |
|-----------------------------|--|
| Alarm Type | BOC |
| Alarmlist message | Sd Generator L2L3 < Voltage |
| Alarm evaluated | Generator excited only |
| Related applications | AMF, MRS |
| Description | <p>This alarm evaluates the generator phase to phase voltage between phases 2 and 3. The following setpoints are related to it:</p> <ul style="list-style-type: none"> > Generator Undervoltage BOC (page 210) > Generator <> Voltage Delay (page 211) |

⬅ back to List of alarms level 2

Sd Generator L3 Overvoltage

| | |
|-----------------------------|---|
| Alarm Type | SD |
| Alarmlist message | Sd Generator L3 > Voltage |
| Alarm evaluated | Generator excited only |
| Related applications | AMF, MRS |
| Description | <p>This alarm evaluates the generator phase voltage in phase 3. The following setpoints are related to it:</p> <ul style="list-style-type: none"> > Generator Overvoltage Sd (page 209) > Generator <> Voltage Delay (page 211) |

⬅ back to List of alarms level 2

BOC Generator L3 Undervoltage

| | |
|-----------------------------|--|
| Alarm Type | BOC |
| Alarmlist message | Sd Generator L3 < Voltage |
| Alarm evaluated | Generator excited only |
| Related applications | AMF, MRS |
| Description | <p>This alarm evaluates the generator phase voltage in phases 3. The following setpoints are related to it:</p> <ul style="list-style-type: none"> > Generator Undervoltage BOC (page 210) > Generator <> Voltage Delay (page 211) |

⬅ back to List of alarms level 2

Sd Generator L3L1 Overvoltage

| | |
|-----------------------------|--|
| Alarm Type | SD |
| Alarmlist message | Sd Generator L3L1 > Voltage |
| Alarm evaluated | Generator excited only |
| Related applications | AMF, MRS |
| Description | <p>This alarm evaluates the generator phase to phase voltage between phases 3 and 1. The following setpoints are related to it:</p> <ul style="list-style-type: none"> > Generator Overvoltage Sd (page 209) > Generator <> Voltage Delay (page 211) |

⬅ back to List of alarms level 2

BOC Generator L3L1 Undervoltage

| | |
|-----------------------------|--|
| Alarm Type | BOC |
| Alarmlist message | Sd Generator L3L1 < Voltage |
| Alarm evaluated | Generator excited only |
| Related applications | AMF, MRS |
| Description | <p>This alarm evaluates the generator phase to phase voltage between phases 3 and 1. The following setpoints are related to it:</p> <ul style="list-style-type: none"> > Generator Undervoltage BOC (page 210) > Generator <> Voltage Delay (page 211) |

◀ back to List of alarms level 2

BOC Generator Overfrequency

| | |
|-----------------------------|--|
| Alarm Type | BOC |
| Alarmlist message | Sd Generator > Frequency |
| Alarm evaluated | Generator excited only |
| Related applications | AMF, MRS |
| Description | <p>This alarm evaluates the generator frequency in the phase L1. The following setpoints are related to it:</p> <ul style="list-style-type: none">➤ Generator Overfrequency BOC (page 211)➤ Generator <> Frequency Delay (page 212) |

◀ back to List of alarms level 2

Generator Underfrequency

| | |
|-----------------------------|---|
| Alarm Type | BOC |
| Alarmlist message | Sd Generator < Frequency |
| Alarm evaluated | Generator excited only |
| Related applications | AMF, MRS |
| Description | <p>This alarm evaluates the generator frequency in the phase L1. The following setpoints are related to it:</p> <ul style="list-style-type: none">➤ Generator Underfrequency BOC (page 212)➤ Generator <> Frequency Delay (page 212) |

◀ back to List of alarms level 2

Sd Overload

| | |
|-----------------------------|--|
| Alarm Type | BOC |
| Alarmlist message | Sd Overload |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | <p>The alarm is issued when the Gen-set power is over the limit for time period longer than the delay. The behavior of the overload alarm is adjusted by the following setpoints:</p> <ul style="list-style-type: none">➤ Overload BOC (page 207) adjusts the overload limit.➤ Overload Delay (page 207) adjusts the delay. |

◀ back to List of alarms level 2

Sd Battery Flat

| | |
|-----------------------------|---|
| Alarm Type | SD |
| Alarmlist message | Sd Battery Flat |
| Alarm evaluated | During cranking |
| Related applications | AMF, MRS |
| Description | <p>This alarm will be issued if the controller was reset during cranking of the gen-set. If this situation occurs, the controller supposes the starting battery is so</p> |

| | |
|--|--|
| | exhausted that its voltage drops so low when starter motor is energized that it causes controller reset. |
|--|--|

🔍 back to List of alarms level 2

Sd GCB Fail

| | |
|-----------------------------|---|
| Alarm Type | SD |
| Alarmlist message | Sd GCB Fail |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | <p>This alarm will occur when the GCB FEEDBACK (PAGE 321) input does not match the expected position given by the GCB CLOSE/OPEN (PAGE 343) output. It stays active until the mismatch between the output and feedback persists.</p> <ul style="list-style-type: none"> ➤ If there was no command issued by the controller and the breaker (feedback) changes suddenly the position itself, the alarm will be issued immediately. ➤ The alarm will be also issued if the breaker does not respond to an open or close command within 2 seconds. |

🔍 back to List of alarms level 2

Sd Overspeed

| | |
|-----------------------------|--|
| Alarm Type | SD |
| Alarmlist message | Sd Overspeed |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | <p>This alarm occurs immediately when the engine speed has exceeded the limit. The behavior of the overspeed alarm is adjusted by the following setpoints:</p> <ul style="list-style-type: none"> ➤ Overspeed Sd (page 192) adjust the overspeed limit ➤ Overspeed Overshot (page 193) adjust the additional overspeed limit ➤ Overspeed Overshot Period (page 193) adjust the time period of additional overspeed limit |

🔍 back to List of alarms level 2

Sd RPM Measurement Fail

| | |
|-----------------------------|--|
| Alarm Type | SD |
| Alarmlist message | Sd RPM Measurement Fail |
| Alarm evaluated | During cranking |
| Related applications | AMF, MRS |
| Description | <p>The alarm is issued if the engine speed has not exceeded the Starting RPM (page 177) within the Maximum Cranking Time (page 176), although some of additional running engine indication sources indicate that the engine has started.</p> |

🔍 back to List of alarms level 2

Sd Start Fail

| | |
|-----------------------------|---|
| Alarm Type | SD |
| Alarmlist message | Sd Start Fail |
| Alarm evaluated | When the gen-set is being started |
| Related applications | AMF, MRS |
| Description | This alarm will be issued after all attempts to start the gen-set have run out but the Gen-set did not start. The following setpoints are related to this alarm: <ul style="list-style-type: none">➤ Cranking Attempts (page 176) adjust the number of attempts |

🔍 back to List of alarms level 2

Sd Underspeed

| | |
|-----------------------------|---|
| Alarm Type | SD |
| Alarmlist message | Sd Underspeed |
| Alarm evaluated | Engine running only |
| Related applications | AMF, MRS |
| Description | This alarm will be issued when the Gen-set is running and then stops by itself, i.e. the RPM drops under the value of setpoint Underspeed Sd (page 192) . The underspeed alarm starts to be evaluated after successful Gen-set start and is being evaluated for the entire time that the fuel solenoid is on. |

🔍 back to List of alarms level 2

Sd Short Circuit

| | |
|-----------------------------|--|
| Alarm Type | Shutdown |
| Alarmlist message | Sd Short Circuit |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | This is a fast overcurrent protection. The following setpoints are related to this alarm: <ul style="list-style-type: none">➤ Short Circuit BOC (page 208) adjusts the short current limit➤ Short Circuit BOC Delay (page 208) adjusts the delay in fine steps |

🔍 back to List of alarms level 2

Sd Charging Alternator Fail

| | |
|-----------------------------|--|
| Alarm Type | SD |
| Alarmlist message | Wrn Charging Alternator Fail |
| Alarm evaluated | Engine running only |
| Related applications | AMF, MRS |
| Description | This alarm is issued if the engine is running and the voltage on the D+ terminal is lower than D+ Threshold (page 184) of the controller supply voltage. This alarm works similar to the red “battery” alarm indicator on a vehicle dashboard. The setpoint has to be in Charge Fail or Enabled position to enable this alarm. |

🔍 back to List of alarms level 2

8.2.4 Fail sensor and other types

What Fail sensor and other types of alarms are

If the measured resistance on an analog input exceeds the valid range, a sensor fail will be detected and a sensor fail message will appear in the Alarmlist.

List of fail sensor

| | |
|------------------------|-----|
| FIs AIN Prot 1 | 401 |
| FIs Coolant Temp | 401 |
| FIs Fuel Level | 401 |
| FIs Oil Pressure | 402 |

[◀ back to Alarms](#)

FIs AIN Prot 1

| | |
|-----------------------------|---|
| Alarm Type | FIs |
| Alarmlist message | FIs + name of analog input 1 |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | This alarm indicates that the value of general analog protection is out of range or is missing. |

[◀ back to List of fail sensor](#)

FIs Coolant Temp

| | |
|-----------------------------|--|
| Alarm Type | FIs |
| Alarmlist message | FIs Coolant Temperature |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | This alarm occurs when measurement value of coolant temperature is out of range or is missing. |

[◀ back to List of fail sensor](#)

FIs Fuel Level

| | |
|-----------------------------|---|
| Alarm Type | FIs |
| Alarmlist message | FIs Fuel Level |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | This alarm occurs when measurement value of fuel level is out of range or is missing. |

[◀ back to List of fail sensor](#)

FIs Oil Pressure

| | |
|-----------------------------|---|
| Alarm Type | FIs |
| Alarmlist message | FIs Oil Pressure |
| Alarm evaluated | All the time |
| Related applications | AMF, MRS |
| Description | This alarm occurs when measurement value of oil pressure is out of range or is missing. |

[▲ back to List of fail sensor](#)

8.3 Modules

8.3.1 Plug-in modules

IMPORTANT: 2nd generation of IntelLite 9 controllers does not support new modules and 3rd generation does not support all old modules.

The available communication plug-in modules are:

- CM-RS232-485 – communication module for connection via RS232 or RS485 line
- CM-4G-GPS – communication module for connection via 4G
- CM-GPRS – communication module for connection via GPRS
- CM-Ethernet – communication module for internet connection via Ethernet

The available extension plug-in modules are:

- EM-BIO8-EFCP – extension module with 8 binary inputs/outputs

Note: Controller has plug-in module slot.

Communication modules

| | |
|--------------------|-----|
| CM-RS232-485 | 403 |
| CM-Ethernet | 405 |
| CM-GPRS | 407 |
| CM-4G-GPS | 410 |

CM-RS232-485


CM-RS232-485 is optional plug-in card to enable IntelLite 9 the RS232 and RS485 communication. This is required for computer or Modbus connection. The CM-RS232-485 is a dual port module with RS232 and RS485 interfaces at independent COM channels. The RS232 is connected to COM1 and RS485 to COM2.



Image 8.58 CM-RS232-485 interface

IMPORTANT: Any manipulation with plug-in module shall be done with disconnected power supply to controller.

RS-232 DB-9 Male Pinout



- PIN 1:** Data Carrier Detect
- PIN 2:** Receive Data
- PIN 3:** Transmit Data
- PIN 4:** Data Terminal Ready
- PIN 5:** Signal Ground
- PIN 6:** Data Set Ready
- PIN 7:** Request to Send
- PIN 8:** Clear to Send
- PIN 9:** Ring Indicator

SERIAL "CROSS-WIRED" CABLE




Image 8.59 Pinout of RS232 line

RS485 internal wiring




Image 8.60 Pinout of RS485 line



Image 8.61 Jumpers description

Note: Balancing resistors shall be both closed at only one device in whole RS485 network.

Maximal distance of line is 10 m for RS232 line and 1200 m for RS485 line.

Terminator 120 Ω

Balancing resistor +5 V

Technical data

| | |
|--------------------------|---------------------|
| Power consumption | 40 mA / 8 VDC |
| | 26 mA / 12 VDC |
| | 14 mA / 24 VDC |
| | 10 mA / 36 VDC |
| Isolation | Galvanic separation |

Firmware upgrade

- Download the newest FW of module from ComAp website (in form of PSI file or installation package)
- Instal package to computer or open PSI to instal it into InteliConfig
- Plug the module into the controller and power the controller on.
- Open a connection with controller via InteliConfig
- Go the menu Tools -> Firmware upgrade, select the Plug-in modules tab and select the appropriate firmware you want to program into the module (in InteliConfig).
- Press the OK button to start upgrade of firmware.

The firmware update process may be performed via any kind of connection including connection via the same module in which the firmware is to be updated. The connection is reestablished again automatically when the update process is finished.

CM-Ethernet

CM-Ethernet is a plug-in card with Ethernet 10/100 Mbit interface in RJ45 connector. It provides an interface for connecting a PC with through ethernet/internet network, for sending active e-mails and for integration of the controller into a building management (MODBUS TCP and SNMP protocols). This card also enables to monitor and control the gen-set over web browser from any location with internet access using appropriate security measures.




Image 8.62 CM-Ethernet interface

IMPORTANT: Any manipulation with plug-in module shall be done with disconnected power supply to controller.

Use an Ethernet UTP cable with a RJ45 connector for linking the module with your Ethernet network. The module can also be connected directly to a PC using cross-wired UTP cable.




Image 8.63 Cross-wired cable

Technical data

General

| | |
|-------------------------------|------------------|
| Width × Height × Depth | 73.8 × 50.3 × 21 |
| Weight | ~30 g |
| Power supply | 8-36 V DC |
| Power consumption | 1 W |
| Peak power consumption | 2 W |
| Operating temperature | -40 °C to +70 °C |
| Storage temperature | -40 °C to +80 °C |

Ethernet port

| |
|-------------------------|
| 100 Mbit/s, full duplex |
| RJ45 socket |

Module setup

All settings related to the module are to be adjusted via the controller setpoints. The respective setpoints are located in the setpoint **Group: CM-Ethernet (page 248)**.

All actual operational values like actual IP address etc. are available in controller values in a specific group as well.

Status LED

| Blinking frequency | Color |
|--------------------|--|
| 1 Hz | Green – everything is OK Red – some of following errors occurred: <ul style="list-style-type: none"> > unplugged Ethernet cable > module cannot connect to AirGate > module can not obtain IP address from DHCP |
| 10 Hz | Green – firmware is currently being programmed Red – no firmware present in the module |

Firmware upgrade

- Download the newest FW of module from ComAp website (in form of PSI file or installation package)
- Instal package to computer or open PSI to instal it into IntelliConfig
- Plug the module into the controller and power the controller on.
- Open a connection with controller via IntelliConfig
- Go the menu Tools -> Firmware upgrade, select the Plug-in modules tab and select the appropriate firmware you want to program into the module (in IntelliConfig).
- Press the OK button to start upgrade of firmware.

The firmware update process may be performed via any kind of connection including connection via the same module in which the firmware is to be updated. The connection is reestablished again automatically when the update process is finished.

CM-GPRS



Image 8.64 CM-GPRS module

IMPORTANT: Any manipulation with plug-in module shall be done with disconnected power supply to controller.

Note: GPRS and CSD services must be provided by your GSM/GPRS operator for successful operation.

Note: The GPRS and CSD connection should not be used for the firmware update process.

Technical data

| | |
|--------------------------|----------------|
| Power consumption | 32 mA / 8 VDC |
| | 18 mA / 12 VDC |
| | 10 mA / 24 VDC |
| | 12 mA / 36 VDC |

SIM card settings

SIM card to be used in CM-4G-GPS or CM-GPRS modules must be adjusted as follows:

- SMS service enabled
- Packet data (Internet access) enabled (when required for the selected mode of operation)
- PIN code security disabled

How to start using CM-GPRS module

> You will need a controller, CM-GPRS module, antenna and SIM card with SMS and packet data service.

Make sure that your SIM supports the packet data network type you want to use. I.e. if you want to use the module in GPRS (2.5G) network you have to confirm with the operator that the particular SIM card does support 2.5G network.

- > Make sure SIM card does not require PIN code. Use any mobile phone to switch the SIM PIN security off.
- > Place the SIM card into slot on CM-GPRS card
- > Connect the antenna to Cellular module antenna connector.
- > Switch off the controller.
- > Insert CM-GPRS module into controller
- > Power up the controller.



Image 8.65 Main screen of CM-GPRS module

GSM Diag Code – Diagnostic code for CM-GPRS modem

GSM Diag Code – Common list of diagnostic codes for cellular modules

| Code | Description |
|------|---|
| 0 | OK. No error. |
| 1 | Not possible to hang up. |
| 2 | Modul is switched off |
| 3 | Module is switched on |
| 4 | Module – error in initialization |
| 5 | Module – not possible to set the APN |
| 6 | Module – not possible to connect to GPRS network |
| 7 | Module – not possible to retrieve IP address |
| 8 | Module – not accepted DNS IP address |
| 9 | Error in modem detection |
| 10 | Error in initialization of analog modem |
| 11 | SIM card is locked (Possibly PIN code required, PIN needs to be deactivated) or unknown status of SIM locking |
| 12 | No GSM signal |
| 13 | Not possible to read the SIM card parameters |

| | |
|-----|--|
| 14 | GSM modem did not accepted particular initialization command, possibly caused by locked SIM card |
| 15 | Unknown modem |
| 16 | Bad answer to complement initialization string |
| 17 | Not possible to read GSM signal strength |
| 18 | CDMA modem not detected |
| 19 | No CDMA network |
| 20 | Unsuccessful registration to CDMA network |
| 21 | SIMCom/ME909s: can't read FW version |
| 22 | SIMCom: GSM signal not found |
| 23 | SIMCom: can't detect module speed |
| 24 | SIMCom: HW reset issued |
| 25 | PUK is required |
| 26 | Error of SIM card detected |
| 27 | ME909s: can't set module bps |
| 28 | ME909s: can't set link configuration |
| 29 | ME909s: can't do power-off |
| 30 | ME909s: can't do power-on |
| 31 | ME909s: can't do hardware reset |
| 32 | ME909s: ME909s not started |
| 33 | ME909s: switch off issued |
| 34 | ME909s: switch on issued |
| 35 | ME909s: HW reset issued |
| 36 | ME909s: can't switch echo off |
| 37 | ME909s: can't find out state of registration |
| 38 | ME909s: GSM signal not found |
| 39 | ME909s: no SIM memory for SMS |
| 40 | ME909s: waiting for registration |
| 41 | Can't read operator name |
| 42 | ME909s: can't set flow control |
| 43 | APN not typed |
| 255 | Only running communication is needed to indicate |

Firmware upgrade

- Download the newest FW of module from ComAp website (in form of PSI file or installation package)
- Instal package to computer or open PSI to instal it into IntelliConfig
- Plug the module into the controller and power the controller on.
- Open a connection with controller via IntelliConfig
- Go the menu Tools -> Firmware upgrade, select the Plug-in modules tab and select the appropriate firmware you want to program into the module (in IntelliConfig).
- Press the OK button to start upgrade of firmware.

The firmware update process may be performed via any kind of connection including connection via the same module in which the firmware is to be updated. The connection is reestablished again automatically when the update process is finished.

CM-4G-GPS



Image 8.66 CM-4G-GPS module

IMPORTANT: Any manipulation with plug-in module shall be done with disconnected power supply to controller.

IMPORTANT: CM-4G-GPS and CM-GPRS modules cant be used in one controller in the same time.

IMPORTANT: Operating temperature of module is from -30 °C to +75 °C.

Note: Cellular data service must be enabled in your SIM card by your mobile operator for successful operation.

Technical data

General

| | |
|------------------------|------------------|
| Width × Height × Depth | 73.8 × 50.3 × 15 |
| Weight | ~35 g |
| Power supply | 8-36 V DC |
| Power consumption | 1.7 W |
| Peak power consumption | 10 W |
| Operating temperature | -30 °C to +70 °C |
| Storage temperature | -40 °C to +80 °C |

GNSS

| | |
|-------------------|-------------------------|
| Antenna interface | SMA female, 4 V / 50 mA |
| Antenna type | Active |

Cellular

| | |
|--|--|
| Supported networks and frequency bands | <ul style="list-style-type: none"> > 2G (GSM/GPRS/EDGE) Quad band, 850/900/1800/1900 MHz > 3G (UMTS/HSPA+) Seven band, 800 |
|--|--|

| | |
|--------------------------|---|
| | (BdXIX) / 850 (BdV) / 900 (BdVIII) / AWS (BdIV) / 1800 (BdIX) / 1900 (BdII) / 2100MHz (BdI) > 4G (LTE) Twelve band, 700 (Bd12 <MFBI Bd17>, Bd28) 800 (Bd18, Bd19, Bd20) 850 (Bd5) / 900 (Bd8) / AWS (Bd4) / 1800 (Bd3) / 1900 (Bd2) / 2100 (Bd1) / 2600MHz (Bd7) |
| Antenna interface | 2x SMA female (Main and Diversity) |

SIM card settings

SIM card to be used in CM-4G-GPS or CM-GPRS modules must be adjusted as follows:

- > SMS service enabled
- > Packet data (Internet access) enabled (when required for the selected mode of operation)
- > PIN code security disabled

How to start using CM-4G-GPS module

- > You will need a controller, CM-4G-GPS module, antenna and SIM card with SMS and packet data service.

Note: Make sure that your SIM supports the packet data network type you want to use. – i.e. if you want to use the module in LTE (4G) network you have to confirm with the operator that the particular SIM card supports 4G network.

- > Contact your mobile operator for getting packet data APN (APN = Access Point Name), username and password.
- > Make sure SIM card does not require PIN code. Use any mobile phone to switch the SIM PIN security off.
- > Place the SIM card into slot on CM-4G-GPS card
- > Connect the antenna to Cellular module antenna connector.
- > Switch off the controller.
- > Insert CM-4G-GPS module into controller
- > Power up the controller.




Image 8.67 Main screen of CM-4G-GPS module

GSM Diag Code – Common list of diagnostic codes for cellular modules

| Code | Description |
|------|---|
| 0 | OK. No error. |
| 1 | Not possible to hang up. |
| 2 | Modul is switched off |
| 3 | Module is switched on |
| 4 | Module – error in initialization |
| 5 | Module – not possible to set the APN |
| 6 | Module – not possible to connect to GPRS network |
| 7 | Module – not possible to retrieve IP address |
| 8 | Module – not accepted DNS IP address |
| 9 | Error in modem detection |
| 10 | Error in initialization of analog modem |
| 11 | SIM card is locked (Possibly PIN code required, PIN needs to be deactivated) or unknown status of SIM locking |
| 12 | No GSM signal |
| 13 | Not possible to read the SIM card parameters |
| 14 | GSM modem did not accepted particular initialization command, possibly caused by locked SIM card |
| 15 | Unknown modem |
| 16 | Bad answer to complement initialization string |
| 17 | Not possible to read GSM signal strength |
| 18 | CDMA modem not detected |
| 19 | No CDMA network |
| 20 | Unsuccessful registration to CDMA network |
| 21 | SIMCom/ME909s: can't read FW version |
| 22 | SIMCom: GSM signal not found |
| 23 | SIMCom: can't detect module speed |
| 24 | SIMCom: HW reset issued |
| 25 | PUK is required |
| 26 | Error of SIM card detected |
| 27 | ME909s: can't set module bps |
| 28 | ME909s: can't set link configuration |
| 29 | ME909s: can't do power-off |
| 30 | ME909s: can't do power-on |
| 31 | ME909s: can't do hardware reset |
| 32 | ME909s: ME909s not started |
| 33 | ME909s: switch off issued |
| 34 | ME909s: switch on issued |

| | |
|-----|--|
| 35 | ME909s: HW reset issued |
| 36 | ME909s: can't switch echo off |
| 37 | ME909s: can't find out state of registration |
| 38 | ME909s: GSM signal not found |
| 39 | ME909s: no SIM memory for SMS |
| 40 | ME909s: waiting for registration |
| 41 | Can't read operator name |
| 42 | ME909s: can't set flow control |
| 43 | APN not typed |
| 255 | Only running communication is needed to indicate |

Firmware upgrade

- > Download the newest FW of module from ComAp website (in form of PSI file or installation package)
- > Instal package to computer or open PSI to instal it into InteliConfig
- > Plug the module into the controller and power the controller on.
- > Open a connection with controller via InteliConfig
- > Go the menu Tools -> Firmware upgrade, select the Plug-in modules tab and select the appropriate firmware you want to program into the module (in InteliConfig).
- > Press the OK button to start upgrade of firmware.

The firmware update process may be performed via any kind of connection including connection via the same module in which the firmware is to be updated. The connection is reestablished again automatically when the update process is finished.

Extension modules

| | |
|--------------------|-----|
| EM-BIO8-EFCP | 413 |
|--------------------|-----|

EM-BIO8-EFCP

EM-BIO8-EFCP is optional plug-in card. Through this card controller can accommodate up to 8 binary inputs or outputs. In InteliConfig PC configuration tool it is possible to easily choose if particular I/O will be binary input or output.



Image 8.68 EM-BIO8-EFCP interface

IMPORTANT: Any manipulation with plug-in module shall be done with disconnected power supply to controller.




Image 8.69 Overview of EM-BIO8-EFCP




Image 8.70 EM-BIO8-EFCP wiring

EM-BIO8-EFCP technical data

Power supply

| | |
|---------------------------|----------------|
| Power supply range | 8-36 VDC |
| Power consumption | 40 mA / 8 VDC |
| | 27 mA / 12 VDC |
| | 22 mA / 24 VDC |
| | 19 mA / 36 VDC |

Binary inputs

| | |
|------------------------------|--|
| Number | Up to 8, non-isolated |
| Close/Open indication | 0-2 VDC close contact >6 VDC open contact |

Binary outputs

| | |
|---------------------|--------------------------|
| Number | Up to 8, non-isolated |
| Max. current | 0,5A |
| Switching to | positive supply terminal |

Firmware upgrade

- > Download the newest FW of module from ComAp website (in form of PSI file or installation package)
- > Instal package to computer or open PSI to instal it into IntelIconfig
- > Plug the module into the controller and power the controller on.
- > Open a connection with controller via IntelIconfig

- Go the menu Tools -> Firmware upgrade, select the Plug-in modules tab and select the appropriate firmware you want to program into the module (in InteliConfig).
- Press the OK button to start upgrade of firmware.

The firmware update process may be performed via any kind of connection including connection via the same module in which the firmware is to be updated. The connection is reestablished again automatically when the update process is finished.

 **back to Appendix**